




UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.



ENSTROM
HELICOPTER CORPORATION

ENSTROM F-28F AND 280F SERIES MAINTENANCE MANUAL



Copyright 1985-2024
The Enstrom Helicopter Corporation
2209 22nd Street
Menominee, Michigan 49858-3515

Telephone: 906-863-1200
Fax: 906-863-6821

www.enstromhelicopter.com

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

INTENTIONALLY LEFT BLANK

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

RECOMMENDED CHANGE REPORT

This maintenance manual is prepared and distributed by The Enstrom Helicopter Corporation and is intended for use by personnel responsible for maintaining Enstrom F-28F, 280F, and 280FX helicopters. This manual is periodically revised. If, in the opinion of the user, any information has been omitted or requires clarification, please direct your comments to Enstrom via this form (duplicate of this page), or via the Enstrom Helicopter website, or other similar form.

To submit comments online via the Enstrom Helicopter website, navigate to the *SUPPORT* drop-down menu at the top of the web page, select *MANUAL UPDATE REQUEST*, fill in the fields, and click *SUBMIT*.

If viewing this page online, access to the form is provided in the following link:

[Manual Update Request - Enstrom Helicopter Corporation](#)

Otherwise, if corresponding by postal mail, send the recommended changes to:

The Enstrom Helicopter Corporation
2209 22nd Street
Menominee, MI 49858-3515

ATTN: Technical Publications

Manual Identification: Enstrom F-28F/280F Series Maintenance Manual, dated 1985

Revision Number and Date: _____

Aircraft

Model: _____

Recommended Change:

|

INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

Section 1 – Introduction

	Table of Contents	MM-1-1
1-1.	Manual Arrangement	MM-1-3
1-2.	Aircraft Effectivity	MM-1-3
1-3.	Maintenance Manual Supplements	MM-1-3
1-4.	Maintenance Manual Changes and Revisions	MM-1-3
1-5.	Service Document Publications	MM-1-4
1-6.	Application of Warnings, Cautions, and Notes	MM-1-5

Section 2 – General Information

	Table of Contents	MM-2-1
2-1.	General Description	MM-2-3
2-2.	General Arrangement	MM-2-3
2-3.	Principal Dimensions	MM-2-3
2-4.	Airframe	MM-2-3
2-5.	Landing Gear	MM-2-9
2-6.	Engine	MM-2-9
2-7.	Engine Cooling	MM-2-9
2-8.	Flight Controls	MM-2-9
2-9.	Power Train	MM-2-10
2-10.	Main Rotor Assembly	MM-2-10
2-11.	tail Rotor Assembly	MM-2-10
2-12.	Operating Limitations and Restrictions	MM-2-10
2-13.	Placards	MM-2-10
2-14.	Vendor Manuals	MM-2-11
2-15.	Special Tools	MM-2-13
2-16.	Torque Data	MM-2-16
2-17.	Consumable Parts List	MM-2-20

Section 3 – Airworthiness Limitations

	FAA Cover Page	MM-3-1
	Log of Revisions	MM-3-2
	Table of Contents	MM-3-3
3-1.	Retirement Life Items	MM-3-5
3-2.	Mandatory Inspection Items	MM-3-5

Section 4 – Servicing, Recommended Overhauls, Inspections, and General Maintenance

	Table of Contents	MM-4-1
4-1.	Servicing	MM-4-5
4-2.	Description	MM-4-5
4-3.	Fuel System	MM-4-25
4-4.	Servicing	MM-4-25
4-5.	Draining	MM-4-26
4-6.	Engine Oil System	MM-4-26
4-7.	Servicing	MM-4-26
4-8.	Draining	MM-4-27

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-9.	Overrunning Clutch.....	MM-4-27
4-10.	Servicing	MM-4-27
4-11.	Main Rotor Transmission.....	MM-4-28
4-12.	Servicing	MM-4-28
4-13.	Draining.....	MM-4-29
4-13.1	Flushing	MM-4-29
4-14.	Tail Rotor Transmission.....	MM-4-30
4-15.	Servicing	MM-4-30
4-16.	Draining.....	MM-4-31
4-16.1	Flushing	MM-4-31
4-17.	Main Rotor Dampers.....	MM-4-32
4-18.	Servicing (Bleeding)	MM-4-32
4-19.	Oleos.....	MM-4-33
4-20.	Servicing	MM-4-33
4-21.	Battery.....	MM-4-34
4-22.	Servicing	MM-4-34
4-23.	Lubrication.....	MM-4-34
4-24.	Description	MM-4-34
4-25.	Lower Pulley (Jackstrut) Bearing	MM-4-34
4-26.	Lubrication.....	MM-4-34
4-27.	Main Rotor Blade Grip	MM-4-34.1
4-28.	Lubrication.....	MM-4-34.1
4-29.	Main Rotor Flapping Bearings	MM-4-36
4-30.	Lubrication.....	MM-4-36
4-31.	Tail Rotor Pitch Control Bearing	MM-4-36
4-32.	Lubrication.....	MM-4-36
4-33.	Lubrication, Preferred Method	MM-4-36
4-34.	Lubrication, Alternate Method.....	MM-4-36
4-35.	Upper Pulley (Jackstrut) Bearing	MM-4-37
4-36.	Lubrication.....	MM-4-37
4-37.	Collective Guidetube Bearing	MM-4-37
4-38.	Lubrication.....	MM-4-37
4-39.	Cyclic Swashplate Bearing	MM-4-37
4-40.	Lubrication.....	MM-4-37
4-41.	Idler Pulley Bearings.....	MM-4-38
4-42.	Lubrication.....	MM-4-38
4-43.	Lubrication, Preferred Method	MM-4-38
4-44.	Lubrication, Alternate Method.....	MM-4-38
4-45.	Recommended Overhaul Cycles	MM-4-39
4-46.	Periodic Inspections.....	MM-4-40
4-47.	General Information	MM-4-40
4-48.	Daily Inspection	MM-4-40
4-49.	Periodic Inspection Checklists	MM-4-40
4-50.	50 Hour Inspection Guide	MM-4-41
4-51.	100 Hour/Annual Inspection Guide	MM-4-42
4-52.	200 Hour Inspection Guide.....	MM-4-57
4-53.	400 Hour Inspection Guide.....	MM-4-58
4-54.	Special Scheduled Inspection Guide	MM-4-59
4-55.	Special Instructions	MM-4-60
4-56.	General	MM-4-60
4-57.	Main Rotor Blade Strike/Sudden Stoppage (Minor)	MM-4-60
4-58.	Main Rotor Blade Strike/Sudden Stoppage (Major)	MM-4-61

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-59.	Tail Rotor Blade Strike/Sudden Stoppage	MM-4-62
4-60.	Hard Landing.....	MM-4-62
4-61.	Main Rotor Overspeed	MM-4-63
4-62.	Main or Tail Rotor Transmission Chip Indication.....	MM-4-64
4-63.	Engine Overboost.....	MM-4-65
4-64.	Engine Overspeed.....	MM-4-66
4-65.	Maintenance Ground Run.....	MM-4-66
4-66.	Ground Handling	MM-4-68
4-67.	Ground Handling Wheels.....	MM-4-68
4-68.	External Power	MM-4-69
4-69.	Parking	MM-4-69
4-70.	Leveling	MM-4-69
4-71.	Hoisting	MM-4-70
4-72.	Cleaning	MM-4-70
4-73.	Exterior.....	MM-4-70
4-74.	Interior	MM-4-72
4-75.	Plexiglass	MM-4-72
4-76.	Aircraft Preservation and Storage.....	MM-4-73
4-77.	General	MM-4-73
4-78.	Low Usage	MM-4-73
4-79.	Storage up to 45 Days.....	MM-4-74
4-80.	Storage from 45 Days to 6 Months	MM-4-75
4-81.	Storage for longer than 6 Months	MM-4-75
4-82.	Preventive Maintenance for Corrosion Control.....	MM-4-76
4-83.	General Information.....	MM-4-76
4-84.	Scheduled Field Preventive Maintenance Program	MM-4-76
4-85.	Component Preservation and Storage.....	MM-4-77
4-86.	Main Rotor Transmission.....	MM-4-77

Section 5 – Weight and Balance

5-1.	General Information.....	MM-5-1
5-2.	Approved Center of Gravity Envelopes.....	MM-5-1
5-3.	Weighing the Helicopter.....	MM-5-3
5-4.	Loading.....	MM-5-6

Section 6 – Electrical System

6-1.	Electrical System	MM-6-1
6-2.	Battery	MM-6-2
6-3.	Alternator.....	MM-6-4
6-4.	Voltage Regulator.....	MM-6-8
6-5.	Overvoltage Relay	MM-6-10
6-6.	Starter	MM-6-10
6-7.	Fuel Boost Pump	MM-6-13
6-8.	Lighting.....	MM-6-14
6-9.	Clutch Disengage Warning Light.....	MM-6-16
6-10.	Manifold Pressure Overboost Caution Light.....	MM-6-16
6-11.	Hourmeter	MM-6-17
6-12.	Trim Motors	MM-6-17
6-13.	Ammeter – Charging System.....	MM-6-18
6-14.	Instrument Cluster Troubleshooting.....	MM-6-19
6-15.	Charts.....	MM-6-25

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Section 7 – Instruments

7-1.	Instrument Panel	MM-7-1
7-2.	Altimeter	MM-7-1
7-3.	Airspeed Indicator.....	MM-7-4
7-4.	Engine and Rotor Tachometer.....	MM-7-5
7-5.	Fuel Quantity Indicator.....	MM-7-5
7-6.	Engine Oil Pressure Gauge	MM-7-6
7-7.	Main Rotor Transmission Temperature Indicator	MM-7-7
7-8.	Engine Oil Temperature Indicator	MM-7-7
7-9.	Ammeter.....	MM-7-8
7-10.	Cylinder Temperature Indicator	MM-7-9
7-11.	Exhaust Gas Temperature Indicator (EGT).....	MM-7-9
7-12.	Manifold Pressure and Fuel Flow Indicator	MM-7-11
7-13.	Outside Air Temperature Indicator.....	MM-7-12
7-14.	Magnetic Compass (F-28F)	MM-7-12
7-15.	Magnetic Compass (280F)	MM-7-12
7-16.	Hourmeter	MM-7-12
7-17.	Pitot Static System	MM-7-13
7-18.	Replacement of Instruments	MM-7-13
7-19.	Inspection of Instruments.....	MM-7-15

Section 8 – Structures

8-1.	Cabin.....	MM-8-1
8-2.	Windshields and Windows	MM-8-4
8-3.	[Reserved]	
8-4.	Cabin Doors	MM-8-11
8-5.	[Reserved]	
8-6.	[Reserved]	
8-7.	Seat Belts – Shoulder and Lap Type	MM-8-17
8-8.	Seat Deck Assembly.....	MM-8-18
8-9.	Landing Gear.....	MM-8-19
8-10.	Pylon	MM-8-39
8-11.	Baggage Compartment.....	MM-8-39
8-12.	Tailcone Assembly	MM-8-42
8-12.1.	Tubular Tail Rotor Guard	MM-8-44
8-12.2.	Tail Rotor Driveshaft Cover.....	MM-8-45
8-13.	Torque Tube Extension	MM-8-46
8-14.	Horizontal Stabilizers (F-28F Pre-1986).....	MM-8-48
8-15.	Horizontal Stabilizers (280F).....	MM-8-49
8-16.	Horizontal and Vertical Stabilizers (F-28F Post 1986; 280FX)	MM-8-50
8-17.	Airscoop (280FX).....	MM-8-59
8-18.	Cabin Closeout Panels (280FX)	MM-8-61

Section 9 – Main Rotor

9-1.	Main Rotor System	MM-9-3
9-2.	Main Rotor Hub	MM-9-3
9-3.	Retention Assembly.....	MM-9-16
9-4.	Universal Block Assembly	MM-9-31
9-5.	Dampers.....	MM-9-34

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

9-6.	Main Rotor Blades	MM-9-49
9-7.	Description	MM-9-49
9-8.	Removal	MM-9-49
9-9.	Inspection	MM-9-52
9-10.	Repair	MM-9-62
9-11.	Refinishing	MM-9-74
9-12.	Corrosion Prevention	MM-9-75
9-13.	Installation	MM-9-76

Section 10 – Tail Rotor

10-1.	Tail Rotor Assembly	MM-10-3
10-2.	Static Balance	MM-10-25
10-3.	Tracking and Dynamic Balance	MM-10-27
10-4.	Tail Rotor Pitch Control Assembly	MM-10-37
10-5.	Tail Rotor Gearbox	MM-10-45
10-5.1.	Tail Rotor Gearbox Chip Detector	MM-10-52
10-6.	Tail Rotor Driveshaft	MM-10-54
10-6.1.	Tail Rotor Driveshaft Flex Coupling	MM-10-60
10-6.2.	Tail Rotor Driveshaft Pillow Block	MM-10-65
10-6.3.	Tail Drive Pulley Guard	MM-10-65
10-7.	Tail Rotor Control System	MM-10-67
10-8.	Tail Rotor Control Cables	MM-10-70

Section 11 – Drive Belt System

11-1.	Clutch Control Rigging	MM-11-3
11-2.	Clutch Cable	MM-11-10
11-3.	Clutch Control Lever	MM-11-13
11-4.	Jackstrut and Pulley Assembly	MM-11-14
11-5.	Drive Belt	MM-11-21
11-6.	Main Rotor Gearbox	MM-11-36
11-6.1.	Chip Detector	MM-11-41
11-7.	Overrunning Clutch and Pulley Assembly	MM-11-42
11-7.1.	Upper Jackstrut Bearing	MM-11-47
11-8.	Idle Pulley – Troubleshooting	MM-11-53
11-8.1.	Yoke End Assembly	MM-11-56
11-8.2.	Actuator Arm Assembly and Snubber Roller Assembly	MM-11-58
11-9.	Belt Tension Assembly	MM-11-73

Section 12 – Flight Controls

12-1.	Troubleshooting the Articulated Rotor System	MM-12-3
12-2.	Main Rotor Blade Tracking	MM-12-5
12-3.	Collective Pitch Control Stick	MM-12-19
12-4.	Collective Trim System	MM-12-22
12-5.	Cyclic Pitch Control Stick	MM-12-27
12-6.	Lateral and Longitudinal Trim Actuators	MM-12-28
12-7.	Flight Control Rigging	MM-12-34
12-8.	Cyclic Azimuth Check	MM-12-42
12-9.	Cyclic Trim Springs Rigging Procedure	MM-12-44
12-10.	Lower Swashplate Assembly	MM-12-46
12-11.	Upper Swashplate Assembly	MM-12-58
12-12.	Main Rotor Push Pull Rods	MM-12-70

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

12-13.	Flight Test Procedure	MM-12-75
--------	-----------------------------	----------

Section 13 – Powerplant and Associated Systems

13-1.	Powerplant (General Information)	MM-13-1
13-2.	Engine	MM-13-3
13-3.	Engine Exhaust System.....	MM-13-19
13-4.	Fuel Injection System	MM-13-23
13-5.	Turbocharger	MM-13-47
13-6.	Turbocharger Static Air Fuel Nozzle Pressure System	MM-13-49
13-7.	Primary Airflow System.....	MM-13-52
13-8.	Cooling System	MM-13-57
13-9.	Ignition System.....	MM-13-64
13-10.	Fuel System	MM-13-72
13-11.	Lubricating System	MM-13-88
13-12.	Correlator	MM-13-94

Section 14 – Utility Systems

14-1.	Cabin Heat	MM-14-1
-------	------------------	---------

MAINTENANCE MANUAL SUPPLEMENT 280FX & 1986 F-28F – SECTIONS 15 THROUGH 25

Section 15 – Supplemental Procedures

15-1.	Introduction.....	MM-15-1
15-2.	Table of Contents	MM-15-1
15-3.	Manual Changes and Revisions	MM-15-1

Section 16 – [Reserved]

Section 17 – [Reserved]

Section 18 – Powerplant

18-1.	General.....	MM-18-1
-------	--------------	---------

Section 19 – Main Rotor Transmission

19-1.	General.....	MM-19-1
19-2.	Main Rotor Gearbox Chip Detector.....	MM-19-1
19-3.	Lubricant Change	MM-19-2

Section 20 – Belt Drive System

20-1.	[Reserved]	MM-20-1
-------	------------------	---------

Section 21 – Electrical Systems and Components

21-1.	General.....	MM-21-1
21-2.	Combined Anticollision and Navigation Lights	MM-21-1
21-3.	Annunciator Panel	MM-21-1

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

21-4.	Anticollision and Navigation Light and Annunciator Panel	
	Troubleshooting Chart	MM-21-6
21-5.	Lamp/Assembly Replacement Guide Chart	MM-21-8
21-6.	Ampere Load Conditions	MM-21-8
21-7.	Hi/Lo Rotor RPM Warning System.....	MM-21-11
21-8.	Schematic Diagrams.....	MM-21-14
21-9.	Illuminated Panels	MM-21-33
	Illuminated Collective Switch Panel	MM-21-33
	Illuminated Switch and Circuit Breaker Panel	MM-21-35

Section 22 – [Reserved]

Section 23 – [Reserved]

Section 24 – Instruments

24-1.	Engine Monitor	MM-24-1
24-2.	Description	MM-24-1
24-3.	Maintenance.....	MM-24-2
24-4.	Programming Alarm Limits	MM-24-2
24-5.	Troubleshooting.....	MM-24-2
24-6.	Clock	MM-24-7
24-7.	Outside Air Temperature Indicator (OAT)	MM-24-7
24-8.	Magnetic Compass.....	MM-24-7
24-9.	Rotor RPM Magnetic Pickup.....	MM-24-8

Section 25 – [Reserved]

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

LOG OF PAGES AND REVISIONS

REV. NO	REV DATE	DESCRIPTION	DATE	FAA APPROVED
1	Apr 3/86	vi, vii, viii and ix MM-3-1 Added Sections 15 through 25 inclusively. Section 17 Supplemental Airworthiness Limitations	Apr 3/86	W. F. Horn ACE 115C
2	Nov 18/88	ix MM-2-10, 2-14 & 2-15 MM-3-13 & 3-20, 4-1 & 4-6 MM-6-1, 6-2, 6-5, 6-9, 6-21, 6-23, 6-24, 6-26, 6-28, 6-29 MM-9-14 & 9-47 MM-11-32 & 11-63 MM-12-43 MM-13-19, 13-22, 13-23, 13-94, 13-95, 13-96 MM-21-3, 21-4, 21-7, 21-10, 21-11, 21-12, 21- 13	Nov 18/88	W. F. Horn ACE 115C
3	Mar 94	MM-4-1, MM-4-2	N/A	N/A
4	Jun 21/12	iii through xii MM-3-1 through MM-3-6 (MM-3-7 through MM-3-30 deleted) MM-4-1 through MM-4-76 MM-9-49 through MM-9-76 MM-10-1, 10-2, 10-13, 10-14, 10-14.1, 10- 14.2, 10-15, 10-16 MM-17-1, 17-2 MM-21-1 through MM-21-30	N/A	G. Michalik ACE 116C
5	Nov 5/13	Cover i through xii MM-1-1 through MM-1-4 MM-2-1 through MM-2-20 MM-4-50, MM-4-55, MM-4-61 MM-4-62, MM-4-64, MM-4-67 MM-6-5, MM-6-6 MM-10-14.1 MM-11-21, MM-11-46 MM-13-33, MM-13-71 MM-13-101, MM-13-103, MM-13-105 MM-13- 107, MM-13-108 MM-21-1, MM-21-8, MM-21-11 MM-21-14, MM-21-19 MM-21-21 through MM-21-30 MM-24-1 through MM-24-6	N/A	N/A

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

REV. NO	REV DATE	DESCRIPTION	DATE	FAA APPROVED
6	Apr 7/15	Cover xi, xii MM-2-13 & 2-14 MM-2-16 through MM-2-19 MM-4-43, MM-4-45 through MM-4-48, MM-4-51, MM-4-63 MM-6-4, 6-5 & 6-6 MM-9-27, MM-9-29 MM-10-13 & 10-14, MM-10-14.2 MM-11-32, MM-11-52, MM-11-65 MM-13-11 & 13-12, MM-13-14, MM-13-16, MM-13-40, MM-13-48, MM-13-62, MM-13-77 & 13-78	N/A	N/A
7	Aug 22/16	Cover xii MM-1-3, MM-1-4 MM-2-11, MM-2-16 MM-3-2 through MM-3-4 MM-4-10 through MM-4-12, MM-4-27 MM-4-32, MM-4-41, MM-4-42, MM-4-57 MM-4-58, MM-4-59, MM-4-69 MM-8-27, MM-8-29, MM-8-30, MM-8-33 MM-8-34, MM-8-36 MM-9-1 through MM-9-30, MM-9-62, MM-9-64, MM-9-75 MM-10-14.1, MM-10-26 through MM-10-30 MM-10-41, MM-10-42, MM-10-45 MM-10-48 through MM-10-50 MM-11-25, MM-11-26 MM-13-14, MM-13-17, MM-13-19, MM-13-20, MM-13-22, MM-13-23, MM-13-33, MM-13-38 MM-13-40, MM-13-78, MM-13-79	N/A	N/A
8	Sep 20/17	Cover iii through ix, xii MM-1-1, MM-1-3, MM-1-4 through MM-1-6 MM-2-18, MM-2-20 MM-3-2, MM-3-3 MM-4-1, MM-4-29 through MM-4-34.2 MM-4-41, MM-4-44, MM-4-46, MM-4-51 MM-4-53, MM-4-54, MM-4-59, MM-4-63 MM-4-65 MM-8-0 through MM-8-60 MM-13-11, MM-13-14, MM-13-17, MM-13-49 MM-13-50, MM-13-61, MM-13-62 MM-15-1, MM-15-2 (MM-15-A and MM-15-B removed) MM-16-1, MM-16-2 (MM-16-2 through MM-16-6 removed) MM-21-6, MM-21-8, MM-21-9, MM-21-10 MM-21-14, MM-21-21 through MM-21-32 MM-22-1, MM-22-2 (MM-22-2 through MM-22-14 removed)	N/A	N/A
9	Dec 14/17	xii, MM-4-31	N/A	N/A

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

REV. NO	REV DATE	DESCRIPTION	DATE	FAA APPROVED
10	Feb 7/19	Cover ix, xiii, xiv MM-4-40, MM-4-42 MM-8-0 through MM-8-0.2 MM-8-12 through MM-8-16.2 MM-12-18 through MM-12-22 MM-21-1 through MM-21-4 MM-21-6 through MM-21-8, MM-21-14 MM-21-33 through MM-21-58 MM-24-7 through MM-24-8	N/A	N/A
11	Oct 25/19	Cover iv through vii, ix, xiii MM-1-3 MM-2-11, MM-2-12 MM-2-14 through MM-2-20 MM-4-3, MM-4-9, MM-4-11 MM-4-22, MM-4-32 MM-4-47, MM-4-51 through MM-4-56 MM-4-65, MM-4-66, MM-4-77, MM-4-78 MM-6-0.1, MM-6-0.2 MM-6-1 through MM-6-8 MM-8-36 MM-9-1 through MM-9-48 MM-10-1 through MM-10-68 MM-12-1 through MM-12-80 MM-13-0.1, MM-13-0.2, MM-13-31 MM-13-35, MM-13-37, MM-13-49 MM-13-67 through MM-13-71 MM-13-93 through MM-13-100 MM-21-15, MM-21-16 MM-24-0.1, MM-24-0.2 MM-24-8 through MM-24-10	N/A	N/A
12	Jul 16/2020	Cover vi, xiii, MM-1-1, MM-1-4, MM-1-5 MM-2-1, MM-2-12, MM-2-21, MM-2-22 MM-8-0, MM-8-0.2, MM-8-17, MM-8-18 MM-8-19, MM-8-20, MM-8-61, MM-8-62 MM-21-2 MM-23-1, MM-23-2	N/A	N/A
13	Jan 5/24	Cover i, vii, viii, ix, xiii MM-10-1 through MM-10-74 MM-11-1 through MM-11-84 MM-20-1 through MM-20-2 MM-25-1 through MM-25-2	N/A	N/A

|

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 1

INTRODUCTION

TABLE OF CONTENTS

Paragraph	Description	Page
	Table of Contents	MM-1-1
1-1.	Manual Arrangement	MM-1-3
1-2.	Aircraft Effectivity	MM-1-3
1-3.	Maintenance Manual Supplements	MM-1-3
1-4.	Maintenance Manual Changes and Revisions	MM-1-3
1-5.	Application of Warnings, Cautions, and Notes	MM-1-5

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 1

INTRODUCTION

TABLE OF CONTENTS

Paragraph	Description	Page
-----------	-------------	------

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 1

INTRODUCTION

1-1. Maintenance Manual Arrangement

The maintenance manual sections divide the aircraft into major systems and related subsystems to provide maintenance procedures required for proper system function and optimum component service life. Each section details the following maintenance functions for the associated subsystems and components, if applicable:

- General Description
- Troubleshooting
- Adjustment/Rigging
- Removal
- Disassembly
- Inspections (other than Periodic Inspections)
- Repair
- Assembly
- Installation

1-2. Aircraft Effectivity

The maintenance data presented in this manual is applicable to all F-28F, 280F, and 280FX model Enstrom helicopters with standard equipment. Optional equipment maintenance procedures are included in the F-28F/280F Series Maintenance Manual for common optional equipment that is installed before aircraft delivery (This does not include avionics installations).

1-3. Maintenance Manual Supplements

Maintenance procedures for optional equipment may be provided in maintenance manual supplements. These supplements are part of the F-28F/280F Series Maintenance Manual when an aircraft is equipped with optional equipment which requires a maintenance manual supplement. The following optional equipment supplements are applicable to the F-28F/280F Series Maintenance Manual.

Supplement 1: Avionic Systems, Revision 8, Dated: Jan 15/19.

1-4. Maintenance Manual Changes and Revisions

Subsequent to the publication of the initial issue of the Enstrom F-28F/280F Series Maintenance Manual, changes in aircraft equipment, support concepts and procedures, as well as information developed by experience, may affect the contents of the manual. To ensure that coverage in the manual continues to reflect such changes, revised information is released by one of the following methods:

- (1) Revision - A revision alters portions of the manual by replacement, addition, and/or deletion of pages. A revision cover page lists the page(s) to be removed and/or inserted.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Reissue - Where large numbers of changes are involved, a complete reissue of the manual is warranted. Preceding issues of the manual then become obsolete and should be discarded.
- (3) Service Directive Bulletins - Used to direct the owner/operator and/or maintenance personnel to make mandatory changes, improvements, or inspections to the aircraft applicable to the entire fleet or a segment of the fleet that are typically safety/airworthiness related. The information provided in the Service Directive Bulletins will be incorporated in the maintenance manual as needed at a later date. At the time of incorporation, the Service Directive Bulletin is superseded by the maintenance manual, and accomplishment or sign-off of the Service Directive Bulletin in the maintenance records book is no longer required. A detailed entry should be made in the maintenance records to indicate that the Service Directive Bulletin is superseded by the maintenance manual.
- (4) Service Information Letters - Used to transmit information, recommendations, and general service instructions to the aircraft owner/operator and/or maintenance personnel applicable to the entire fleet or a segment of the fleet. The information provided in the Service Information Letters will be incorporated into the maintenance manual as needed at a later date.
- (5) Service Instructions – Used to provide the owner/operator and/or maintenance personnel with information that is applicable to specific aircraft and does not meet the criteria of a Service Information Letter or Service Directive Bulletin. Service Instructions will not be distributed to the entire fleet.

Enstrom distributes maintenance manual revisions and reissues in electronic form via the Enstrom Helicopter website: www.enstromhelicopter.com (follow the applicable link under the Technical Publications section of the Technical Support page). Revision update notices are sent via email to owners and operators who are registered with Enstrom. Registration to receive publication mailing notifications can be coordinated through the Enstrom Technical Publications Administrator. A complete manual hardcopy may be ordered through Enstrom Customer Service.

Service Information Letters and Service Directive Bulletins incorporated into the maintenance manual are logged in the Service Information Letter Index or the Service Directive Bulletin Index (as appropriate) located on the Enstrom Helicopter website: www.enstromhelicopter.com (follow the applicable link under the Technical Publications section of the Technical Support page). Each index numerically lists all Service Information Letters and Service Directive Bulletins, respectively, and identifies those which have been incorporated into the maintenance manual. All Service Information Letters and Service Directive Bulletins are also located under the Technical Publications section of the website.

Notice of recently released Service Information Letters and Service Directive Bulletins is provided via email notification. Registration to receive publication mailing notifications can be coordinated through the Enstrom Technical Publications Administrator.

1-5. Application of Warnings, Cautions, and Notes

Warnings, Cautions, and Notes emphasize important and critical instructions and are used for the following conditions.

WARNING

Calls attention to use of materials, processes, methods, or procedures that must be followed to avoid personal injury or loss of life.

CAUTION

Calls attention to methods and procedures which must be followed to avoid damage to the aircraft or equipment.

NOTE

Calls attention to information essential to highlight for clarification of procedures.

|

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 2

GENERAL INFORMATION

TABLE OF CONTENTS

Paragraph	Description	Page
	Table of Contents	MM-2-1
2-1.	General Description	MM-2-3
2-2.	General Arrangement	MM-2-3
2-3.	Principal Dimensions	MM-2-3
2-4.	Airframe	MM-2-3
2-5.	Landing Gear	MM-2-9
2-6.	Engine	MM-2-9
2-7.	Engine Cooling	MM-2-9
2-8.	Flight Controls	MM-2-9
2-9.	Power Train	MM-2-10
2-10.	Main Rotor Assembly	MM-2-10
2-11.	Tail Rotor Assembly	MM-2-10
2-12.	Operating Limitations and Restrictions	MM-2-10
2-13.	Placards	MM-2-10
2-14.	Vendor Manuals	MM-2-11
2-15.	Special Tools	MM-2-13
2-16.	Torque Data	MM-2-16
2-17.	Consumable Parts List	MM-2-20
2-18.	Taper Pin Size Chart	MM-2-21

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 2

GENERAL INFORMATION

TABLE OF CONTENTS

Paragraph	Description	Page
-----------	-------------	------

INTENTIONALLY LEFT BLANK

SECTION 2

GENERAL INFORMATION

2-1. General Description

The F-28F, 280F, and 280FX helicopters are a 3 bladed, single engine helicopter manufactured by the Enstrom Helicopter Corporation and certificated by the FAA under CAR 6. Additionally, the F-28F, 280F, and 280FX models have demonstrated compliance with 14 CFR 36, amendment 20 (Appendix J), effective September 11, 1992.

The F-28F, 280F, and 280FX models are powered by a turbocharged, fuel injected Textron-Lycoming piston engine. The turbocharger system is equipped with a variable waste gate assembly, and the throttle is equipped with a correlator.

2-2. Principal Dimensions

Figure 2-1 depicts the general arrangement.

2-3. Principal Specifications

Table 2-1 lists the principal specifications of the different model aircraft.

2-4. Airframe

The airframe is comprised of three sections: cabin assembly, pylon assembly, and tail cone assembly.

- A. Cabin Assembly: The cabin assembly is fabricated from molded fiberglass and is an integral unit. It is attached to the pylon by six bolts and contains the aluminum seat structure, plus the instrument panel, cyclic, collective, and tail rotor controls. The windshield and upper and lower windows provide excellent visibility. The swing-open style doors provide access to the cabin.
- B. Pylon Assembly: The pylon assembly is fabricated from steel tubing, houses the engine, and supports the landing gear, cabin, main transmission and tail cone.
- C. Tail Cone Assembly: The tail cone assembly is a semi-monocoque type and attaches to the pylon assembly with three bolts for easy removal and installation. The tail cone supports the horizontal stabilizers, tail rotor driveshaft, tail rotor gearbox, tail rotor, and tail rotor guard.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL





Figure 2-1. Principal Dimensions - F-28F Pre-1986 (S/N 743 and Prior)

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-2-4

Rev. 5
Nov 5/13



Sheet 2 of 4

Figure 2-1. Principal Dimensions - F-28F Post-1986 (S/N 744 and Subsequent)





Figure 2-1. Principal Dimensions - 280F

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-2-6

Rev. 5
Nov 5/13



Sheet 4 of 4

Figure 2-1. Principal Dimensions - 280FX

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-1. F-28F/280F/FX Specifications

	Model	
	F-28F	280F/FX
Power Plant:		
Designation	HIO-360-F1AD	HIO-360-F1AD
Cylinders	4	4
Normal Power	225 (168 kW)	225 (168 kW)
Normal RPM	3050	3050
Specific Fuel Consumption	.69 lb/hp-hr (.42 g/W-h)	.69 lb/hp-hr (.42 g/W-h)
Weight	324 lb (147 kg)	324 lb (147 kg)
Oil	10 qts (9.5 l)	10 qts (9.5 l)
Turbocharger:		
Designation	3BT5EE10J2	3BT5EE10J2
Operating RPMs:		
Engine	2900-3050	2900-3050
Main Rotor	351 @ 3050	351 @ 3050
Tail Rotor	2514 @ 3050	2514 @ 3050
Autorotation (Main Rotor)	332-385	332-385
Ratios:		
Lower Pulley to Upper Pulley	1.213:1	1.213:1
Upper Pulley to Main Rotor	7.154:1	7.154:1
Engine to Main Rotor	8.689:1	8.689:1
Upper Pulley to Tail Rotor	1:1	1:1
Main Rotor System:		
Number of Blades	3	3
Blade Cord - Each	9.5 in (24.1 cm)	9.5 in (24.1 cm)
Diameter	32 ft (9.75 m)	32 ft (9.75 m)
Disc Area	804 ft ² (74.7 m ²)	804 ft ² (74.7 m ²)
Tail Rotor System:		
Number of Blades	2	2
Blade Cord - Each	4.4 in (11.2 cm)	4.4 in (11.2 cm)
Diameter	4.67 ft (1.42 m)	4.67 ft (1.42 m)
Disc Area	17 ft ² (1.58 m ²)	17 ft ² (1.58 m ²)
Miscellaneous:		
Maximum Speed - V _{NE}	112 mph	117 mph
Maximum Gross Weight	2600 lbs (1179 kg)	2600 lbs (1179 kg)
Fuel Capacity (Useable)	40 gal (151.4 l)	40 gal (151.4 l)

2-5. Landing Gear

- A. Main Landing Gear: The main landing gear consists of two tubular aluminum skids attached to the airframe by means of the forward and aft cross tubes through four air-oil oleo struts. The struts cushion ground contact during landing. Drag struts give the gear stability and strength and prevent fore and aft movement during ground contact maneuvers. Replaceable hardened steel skid shoes are installed on each skid to resist skid wear on hard surfaces.
- B. Tail Rotor Guard: A tubular aluminum tail rotor guard is installed on the aft end of the tailcone. It acts as a warning to the pilot upon an inadvertent tail-low landing and aids in protecting the tail rotor from damage.

WARNING

Ensure the locking pin is installed in ground handling wheel before removing the wheel bar from the wheel assembly and moving the aircraft.

- C. Ground Handling Wheels: Each landing gear skid tube has ground handling wheels or provisions for installing removable ground handling wheel assemblies. Each assembly has a manually operated over-centering device to lift the skids clear of the ground. The ground handling wheels should be retracted for engine run-up. If the aircraft has optional removable Brackett® wheels, they should be removed before engine run-up.

2-6. Engine

The F-28F/280F series helicopters are powered by a Textron-Lycoming HIO-360 series piston engine. The Textron-Lycoming HIO-360 series engine is a four cylinder, direct drive, horizontally opposed, air cooled, fuel injected engine. The F-28F/280F series helicopters are equipped with an Enstrom installed turbocharger system which allows the engine to produce its rated horsepower up to the certified altitude limit.

2-7. Engine Cooling

A fan mounted on the engine crankshaft flange forces cooling air through a shroud assembly and baffles onto the engine cylinders. A portion of the cooling air is diverted through ducting to the engine oil cooler(s). If the optional cabin heating system is installed, a portion of the cooling air is directed to the heater shroud.

2-8. Flight Controls

The flight controls include three primary systems: the collective, cyclic, and anti-torque/directional controls. The flight control systems are not hydraulically boosted. The collective flight control system incorporates a spring capsule that balances the steady collective forces from the main rotor system. The cyclic control system also incorporates spring capsules used to trim out the control system forces produced by the main rotor system. The spring capsules are part of electrical trim assemblies that are controlled by a switch located on the cyclic stick grip. The aircraft also has fixed horizontal and vertical stabilizers mounted on the tailcone to provide additional stability during forward flight.

2-9. Power Train

The power train includes the main rotor transmission, upper pulley/overrunning clutch assembly, drive belt, belt drive system, tail rotor drive shaft, and the tail rotor transmission.

- A. **Main Rotor Transmission:** The main rotor transmission provides a 7.154:1 reduction ratio between the upper pulley and main rotor system. The transmission incorporates an over-running clutch in the upper pulley which allows the main and tail rotors to over-run when the engine is throttled back for autorotations. The transmission has a sight gauge which is located on the aft right side and is visible through a panel in the baggage compartment or through the upper access step. Total oil quantity in the transmission is 6 pints (2.84 liters). A magnetic drain plug located on the bottom left aft side of the transmission can be checked for metal particle contamination. All 280FX aircraft are equipped with chip detector annunciator in the instrument panel. Starting with serial number 744, F-28F aircraft may be equipped with the chip detector annunciator as optional equipment. The chip detector is standard equipment on all later production F-28F aircraft.

- B. **Tail Rotor Transmission:** The tail rotor transmission supports and drives the tail rotor assembly. The transmission utilizes a splash lubricated, non-vented, closed oil system. A filler port and a sight gauge are located in the aft end of the transmission. A magnetic drain plug located on the bottom aft side of the transmission can be checked for metal particle contamination. All 280FX aircraft are equipped with chip detector annunciator in the instrument panel. Starting with serial number 744, F-28F aircraft may be equipped with the chip detector annunciator as optional equipment. The chip detector is standard equipment on all later production F-28F aircraft. The total oil capacity of the transmission is 5 ounces/.15 liters. An inspection plug, used to visually inspect the transmission gears, is located on the top right side of the transmission. The tail rotor transmission reduction ratio is 1:1.

2-10. Main Rotor Assembly

The main rotor assembly is a three bladed, high inertia, fully articulated rotor system. Three hydraulic dampers are incorporated to control the lead-lag motions of the blades.

2-11. Tail Rotor Assembly

The tail rotor assembly is a two bladed, teetering, delta hinged rotor assembly.

2-12. Operating Limitations and Restrictions

Refer to the applicable F-28F/280F/280FX Rotorcraft Flight Manual for the aircraft operating limitations and restrictions.

2-13. Placards

Refer to the applicable F-28F/280F/280FX Rotorcraft Flight Manual for the required placards.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2-14. Vendor Information

The following components listed in Table 2-2 are to be maintained I/A/W the manufacturer's instructions to ensure the continued airworthiness of the aircraft. The owner/operator is responsible for ensuring that current maintenance publications are available to ensure continued airworthiness of the aircraft.

Table 2-2. Vendor Contact Information

Component	Part Number*	Manufacturer*	
Engine	M/N HIO-360-F1AD	Textron-Lycoming 625 Oliver Street Williamsport, PA 17701	(570) 327-7049 www.lycoming.com
Magneto	SYS P/N 66E21585-70 P/N 10-682605-13	Hartzell Engine Technologies 2900 Selma Highway Montgomery, AL 36116	(877) 359-5355 www.hartzell.aero
Alternator	P/N 32C19553 (24V) P/N ALX-8521LS (12V) P/N ALU-8521LS (24V)		
Fuel Pump	P/N 62D26035		
Turbocharger	M/N 3BT5EE10J2 P/N 600700-0000		
Starter Vibrator	P/N 10-382780-123 (12V) P/N 10-400608-243 (24V)	Teledyne Continental Motors 2039 Broad Street Mobile, AL 36615	(630) 513-9599 www.aviall.com
Fuel Servo	M/N RSA-5AB1 P/N 2524858-5	Precision Airmotive Corporation 14800 40th Avenue, North East Marysville, WA. 98271	(360) 651-8282 www.precisionairmotive.com
Fuel Boost Pump	P/N A-10019-D (12V) P/N A-10019-E (24V)	Weldon Pump 640 Golden Oak Parkway Oakwood Village, Ohio 44146	(440) 232-2282 www.weldonpumps.com
Scavenge Oil Pump	P/N 101678-0002	Kelly Aerospace Power Systems 1404 E. South Blvd. Montgomery, AL 36116	(877) 359-5355 www.hartzell.aero
Starter	P/N 149-12HT (12V) P/N 149-24HT (24V)	Sky-Tec 350 Howard Clemmons Road Granbury, TX 78230	(877) 359-5355 www.hartzell.aero
Battery	P/N RG-35A (12V) P/N RG24-11M (24V)	Concorde Battery Corporation 2009 San Bernardino Road West Covina, CA 91790	(800)757-0303 www.concordebattery.com
EGT Indicator	P/N 45817	Alcor 300 Breesport San Antonio, TX 78216	(800) 354-7233 www.alcorinc.com
Graphic Engine Monitor	M/N GEM 603 M/N GEM 610	Insight Instrument Corporation Box 194 Buffalo, NY 14205-0194	(905) 871-0733 www.insightinstruments.com
	M/N EDM-700	J. P. Instruments Inc. P.O. Box 7033 Huntington Beach, CA 92646	(800) 345-4574 www.jpinstrument.com

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-2. Vendor Contact Information

Component	Part Number*	Manufacturer*	
Tension-Torson (TT) Straps	P/N AA-ECD-084-280 (STC SR03465CH)	Airwolf Aerospace LLC 15369 Madison Rd. Middlefield, OH 44062-8404	(440) 632-1687 (440) 632-1685 Fax www.airwolfaerospace.com info@airwolfaerospace.com
Anti-Collision Strobe	P/N 02-0250276-00 P/N 36-0050626-01 P/N 01-0790340-03 P/N 01-0790340-04	Whelen Aerospace Technologies 210 Airport Drive East Sebastian, FL 32958	(860) 526-9504 www.flyWAT.com info@flyWAT.com
Landing Light	P/N 01-0771833-20		
Landing Light	P/N 01-1030-H-A()	AeroLEDs, LLC 8475 W. Elisa St. Boise, ID 83709	(208) 850-3297 https://aeroleds.com/contact sales@AeroLEDs.com

* The manufacturer of the component may differ depending on the time the aircraft was manufactured or overhauled. Refer to the manufacturer's data plate affixed to the component for accurate part number information.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2-15. Special Tools

The special tools listed in Table 2-2 are used for removal, installation, and overhaul of components used on the F-28F/280F series aircraft:

NOTE

The special tools listed in Table 2-2 are available through Enstrom's Tool Rental Program. Contact Enstrom Helicopter Product Support for details.

Table 2-3. Special Tools

Part Number	Nomenclature
T-0003	Main Rotor Lead/Lag Lower Nut Tool
T-0005	Damper Rod End Removal Tool
T-0009	Main Rotor Blade Bolt Guide Bullet
T-0011	Main Rotor Hoist Sling
T-0013	Main Rotor Lamiflex Nut Socket
T-0014	Needle Point Grease Adapter
T-0016	Lower Swashplate Gimbal Tool
T-0017	Transmission Hoist Eye
T-0022	Collective Spring Capsule Retainer Tool
T-0026	Main Rotor Blade Tab Bending Tool
T-0027	Main Rotor Blade Tab Angle Tool
T-0029-SET	Idler Assembly/Disassembly Tool
T-0035	Oleo Disassembly Tool
T-0036	Blade Grip Seal Installation Tool
T-0044	Pulley Alignment Tool
T-0045-1	Lower Swashplate Dogleg Puller
T-0048	Main Rotor Mast Nut Tool
T-0051-3	Main Rotor Flapping Nut Tool
T-0054	Swashplate Dogleg Alignment Tool
T-0056-3	Tail Rotor Thrust Bearing Retention Nut Tool
T-0057	Damper Bleeding Fixture
T-0068-3	Tail Rotor Transmission Output Shaft Runout Tools
T-0078	Engine Adapter Installation Tool
T-0079-1	Bearing Swagging Tool

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-3. Special Tools

Part Number	Nomenclature
T-0080	Tail Rotor Rigging Tool
T-0086	Upper Guidetube Nut Tool
T-0087-15	Tail Rotor Assembly Static Balance Mandrel
T-0088	Tail Rotor Driveshaft Alignment Tool
T-0092-5	Taper Pin Removal Tool
T-0095	Damper Tool
T-0100-1	Swashplate DU Bushing Removal Tool
T-0102-1-SET	Guidetube Disassembly Tool
T-0104-1	Swashplate Bushing Installation Tool
T-0111-SET	Correlator Rigging Tool
T-0121-1	Tail Rotor Static Balance Stand
T-0127	Magnetic Pickup Bracket
T-0133-1	Pulley Restraint Tool Assembly
T-0134	Plate Assembly (Lower Swashplate Assembly)
T-0135-1-SET	Main Rotor Transmission Pinion Crows Foot
T-0140	Tail Rotor Rigging Tool
T-0151-1	Universal Block Bearing Tool Set (Grease Lubricated)
T-0152	Tail Rotor Balance Tool (Photo Cell Bracket)
T-0156	Oil Filler Tube Adapter Wrench
T-0160-1	Damper Ring Seal Installation Tools
T-0168-1	Tail Rotor Assembly Holder
T-0169-1	Oleo Disassembly Tool
T-0174-1	Hub Puller
T-0179	Magneto Spring Installation Tool
T-0197-7	MR Hub Nut Torque Multiplier Wrench
T-0198-11	Enabler, Oil Drain MRGB
T-0204	Fan Shroud Alignment Tool

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-3. Special Tools

Part Number	Nomenclature
T-1575	Swashplate Centering Tool
T-1709	Guidetube Bearing Collar Tool
T-1758	Guidetube Clamps
T-1775	Cyclic Centering Rigging Tool
T-1794	Weight and Balance Datum Tool
T-2893	Tail Rotor Needle Teeter Bearing Removal/Installation Tool Kit
T-2896-1	Damper Bleeding/Servicing Tool (2 Required)
*	Main Rotor Transmission Stand
*	Main Rotor Hub Stand
*	Sprag Clutch Purge Tool
ATP761	Digital Mast Torque Multiplier

* Contact the Enstrom Helicopter Product Support for assistance in obtaining these tools.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2-16. Torque Data

Unless specified in Table 2-4 and/or in this manual's maintenance procedures or as called out in the component manufacturer's specifications, all hardware should be torqued to standard torque values listed in Tables 2-5 through 2-12.

Table 2-4. Special Torque Values

	Location	Torque Value
1.	Main rotor mast nut	400 ft-lb/542.3 Nm
2.	Main rotor transmission pinion nut	250 ft-lb/339 Nm
3.	Main rotor blade attachment nuts	50 ft-lb/68.2 Nm
4.	Main rotor blade drag link nuts	140 in-lb/15.9 Nm
5.	Main rotor damper pivot nut	190 in-lb/21.6 Nm
6.	Main rotor hub U-block lower nut	50 ft-lb/67.8 Nm
7.	Main rotor hub U-block upper nut	20 ft-lb/27.1 Nm
8.	Lamiflex bearing retention nut	12-15 in-lb/1.4-1.7 Nm
9.	Upper swashplate guidetube nuts	240 in-lb/27.1 Nm
10.	Engine mount nut	460-500 in-lb/52-56.5 Nm
11.	Tailcone attachment bolts	240 in-lb/27.3 Nm
12.	Tail rotor assembly retention bolt	300 in-lb/34.1 Nm
13.	Tail rotor blade grip nuts ¹	75 in-lb/8.5 Nm
14.	Tail rotor thrust bearing retention nut	80-90 ft-lb/108.5-122.0 Nm
15.	Lower engine pulley to crankshaft bolts	50 ft-lb/67.8 Nm
16.	Pitch change bellcranks	
	a. Push/pull rod bolt	40 in-lb/4.5 Nm
	b. Push/pull rod bolt with floating bushing	75 in-lb/8.5Nm
17.	Landing gear pivot points (all)	40-60 in-lb/4.5-6.8 Nm
18.	Landing gear oleo pivots points (all)	2 lb/0.9 kg drag (²)
19.	Tail rotor driveshaft taper pins	25 in-lb/2.8 Nm
20.	Dogleg nut	130-140 in-lb/14.7-15.9 Nm
21.	Dogleg to swashplate nut	40-60 in-lb/4.5-6.8 Nm
22.	Idler yoke/shaft jam nut	40-45 in-lb/4.5-5.1 Nm
23.	Fuel pump and fuel injector attach nuts	204 in-lb/23.1 Nm
24.	Main Rotor Transmission Magnetic Pick-up	60-65 in-lb/6.8-7.3 Nm

1 Foot-Pound (ft-lb) = 1.3558 Newton Meter (Nm)

1 Inch-Pound (in-lb) = 0.113 Newton Meter (Nm)

1 Nm = 0.7376 ft-lb

1 Nm = 8.851 in-lb

¹ Torque for oversize bolts: 140 in-lb/15.9 Nm maximum.

² Refer to paragraph 8-9.D.5.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-5. Torque Values for Nuts and Bolts

CAUTION THE FOLLOWING TORQUE VALUES ARE DERIVED FROM OIL FREE CADMIUM PLATED THREADS.					
		TORQUE LIMITS RECOMMENDED FOR INSTALLATION (BOLTS LOADED PRIMARILY IN SHEAR) (inch-pounds)		MAXIMUM ALLOWABLE TIGHTENING TORQUE LIMITS (inch-pounds)	
Thread Size	Tension type nuts MS20365 and AN310 (40,000 psi in bolts)	Shear type nuts MS20364 and AN320 (24,000 psi in bolts)	Nuts MS20365 and AN310 (90,000 psi in bolts)	Nuts MS20364 and AN320 (54,000 psi in bolts)	
FINE THREAD SERIES					
8-36	12-15	7-9	20	12	
10-32	20-25	12-15	40	25	
1/4-28	50-70	30-40	100	60	
5/16-24	100-140	60-85	225	140	
3/8-24	160-190	95-110	390	240	
7/16-20	450-500	270-300	840	500	
1/2-20	480-690	290-410	1100	660	
9/16-18	800-1000	480-600	1600	960	
5/8-18	1100-1300	600-780	2400	1400	
3/4-16	2300-2500	1300-1500	5000	3000	
7/8-14	2500-3000	1500-1800	7000	4200	
1-14	3700-5500	2200-3300*	10,000	6000	
1-1/8-12	5000-7000	3000-4200*	15,000	9000	
1-1/4-12	9000-11,000	5400-6600*	25,000	15,000	
COARSE THREAD SERIES					
8-32	12-15	7-9	20	12	
10-24	20-25	12-15	35	21	
1/4-20	40-50	25-30	75	45	
5/16-18	80-90	48-55	160	100	
3/8-16	160-185	95-100	275	170	
7/16-14	235-255	140-155	475	280	
1/2-13	400-480	240-290	880	520	
9/16-12	500-700	300-420	1100	650	
5/8-11	700-900	420-540	1500	900	
3/4-10	1150-1600	700-950	2500	1500	
7/8-9	2200-3000	1300-1800	4600	2700	
The above torque values may be used for all cadmium-plated steel nuts of the fine or coarse thread series which have approximately equal number of threads and equal face bearing areas. * Estimated corresponding values.					

Table 2-6. Fittings, Tubing



Aluminum Alloy Tubing



Steel Tubing

Fitting Size	Tubing OD (inches)	6061-O & 5052-O Aluminum-Alloy Tube: Fitting or Nut Torque (in-lb)	Steel Tube: Fitting or Nut Torque (in-lb)
-2	1/8	20-30	75-85
-3	3/16	25-35	95-105
-4	1/4	50-65	135-150
-5	5/16	70-90	170-200
-6	3/8	110-130	270-300
-8	1/2	230-260	450-500
-10	5/8	330-360	650-700
-12	3/4	460-500	900-1000

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-7. Fittings, Hose Assemblies



Flexible Hose or Tube Fittings (excluding nylon pitot static lines)						
Measurements based on Hose Inside Diameter or Fitting Size						
Fitting Size	Tube Size (inches)	Thread	Flex Hose and 6061-T6 Aluminum Alloy Torque Limits (in-lb)		Steel (Torque Limits (in-lb))	
			Min	Max	Min	Max
-3	3/16	3/8-24	30	70	90	140
-4	1/4	7/16-20	70	120	135	185
-5	5/16	1/2-20	70	120	180	230
-6	3/8	3/4-16	130	180	270	345
-8	1/2	3/4-16	300	400	450	525
-10	5/8	7/8-14	430	550	650	750
-12	3/4	1-1/6-12	650	800	900	1,100

Table 2-7.1. Fittings



Nominal Tube O.D. (inches)	Fitting Thread Size	Torque Limits (inch-pounds)									
		For Gasketed Aluminum or Steel Fittings*						For Jamnuts and Fittings Without Gaskets**			
		AN924 Nut AN815 Union		AN814 Plug		AN6289 Nut		Aluminum		Steel	
		Min	Max	Min	Max	Min	Max	Min	Max	Min	Max
1/8	5/16-24	25	35	10	16	25	35	35	50	-	-
3/16	3/8-24	50	75	30	40	50	75	65	80	70	90
1/4	7/16-20	55	80	40	65	75	100	90	105	110	130
5/16	1/2-20	75	100	60	80	90	120	105	125	140	160
3/8	9/16-18	100	150	80	120	150	200	125	145	225	275
1/2	3/4-16	180	230	150	200	200	250	240	280	400	450
5/8	7/8-14	250	350	200	350	275	400	330	370	550	650
3/4	1-1/6-12	420	600	300	500	450	650	540	660	800	960

* For use with O-rings and aluminum, asbestos, leather, Teflon, gaskets, or washers.
 ** For combinations of materials (either jamnut, fittings, or boss), use the lowest applicable values shown.

Table 2-8. Steel Fittings Using Jam Nuts or Straight Thread O-Ring Boss



AN814
Plug and Bleeder
(Steel)



MS51525
Flared AN to Straight Pipe
Thread Male Adapter

Tube Size	Thread Size (inches)	Torque Limits (inch-pounds)	
		Min	Max
-02	5/16-24	72	84
-03	3/8-24	95	105
-04	7/16-20	155	180
-05	1/2-20	170	180
-06	9/16-18	275	290
-08	3/4-16	480	515
-10	7/8-14	515	575

Table 2-9. Pitot Static System Nylon Fittings



268N04X02: Adapter



264N04: Union Tee



269N04X02: Male Elbow

Nominal Tube O.D. (inches)	Thread Size (inches)	Torque Limits (inch-pounds)	
		Min	Max
1/4	7/16-20	7	10

Table 2-10. Pipe Plugs



MS20822
90° AN to Pipe
Fitting



MS20823
45° AN to
Pipe Fitting



AN816
Nipple, Flared
Tube and Pipe
Thread



AN932 Plug



MS20913
Plug, Square
Head

Thread Size (inches)	Torque Limits (inch-pounds)
1/16-27 NPT	40 to 44
1/8-27 NPT	40 to 44
1/4-18 NPT	85 to 94
3/8-18 NPT	110 to 121
1/2-14 NPT	160 to 176
3/4-14 NPT	230 to 252
1-11-1/2 NPT	315 to 347

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 2-11. Crush Type Gaskets

NOTE

Turn the part until the sealing surfaces are in contact and then tighten to the angle of turn listed for the appropriate thread size.

Thread Pitch On Part to be Tightened (Threads per Inch)	Angle of Turn	
	Aluminum	Copper
8	135°	67°
10	135°	67°
12	180°	90°
14	180°	90°
16	270°	135°
18	270°	135°
20	270°	135°
24	360°	180°
28	360°	180°



Measuring thread pitch with thread gauges



Table 2-12. Prevailing Torque Values for Re-used Self-Locking Nuts

Bolt, or Screw Thread Size (inches)	Seating Torque (in-lb ±10%)	Prevailing Torque Max. On or Off (in-lb)	Prevailing Torque Min. On or Off (in-lb)
4-40	8	5	0.5
6-32	15	8	1.0
8-32	28	12	1.5
AN3	45	18	2.0
AN4	110	40	3.0
AN5	190	85	5.0
AN6	345	110	9.0
AN7	545	150	12.0
AN8	850	220	16.0

If not listed in Table 2-12, a self-locking nut can be reused as long as a wrench is required to turn it on the bolt.

I

INTENTIONALLY LEFT BLANK

2-17. Consumable Parts List

Table 2-13 lists the consumable parts and lubricants that are normally used during servicing or periodic inspection of the aircraft. The quantities listed reflect normal inspection intervals; however, they may need to be adjusted if adverse operating conditions require more frequent servicing or inspections.

Refer to the Lycoming Operator's Manual (Document 60297-12) and the Lycoming Parts Catalog (Document PC-406-2) for the consumable parts required for servicing or periodic inspection of the engine.

NOTE

Enstrom does not stock engine parts for customer service use. Obtain engine parts through Lycoming Engines Distribution Partners. For assistance, refer to the Genuine Parts tab on the Lycoming Products web page to find distributors near you (www.lycoming.com).

Table 2-13. Consumable Parts List

Item	Part Number †	Quantity
<u>50 Hour Service</u>		
1. Grease	MIL-PRF-81322 and MIL-G-25537	As Required
2. Silicon Oil	SF96-20	As Required
3. Oil	MIL-PRF-23699	As Required
4. O-ring	NAS1612-2	6 EA *
<u>100 Hour Service/Inspection</u>		
1. Same as 50 hour Requirements		
2. Crush Washer	AN900-8 or MS35769-9	1 EA
3. Crush Washer	AN900-10 or MS35769-11	1 EA
4. Oil	MIL-PRF-23699	1 OZ
5. Oil	MIL-PRF-2105/API GL-5	7 PTS
6. Air Filter Element	BA-15	1 EA
<u>200 Hour Service/Inspection</u>		
1. Same as 100 hour requirements		
<u>300 Hour Service/Inspection</u>		
1. Same as 100 hour requirements		
NOTES:		
*	Replace on condition	
†	Verify configuration, part number and quantity with latest revision of illustrated parts catalog, service letters, and service bulletins as required.	

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2-18. Taper Pin Size Chart

Table 2-14 lists information pertaining to taper pin part numbers and physical properties.

NOTES

Always check the condition and security of taper pins at every inspection.

The dash number of the 28-16323 series taper pins is vibro-etched on the head of the taper pin.

Table 2-14. Taper Pin List



Old Enstrom P/N	Current Enstrom P/N	Head Diameter	Grip Length
AN386-2-7A ¹	AN386-2-7A ¹	0.296 in / 7.5 mm	1.00 in / 25.4 mm
AN386-2-8A ¹	AN386-2-8A ¹	0.302 in / 7.6 mm	1.12 in / 28.4 mm
AN386-2-9A ¹	AN386-2-9A ¹	0.308 in / 7.8 mm	1.26 in / 32 mm
28-13600-3 ²	28-13623-25 ²	0.302 in / 7.6 mm	1.00 in / 25.4 mm
28-13600-4 ²	28-13623-27 ²	0.307 in / 7.7 mm	1.00 in / 25.4 mm
28-13600-5 ²	28-13623-29 ²	0.314 in / 7.9 mm	1.00 in / 25.4 mm
NA	28-13623-31 ²	0.316 in / 8 mm	1.00 in / 25.4 mm
28-13600-7 ³	28-13623-13 ³	0.310 in / 7.8 mm	1.12 in / 28.4 mm
28-13600-8 ³	28-13623-17 ³	0.318 in / 8 mm	1.12 in / 28.4 mm
NA	28-13623-15 ³	0.315 in / 8 mm	1.12 in / 28.4 mm
28-13600-6 ³	28-13623-11 ³	0.305 in / 7.7 mm	1.12 in / 28.4 mm
¹ Standard ² Tail Rotor Transmission ³ Main Rotor Transmission			

INTENTIONALLY LEFT BLANK

SECTION 3

AIRWORTHINESS LIMITATIONS

The Airworthiness Limitations Section is FAA approved and specifies inspections and other maintenance required under 14 CFR §§ 43.16 and 91.403 of the Federal Aviation Regulations unless an alternative program has been FAA approved.

FAA APPROVED BY



DATE

7/2/12

MANAGER
CHICAGO AIRCRAFT CERTIFICATION OFFICE
CENTRAL REGION
FEDERAL AVIATION ADMINISTRATION

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FAA Approved: July 2, 2012

MM-3-1

Rev. 4
Jun 21/12

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

**SECTION 3
LOG OF REVISIONS**

Rev. Num.	Rev. Date	Pages Affected	Approval Date	F.A.A. Approved
1	4/3/86	MM-3-1	4/3/86	W. F. Horn
2	11/18/88	MM-3-13 and MM-3-20	11/18/88	W. F. Horn
3	N/A	None	N/A	N/A
4	6/21/12	MM-3-1 through MM-3-6	Jul 2/12	G. Michalik
5	Nov 5/13	None	N/A	N/A
6	Apr 7/15	None	N/A	N/A
7	Aug 22/16	MM-3-2 through MM-3-4	Aug 26/16	G. Michalik
8	Sep 20/17	MM-3-2, MM-3-3	10/10/17	M. James

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FAA Approved:

MM-3-2

Rev. 8
Sep 20/17

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

**SECTION 3
EASA LOG OF REVISIONS**

Rev. Num.	Date	EASA Approved	FAA Approval on Behalf of EASA
1	9/28/03	Article 3, Commission Regulation (EU) 748/2012	N/A
2	9/28/03	Article 3, Commission Regulation (EU) 748/2012	N/A
3	N/A	N/A	N/A
4	7/9/15	FAA/EASA T.I.P.*	G. J. Michalik
5	N/A	N/A	N/A
6	N/A	N/A	N/A
7	9/9/16	FAA/EASA T.I.P.*	G. J. Michalik
8	10/23/17	N/A	N/A

* Section 3.2 T.I.P.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FAA Approved:

MM-3-3

Rev. 8
Sep 20/17

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 3

AIRWORTHINESS LIMITATIONS

TABLE OF CONTENTS

Paragraph	Description	Page
	FAA Cover.....	MM-3-1
	Log of Revisions.....	MM-3-2
	EASA Log of Revisions.....	MM-3-3
	Table of Contents.....	MM-3-4
3-1.	Retirement Life Items.....	MM-3-5
3-2.	Mandatory Inspection Items.....	MM-3-5

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 3

AIRWORTHINESS LIMITATIONS

3-1. Retirement Life Items

A. The items listed in Table 3-1 require mandatory retirement at the hours or calendar time established by Enstrom Helicopter Corporation and other component manufacturers.

B. Retirement life components authorized for installation on the F-28F and 280F Series must use the shorter retirement life limit for the life of the component if the component is removed from one model of aircraft and installed on a model with a different retirement life.

3-2. Mandatory Inspection Items

The Enstrom F-28F and 280F Series helicopters have no mandatory inspection items.

Table 3-1. Retirement Life Items

ITEM	PART NUMBER	RETIREMENT LIFE		
		F-28F	280F	280FX
Bearing, Idler Pulley	ECD018-11 (202SZZ)	600 Hrs	600 Hrs	600 Hrs
Bearing, Lower Swashplate	ECD009-11, -13 (5201SBKZZ)	1,200 Hrs+	1,200 Hrs+	On Condition
Bearing, Upper Swashplate	ECD013-11, -13 (Z993L13XR3B)	1,200 Hrs+	1,200 Hrs+	On Condition
Housing, Lower Swashplate	28-16119-1, -3	17,700 Hrs	17,700 Hrs	17,700 Hrs
Main Rotor Drag Link	28-14283-1	13,750 Hrs++	13,750 Hrs++	13,750 Hrs
Tail Rotor Blade	28-150002-1	3,100 Hrs	3,100 Hrs	3,100 Hrs
Tail Rotor Blade Grip	28-150044-1, -3	6,200 Hrs	6,200 Hrs	6,200 Hrs
Tail Rotor Driveshaft Coupling	28-13609-1	1,200 Hrs	1,200 Hrs	N/A
Tail Rotor Driveshaft Flex Pack	28-01041-3	1,200 Hrs	1,200 Hrs	1,200 Hrs
Tail Rotor Gear Set	ECD074-1, -2 (XR-137-2YL, -2R)	1,200 Hrs	1,200 Hrs	1,200 Hrs
	ECD100*	1,200 Hrs	1,200 Hrs	1,200 Hrs
	ECD101-1, -2	1,200 Hrs	1,200 Hrs	1,200 Hrs
Tail Rotor Spindle	28-150064-11, -13	1,200 Hrs	1,200 Hrs	1,200 Hrs
Tail Rotor Spindle	28-150074-11, -13	1,200 Hrs	1,200 Hrs	1,200 Hrs
Turbocharger	RJ0332 (325E10-2)	2,000 Hrs	2,000 Hrs	2,000 Hrs
	103574-00 (3BT2EE10J2)	2,000 Hrs	2,000 Hrs	2,000 Hrs
	600700-0 (3BT5EE10J2)	2,000 Hrs	2,000 Hrs	2,000 Hrs
Thrust Bearing	28-14320-12, -15	**	**	**
Tachometer Drive Belt (O-Ring)	NAS1611-333	***	***	***

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FAA Approved: July 2, 2012

MM-3-5

Rev. 4
Jun 21/12

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- * Applies to all dash numbers.
- ** Retire from service 5 calendar years from date of manufacture all Lamiflex bearings serial number 5997 and prior. Retire from service 5 calendar years from date of installation (defined as the date the Lamiflex bearing packaging is opened) or 8 calendar years from date of manufacture, whichever occurs first, all Lamiflex bearings serial numbers 5998 and subsequent.
- *** Retire from service 5 calendar years from date of installation or package opening, or 8 years from date of manufacture, whichever occurs first.
- + On condition when used with grease fitting.
- ++ For aircraft certified to 2350 lb maximum weight, component has no time limit. Remove component on condition per maintenance manual inspection criteria.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 4

SERVICING, RECOMMENDED OVERHAULS, INSPECTIONS, AND GENERAL MAINTENANCE

TABLE OF CONTENTS

Paragraph	Description	Page
	Table of Contents.....	MM-4-1
4-1.	Servicing.....	MM-4-5
4-2.	Description.....	MM-4-5
4-3.	Fuel System.....	MM-4-25
4-4.	Servicing.....	MM-4-25
4-5.	Draining.....	MM-4-26
4-6.	Engine Oil System.....	MM-4-26
4-7.	Servicing.....	MM-4-26
4-8.	Draining.....	MM-4-27
4-9.	Overrunning Clutch.....	MM-4-27
4-10.	Servicing.....	MM-4-27
4-11.	Main Rotor Transmission.....	MM-4-28
4-12.	Servicing.....	MM-4-28
4-13.	Draining.....	MM-4-29
4-13.1	Flushing.....	MM-4-29
4-14.	Tail Rotor Transmission.....	MM-4-30
4-15.	Servicing.....	MM-4-30
4-16.	Draining.....	MM-4-31
4-16.1	Flushing.....	MM-4-31
4-17.	Main Rotor Dampers.....	MM-4-32
4-18.	Servicing.....	MM-4-32
4-19.	Oleos.....	MM-4-33
4-20.	Servicing.....	MM-4-33
4-21.	Battery.....	MM-4-34
4-22.	Servicing.....	MM-4-34
4-23.	Lubrication.....	MM-4-34
4-24.	Description.....	MM-4-34
4-25.	Lower Pulley.....	MM-4-34
4-26.	Lubrication.....	MM-4-34
4-27.	Main Rotor Blade Grip.....	MM-4-34.1
4-28.	Lubrication.....	MM-4-34.1
4-29.	Main Rotor Flapping Bearings.....	MM-4-36
4-30.	Lubrication.....	MM-4-36
4-31.	Tail Rotor Pitch Control Bearing.....	MM-4-36
4-32.	Lubrication.....	MM-4-36
4-33.	Lubrication, Preferred Method.....	MM-4-36
4-34.	Lubrication, Alternate Method.....	MM-4-36
4-35.	Upper Pulley Bearing.....	MM-4-37
4-36.	Lubrication.....	MM-4-37
4-37.	Collective Guidetube Bearing.....	MM-4-37
4-38.	Lubrication.....	MM-4-37

SECTION 4

SERVICING, RECOMMENDED OVERHAULS, INSPECTIONS,
AND GENERAL MAINTENANCE

TABLE OF CONTENTS

Paragraph	Description	Page
4-39.	Cyclic Swashplate Bearing	MM-4-37
4-40.	Lubrication	MM-4-37
4-41.	Idle Pulley Bearing.....	MM-4-48
4-42.	Lubrication	MM-4-38
4-43.	Lubrication, Preferred Method	MM-4-38
4-44.	Lubrication, Alternate Method.....	MM-4-38
4-45.	Recommended Overhaul Cycles	MM-4-39
4-46.	Periodic Inspections	MM-4-40
4-47.	General Information	MM-4-40
4-48.	Daily Inspection.....	MM-4-40
4-49.	Periodic Inspection Checklists	MM-4-40
4-50.	50 Hour Inspection.....	MM-4-41
4-51.	100 Hour Inspection.....	MM-4-42
4-52.	200 Hour Inspection.....	MM-4-57
4-53.	400 Hour Inspection.....	MM-4-58
4-54.	Special Scheduled Inspection.....	MM-4-59
4-55.	Special Instructions	MM-4-60
4-56.	General Information	MM-4-60
4-57.	Main Rotor Blade Strike/Sudden Stoppage (Minor).....	MM-4-60
4-58.	Main Rotor Blade Strike/Sudden Stoppage (Major).....	MM-4-61
4-59.	Tail Rotor Blade Strike/Sudden Stoppage	MM-4-62
4-60.	Hard Landing	MM-4-62
4-61.	Main Rotor Overspeed.....	MM-4-63
4-62.	Main Rotor or Tail Rotor Transmission Chip Indication	MM-4-64
4-63.	Engine Overboost	MM-4-65
4-64.	Engine Overspeed	MM-4-66
4-65.	Maintenance Ground Run	MM-4-66
4-66.	Ground Handling.....	MM-4-68
4-67.	Ground Handling Wheels	MM-4-68
4-68.	External Power	MM-4-69
4-69.	Parking.....	MM-4-69
4-70.	Leveling.....	MM-4-69
4-71.	Hoisting.....	MM-4-70
4-72.	Cleaning.....	MM-4-70
4-73.	Exterior	MM-4-70
4-74.	Interior	MM-4-72
4-75.	Plexiglass.....	MM-4-72
4-76.	Aircraft Preservation and Storage.....	MM-4-73
4-77.	General.....	MM-4-73
4-78.	Low Usage.....	MM-4-73
4-79.	Storage Up to 45 Days	MM-4-74

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 4

SERVICING, RECOMMENDED OVERHAULS, INSPECTIONS,
AND GENERAL MAINTENANCE

TABLE OF CONTENTS

Paragraph	Description	Page
4-80.	Storage from 45 Days to 6 Months	MM-4-75
4-81.	Storage for Longer than 6 Months	MM-4-75
4-82.	Preventive Maintenance for Corrosion Control	MM-4-76
4-83.	General Information	MM-4-76
4-84.	Scheduled Field Preventive Maintenance Program	MM-4-76
4-85.	Component Preservation and Storage.....	MM-4-77
4-86.	Main Rotor Transmission.....	MM-4-77

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-1. Servicing

4-2. Description – Servicing

A. Servicing of the F-28/280F series helicopter is normally accomplished at specified hourly intervals. Operators should take into consideration the environmental conditions and determine whether more frequent servicing intervals are necessary. Refer to Tables 4-1 thru 4-7 and Figure 4-1 for approved fuels, oils, lubricants, intervals, and locations.

Table 4-1. Fuels, Lubricants, Specification, and Capacities

SYSTEM/COMPONENT	SPECIFICATION	CAPACITY
Fuel	100/130 Aviation Gasoline 100 Aviation Gasoline 100LL Aviation Gasoline (Note 1)	42.0 U.S. Gal. – Total 40.0 U.S. Gal. – Usable 159.0 Liters – Total 151.4 Liters – Usable
Engine Oil	MIL-L-22851/SAE-J1899 (Note 2 & 3)	10.0 U.S. Qt – Total 8.0 U.S. Qt – Engine Sump 7.6 Liters – Total 5.7 Liters – Engine Sump
Overrunning Clutch	MIL-PRF-7808 (Note 4) or MIL-PRF-23699 (Note 5)	As Required
Main Rotor Transmission	MIL-PRF-2105/SAE-J2360 or API GL-5 (Note 6)	3.0 Qt – Dry 2.75 Qt – Servicing 2.84 Liters – Dry 2.6 Liters – Servicing
Tail Rotor Transmission	MIL-PRF-2105/SAE-J2360 or API GL-5 (Note 6)	5 U.S. Ounces .15 Liters
Main Rotor Dampers	L-45 or SF96-20 Silicone Oil - Grade 20 (Note 8)	As Required
Main Rotor Blade Grips	MIL-PRF-81322 (Note 12)	As Required
Main Rotor Lead-Lag Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 10, 11, 12, 13)	As Required
Main Rotor Flapping Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 10, 11, 12, 13)	As Required
Pitch Change Bellcrank Pivot Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 11, 12, 13)	As Required
Upper Pulley (Jackstrut) Bearing	MIL-PRF-81322 (Note 12)	As Required
Lower Pulley (Jackstrut) Bearing	MIL-G-25537 or MIL-PRF-81322 (Notes 11, 12, 13)	As Required

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 4-1. Fuels, Lubricants, Specification, and Capacities

SYSTEM/COMPONENT	SPECIFICATION	CAPACITY
Idler Pulley Bearings	MIL-PRF-81322 (Note 12)	As Required
Snubber Roller Bearings	MIL-PRF-81322 (Note 12)	As Required
Drive Belt Clutch Cable	MIL-G-25537 or MIL-PRF-81322 (Notes 11, 12, 13)	As Required
Main Rotor Tachometer Drive Bearings	MIL-PRF-81322 (Note 12)	As Required
Tail Rotor Drive Shaft Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 11, 12, 13)	As Required
Tail Rotor Pitch Control Bearing	MIL-PRF-81322 (Note 12)	As Required
Tail Rotor Feathering Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 10, 11, 12, 13)	As Required
Tail Rotor Teeter Bearings	MIL-G-25537 or MIL-PRF-81322 (Notes 10, 11, 12, 13)	As Required
Collective Guidetube Bearing	MIL-PRF-81322 (Note 12)	As Required
Cyclic Swashplate Bearing	MIL-PRF-81322 (Note 12)	As Required
Idler Pulley Actuator Arm Pivots	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Tail Rotor Rotating Control Pivots	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Pitch Change Bellcrank Inboard Pivot Points	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Cyclic Swashplate Control Rod Pivot	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Trim Motor Attachment Points	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Tail Rotor Pedal Pivot Bushings	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Cabin Flight Control Bellcrank Bushings	MIL-L-6082/SAE-J1966 or MIL-L-22851/SAE-J1899 (Note 7)	As Required
Landing Gear Oleos	MIL-PRF-5606	As Required
Ground Handling Wheels	MIL-G-25537 or MIL-PRF-81322 (Notes 11, 12, 13)	As Required
Other	Note 14	As Required

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- Note 1: Refer to Textron-Lycoming Service Instruction 1070 (latest revision) for fuel recommendations.
- Note 2: Refer to Textron-Lycoming Service Instruction 1014 (latest revision) for lubricating oil recommendations and seasonal oil grade recommendations.
- Note 3: Textron-Lycoming recommends using the following engine oil for the specified average ambient air temperatures (See Note 2):

<u>Textron-Lycoming Lubricating Oil Recommendations</u>		
Average Ambient Air Temperature	MIL-L-6082 or SAE-J1966	MIL-L-22851 or SAE-J1899
All temperature		SAE 15W-50 or SAE 20W-50
Above 80°F (27°C)	SAE 60	SAE 60
Above 60°F (16°C)	SAE 50	SAE 40 or SAE 50
30°F to 90°F (-1°C to 32°C)	SAE 40	SAE 40
0°F to 70°F (-18°C to 21°C)	SAE 30	SAE 30, SAE 40, or SAE 20W-40
0°F to 90°F (-18°C to 32°C)	SAE 20W-50	SAE 20W-50 or SAE 15W-50
Below 10°F (-12°C)	SAE 20	SAE 30 or SAE 20W-30

- Note 4: Refer to Table 4-3 for approved domestic commercial oils.
- Note 5: Refer to Table 4-4 for approved domestic commercial oils.
- Note 6: Refer to Table 4-5 for approved domestic commercial oils.
- Note 7: Any grade.
- Note 8: SF96-20 Silicon Oil replaces L-45 Silicon Oil. These oils may be mixed.
- Note 9: MIL-G-25537 grease primary, MIL-PRF-81322 grease alternate. Do not use MIL-G-25537 grease if aircraft is equipped with Lamiflex Bearings, P/N 28-14320-15. Do not use Mobilgrease 28 as alternate grease. (Refer to SIL 0168.)
- Note 10: MIL-G-25537 grease primary, MIL-PRF-81322 grease alternate. Do not use Mobilgrease 28 as alternate grease. (Refer to SIL 0168.)
- Note 11: Refer to Table 4-6 for approved MIL-G-25537 commercial greases.
- Note 12: Refer to Table 4-7 for approved MIL-PRF-81322 commercial greases.
- Note 13: MIL-PRF-23827 acceptable as an alternate grease. Refer to Table 4-8 for approved MIL-PRF-23827 commercial greases.
- Note 14: Refer to SIL 0137 for additional components and approved lubricants.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 4-2. Servicing Intervals, Methods, and Locations

SYSTEM/COMPONENT	FREQUENCY	METHOD	NUMBER OF SERVICING POINTS (LOCATION) (Note 1)
Fuel	As Required		2 places (A-1)
Engine Oil	50 Hours/As Required	Filler Can	1 place (A-3)
Main Rotor Transmission	100 Hours/As Required	Filler Can	1 place (F-14)
Overrunning Clutch	100 Hours	Oil Can	1 place (G-15)
Upper Pulley (Jackstrut) Bearing (Note 3)	100 Hours	Grease Gun Or Hand Pack	1 place (G-16)
Lower Pulley (Jackstrut) Bearing	50 Hours	Grease Gun	1 place (H-17)
Idle Pulley Bearings	300 Hours	Syringe	2 places (I-18)
Idle Pulley Actuator Arm Pivots	100 Hours	Oil Can	2 places (I-19)
Snubber Roller Bearings	50 Hours	Grease Gun	1 place (J-20)
Drive Belt Clutch Cable	50 Hours	Grease Gun	2 places (K-21)
Main Rotor Tachometer Drive Bearings	100 Hours	Grease Gun	1 place (L-22)
Tail Rotor Drive Shaft Bearings	25 Hours	Grease Gun	5 places (M-23)
Tail Rotor Transmission	100 Hours/As Required	Oil Can	1 place (N-25)
Tail Rotor Rotating Control Pivots	100 Hours	Oil Can	4 places (N-27)
Tail Rotor Feathering Bearings	25 Hours	Grease Gun	2 places (N-28)
Tail Rotor Teeter Bearings (Note 4)	25 Hours	Grease Gun	2 places (N-29)
Tail Rotor Pitch Control Bearing	100 Hours	Syringe	1 place (N-30)
Collective Guidetube Bearing (Note 3 & 6)	50 Hours	Grease Gun Or Hand Pack	1 place (O-31)
Cyclic Swashplate Bearing (Note 3 & 7)	50 Hours	Grease Gun Or Hand Pack	1 place (O-32)
Cyclic Swashplate Control Rod Pivot	50 Hours	Oil Can	1 place (O-33)
Pitch Change Bellcrank Pivot Bearings	50 Hours	Grease Gun	3 places (P-34)
Pitch Change Bellcrank Inboard Pivot Points	50 Hours	Oil Can	3 places (P-35)
Main Rotor Blade Grips (Feather Bearing) (Note 2)	50 Hours	Grease Gun	6 places (P-37)
Main Rotor Dampers	50 Hours/As Required	Tool # T-2896	6 places (P-38)
Main Rotor Lead-Lag Bearings	50 Hours	Grease Gun	3 places (Q-39)
Main Rotor Flapping Bearings	50 Hours	Grease Gun	9 places (Q-40)
Landing Gear Oleos	100 Hours/As Required	Filler Can	4 places (R-41)
Ground Handling Wheels	As Required	Hand Pack	2 places (R-42)
Battery	(Note 5)		All cells (S-43)
Tail Rotor Pedal Pivot Bushings	100 Hours	Oil Can	4 places (T-44/45)
Cabin Flight Control Bellcrank Bushings	100 Hours	Oil Can	13 places (U-46)
Trim Motor Attachment Points	100 Hours	Oil Can	4 places (U-46)

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- Note 1: Refer to the Figure 4-1 illustrations on pages MM-4-13 through MM-4-24 for the lubrication/servicing locations.
- Note 2: Refer to paragraph 4-28 for lubrication procedure.
- Note 3: Hand pack the bearing if the bearing housing is not equipped with a grease fitting.
- Note 4: Only applies to 28-150050 and 28-150079 series tail rotor assemblies.
- Note 5: Service in accordance with manufacturer's instructions.
- Note 6: Also referred to as Upper Swashplate Bearing.
- Note 7: Also referred to as Lower Swashplate Bearing.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 4-3. Qualified Domestic Commercial Oils for MIL-PRF-7808

MANUFACTURER	MANUFACTURER'S DESIGNATION
Air BP Lubricants, Inc.	BP Turbo Oil 2389
American Oil	American PQ Lubricant 689
Castrol, Inc.	Brayco 880
Exxon Mobil Corp.	EXXON ETO 2389
Exxon Mobil Corp.	Mobil Avrex S Turbo 256, Mobil RM-201A, Mobil RM-184A
Stauffer Chemical Co.	Stauffer Jet 1

Table 4-4. Qualified Domestic Commercial Oils for MIL-PRF-23699

MANUFACTURER	MANUFACTURER'S DESIGNATION
Exxon Mobil Corp.	Mobil Jet Oil II
NYCO America	Turbonoycoil 600 (TN600)
Anderol Specialty Lubricants	Aeroshell/Royco Turbine Oil 500
American Oil and Supply Co.	American PQ Lubricant 6700
Castrol, Inc.	BRAYCO 89
Hatcol Corp.	HATCOL 3211
Air BP Lubricants, Inc.	Air BP Turbo Oil 2380
Exxon Mobil Corp.	EXXON ETO 2380
Stauffer Chemical Co.	Stauffer Jet II (Castrol 205)
Caltex Petroleum Corp.	Caltex RPM Jet Engine Oil 5
Chevron International Oil Co.	Chevron Jet Engine Oil 5
Exxon Mobil Corp.	Mobil Jet Oil 254 (Generation 3/HTS Oil)
Anderol Specialty Lubricants	Royco 560 (Generation 3/HTS Oil)
Shell Oil Company	Aeroshell Turbine Oil 560 (Generation 3/HTS Oil)

Table 4-5. Qualified Domestic Commercial Oils for SAE-J2360/API GL-5/MIL-PRF-2105

MANUFACTURER	MANUFACTURER'S DESIGNATION
Exxon Mobil Corp.	Mobil 1 Synthetic Gear Lubricant LS 75W-90 Mobil Delvac 1 ¹ Synthetic Gear Oil 75W-90 Mobilube HD LS 80W-90 Mobilube HD Plus 80W-90
Shell Oil Company	Shell Helix Racing Gear Oil 75W-90
Exxon	Exxon Gear Oil GX 80W-90 Exxon Synthetic Gear Oil (SGO) 75W-90
Esso	Esso Gear Oil GX 75W-90 Esso Gear Oil GX Extra 75W-90
BP Lubricants USA, Inc.	Castrol Syntrox Limited Slip 75W-90 (Syntec Gear Oil)

Table 4-6. Qualified Domestic Commercial Greases for MIL-G-25537

MANUFACTURER	MANUFACTURER'S DESIGNATION
Anderol Specialty Lubricants	Royco 37
Shell Oil Company	Aeroshell Grease 14


Table 4-7. Qualified Domestic Commercial Greases for MIL-PRF-81322

MANUFACTURER	MANUFACTURER'S DESIGNATION
Anderol Specialty Lubricants	Royco 22CF Aeroshell Grease 22CF
Air BP Lubricants	Aeroplex 622
Arpol Petroleum Co.	ARPOLUBE 81322
Exxon Mobil Corp.	Mobilgrease 28
Castrol, Inc.	Braycote 622
Shell Oil Company	Aeroshell 22, 22CF

¹ Mobil Delvac 1 75W-90 supersedes Mobil Delvac 75W-90 and Mobil SHC 75W-90.


Table 4-8. Qualified Domestic Commercial Greases for MIL-PRF-23827

MANUFACTURER	MANUFACTURER'S DESIGNATION
NYCO America	Nyco Grease GN10
Anderol Specialty Lubricants	Royco 27
Exxon Mobil Corp.	Beacon 325
Exxon Mobil Corp.	Mobilgrease 27
Petronomics Manufacturing Group	Petronomics Plus M-P Aircraft Grease
Shell Oil Company	Aeroshell Grease 33 Aeroshell Grease 7
Arpol Petroleum Co.	Arpolube 23827
Castrol Industrial North America, Inc.	Castrol Aeroplex AI



View A


1. Fuel Tanks (2 places)
2. Fuel Tank Sump Drain (2 places)
3. Engine Oil Filler
4. Engine Oil Dipstick



View B


5. Main Fuel Filter (P/N 33-199-916)

Figure 4-1. Servicing Locations



View C


- 6. Engine Oil Filter (P/N CH48103)



View D


- 7. Engine Air Filter (P/N 6487923)
- 8. Engine Main Oil Cooler
- 9. Engine Oil Sump Drain
- 10. Aux. Engine Oil Cooler
- 11. Main Fuel Filter Drain

Figure 4-1. Servicing Locations



View E


- 12. Main Rotor Gearbox Drain and Magnetic Particle Plug
- 13. Main Rotor Gearbox Oil Level Sight Gauge



View F


- 14. Main Rotor Gearbox Filler and Screen

Figure 4-1. Servicing Locations



View G


- 15. Main Rotor Gearbox Overrunning Clutch Drain and Filler Plugs
- 16. Upper Jackstrut Bearing Grease Fitting



View H


- 17. Lower Jackstrut Bearing Grease Fitting and Purge Plug

Figure 4-1. Servicing Locations



View I


- 18. Idler Roller Bearings (2 places)
- 19. Idler Strap Bushings (2 places)




View J

- 20. Drive Belt Snubber Roller Bearings

Figure 4-1. Servicing Locations



21




View K

21. Drive Belt Clutch Engagement Cable Grease Fitting
(2 places: Aft, top photo; Forward, bottom photo)


Sheet 6 of 12

Figure 4-1. Servicing Locations



View L


22. Rotor Tach Drive Grease Fitting



View M

23. Tail Rotor Drive Shaft Bearings (5 places)


Figure 4-1. Servicing Locations



View N

- 24. Tail Rotor Gearbox Drain and Magnetic Particle Plug
- 25. Tail Rotor Gearbox Filler Plug
- 26. Tail Rotor Gearbox Sight Gauge
- 27. Tail Rotor Control Yoke Pivot Points (4 places)
- 28. Tail Rotor Feathering Bearings (2 places)
- 29. Tail Rotor Teetering Bearings (2 places)
- 30. Tail Rotor Pitch Change Bearing


Figure 4-1. Servicing Locations



View O


- 31. Collective Guidetube Bearing Grease Fitting
- 32. Cyclic Swashplate Bearing Grease Fitting
- 33. Cyclic Swashplate Control Rod Pivots

Figure 4-1. Servicing Locations



View P


- 34. Pitch Change Bellcrank Pivot Bearings (3 places)
- 35. Pitch Change Bellcrank Inboard Pivot Points (3 places)
- 36. Main Rotor Lead/Lag Bearings (3 places)
- 37. Main Rotor Feathering Bearings (6 places)
- 38. Main Rotor Damper Service Plugs



View Q


- 39. Main Rotor Lead/Lag Bearings (3 places)
- 40. Main Rotor Flapping Bearings (9 places)

Figure 4-1. Servicing Locations



View R


- 41. Landing Gear Oleo Service Point
- 42. Ground Handling Wheel Bearing



View S


- 43. Battery Servicing Points (Forward, left photo, or aft, right photo, installation)

Figure 4-1. Servicing Locations



View T

- 44. Tail Rotor Pedals Lubricating Points (4 places)
- 45. Tail Rotor Control Bushings (4 places)



View U

- 46. Cabin Flight Control Bellcrank Pivot Bushings (11 places)

Figure 4-1. Servicing Locations

4-3. Fuel System

4-4. Servicing – Fuel System (Figure 4-1, View A and View B)

NOTE

Refer to Table 4-1 for system capacity and approved fuels.

WARNING

In the event of a major spillage of fuel, all powered equipment must be shut down. All personnel should leave the vicinity and be positioned to prevent any sources of possible ignition from entering the area. The appropriate authorities should be notified to contain and disperse the spill.

- A. Attach the fuel truck or refueling equipment ground wire to landing gear skids.

CAUTION

Take care not to bend fiberglass fuel tanks by not allowing nozzle to bend filler neck.

CAUTION

If fueling from drums or any questionable source of supply, a clean funnel and a screen or filter should be used to remove any foreign materials.

- B. Remove the fuel cap from one of the fuel tanks and insert the fuel nozzle.

NOTE

When the aircraft engine is hot, service the right tank first.

- C. Service the fuel tank as required.
D. Remove the fuel nozzle and install the fuel cap.
E. Remove the fuel cap from the opposite tank and insert the fuel nozzle.
F. Service the fuel tank as required.

- G. Remove the fuel nozzle and install the fuel cap.

NOTE

Because of cross-feeding which occurs during refueling, it may be necessary to add fuel to the first fuel tank refueled to obtain the required fuel quantity.

- H. Remove the ground wire.

4-5. Draining – Fuel System

WARNING

In the event of a major spillage of fuel, all powered equipment must be shut down. All personnel should leave the vicinity and be positioned to prevent any sources of possible ignition from entering the area. The appropriate authorities should be notified to contain and disperse the spill.

- A. Open the filler cap on the right fuel tank.
- B. Remove the fuel from the fuel tanks using a suitable pump or siphon and containers.
- C. Drain the remaining fuel from the tanks and lines into suitable containers using the tank sump drain valves and the gascolator drain valve.
- D. Reinstall the filler cap on the right fuel tank.

4-6. Engine Oil System (Figure 4-1, View C and View D)

4-7. Servicing – Engine Oil System

NOTE

Refer to Table 4-1 for system capacity and approved oils.

- A. Visually check the oil level on the dip stick.
- B. Remove the filler cap from the fill tube.
- C. Add oil as required to bring the oil level to the 8 quart mark.

NOTE

Normal operating oil level is between 6 and 8 quarts.

- D. Secure the dip stick and filler cap.

E. If servicing after draining the engine oil system, ground run the engine in accordance with the applicable rotorcraft flight manual/pilots operating manual. After the ground run, check the oil level and service as required.

4-8. Draining – Engine Oil System

- A. Place a suitable container under the drain plug in the bottom of the engine sump.
- B. Remove the drain plug or open the drain valve and allow oil to drain sump.
- C. Reinstall the drain plug and safety wire or close the drain valve after draining the oil.
- D. Place a suitable container under the lower oil line connection of the engine oil cooler.
- E. Disconnect the oil line from the cooler and drain the oil from the oil cooler and line.
- F. Reconnect the oil line.
- G. If the helicopter is equipped with an auxiliary engine oil cooler, place a suitable container under the oil cooler.
- H. Disconnect the oil line from the oil cooler and drain the oil from the oil cooler and oil line.
- I. Reconnect the oil line.

4-9. Overrunning Clutch (Figure 4-1, View G)

4-10. Servicing – Overrunning Clutch

NOTE

Refer to Table 4-1 for system capacity and approved oil. An alternate servicing procedure is described in step F.

- A. Rotate the upper pulley/overrunning clutch until the service plugs in the clutch are in the horizontal and vertical positions. Continue to rotate the upper pulley/overrunning clutch until one of the horizontal filler plugs is slightly above horizontal.
- B. Remove the filler plugs that are in the above horizontal and beyond vertical positions.
- C. Slowly rotate the upper pulley/overrunning clutch so that the open filler ports move towards the horizontal and vertical position.
- D. The overrunning clutch is properly serviced when the oil starts to drain from the open filler port as the port reaches the horizontal position.
- E. Add oil to the overrunning clutch until oil starts to drain from the filler port in the horizontal position.

NOTE

Because of the location of the filler passage, it is possible for the filler port to be partially blocked by the clutch sprags. If the filler port is partially blocked, the clutch will take oil very slowly.

F. Alternate Method:

- (1) Obtain a ¼-28 right angle zerk fitting, unscrew the end off, and discard the ball and spring.
- (2) Perform steps A and B. Install the modified zerk fitting in the top hole.
- (3) Using a suitable oil pump or syringe, push oil into the clutch until the oil runs clear from the side plug hole.

G. Reinstall the filler plugs and wipe up the excess oil.

4-11. Main Rotor Transmission (Figure 4-2, View E and View F)

4-12. Servicing – Main Rotor Transmission

NOTE

Refer to Table 4-1 for system capacity and approved oils.

A. The main transmission oil level is checked by a sight gauge located on the right aft side of the transmission. The sight gauge is visible through an access panel in the baggage compartment or via the top step in the step access panel on the right side of the helicopter. With the helicopter in a relatively level position, the oil level should be at or near the halfway level in the sight gauge. If oil is visible, no additional oil is required. If oil is not visible, add oil until the oil level is half way up the sight gauge.

NOTE

Check the transmission for leaking seals if servicing is required between periodic inspections.

B. Servicing the main rotor transmission.

- (1) Open the cover on the transmission filler port.
- (2) Add oil as required.
- (3) Close the cover on the transmission filler port.

4-13. Draining – Main Rotor Transmission

- A. Remove the access panel located below the left side fuel tank.
- B. Place a trough under the chip detector/magnetic plug located by the aft left side transmission mount and use a suitable container to collect the oil.
- C. If equipped with a chip detector, remove the chip detector from the quick disconnect receptacle.
- D. Remove the quick disconnect receptacle/magnetic plug from the transmission to drain the oil.
- E. When the transmission is drained, replace the crush washer on the receptacle/magnetic plug and reinstall receptacle/magnetic plug finger tight. Tighten an additional 90° and lockwire the receptacle/magnetic plug.
- F. If equipped with chip detector, reinstall the chip detector.

4-13.1 Flushing – Main Rotor Transmission

- A. Lower the ground handling wheels (paragraph 4-67.B).
 - (1) Helicopters equipped with MRGB chip detector: Set 1.5 inch (4 cm) wood blocks under the forward skid shoes raise the left side ground handling wheel (paragraph 4-67.C).
 - (2) Helicopters not equipped with MRGB chip detector and having a forward MRGB drain port: Install a block (2-3 inches) under the forward right skid plate and leave both ground handling wheels in the lowered position.
- B. Remove the left side upper access panel.
- C. Drain the transmission oil (paragraph 4-13).
- D. Remove the filler cap and tube assembly.
- E. Inspect the gears.
 - (1) Using a bright light source, inspect ring and pinion gear teeth for cracks, any pitting, any spalling (frosting), or hard wear lines. Turn the transmission by turning the upper pulley or the tail rotor.
- F. Use a syphon sprayer with kerosene, mineral spirits, or equivalent oil-based solvent to spray the interior of the gearbox. Direct the aim of the sprayer around the inside of the gearbox and the ring gear and carrier while turning the gearbox.
 - (1) Use a sufficient volume of solvent to thoroughly flush out any debris.
- G. Allow the MRGB to drain completely.
- H. Loosely install the magnetic drain plug or chip detector, as applicable.

- I. Add 4 quarts of the gear lube currently used in the gearbox (ref. Table 4-1).
- J. Manually rotate the main rotor hub to spin the gearbox 7-10 revolutions.
- K. Remove the magnetic plug/chip detector and drain the gearbox. Collect the oil to inspect for contamination. Repeat the flushing procedure until it drains free of contamination.
- L. Inspect and clean the magnetic drain plug or chip detector, if installed.
- M. Install and safety the magnetic drain plug/chip detector.
- N. Install and secure the filter cap and tube assembly using a new P/N 28-13107-13 gasket.
- O. Torque the bolts to 50-70 in-lb/5.6-7.9 Nm.
- P. Service the gearbox (paragraph 4-12).
- Q. Remove the blocks from under the forward skids and position the ground handling wheels, as desired.
- R. Install the left side upper access panel.

4-14. Tail Rotor Transmission (Figure 4-1, View N)

4-15. Servicing – Tail Rotor Transmission

NOTE

Refer to Table 4-1 for system capacity and approved oils.

NOTE

When the tail rotor transmission is properly serviced (5 oz./.147 l), the sight glass will be completely full. The transmission oil level is serviceable until the oil level is at the center of the sight glass.

A. Check the oil level of the transmission by using the sight plug located in the aft side of the transmission. The transmission is serviceable until the oil level is at the center of the sight glass. Raise and lower the tail to change the attitude of the aircraft to verify the level of the oil in the transmission if a bubble is present in the sight glass.

NOTE

Check the transmission for leaking seals if servicing is required between periodic inspections.

- B. Remove the filler port located directly above the sight glass.
- C. Add 5 oz./.147 l of oil if servicing the transmission after draining or slowly add oil until oil flows from the filler port.
- D. Reinstall the filler plug (72-84 in lbs/8.1-9.5 Nm) and lockwire (.032) to the magnetic plug/chip detector and the sight glass.

4-16. Draining – Tail Rotor Transmission

- A. If equipped with a chip detector, remove the chip detector from the quick disconnect receptacle.
- B. Place a suitable container under the receptacle/magnetic plug.
- C. Remove the quick disconnect receptacle/magnetic plug and drain the transmission.
- D. When the transmission is drained, replace the crush washer and reinstall the magnetic plug/chip detector. Tighten the magnetic plug/chip detector until the turning surfaces are in contact, then tighten an additional 135° (not to exceed 35 in-lb/4 Nm). Lockwire the receptacle/magnetic plug to the sight glass and the filler plug after the transmission has been serviced.
- E. If equipped with a chip detector, reinstall the chip detector.

4-16.1 Flushing – Tail Rotor Transmission

- A. Drain the oil (paragraph 4-16, steps A through C only).
- B. Remove the filler plug, sight glass, and top visual inspection plug (if not already removed) from the gearbox.
- C. Inspect the gears closely for cracked or missing teeth and the gearbox for damage.
- D. Use a syphon sprayer with kerosene, mineral spirits, or equivalent oil-based solvent to spray down the interior of the gearbox and flush any debris out of the gearbox. Direct aim the sprayer around the inside of the gearbox to flush the input and output bearings, while rotating the gearbox.
- E. Loosely install the bottom drain plug, sight glass, and fill plug.
- F. Add one-half quart of the gear lube that is currently used in the gearbox (Table 4-1).
- G. Rotate the gears at least ten times to circulate the oil.
- H. Place a container covered with a clean, white cloth or filter under the drain plug. Remove the drain plug and drain the oil into the container while rotating the gears. Allow the gearbox to drain completely.
- I. Inspect the cloth for contamination. If there is contamination, repeat steps D through H using a new cloth or filter each time the gearbox is drained. Proceed to step J if there is no contamination.
- J. Replace the crush washer and reinstall the top visual inspection plug. Tighten until the turning surfaces are in contact, then tighten an additional 90°. Lockwire the plug to the pivot bushing (.032).
- K. Replace the crush washer and reinstall the bottom magnetic plug/chip detector. Tighten until the turning surfaces are in contact, then tighten an additional 135° (not to exceed 35 in-lb/4 Nm).
- L. Service the gearbox (para. 4-15).

4-17. Main Rotor Dampers (Figure 4-5, View P)

4-18. Servicing (Bleeding) – Main Rotor Dampers

NOTES

Refer to Table 4-1 for system capacity and approved oil.

The dampers may be serviced while installed on or removed from the aircraft.

A. Servicing the dampers with tools T-2896 (Figure 4-1, View P, right):

- (1) Fill the tools approximately half full with L-45 Silicone Oil.
- (2) Remove the reservoir plugs and replace the O-rings as required.
- (3) Install the tools into the reservoir.
- (4) Depress one plunger only until the bubbles stop entering the other syringe. Then cycle the second syringe until the plunger is almost at the bottom.
- (5) Slowly cycle the plungers until all the air bubbles are purged from the damper.
- (6) Remove the tool from the “lower” port of the reservoir and install the plug.
- (7) Remove the tool from the “upper” port of the reservoir and completely fill the reservoir before installing the plug.
- (8) Tighten and lockwire (.025) the plugs.

B. Alternate method of servicing the dampers:

NOTE

Do not cycle the blades back and forth during this procedure as it will mix any air that is in the reservoirs and distribute it through the damper.

- (1) **Slowly** cycle the three blades in one direction until the damper piston is fully compressed.
- (2) Remove all of the caps from the reservoirs and fill the reservoirs to the top of the port. Reinstall the caps.
- (3) **Slowly** cycle the three blades in the other direction until the damper piston is fully extended.
- (4) Remove all of the caps from the reservoirs and fill the reservoirs to the top of the port. Reinstall the caps.
- (5) Perform this procedure three times or until the reservoirs show full when the caps are removed.

- (6) Install the reservoir plugs and lockwire (.025). Replace the plug O-rings as required.

4-19. Oleos (Figure 4-1, View R)

4-20. Servicing – Oleos

NOTES

Check the serviceability of the oleos by rocking the aircraft to distribute the weight of the aircraft evenly. The oleos are serviceable if .75" (19mm) to 1.75" (51mm) of the chromed piston extends past the seal retainer. When protective boots are installed, measure from upper flange of piston assembly to the lower flange on the seal housing assembly; proper length is 8" (20.3 cm) to 9" (22.9 cm). On 280FX models with the oleo fairings installed, use the back side of the fuel quantity dip stick, P/N 28-12478-11, to determine if the oleos are properly serviced.

If the oleos are not installed on the aircraft or the aircraft is jacked or hoisted off the ground, pressurize the aft oleos to 450 lbs and the front oleos to 400 lbs.

In some circumstances, individual oleo pressures may have to be adjusted to compensate for differences between individual helicopters and environmental factors.

The oleo struts should be serviced as pairs such that either both front or both aft oleos are serviced at the same time.

A. Service the oleos using the following procedures:

- (1) On 280FX models, remove the screws securing the lower end of the flex boot to the oleo fairing, and lift the flex boot to gain access to the oleo valve.

NOTE

The use of nitrogen is recommended for servicing, as it has no moisture content.

- (2) Sling or hoist the helicopter.
- (3) Remove the valve cap and connect the servicing equipment pressure line to the oleo valve. Set the nitrogen tank regulator pressure to 450 psi for the aft oleos or 400 for the front oleos.

WARNING

The oleo may extend when the valve is opened.

- (4) Slowly open the oleo valve.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (5) After the pressure in the oleo has equalized to the regulator pressure, close the oleo valve.
- (6) Turn off the nitrogen tank and set the regulator pressure back to zero.
- (7) Disconnect the service equipment and install the valve cap.
- (8) (280FX) Slide the landing gear fairing into position and install the retaining screws.

NOTE

On 280FX models, lower the flex boot, and install the screws securing the flex boot to the oleo fairing.

- (9) Remove the helicopter from the sling, as necessary.

4-21. Battery (Figure 4-1, View S)

4-22. Servicing – Battery

- A. Service the battery in accordance with manufacturer's instructions.

4-23. Lubrication

4-24. Description – Lubrication

A. Lubrication of F-28/280 Series helicopters is normally accomplished at specified hourly intervals. Operators should take into consideration the environmental conditions and determine whether more frequent lubrication intervals are necessary. Refer to Tables 4-1 to 4-5 and Figure 4-1 for approved lubricants, intervals, and locations.

B. Purge lubricate all bearings and remove the excess grease before performing the post maintenance ground run. Follow the procedures listed below for lubricating the lower pulley (jackstrut), main rotor blade grips, main rotor flapping bearings, tail rotor pitch control bearing, upper pulley (jackstrut) bearing, collective guide tube bearing, cyclic swashplate bearing, and the idler pulley bearings.

- C. Lubricate the flight control pivot points sparingly to prevent the accumulation of dirt.

4-25. Lower Pulley (Jackstrut) Bearing (Figure 4-1, View H)

4-26. Lubrication – Lower Pulley (Jackstrut) Bearing

- A. Remove the purge plug.
- B. Purge lubricate the lower pulley bearing.
- C. Reinstall the purge plug.

4-27. Main Rotor Blade Grip (Figure 4-1, View P, and Figure 4-2)

4-28. Lubrication - Main Rotor Blade Grip

NOTE

Purge all three blade grips when lubricating the hub to prevent an "out of balance" condition.

CAUTION

Disconnect the pitch links and before rotating the grips. Do not over-rotate.

- A. Disconnect the pitch links and rotate grips a few degrees up and down to release pressure.
- B. Remove the purge screw (2) and pump grease into the grease fitting (1) until grease purges through the screw hole. Install the screw (2).
- C. Remove the purge screw (3) and pump grease into the grease fitting (1) until grease purges through the screw hole.
- D. Pump grease into the fitting (4) until grease purges through the screw hole. Install the screw (3).
- E. Pump grease into the grease fitting (4) until grease purges through the seal between the end of the grip and the spindle.
- F. Remove the purge screw (3) to relieve any internal pressure against the seals. Install the screw.
- G. Check seal to determine that it has not been displaced.

|

INTENTIONALLY LEFT BLANK




Figure 4-2. Main Rotor Blade Grip, Lead-Lag Bearing, and Flapping Bearing Lubrication

4-29. Main Rotor Flapping Bearings (Figure 4-1, View Q, and Figure 4-2)

4-30. Lubrication – Main Rotor Flapping Bearings

NOTE

Refer to paragraphs 4-20 through 4-22 if the main rotor hub assembly is equipped with oil lubricated flapping bearings.

A. Purge lubricate the main rotor flapping bearings using the grease fitting located in the recess of the bottom of the vertical hinge pin (Figure 4-2).

4-31. Tail Rotor Pitch Control Bearing (Figure 4-1, View N)

4-32. Lubrication – Tail Rotor Pitch Control Bearing

4-33. Lubrication, Preferred Method – Tail Rotor Pitch Control Bearing

NOTE

Purge the needle prior to each use and lubricate the external surface of the needle with grease to prevent seal damage.

A. Using a 6 cubic centimeter (cc) medical syringe and an 18 gauge hypodermic needle, inject .5cc of grease into the bearing in two places, approximately 180° apart. Carefully insert the tip of the needle under the lip of the seal where it contacts the inner race of the bearing. The tip of the needle can be worked under the lip of the seal and into the bearing between the balls. If the needle does not penetrate between the balls, the needle can be withdrawn and inserted in another position on the bearing.

B. Wipe the excess grease from the surface of the seal as necessary

4-34. Lubrication, Alternate Method – Tail Rotor Pitch Control Bearing

WARNING

Use caution when removing the seal to prevent from injuring yourself.

A. Using a small flat-blade screwdriver or small knife blade, remove the seal from the inboard side of the bearing.

B. Hand pack the bearing with grease.

C. Reinstall the seal. Ensure it is properly seated.

4-35. Upper Pulley (Jackstrut) Bearing (Figure 4-1, View G)

4-36. Lubrication – Upper Pulley (Jackstrut) Bearing

A. Purge lubricate the bearing via the grease fitting.

4-37. Collective Guidetube Bearing (Figure 4-1, View O)

4-38. Lubrication – Collective Guidetube Bearing

A. Purge lubricate the bearing via the grease fitting.

4-39. Cyclic Swashplate Bearing (Figure 4-1, View O)

4-40. Lubrication – Cyclic Swashplate Bearing

A. Purge lubricate the bearing via the grease fitting.

4-41. Idler Pulley Bearings (Figure 4-1, View I)

4-42. Lubrication – Idler Pulley Bearings

4-43. Lubrication, Preferred Method – Idler Pulley Bearings

NOTE

Purge the needle prior to each use and lubricate the external surface of the needle with grease to prevent seal damage.

A. Using a 6 cubic centimeter (cc) medical syringe and an 18 gauge hypodermic needle, inject .5cc of grease into the bearing in two places, approximately 180° apart. Carefully insert the tip of the needle under the lip of the seal where it contacts the inner race of the bearing. The tip of the needle can be worked under the lip of the seal and into the bearing between the balls. If the needle does not penetrate between the balls, the needle can be withdrawn and inserted in another position on the bearing.

B. Wipe the excess grease from the surface of the seal as necessary

4-44. Lubrication, Alternate Method – Idler Pulley Bearings

WARNING

Use caution when removing the seal to prevent from injuring yourself.

A. Using a small flat-blade screwdriver or small knife blade, remove the seal from the aft side of the aft bearing or the front side of the bearing.

B. Hand pack the bearing with grease.

C. Reinstall the seal. Ensure it is properly seated.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-45. Recommended Overhaul Cycles

A. Refer to Table 4-9 for components with recommended overhaul cycles established by Enstrom Helicopter Corporation and other component manufacturers.

NOTE

Refer to the latest revision of Textron-Lycoming Service Instruction No. 1009 for the recommended overhaul cycle for the HIO-360 Series engine.

NOTE

Refer to the latest revision of the *Rayjay Aircraft Turbocharger Overhaul and Test Manual* for the recommended overhaul cycle for the turbocharger.

NOTE

All other components not listed in Table 4-9 are “on condition” items.

B. Overhaul cycle components authorized for installation on the F-28F, 280F, and 280FX must use the shorter overhaul cycle for the duration of the component overhaul cycle if the component is removed from one model of aircraft and installed on a model with a different overhaul cycle.

Table 4-9. Recommended Overhaul Cycles

ITEM	PART NUMBER	OVERHAUL CYCLE
		F-28/280 Series
Clutch, Overrunning	28-13401-2, -4	2400 Hrs
Transmission, Main Rotor	28-13101 (All dash numbers)	1200 Hrs
	28-13170 (All dash numbers)	1200 Hrs
Transmission, Tail Rotor	28-13520 (All dash numbers)	1200 Hrs
	28-13525 (All dash numbers)	1200 Hrs

4-46. Periodic Inspections

4-47. General Information

A. Periodic Inspection Checklists are set forth in paragraphs 4-50 through 4-53. These inspection checklists are intended to be used in conjunction with more detailed procedures presented in other sections of this manual, optional equipment maintenance manual supplements, or vendor manuals. Special inspections are set forth in paragraph 4-54. These special inspections are required following such occurrences as a main rotor and/or tail rotor blade strike, a hard landing, or a rotor overspeed.

- (1) The time extension for the periodic inspections is as follows:
 - a. 50, 100, 200, and 400 hour periodic inspections – 10 hours.
- (2) If the extension is used, the next scheduled inspection is due at the time applicable prior to using the extension. For example, if a 100 hour periodic inspection is due at 100 hours, but is performed at 108 hours, the next periodic 100 hour inspection is due at 200 hours not 208 hours.
- (3) If the periodic inspection is performed early, the next periodic inspection is due based on when the inspection was performed. For example, if the periodic inspection was performed at 98 hours instead of 100 hours, the next periodic inspection is due at 198 hours, not 200 hours.
- (4) The 10 hour extension does not apply to life limited components.

B. Mandatory component replacement times in flight hours are specified in paragraph 3-2.

C. Recommended component overhaul cycles are specified in paragraph 4-45.

4-48. Daily Inspection

The Enstrom F-28F, 280F, and 280FX do not require a mandatory daily (maintenance) inspection. Owner/Operators opting to have maintenance personnel check the aircraft should perform a pre-flight check I/A/W the F-28F, 280F, or 280FX Rotorcraft Flight Manual.

4-49. Periodic Inspection Checklists

A. These inspection checklists are intended for aircraft operating under normal condition. More frequent inspections may be required should adverse operations be encountered.

B. For more detailed inspection procedures and tolerance, refer to the appropriate section in the maintenance manual, optional equipment maintenance manual supplements, or vendor manuals.

C. Perform a 100 hour inspection, as a minimum, to meet the requirements for an Annual Inspection.

D. Refer to the Textron-Lycoming O, HO, AIO, HIO, TIO-360 Series Operator's Manual (60297-12) for the specific inspection requirements for continued airworthiness of the engine.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-50. 50 Hour Inspection Guide – Periodic Inspection

AIRCRAFT REGISTRATION NUMBER:			SIGNATURE:	
AIRCRAFT SERIAL NUMBER:			DATE:	
HOURS:	Engine:	Flight:		
50 HOUR INSPECTION GUIDE				
INITIAL EACH ITEM AFTER ACCOMPLISHMENT				INITIAL
1. GENERAL INSPECTION				
A. Inspect the engine records and discrepancy sheets.				_____
B. Check the engine records for time remaining TBO.				_____
C. Check for special engine inspections.				_____
D. Check compliance with applicable engine Service Letters, Service Bulletins, and Airworthiness Directives.				_____
E. Remove cowling and access panels as required to inspect the engine.				_____
2. ENGINE				
A. Inspect the engine in accordance with the Textron-Lycoming <u>O, HO, AIO, HIO, TIO-360 Series Operator=s Manual (60297-12)</u> .				_____
3. FLIGHT CONTROLS				
A. Verify the tail rotor pitch change horn/pitch change link installation torque (SDB 0125).				_____

4-51. 100 Hour/Annual Inspection Guide – Periodic Inspection

AIRCRAFT REGISTRATION NUMBER:		SIGNATURE:	
AIRCRAFT SERIAL NUMBER:		DATE:	
HOURS: Engine:		Flight:	
100 HOUR/ANNUAL INSPECTION GUIDE			
INITIAL EACH ITEM AFTER ACCOMPLISHMENT			INITIAL
1. GENERAL INSPECTION			
A. Perform a complete 50 Hour Inspection.			_____
B. Inspect the aircraft records and discrepancy sheets.			_____
C. Check the aircraft and engine records for TBO and Retirement Life items.			_____
D. Check for special airframe or engine inspections.			_____
E. Check compliance with applicable Service Information Letters, Service Directive Bulletins, and Airworthiness Directives.			_____
F. Inspect the aircraft for evidence of fuel and oil leaks.			_____
G. Clean the aircraft thoroughly.			_____
H. Remove the following cowling, access panels, and components:			
1) Wrap around cowling (top and sides)			_____
2) Engine side panels			_____
3) Upper side panels			_____
4) Spark plug covers			_____
5) Cabin doors			_____
a. Verify door latch operation and inspect and adjust the door handle assembly, if required, in accordance with paragraph 8-4.H.			_____
6) Seat deck			_____
7) Floor panels			_____
8) Firewall panels (cabin backwall)			_____
9) Fuel transmitter panel (right fuel tank)			_____
2. AIRCRAFT STRUCTURE & FUSELAGE			
A. Aircraft Exterior:			
1) Inspect the aircraft exterior for cleanliness, corrosion, and damage.			_____
2) Inspect the cowling and access panels for worn, loose, or missing fasteners.			_____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

B. Fuel System:

- 1) Inspect the fuel tanks for evidence of loose rivets, bond separation, leaks, condition of gasket in the fuel caps, and proper operation of the fuel caps. _____
- 2) Inspect the fuel supply lines for condition, leaks, and security of installation. _____
- 3) Inspect the vent and drain lines for obstructions, condition, and security of installation. _____
- 4) Inspect the drain valves and the fuel shutoff valve for leaks, condition, proper operation, and security of installation. _____
- 5) Inspect the scupper bags for looseness, tears, condition, and security of installation. _____
- 6) Inspect the fuel quantity transmitter wiring and transmitter terminals for evidence of corrosion, condition, and security of installation. _____

3. COMPONENTS

A. Components:

- 1) Inspect components installed on the aircraft for condition, damage, proper operation, and security of installation. _____

4. ENGINE

A. Inspect and service the engine in accordance with the Textron-Lycoming O, HO, AIO, HIO, TIO-360 Series Operator=s Manual (60297-12). _____

B. Lubrication System:

- 1) Drain the engine oil coolers I/A/W para.4-8 and inspect the oil cooler(s) for condition, security of installation, and obstruction of airflow. _____
- 2) Inspect the cooler clean out doors for condition and security. _____
- 3) Inspect the scavenge oil pump for condition, security of installation, and leaks. _____
- 4) Inspect the oil lines for condition, chaffing, and security. _____
- 5) Service the engine oil I/A/W para. 4-7. _____

C. Fuel System:

- 1) Inspect the fuel boost pump for condition, security of installation, operation, and leakage. _____
- 2) Inspect the engine driven fuel pump for condition, security of installation, and leakage. _____
- 3) Inspect the main fuel filter for condition, security of installation, and leakage. _____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

4) Inspect and clean the main fuel filter element.	_____
5) Inspect the fuel lines for condition, chaffing, and security.	_____
6) Inspect the fuel nozzle air manifolds and lines for condition and security of installation.	_____
D. Fuel Servo:	
1) Inspect the fuel servo for condition and security of installation.	_____
2) Inspect the Automatic Mixture Control (AMC) blast tube for condition and security of installation.	_____
3) Inspect the throttle and mixture controls for proper operation, condition, and security of installation.	_____
E. Exhaust System:	
1) Inspect the exhaust system for evidence of leaks or cracks and proper security and installation of all clamps (SDB 0122).	_____
2) Inspect the heat exchanger (muff heater) for evidence of leaks, cracks, condition, and security of installation.	_____
F. Turbocharger System:	
1) Inspect the turbocharger, oil lines, and fittings for leaks, condition, and security of installation.	_____
2) Inspect the turbocharger support brackets for condition and security of installation.	_____
3) Inspect the turbo inlet adaptor gasket condition, and condition security of installation (torque per SIL 0175).	_____
4) Inspect the exhaust pipe, air induction pipes, and clamps for condition and security of installation (SIL 0054 Revision 1 or later revision).	_____
5) Inspect the turbocharger heat shield for condition and security of installation.	_____
6) Inspect the wastegate system for proper operation and security of installation.	_____
7) Inspect the wastegate control rod for proper operation of the override detent.	_____
G. Cooling System:	
1) Inspect the fan shroud for condition, alignment, worn or missing fasteners.	_____
2) Inspect the fan shroud seal for condition.	_____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE	
3) Inspect the cowling and baffling for condition and security of installation.	_____
4) Inspect the cooling fan for condition and security of the fan blades and proper clearance at the shroud.	_____
5) Inspect the fire curtain for condition and security of installation.	_____
H. Starter:	
1) Inspect starter for condition and security of installation.	_____
I. Alternator:	
1) Inspect alternator for condition, evidence of overheating, and security of installation.	_____
2) Inspect the alternator drive belt for condition and proper tension.	_____
J. Engine Mounts:	
1) Inspect the engine mounts for condition and security of installation.	_____
K. Engine Electrical System:	
1) Inspect the engine electrical wiring harness for chaffing, condition, proper clamping, and security of installation.	_____
2) Inspect the electrical component panel and components for condition and security of installation.	_____
3) Inspect the engine to pylon ground strap for condition and security of installation.	_____
L. Pylon Assembly:	
1) Inspect the pylon in the engine area for corrosion, cracks, dents, or other damage, and condition of the protective primer/epoxy coating.	_____
M. Air Induction System:	
1) Inspect the filter container assembly for condition, proper operation of the bypass door, and security of installation.	_____
2) Replace the filter element.	_____
3) Inspect the flex duct and fuel servo adapter for condition and security of installation.	_____

100 HOUR/ANNUAL INSPECTION GUIDE

- 4) Inspect the vent line and check valve for condition and security of installation. _____
- 5) Inspect engine access panel seal for condition. _____

N. Engine Cylinder Compression:

- 1) Inspect engine cylinders for proper compression (Refer to the latest revision of Textron-Lycoming Service Instruction No. 1191A).
 Cylinder 1 _____ Cylinder 2 _____
 Cylinder 3 _____ Cylinder 4 _____

O. Engine Access Panels:

- 1) Inspect the engine access panels for cracks, damage, condition of hinges, and worn or missing fasteners. _____

5. LANDING GEAR ASSEMBLY

A. Crosstubes:

- 1) Inspect the crosstube attachment clamps for deformation, corrosion, cracks, evidence of elongated bolt holes, and security of the attaching hardware (SDB 0124). _____
- 2) Inspect the crosstubes for damage, worn or missing hardware, and security of installation. _____
- 3) Inspect the crosstubes for excessive bowing (>0.5 inch/12.7 mm) while the aircraft is hanging and not sitting on ground. _____

B. Landing Gear Legs and Drag Struts:

- 1) Inspect the landing gear legs and drag struts for cracks, damage, and security of installation. _____
- 2) Inspect the landing gear leg fairings for condition and security of installation (280FX). _____

C. Landing Gear Oleos:

- 1) Inspect the oleos for leaks, corrosion, proper servicing, and security of installation. _____
- 2) Inspect the oleo fairings for condition and security of installation (280FX). _____

D. Skid Tubes:

- 1) Inspect the skid tubes for condition and security of installation. _____
- 2) Inspect the skid shoes for condition and security of installation. _____
- 3) Inspect the non-skid tape/paint for condition. _____

100 HOUR/ANNUAL INSPECTION GUIDE	
<p>E. Ground Handling Wheels:</p> <ol style="list-style-type: none"> 1) Inspect the ground handling wheels and brackets for condition and security of installation. 2) Inspect the tires for condition and proper inflation. 3) Inspect the quick disconnect locking pins for condition. 	<p>_____</p> <p>_____</p> <p>_____</p>
6. DRIVE BELT SYSTEM	
<p>A. Belt Engagement (Clutch) Assembly:</p> <ol style="list-style-type: none"> 1) Inspect the spring capsule for proper extension with the belt clutch engaged, worn bushings in the side plates, condition, and security of installation. 2) Inspect clutch capsule adapter and bushing for wear. Replace Bushing (P/N 07-DU-08 as required). <p><u>NOTE:</u> Lube springs and capsule in accordance with Paragraph G, (10) on Page MM-11-65.</p> <ol style="list-style-type: none"> 3) Inspect the side plates for wear in the slot, condition and security of installation. 4) Inspect the over-center microswitch for condition and proper operation. 5) Inspect the engagement bellcrank for loose or worn bushings, condition, and security of installation. 6) Inspect the clutch engagement cable for condition and security of installation. 	<p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p>
<p>B. Idler Pulley Assembly:</p> <ol style="list-style-type: none"> 1) Inspect the idler pulley support bracket for worn bushings, cracks, condition, and security of installation. 2) Inspect the idler pulley yoke and shaft for cracks, worn rod end bearing, rod end threads (corrosion and corrosion protection condition (SDB 0127)), condition and security of installation. 3) Inspect the idler pulley yoke straps for worn bushings, cracks, condition, and security of installation. 4) Inspect the idler pulley for worn bearings, evidence of the drive belt not tracking properly, condition, and security of installation. 5) Inspect the belt snubber roller for worn bearings, condition, security of installation, and proper alignment/clearance with the drive belt (drive belt engaged). 6) Inspect the idler pulley pylon support strut for condition and security of installation. 	<p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p>

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

C. Jackstrut and Lower Pulley Assembly:

- 1) Inspect the jackstrut for bond separations, condition, and security of installation. _____
- 2) Inspect the lower pulley for wear, excessive grease leakage, condition, and security of installation. _____

D. Upper Pulley Assembly:

- 1) Inspect the upper pulley wear, condition, and security of installation. _____
- 2) Inspect the overrunning clutch for proper servicing, leaks, condition, and security of installation. Service the overrunning clutch I/A/W para. 4-13. _____
- 3) Inspect the pinion bearing assembly for evidence of worn or loose bearing, condition, and security of installation. _____
- 4) Check pinion bearing nut for proper torque. _____

E. Drive Belt

- 1) Inspect the drive belt for cracks, fraying, missing sections, and I/A/W SIL 0074. _____

F. Pylon:

- 1) Inspect the pylon in the belt drive area for corrosion, cracks, dents, or other damage, and condition of the protective primer/epoxy coating. _____

7. TAIL CONE ASSEMBLY

A. Tail Cone:

- 1) Inspect the tail cone bulkheads, longerons, stringers, doublers, and fittings for cracks, dents, and loose rivets. _____
- 2) Inspect the tail cone for proper installation. _____
- 3) Inspect the static ports for obstructions, damage, and security of installation. _____

B. Horizontal and Vertical Stabilizers:

- 1) Inspect the horizontal and vertical stabilizers for damage, cracks, loose rivets, and security of installation. _____

C. Tail Rotor Guard:

- 1) Inspect the tail rotor guard for damage, loose rivets, and security of installation. _____

100 HOUR/ANNUAL INSPECTION GUIDE

D. Extension (Stinger) Tube:

- 1) Inspect the extension tube for damage and security of installation. _____
- 2) Inspect the extension tube mounting brackets for damage and loose/sheared rivets/fasteners. _____

E. Tail Rotor Driveshaft:

- 1) Inspect the tail rotor driveshaft, hubs, and taper pins for damage and security of installation. _____
- 2) Inspect the splined couplings, P/N 28-13609-1, proper lubrication, wear, and security of installation. _____
- 3) Inspect the flex pack couplings for damage and security of installation. _____
- 4) Inspect the pillow block assemblies for evidence of rough/worn bearings, condition of the rubber inserts, and security of installation. _____
- 5) Inspect the main rotor tachometer drive belts and tachometer drive assembly for condition and security of installation. _____

8. TAIL ROTOR TRANSMISSION

A. Tail Rotor Transmission:

- 1) Inspect the tail rotor transmission for seal leakage, cracked/damaged housing, condition and security of plugs/sight plugs, and security of installation. _____
- 2) Drain the transmission and inspect the magnetic plug/chip detector for the presence of magnetic particles. _____
- 3) Service the transmission. _____

B. Tail Rotor Pitch Controls:

- 1) Inspect the tail rotor pitch controls for worn bushings at the pivot points, damage, and security of installation. _____
- 2) Inspect the slider assembly for freedom of operation and wear. _____
- 3) Inspect the pitch control bearing for condition. _____

100 HOUR/ANNUAL INSPECTION GUIDE

9. TAIL ROTOR ASSEMBLY

A. Tail Rotor Assembly:

- 1) Inspect the tail rotor blade and grip assemblies for cracks, nicks, dents, scratches, bends, fretting, bond separations, corrosion, loose tip rivets, and condition of strike tabs. _____
- 2) Inspect the tail rotor spindle and hub for cracks, nicks, scratches, corrosion. _____
- 3) Inspect the teeter bearings for wear or excessive end play. _____
- 4) Inspect the tail rotor blade grip bearings for excessive play or notchiness. _____
- 5) Inspect the pitch change links for condition, worn rod end bearings, proper hardware, and security of installation. _____
- 6) Inspect tail rotor static stop and rubber bumpers for condition and security of installation. _____

10. MAIN ROTOR TRANSMISSION

A. Main Rotor Transmission

- 1) Inspect the main rotor transmission for seal leakage, corrosion, damage, cleanliness of sight glass, and condition of installation hardware slippage marks. _____
- 2) Inspect the main rotor mast for corrosion, nicks, scratches or other damage. _____
- 3) Drain the transmission and inspect the magnetic pickup/chip detector for metal particles. _____
- 4) Inspect the ring and pinion gears for wear and spalling. _____
- 5) Service the transmission. _____

B. Pylon:

- 1) Inspect the pylon in the main rotor transmission area for corrosion, cracks, dents, or other damage, and condition of the protective primer/epoxy coating. _____

11. MAIN ROTOR ASSEMBLY

A. Main Rotor Blades:

- 1) Inspect the main rotor blades for corrosion, nicks, dents, scratches, and bonding separations and security of installation. _____
- 2) Inspect the trim tabs, drag link attachment fittings, and tip rib for condition and loose rivets. _____
- 3) Inspect the blade tape, if installed, for condition and security of installation. _____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

B. Main Rotor Retention Assemblies:

- 1) Inspect the flapping stops and pitch horn for condition and security of installation. _____
- 2) Inspect the blade grips and drag links for condition and security of installation. _____
- 3) Inspect the blade pins for corrosion and condition. _____
- 4) Inspect Lamiflex bearings for condition. _____

C. Universal Block Assemblies:

- 1) Inspect the lead/lag stops and lower nuts for condition and security of installation. _____

D. Main Rotor Dampers:

- 1) Inspect the main rotor dampers for leaks, condition, and security of installation. _____
- 2) Inspect the damper rod end bearings for excessive radial wear (.007"/.18 mm max.), inspect for corrosion in the threads (SDB 0127) and thread corrosion protection condition. _____

E. Main Rotor Hub Center Section:

- 1) Inspect the hub center section for cracks, nicks, scratches, corrosion, and condition and security of hardware. _____
- 2) Inspect the upper and lower spline adapters for fretting. _____
- 3) Inspect the torque stripe indicators on the mast nut. If the indicators show loss of torque on the mast nut or are not installed, check the torque on the mast nut (400 ft-lb/542.3 Nm). _____

F. Pitch Change Bellcranks:

- 1) Inspect the pitch change bellcranks for condition, excessive wear and bearing operation at pivot points, and security of installation (refer to para. 12-11, D). _____

G. Pitch Change Links:

- 1) Inspect the pitch change links for excessive rod end bearing wear, condition and security of installation. _____

H. Upper Control Push-Pull Rods:

- 1) Inspect the push-pull rods for excessive wear in the upper fitting, looseness of fitting, and evidence of damage. _____

100 HOUR/ANNUAL INSPECTION GUIDE

12. SWASHPLATE CONTROL SYSTEM

A. Swashplate Assembly:

- 1) Inspect the lower swashplate assembly for condition and security of installation. _____
- 2) Inspect the lower swashplate assembly universal joint for looseness (Refer to para. 12-10, C). _____
- 3) Inspect the upper control rod end (dogleg) bearings for excessive wear and security of installation (Refer to para. 12-11, D). _____
- 4) Inspect the longitudinal and lateral control rod ends for excessive wear, corrosion, and security of installation (Refer to para. 12-12, B and SDB 0096, latest revision). _____
- 5) Inspect the cyclic bearing for excessive wear. _____

B. Collective Guide Tube Assembly:

- 1) Inspect the collective guide tube assembly for condition and security of installation. _____
- 2) Inspect the guide tube DU washers for radial wear. _____
- 3) Inspect the collective bearing for excessive wear. _____
- 4) Inspect the collective walking beam for cracks, nicks, scratches, condition, excessive wear at the pivot strap bushings, and security of installation. _____

13. CABIN SECTION

A. Cabin Exterior:

- 1) Inspect the cabin doors for proper operation, condition, and security of installation. _____
- 2) Inspect the windshield(s), cabin windows, and door windows for cracks, crazing, and other damage. _____
- 3) Inspect the pitot tube for obstructions, damage, and security of installation. _____
- 4) Inspect the position light assemblies for condition and security of installation (If applicable). _____

B. Cabin Interior:

- 1) Inspect the cabin interior for corrosion, damage, and presence/legibility of required and other placards. _____
- 2) Inspect the carpeting/upholstery and trim for condition and security of installation. _____
- 3) Inspect the seat cushions and seat deck for damage and security of installation. _____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE	
4) Inspect the safety belts and shoulder harnesses for condition, proper operation, and security of attachment.	_____
5) Inspect the fire extinguisher for date of the last inspection and security of installation.	_____
C. Instrument Console/Panel:	
1) Inspect the instrument console/panel and shrouds/covers for condition, security of installation, presence/legibility of required placards and other placards.	_____
2) Inspect the instruments and other equipment for condition and security of installation.	_____
D. Seat Structure	
1) Inspect the seat structure and bulkheads for corrosion, loose rivets, and other damage.	_____
E. Cabin Heating System:	
1) Inspect the heating system ducts and outlets for obstructions, condition, and security of installation.	_____
2) Inspect the heater controls for proper operation, condition, and security of installation.	_____
14. FLIGHT CONTROLS	
A. Cyclic Flight Controls:	
1) Inspect the cyclic flight controls for freedom of operation and proper range of travel (refer to para. 12-7, B).	_____
2) Inspect the cyclic sticks, control rods, and bellcranks for condition, excessively worn rod end bearings/bushings, and security of installation.	_____
3) Inspect the upper cabin bellcrank mounts for cracks, condition, and security of installation (SDB 0126).	_____
4) Inspect the trim motor assemblies and bias springs for condition and security of installation.	_____
B. Collective Flight Controls:	
1) Inspect the collective flight controls for freedom of operation and proper range of travel (collective contacts up stop and down stop).	_____
2) Inspect the collective friction for proper operation, condition, and security of installation.	_____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

- 3) Inspect the collective sticks, torque tube assembly, control rods and bellcranks for excessively worn rod end bearings/bushings, and security of installation. _____
- 4) Inspect the collective spring capsule assembly for proper operation, condition and security of installation. _____
- 5) Inspect the correlator system for proper operation, condition, and security of installation. _____

C. Tail Rotor Controls:

- 1) Inspect the tail rotor control cables and turnbuckles for wear, corrosion, proper operation, proper cable tension, correct range of travel, and security of installation (refer to para. 10-8, A). _____
- 2) Inspect the pulleys and fairleads for wear, proper operation, and security of installation. _____
- 3) Inspect the pedal assemblies, control rods, and bellcranks for excessively worn rod end bearings/bushings, condition, and security of installation. _____
- 4) Inspect the tail rotor pitch change horn/pitch change link assembly for condition and security of installation (SDB 0125). _____

15. BATTERY AREA

A. Battery

- 1) Inspect the battery as required in accordance with the manufacturer's instructions. _____

B. Battery Tray (Forward or Aft Installation):

- 1) Inspect the battery tray, hold down hardware, and surrounding area for evidence of electrolyte leakage and other damage. _____
- 2) Inspect the battery cables and other electrical components/wiring in the area for corrosion, condition, and security of installation. _____
- 3) Inspect the battery vent lines for obstructions, condition, and security of installation. _____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

100 HOUR/ANNUAL INSPECTION GUIDE

16. ELECTRICAL SYSTEMS

- A. Inspect the wiring harness and terminal strips for condition and security of installation. _____
- B. Inspect the external power system for proper operation, condition and security of installation. _____
- C. Inspect the cockpit/instrument lighting for proper operation, condition, and security of installation. _____
- D. Inspect the landing, anti-collision, and position light systems for proper operation, condition, and security of installation. _____
- E. Inspect the caution and warning systems for proper operation, condition, and security of installation. _____
- F. Inspect the cyclic trim system for proper operation, condition, and security of installation. _____
- G. Inspect the fuel boost pump for proper operation. _____
- H. Cycle all switches and circuit breakers and inspect for proper operation, condition, and security of installation. _____
- I. Inspect all other electrical equipment not specifically covered by this checklist for proper operation, condition, and security of installation. _____

16.1 OPTIONAL EQUIPMENT WITH MAINTENANCE MANUAL SUPPLEMENTS

- A. Avionic Systems:
 - 1) Inspect the applicable Avionic System(s) I/A/W Maintenance Manual Supplement 1, Paragraph 3-3 _____

100 HOUR/ANNUAL INSPECTION GUIDE

17. POST INSPECTION

A. Lubrication and Servicing:

- 1) Ensure all required items have been lubricated and serviced per the maintenance manual lubrication and servicing charts.

B. Correct all discrepancies and install all cowling, access panels, doors, and other items removed for this inspection.

C. Operation Check:

1) Engine Run-Up:

Check engine/post flight requirements in the Textron-Lycoming O, HO, AIO, HIO, TIO-360 Series Operator's Manual. Run the aircraft I/A/W the Enstrom F-28F, 280F, or 280FX Rotorcraft Flight Manual. Check the engine instruments, fuel quantity and flow systems for proper operation.

2) Flight Control Check:

Whenever disassembly of the flight controls, especially the removal of the main rotor hub, has been accomplished, it is recommended that a test flight be performed. See the Enstrom F-28F/280F Series Maintenance Manual for full details.

WARNING

Test flight to be performed by authorized personnel only.

- 3) Avionics and Flight Instruments: Check operation.

D. Post Operation Check:

- 1) Inspect the engine compartment for oil and fuel leaks.

E. Enter the inspection compliance in the airframe and engine logbooks as applicable.

F. Perform a maintenance test flight.

WARNING

Test flight to be performed by authorized personnel only.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-52. 200 Hour Inspection Guide – Periodic Inspection

AIRCRAFT REGISTRATION NUMBER:		SIGNATURE:	
AIRCRAFT SERIAL NUMBER:		DATE:	
HOURS:	Engine:	Flight:	
200 HOUR INSPECTION GUIDE			
INITIAL EACH ITEM AFTER ACCOMPLISHMENT			INITIAL
1. GENERAL INSPECTION			
A. Perform a complete 100 Hour/Annual Inspection.			_____
2. MAIN ROTOR ASSEMBLY			
A. Inspect the main rotor retention assemblies for:			
1) Evidence of ratcheting or binding in the feathering bearings.			_____
2) Proper spring-back of the Lamiflex bearings.			_____
3) Evidence of Lamiflex bearing deterioration.			_____
4) Condition of the Lamiflex Nylatron straps.			_____
5) Condition of the Lamiflex bearing shim installation (Reference paragraph 9-4, A, (16); and SDB 057).			_____
6) Evidence of O-ring leakage.			_____
7) Security of the spindle retention nut.			_____
8) Evidence of a sheared roll pin at the hinge pin.			_____
9) Evidence of ratcheting or binding of the flapping bearings.			_____
10) Proper preload setting of the retention assemblies in the flapping axis (Does not apply to retention assemblies installed I/A/W SIL 0147).			_____
11) Proper security of the hinge pin locking tang washer.			_____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-53. 400 Hour Inspection Guide – Periodic Inspection

AIRCRAFT REGISTRATION NUMBER:		SIGNATURE:	
AIRCRAFT SERIAL NUMBER:		DATE:	
HOURS:	Engine:	Flight:	
400 HOUR INSPECTION GUIDE			
INITIAL EACH ITEM AFTER ACCOMPLISHMENT			INITIAL
1. GENERAL INSPECTION			
A. Perform a complete 100 Hour/Annual Inspection.			_____
2. ENGINE			
A. Inspect the engine in accordance with the Textron-Lycoming <u>O, HO, AIO, HIO, TIO-360 Series Operator=s Manual (60297-12).</u>			_____

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4-54. Special Scheduled Inspection Guide – Periodic Inspection

AIRCRAFT REGISTRATION NUMBER:		SIGNATURE:	
AIRCRAFT SERIAL NUMBER:		DATE:	
HOURS:	Engine:	Flight:	
SPECIAL SCHEDULED INSPECTION GUIDE			
INITIAL EACH ITEM AFTER ACCOMPLISHMENT			INITIAL
1. MAIN ROTOR TRANSMISSION A. Retorque the aft pinion nut 20-25 hours after installation.			_____
2. PYLON ASSEMBLY A. Inspect the pylon I/A/W SIL 0173 every 10 hours time in service for aircraft used for agricultural or external load operations during that time period.			_____
3. HORIZONTAL STABILIZER A. For aircraft F-28F S/N 744 and subsequent and all 280FX, remove and disassemble the horizontal stabilizers and spar at the first 1200 hours of service and every 1200 hours of service thereafter for the inspection of the following: <u>NOTE:</u> Refer to Section 8, Paragraph 8-16 for complete disassembly, assembly, and inspection criteria.			
1) Visually inspect all components for damage, cracks, loose rivets, and security of installation.			_____
2) Fluorescent inspect (Zyglo) or visually inspect with a 10 power glass the spar fitting, attachment rivets, bulkhead and vertical endplate attachments.			_____
3) Magnetic particle inspect the horizontal stabilizer steel spar.			_____

4-55. Special Instructions

4-56. General Information – Special Instructions

NOTE

Refer to the applicable Textron-Lycoming Technical Publications for special inspections applicable to the engine.

A. This section contains guidelines for performing the required inspections, by qualified maintenance personnel, after experiencing any of the following occurrences: main rotor blade and/or tail rotor strikes, hard landing, main rotor overspeed, chip indications on the main rotor or tail rotor transmission, engine overboost, and engine overspeed. It should be emphasized that other parts and/or adjacent components not listed may also be damaged, depending on the severity of the incident. Therefore, this guide should not be considered absolute and should be expanded as required by the inspecting maintenance personnel, as the occurrence may require, per the appropriate sections of this manual.

B. All aluminum and steel components must be inspected by the following processes after visual inspection has revealed a possible defect or as noted in the special inspections:

- (1) Aluminum machined or cast components are to be inspected by liquid penetrant inspection.
- (2) Aluminum sheet metal components are to be inspected by liquid penetrant inspection.
- (3) Steel components are to be inspected by magnetic particle inspection.

C. All parts and components that may be affected by the specific occurrence are to be given a complete inspection for possible damage.

4-57. Main Rotor Blade Strike/Sudden Stoppage (Minor) – Special Instruction

NOTE

The following inspections are mandatory.

A. Blade damage does not exceed damage as defined in paragraph 9-9, and shows no visible kinks, ripples in the skin or the trailing edge. Perform the following:

- (1) Repair the blade I/A/W paragraph 9-10.
- (2) Refer to the latest revision of Textron-Lycoming Service Bulletin 533 for the recommended engine inspection.

B. Blade damage exceeds limits of paragraph 9-9, but has not contacted the airframe or other rigid object and shows no visible kinks, ripples in the skin or trailing edge. Perform the following:

- (1) Replace the blade(s).
- (2) Refer to the latest revision of Textron-Lycoming Service Bulletin 533 for the recommended engine inspection.
- (3) Check the main rotor shaft run out. Maximum allowed is .012 inches/.305 mm FIM.
- (4) Inspect the tail rotor driveshaft taper pins (para. 10-6, H) and flex packs (para. 10-6, C).

NOTE

If the main rotor shaft run out, taper pins, or flex packs do not meet inspection requirements, proceed to paragraph 4-59.

4-58. Main Rotor Blade Strike/Sudden Stoppage (Major) – Special Instruction

A. Obvious blade damage exceeding the limits of paragraph 9-9. Perform the following:

- (1) Replace the damaged blade(s) and inspect the remaining blade(s).
- (2) Remove the main rotor transmission including the upper pulley and tail rotor drive shaft hub and return to Enstrom Helicopter Corporation for inspection and overhaul/replacement.
- (3) Remove the main rotor hub and inspect by liquid penetrant inspection and in accordance with the inspection tables in para. 9-1, D, or return to Enstrom Helicopter Corporation for inspection and overhaul/replacement.
- (4) Inspect all flight control push-pull rods and torque tubes for sheared/damaged rivets at the fittings, damaged rod ends, or sheared/damaged roll pins.
- (5) Inspect all flight control bellcranks for buckling and elongated bolt holes.
- (6) Inspect the lower swashplate for warped or cracked casting and for bent or damaged guidetubes in the upper swashplate. Inspect the tie rod and universal rod for straightness. Inspect the bolt holes for elongation.
- (7) Replace all tail rotor driveshaft taper pins.
- (8) Inspect the tail rotor driveshafts for complete or partial failure at the taper pin holes.
- (9) Magnetic particle inspect the tail rotor driveshafts.
- (10) Inspect the pylon structure at the gearbox mounting areas for broken or bent tubes. Check the trueness of the four gearbox attachment points.

- (11) Inspect all components of the drive system.
- (12) Refer to the latest revision of Textron-Lycoming Service Bulletin 533 for the recommended engine inspection.

4-59. Tail Rotor Blade Strike/Sudden Stoppage – Special Instruction

- A. Strike tab missing but no physical damage to the tail rotor blade(s).
 - (1) Inspect the taper pins, flex packs, and drive shaft hubs at the tail rotor transmission coupling location (para. 10-6, C). If no damage is found, make a log book entry and notify Enstrom Helicopter Corporation to order replacement strike tabs. If damage is found, proceed to the following paragraph for inspection procedures.
- B. Obvious physical damage to the tail rotor blade. Perform the following:
 - (1) Remove the tail rotor transmission with the tail rotor pitch controls, the input drive hub, and the tail rotor assembly.
 - (a) Remove the tail rotor pitch controls and inspect in accordance with the inspection tables in para. 10-4, C.
 - (b) Return the tail rotor transmission to Enstrom Helicopter Corporation for inspection and overhaul/replacement.
 - (c) Inspect the tail rotor assembly in accordance with the inspection tables in para. 10-1, F.
 - (2) Replace all tail rotor driveshaft taper pins.
 - (3) Inspect the tail rotor driveshafts for complete or partial failure at the taper pin holes.
 - (4) Inspect the taper pin hole in the main rotor transmission pinion for complete or partial failure. If damage is found, return the main rotor transmission to Enstrom Helicopter Corporation for overhaul/replacement.
 - (5) Magnetic particle inspect the tail rotor driveshafts.
 - (6) Inspect the hangar bearing housings and attachments.
 - (7) Inspect the tail rotor control cables and pulley attachments.
 - (8) Inspect the tail rotor pedal push-pull rods and bellcranks.

4-60. Hard Landing – Special Instruction

- A. In the event of a hard landing which may or may not be associated with a main or tail rotor strike, perform the following:
 - (1) Inspect the forward and aft crosstube for bends or bowing. Replace the crosstube if bent or bow is greater than 0.5 inches/13 mm. It will be necessary to hoist the aircraft or remove the crosstubes to obtain a measurement.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Inspect the forward and aft crosstube attachment clamps for damage and cracks. Inspect all fittings and bolt holes for elongation. See SDB 0124 for additional inspection criteria.
- (3) Inspect the landing gear leg assemblies for distortion or deformation. Inspect all fittings and bolt holes for elongation. Inspect all welds and gussets for cracks.
- (4) Inspect the skid tubes for damage and straightness. Inspect all hardware attachment holes for elongation or tears.
- (5) Inspect the oleos for damage, freedom of movement, and leakage.
- (6) Inspect the tailcone to pylon, main rotor transmission to pylon, engine to pylon, crosstube to pylon, and cabin to pylon attachment points for deformation or hardware failures.
- (7) Inspect the keel structure edges, beams, lightening holes, and intercostals for buckling or deformation. Closely inspect the keel structures for interference or contact with flight control mechanisms.
- (8) Check the main rotor shaft run out. Maximum allowed is 0.012 inch/0.305 mm FIM.
- (9) Check the main rotor transmission mount bolt torque. If torque is lost, replace the hardware or remove and magnetic particle inspect the hardware.
- (10) Inspect the main rotor transmission mount lugs with liquid penetrant method.
- (11) Refer to the latest revision of Textron-Lycoming Service Bulletin 533B for the recommended engine inspection.

4-61. Main Rotor Overspeed – Special Instruction

- A. Overspeeds from 385-405 rpm for 5 seconds or less. No inspection required.

NOTE

If any damage is found, remove the main rotor hub and return to Enstrom Helicopter Corporation for inspection and overhaul/replacement.

- B. Overspeeds from 385-405 rpm for more than 5 seconds or overspeeds from 406-420 rpm. Perform the following:
 - (1) Remove the main rotor blades and inspect flapping axis for proper drag, notchiness, and freedom of movement.
 - (2) Inspect the main rotor blade retention for any deformation.
 - (3) Inspect the lamiflex bearings for deformation, proper thickness, delamination or extruded brass. Inspect the nylatron strap for any damage or unusual wear.
 - (4) Inspect the main rotor spindles for pulled or distorted threads.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-4-63

Rev. 8
Sep 20/17

C. Overspeeds exceeding 420 rpm. Perform the following:

- (1) Remove the main rotor hub and inspect by liquid penetrant inspection and in accordance with the inspection tables in para. 9-1, D, or return to Enstrom Helicopter Corporation for inspection and overhaul/replacement.

4-62. Main Rotor or Tail Rotor Transmission Chip Indication – Special Instruction

NOTE

New or recently overhauled transmissions will often make a magnetic "fuzz" which will collect on the magnetic plug as gray sludge. This is normal and may be cleaned off the plug. The plug may then be reinstalled and the helicopter returned to service. If any main rotor transmission chips are found which are larger than .065 inch/1.65 mm in cross-section or if any tail rotor transmission chips are found which are larger than .035 inch/.9 mm in cross-section, contact Enstrom Customer Service Department and discontinue use until further instructions are received from Enstrom Customer Service Department.

A. Main rotor transmission chip indication. Perform the following:

- (1) Inspect the chip detector for accumulation of metal particles as follows:
 - a. Main rotor transmission metal particles, flakes, or slivers exceeding .065 inch/1.65 mm: Contact Enstrom Customer Service Department and discontinue use until further instructions are received from Enstrom Customer Service Department.

NOTE

Sludge normally will not cause a chip indication by itself. There is normally a small particle, flake, or sliver on the detector also.

- b. Sludge (a mixture of oil and fine metal particles resulting from normal gear operation): Clean the detector and return the transmission to service.
 - (2) If the indication was caused by sludge or a particle, flake, or sliver not exceeding the maximum size, return the transmission to service and annotate the chip indication and results in the aircraft maintenance records.
- B. Tail rotor transmission chip indication. Perform the following:
- (1) Remove the tail rotor assembly and remove the flex pack.
 - (2) Turn the gearbox by hand.
 - (3) Inspect the chip detector for accumulation of metal particles as follows:

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- a. Tail rotor transmission metal particles, flakes, or slivers exceeding .035 inch/.9mm: Contact Enstrom Customer Service Department and discontinue use until further instructions are received from Enstrom Customer Service Department.

NOTE

Sludge normally will not cause a chip indication by itself. There is normally a small particle, flake, or sliver on the detector also.

- b. Sludge (a mixture of oil and fine metal particles resulting from normal gear operation): Clean the detector and return the transmission to service.
- C. Three main rotor or two tail rotor transmission chip indications occur within 10 flying hours. Perform the following:

NOTE

Check the aircraft inspection records for any annotations about the condition of the main rotor transmission ring and pinion gears or the tail rotor transmission input and output gears.

- (1) Drain the oil from the transmission and inspect the ring and pinion gears (main rotor transmission) or the input and output gears (tail rotor transmission) for cracks, excessive pitting, excessive spalling, or "hard wear" lines.
- (2) Remove the tail rotor assembly from the tail rotor transmission output shaft and the aft tail rotor drive shaft flex plate assembly. Turn the tail rotor transmission output shaft by hand. If indications of a rough bearing are felt, the transmission must be replaced.

NOTE

If the gearbox is to be returned to Enstrom Service, do not clean the metal from the chip detector.

- (3) If none of the above conditions are found, flush and service the transmission (main rotor, para. 4-13.1; tail rotor, para. 4-16.1), and return to service. If two chip indications occur within the next 10 flying hours, repeat the flush and servicing procedure. If two additional indications occur within the next 10 flying hours, contact Enstrom Helicopter Corporation for further instructions.

4-63. Engine Overboost – Special Instruction

- A. Inspect the engine in accordance with the latest revision of Textron-Lycoming Service Bulletin 592.

4-64. Engine Overspeed – Special Instruction

A. Inspect the engine in accordance with the latest revision of Textron-Lycoming Service Bulletin 369.

NOTE

Perform the appropriate main rotor overspeed inspection if required.

4-65. Maintenance Ground Run

A. General

- (1) Perform a maintenance ground run after conducting a periodic inspection or maintenance action that will require operation of the aircraft to verify satisfactory performance of the aircraft.
- (2) The periodic inspection or maintenance action will determine the extent of the post maintenance ground run.

B. Flight controls

- (1) Position lateral and fore/aft trim motors to the neutral position.
- (2) Move the cyclic stick around the cyclic stop in the floor. The stick must remain against the stop through the circle. If binding or interference is detected, re-check the basic rigging.
- (3) Move the fore/aft trim to full forward position and move the cyclic stick full aft. Stick should contact the cyclic stop. Reverse the trim motor and stick positions and check that stick contacts the cyclic stop.
- (4) Repeat step (3) using the lateral trim motor and moving the stick in the lateral direction.

C. Inspect engine operation for (1500 rpm idle):

- (1) Oil pressure
- (2) Alternator
- (3) Engine compartment for oil or fuel leakage
- (4) Magnetos for:
 - (a) Left
 - (b) Right
 - (c) Off
- (5) Mixture control for idle cut-off operation.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- D. Inspect rotor engagement for (1500 rpm idle):
 - (1) Smoothness of operation and positive over-center position (light)
 - (2) Proper clutch handle stowage
 - (3) Track of belt on idler roller
- E. Inspect the following instruments for “green” operation:
 - (1) Oil pressure
 - (2) Oil temperature
 - (3) Cylinder head temperature
 - (4) Main gearbox temperature
 - (5) Tach needles married
- F. Inspect ground run for (3050 rpm):
 - (1) Manifold pressure (17.5” to 19”)
 - (2) Operation of one way clutch
 - (3) Rotor blades for out of track
 - (4) Magneto check (left – right)
 - (5) Proper operation of all instruments
 - (6) Proper operation of “press-to-test” lights
 - (7) Proper operation of all avionics
- G. Post Ground Run:
 - (1) Shut the aircraft down I/A/W the Rotorcraft Flight Manual.
 - (2) Record any discrepancies found during the ground run and notify maintenance personnel for corrective action.

4-66. Ground Handling

4-67. Ground Handling Wheels

A. Each skid tube is equipped with a manually operated ground handling wheel assembly. The ground handling wheels shall be in the raised position for flight or ground operations with the engine running and the rotor systems turning. The wheels should also be in the raised position when the aircraft is parked.

CAUTION

Pushing on the nose of the helicopter may cause the cabin nose to deform thereby weakening the cabin structure and causing extensive repair. Use caution when pushing on the nose to move the aircraft backwards.

B. Use the following procedure to lower the ground handling wheels:

- (1) Support the aircraft at the tail rotor guard.

WARNING

Ensure the wheel bar handle is completely installed onto the ground handling wheel lug. DO NOT let go of the wheel bar handle while lowering or raising the ground handling wheels.

- (2) Insert the wheel bar handle onto the lug on the ground handling wheel with the handle towards the aft end of the aircraft.
- (3) Remove lock pin from the ground handling wheel.
- (4) With a steady motion, rotate wheel bar handle 180° towards the front of the aircraft and install lock pin when holes line up.
- (5) Remove the wheel bar handle from the ground handling wheel lug.

C. Use the following procedure to raise the ground handling wheels:

- (1) Support the aircraft at the tail rotor guard.

WARNING

Ensure the wheel bar handle is completely installed onto the ground handling wheel lug. DO NOT let go of the wheel bar handle while lowering or raising the ground handling wheels.

- (2) Insert the wheel bar handle onto the lug on the ground handling wheel with the handle towards the front end of the aircraft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (3) Remove lock pin from the ground handling wheel.
- (4) With a steady motion, rotate wheel bar handle 180° towards the aft end of the aircraft and install lock pin when holes line up.
- (5) Remove the wheel bar handle from the ground handling wheel lug.

4-68. External Power

CAUTION

Ensure the external power source voltage rating (14 volts or 28 volts) matches the helicopter electrical system before applying external power.

- A. Turn the helicopter MASTER and ALTERNATOR switches OFF.
- B. Turn the external power source OFF.
- C. Plug the external power source cable securely into the external power receptacle.
- D. Turn the external power source ON.
- E. Turn the helicopter MASTER switch ON.

4-69. Parking

- A. Raise the ground handling wheels allowing the helicopter to rest on its skids.
- B. Install the main rotor tie down.
- C. Install static ground.
- D. Install the main rotor hub cover.
- E. Install the tail rotor gearbox and hub cover.

4-70. Leveling

WARNING

Do not climb on or enter the aircraft while it is being leveled.

NOTE

The tail of the aircraft may have to be supported to maintain the aircraft in a level attitude.

- A. Level the aircraft longitudinally by placing a level on the leveling location on the longitudinal pylon tube located on the left side of the pylon assembly. Adjust the attitude of the aircraft by using the ground handling wheels and/or shoring materials and by raising or lowering the tail of the aircraft. Level the aircraft laterally by placing the level on the cockpit floor and adjust the shoring materials under the skid tubes as required.

4-71. Hoisting (Figure 4-3)

A. If the main rotor hub is installed, install the lifting sling (T-0011) so that the arms are between the pitch arm and the blade retention assembly, over the lead/lag retaining nut, and outboard of the main rotor damper rod-end. The sling arms are long enough to be double rapped if preferred.

B. If the main rotor hub is removed, install the lifting eye (T-0017) onto the main rotor mast.

warning

The lifting device must have a lifting rating equal to or greater than the actual weight of the aircraft to be hoisted.

C. Connect a suitable lifting device to the lifting sling or eye.

D. Station a person at the tail rotor guard to steady the aircraft when hoisted. If lifting beyond reach from the ground, two people and two steadying ropes will be necessary.

E. Slowly hoist the aircraft using a steady lifting force.

4-72. Cleaning

4-73. Exterior – Cleaning

NOTE

The exterior of the aircraft is painted with a high quality paint. Proper maintenance of this finish will provide corrosion protection as well as an attractive finish.

NOTE


Do not wash the aircraft using pressure washing equipment.

A. Wash the exterior as follows:


- (1) Check the security of all doors and access panels before starting the washing operation.
- (2) Flush the entire aircraft free of dirt.

NOTE

Avoid direct spraying of the main rotor hub, tail rotor assembly, and tail rotor driveshaft bearings to prevent the loss of lubricant. These areas should be purged with grease after washing to eliminate any moisture.



Lifting Sling Installation



Lifting Sling Arm Routing

Figure 4-3. Lifting Sling Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (3) Using a soap and water solution and a soft cloth pad, wash a specific area using a circular motion.
- (4) Flush the washed area immediately.
- (5) Repeat steps c and d until the entire aircraft is clean.
- (6) Rinse with clear water and dry with a chamois.

B. Wax the exterior as follows:

- (1) Clean the aircraft exterior as described in the washing procedure.
- (2) Using a soft cloth, apply a good quality paste wax to the painted exterior using a circular motion.
- (3) Polish the waxed area to a high luster using a clean and dry soft cloth.

4-74. Interior – Cleaning

NOTE

Do not use a solvent type cleaner to clean the inside of the cabin shell.

A. Clean the interior as follows:

- (1) Clean the dirt and dust from the cabin using a small broom or brush.
- (2) Vacuum the interior to remove any remaining dirt.
- (3) Use a good quality upholstery cleaner to remove dirt and grease from the seat cushions and the floor covering.

4-75. Plexiglas – Cleaning

A. Wash the Plexiglas using your bare hand or a clean soft cloth and a mild soap and water solution. Rinse with clean water.

B. Dry the surface with a soft, clean cloth or tissue and polish it with a windshield cleaner especially approved for use on aircraft transparent plastics.

CAUTION

Do not use coarse abrasive type soaps as they can cause fine scratches in the plexiglass.

C. Removal of fine scratches from the Plexiglas is accomplished by polishing and waxing the glass using Meguiar's Mirror Glaze - Plastic Cleaner MGH-17.

4-76. Aircraft Preservation and Storage

4-77. General – Aircraft Preservation and Storage

A. Aircraft that see low usage or are stored for extended periods exhibit an accelerated rate of corrosion damage. Special attention should be given to aircraft inactive in a corrosive atmosphere (coastal, high humidity, air pollution, or sandy areas) to assure components remain in a serviceable condition.

B. The following maintenance procedures are categorized in terms of aircraft with low usage and those scheduled to be inactive for an extended period. This information is intended to cover both hangared and outdoor conditions unless otherwise noted, and is subject to owner/operator judgment regarding the helicopter's operating environment, and should be considered in addition to the normal servicing requirements.

NOTE

Wash and wax the helicopter prior to any type of storage.

4-78. Low Usage – Aircraft Preservation and Storage

NOTE

Aircraft flown for short periods several times a month.

NOTE

Preserve the engine I/A/W the applicable Textron-Lycoming Technical Publication if warranted by local corrosive conditions.

A. Ground run the aircraft every 14 days until normal operating temperatures for the engine are obtained.

B. Position the main rotor blades so that the tail rotor assembly is horizontal to the earth. Tie down the main rotor blades with the collective locked halfway up to relieve the steady load on the lamiflex bearings.

C. Install the main rotor hub and tail rotor assembly covers.

D. Protect the windshields and interior equipment with suitable dust covers and/or solar shields.

NOTE

If the interior temperature of the cabin exceeds 150°F, ventilate the cabin by opening the doors or vents.

E. Cover the pitot and static air vents.

- F. Wash and wax the aircraft monthly to remove contaminants.
- G. Prior the next flight, complete the following:
 - (1) Remove all covers and tiedowns.
 - (2) Perform a preflight inspection.

NOTE

When inspecting oil levels, inspect for evidence of water contamination.

- (3) If preserved, depreserve the engine I/A/W the applicable Textron-Lycoming Technical Publication.

4-79. Storage Up to 45 Days – Aircraft Preservation and Storage

- A. Complete steps A through F of paragraph 4-78.
- B. Disconnect the battery.
- C. Remove the main rotor blades.

NOTE

Store the main rotor blades in a horizontal position on wood racks cut out to the contour of the leading edge of the blades. Use care in handling the blades to prevent damage to the blades and trim tabs.

- D. Return the aircraft to service using the following procedures:
 - (1) Remove all covers and tiedowns.
 - (2) Connect the battery.
 - (3) Install the main rotor blades.
 - (4) Perform a preflight inspection.

NOTE

When inspecting oil levels, inspect for evidence of water contamination.

- (5) Lubricate the aircraft I/A/W the 50 Hour requirements.
- (6) Depreserve the engine I/A/W the applicable Textron-Lycoming Technical Publication.

4-80. Storage from 45 Days to 6 Months – Aircraft Preservation and Storage

- A. Complete steps A through C of paragraph 4-79.
- B. Remove the battery and store in a cool dry area. Clean the battery shelf if required (AC43.13-1B).

NOTE

The aircraft may require an annual inspection.

- C. Return the aircraft to service following the procedures in step D of paragraph 4-79.

4-81. Storage for Longer Than 6 Months – Aircraft Preservation and Storage

- A. Complete steps A and B of paragraph 4-80.
- B. Hangar the aircraft.
- C. Return the aircraft to service using the following procedures:
 - (1) Remove all covers, tiedowns, and shields.
 - (2) Service the battery I/A/W the manufacturer's instructions. Install and connect the battery.
 - (3) Install the main rotor blades.
 - (4) Perform a 100 hour periodic inspection and lubricate I/A/W the 100 hour requirements.

NOTE

The aircraft may require an annual inspection.

- (5) Depreserve the engine I/A/W the applicable Textron-Lycoming Technical Publication.

4-82. Preventive Maintenance for Corrosion Control

4-83. General Information – Preventive Maintenance for Corrosion Control

The airframe is fabricated of high strength aluminum and steel alloys and should be inspected regularly for signs of corrosion. Any areas where the protective finishes may have been scuffed, scratched, chipped, or worn off should be treated temporarily to control the onset of corrosive action. Then at the earliest convenience a permanent refinish of the area should be accomplished. Another very important step in any corrosion prevention program is regularly scheduled washing and waxing of the aircraft surfaces.

It is extremely important that the main rotor and tail rotor blade coatings be maintained and protected against oxidation, erosion, and atmospheric residues which are continually attacking these components during their service life. Once this coating is breached and corrosive action is allowed to propagate unchecked, premature bond line corrosion will occur resulting in early retirement of these components. Refer to the appropriate paragraphs in Section 9 of this manual for the inspection and repair procedures for the main and tail rotor blades. In coastal areas or wherever the air has a high moisture content, blade tape can be installed on the leading edge of the main rotor blades to help prevent the leading edge and bond line corrosion from occurring. In coastal areas, it is recommended that the blade tape be installed when the aircraft is placed into service. Refer to the appropriate paragraphs in Section 9 of this manual for the installation and repair procedures for blade tape.

NOTE

Refer to SIL 0170 for the application of corrosion prevention compound for the main rotor blades.

4-84. Scheduled Field Preventive Maintenance Program

NOTE

This procedure is intended for the complete helicopter; however, give special attention given the main and tail rotor blades.

NOTE

Aircraft based in or near heavy industrial and/or metropolitan areas with heavy atmospheric pollution should use procedure "A" below.

NOTE

Do not wash the aircraft using pressure washing equipment.

A. Aircraft that are operated over salt water or coastal regions. Use the following procedures:

- (1) Thoroughly flush the aircraft with fresh water daily.

- (2) Wash the aircraft with mild soap and fresh water weekly.

NOTE

Use a good quality paste wax.

- (3) Wax the aircraft every second week.

B. Aircraft that are operated in tropical or semi-tropical high humidity regions. Use the following procedures:

- (1) Wash the aircraft with mild soap and fresh water weekly.
- (2) Wax the aircraft every second week.

C. Aircraft that are operated in arid, moderate, or cold regions. Use the following procedures:

NOTE

This procedure may be suspended during cold or winter months if step 3 was accomplished prior to the cold season.

- (1) Flush with fresh water weekly.
- (2) Wash the aircraft with mild soap and fresh water monthly.
- (3) Wax the aircraft every second month.

4-85. Component Preservation and Storage

4-86. Main Rotor Transmission

NOTE

This procedure applies to an uninstalled main rotor transmission.

A. Service the main rotor transmission (para. 4-12), or alternatively, completely fill the transmission. Refer to Table 4-1 for system capacity and approved oils (30 weight engine oil is acceptable for storage).

- B. Plug or cap the breather tube.
- C. Ensure the fill cap is secured.
- D. Place the transmission in storage with the mast upright.
- E. Every 90 days, move the transmission to allow oil to flow to all internal surfaces.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) Tip the transmission to horizontal or vertical, as appropriate, approximately 90° from its storage position.
 - (2) Tip the transmission back to storage position.
- F. Turn the pinion approximately three times completely lubricate all moving parts.
- G. Prior to returning the main rotor transmission to service:
- (1) Remove the breather tube plug or cap, if installed.
 - (2) Drain the oil (para. 4-13).
 - (3) Service the main rotor transmission (para. 4-12).

MAINTENANCE MANUAL

SECTION 5

WEIGHT AND BALANCE

5-1 GENERAL INFORMATION

This helicopter must be flown within the weight and center of gravity limits. The helicopter empty weight, empty weight c.g., total basic weight and basic weight c.g. for this helicopter are found on form F-168A, Figure 5-9. Removal or installation of approved optional equipment will change the basic helicopter weight and moment. This change shall be recorded on Form F-165A, Figure 5-8, Basic Weight and Balance Record. The pilot will use the figures on Form F-165A when performing calculations to insure the helicopter is loaded properly.

5-2 APPROVED CENTER OF GRAVITY ENVELOPES

A. Longitudinal c.g.

- (1) Station zero located 100.0 inches forward of centerline of main rotor hub.
- (2) Longitudinal c.g. range varies with gross weight from 92.0 inches to 100.0 inches. See Figure 5-1.




Figure 5-1

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

B. Lateral Offset Moment

- (1) Centerline of helicopter is 0 inch lateral moment arm. Moment arms left of centerline are negative.
- (2) Lateral c.g. Locations
 - a. Two on board
 - (1) Left seat (pilot) -13.5
 - (2) Right seat (co-pilot) +13.5
 - b. Three on board
 - (1) Left seat (pilot) -13.5
 - (2) Center passenger + 3.0
 - (3) Right passenger +20.5
- (3) Lateral offset moments variable with gross weight from -3250 in-lb to +3700 in-lb. See Figure 5-2.




Figure 5-2

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

5-3 WEIGHING THE HELICOPTER

A. Tools and Equipment

- (1) Tape measure
- (2) Two scales - 1000 lb capacity
- (3) Scale - 100 lb capacity
- (4) Bubble level
- (5) Work stand

B. Weighing Procedure

- (1) Clean helicopter - remove rags, charts, etc.
- (2) Drain fuel, check all other operating fluids full.
- (3) Move helicopter inside closed building.
- (4) Check for proper installation of accessory items.
- (5) Close and secure both doors.
- (6) Align one main rotor blade over tail cone.
- (7) Hoist or jack helicopter to a height to clear scales.
- (8) Position a pipe nipple in the center of left and right 1000 lb capacity scales. Place scales under landing skids so nipples will contact skid gear at a point 17.7 inches aft of forward 3 inch diameter cross tube (Station 93.4).

NOTE: See Figure 5-3 for locating fulcrum by using T-1794. This tool may be purchased from Enstrom Helicopter Service Department.


- (9) Locate the 100 lb capacity scale at the center line of the tail rotor output shaft. See Figure 5-4.
- (10) Adjust height of tail to level helicopter. Level checked at left lower pylon tube. Lateral level checked at lower forward pylon tube.
- (11) When helicopter is level, read the scales and enter weights on Weight Chart, Figure 5-7.

CAUTION: Weight and measurement readings are critical. Double check results.

- (12) Remove helicopter from scales.


NOTE: DO NOT remove curbing, nipples, blocks, etc. from scales. Weigh these items and enter weights in tare column on Figure 5-7.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED



WEIGHT AND BALANCE
TOOL POSITIONING

Fig. 5-3



WEIGHING STATIONS

Fig. 5-4

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (13) Subtract tare from scale readings and enter net weights.
- (14) Enter arms and multiply by weights to get moments.
- (15) Total weights and moments.
- (16) Using formula on bottom of Figure 5-7, calculate c.g.
- (17) Transfer weight, c.g. or arm and moment to top of form F-168A (Figure 5-8).
- (18) On Form F-168A enter all optional and surplus equipment in the helicopter at weigh-in. Then enter all standard equipment not installed on the helicopter at weigh-in.
- (19) Total weights and moments.
- (20) Find total empty weight and moment of standard helicopter.
- (21) Add to this figure optional equipment to obtain total basic weight and moment.
- (22) Transfer these figures to Form F-165A (Figure 5-8), Basic Weight and Balance Record.

NOTE: Any changes to the helicopter such as structural repairs or modifications, installation of optional equipment or removal of optional equipment, will require an entry on Form F-165A.

5-4 LOADING

A. General Information

It is the responsibility of the helicopter pilot to insure that the helicopter is loaded properly. Using the basic weight and moment from Form F-165A (Figure 5-8) and the loading Chart (Figure 5-5), the pilot can obtain the total weight and moment for various loading conditions. The pilot should first calculate the total weight and moment for zero usable fuel, as this will show the c.g. shift with fuel burn-off. If the c.g. is within limits, add the planned fuel load and compute the c.g. If the c.g. is within limits, the last item to check is the lateral offset moment.

MAINTENANCE MANUAL

B. Sample Calculation - Longitudinal C.G.

SAMPLE LOADING CALCULATIONS	SAMPLE HELICOPTER			HELICOPTER S/N	
	Arm in.	Weight lbs	Moment 100 in-lb	Weight lbs	Moment 1000 in-lbs
1. Basic empty weight from Form F-165A	100.7	1610.0	162.1		
2. Pilot and passengers Cabin seats	62.0	480.0	29.8 ⁽¹⁾		
3. Baggage compartment load	135.0	20.0	2.7 ⁽¹⁾		
4. Total weight and moment with zero usable fuel to check c.g. shift with fuel burn-off (landing condition)	92.2 ⁽²⁾	2110.0	194.6		
5. Usable fuel	96.0	240.0	23.0 ⁽¹⁾		
6. Total weight and moment with usable fuel (takeoff condition)	92.6 ⁽²⁾	2350.0 ⁽³⁾	217.6		

(1) Moments obtained by multiplying weight times arm or from Loading Chart, Figure 5-4.

(2) The longitudinal c.g. relative to the datum line may be found by dividing the moment by the weight.

$$\text{c.g. zero fuel} = \frac{194,600 \text{ in-lbs}}{2110.0 \text{ lbs}} = 92.2 \text{ in.}$$

$$\text{c.g. full fuel} = \frac{217,600 \text{ in-lbs}}{2350 \text{ lbs}} = 92.6 \text{ in.}$$

The total weight and moment can also be plotted on Figure 5-5 to determine if the loading is within longitudinal limits.

(3) Total weight not to exceed 2600 lbs.

MAINTENANCE MANUAL


C. Sample Calculations - Lateral Offset Moment

	<u>Arm in.</u>	<u>Weight lbs</u>	<u>Moment in-lbs</u>
Pilot (left seat)	- 13.5	170	- 2295
Passenger (center seat)	+ 3.0	140	+ 420
Passenger (right seat)	+ 20.5	170	+ 3485
			+ 1610

Plot 2350 lbs and +1610 in-lbs on Figure 5-2 to assure moment is in approved area.

LOADING CHART

Fig. 5-5



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED




Fig. 5-6

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

WEIGHT SHEET

MODEL _____ SERIAL NO. _____ REG. NO. _____

WEIGH POINT	SCALE-LBS.	TARE	NET WT.	ARM	MOMENT X 1000
LEFT GEAR			(W _L)		
RIGHT GEAR			(W _R)		
TAIL			(W _T)		
TOTAL				X	

$$LCG = \frac{W_T(320.0) + (W_L + W_R)(93.446)}{W_T + W_L + W_R} = \underline{\hspace{10em}}$$

DATE _____ WEIGHED BY _____

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Fig. 5-7

MAINTENANCE MANUAL

HELICOPTER WEIGHT AND C.G. CALCULATION		
MODEL _____	SERIAL NO. _____	REG. NO. _____

	WEIGHT LBS.	ARM IN.	MOMENT 1000IN-LB.
WEIGHT (AS WEIGHED)			
PLUS: MISSING STD. EQUIPMENT			
LESS: OPTIONAL & SURPLUS WT.			
LESS: ENGINE OIL			
PLUS: 12 LBS. UNUSABLE FUEL			
WEIGHT EMPTY STD. HELICOPTER	COMPUTED		
	ACTUAL		
PLUS: ENGINE OIL			
PLUS: OPTIONAL EQUIPMENT			
TOTAL BASIC WEIGHT			

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Fig. 5-9

FORM F-168A

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 6

ELECTRICAL

TABLE OF CONTENTS

Paragraph	Description	Page
6-1	Electrical System	MM-6-1
	A. General Information	MM-6-1
	B. General Troubleshooting	MM-6-1
6-2	Battery	MM-6-2
	A. General Information	MM-6-2
	B. Troubleshooting – Battery	MM-6-2
	C. Troubleshooting – Battery Master Power	MM-6-2
	D. Buss Faults Breaker System	MM-6-4
6-3	Alternator	MM-6-4
	A. General Information	MM-6-4
	B. Troubleshooting	MM-6-4
	C. Removal	MM-6-5
	D. Inspection	MM-6-5
	E. Installation	MM-6-5
6-4	Voltage Regulator	MM-6-8
	A. General Information	MM-6-8
	B. Troubleshooting	MM-6-8

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

INTENTIONALLY LEFT BLANK

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-6-0.2

Rev. 11
Oct 25/19

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 6

ELECTRICAL

6-1. ELECTRICAL SYSTEM

A. General Information

The F28F/280F Series electrical system is either a 12 volt or a 28 volt D.C. solid state regulated type. The system consists of one main buss, one generating source and one power storage source. Electric current is distributed via buss bar thru individual trip free circuit breakers. Networks not protected by trip free breakers contain inline fuses. Later F-28F/280FX helicopters are equipped with a 28 volt D.C. electrical system. Electrical power is supplied by a 24-volt, direct current, 70 ampere alternator and an 11 amp-hour lead acid battery.

Electrical safety devices are provided for buss overcurrent and overvoltage protection.

Aircraft equipped with avionics systems are supplied with radio frequency interference filters.

Refer also to Section 21 for discussion regarding F-28F/280FX electrical system equipment updates.

B. General Troubleshooting

- (1) Always refer to the Electrical System Schematic for system interconnections (Section 6 or Section 21 as applicable).
- (2) Simple, fast, wire checks can be performed by making continuity tests with an ohmmeter. The continuity check is a quick procedure for isolating electrical problems to a specific circuit.
- (3) Check for loose hardware or loose connectors at wire terminations.
- (4) Check all ground connections for evidence of looseness or corrosion.
- (5) Check wire insulation, grommets, and tie wraps for wear or deterioration.
- (6) In the event of trouble with A/C lighting (non-LED type), substitute equivalent bulbs (known to operate) from a different location on the A/C to determine whether the problem is lamp or system related. This is especially useful for check strobes and anti-collision lamps.
- (7) The following devices should be serviced as recommended the respective manufacturers.
 - (a) Alternator
 - (b) Starter motor
 - (c) Magneto-vibrator-ignition switch
 - (d) Fuel boost pump motor
 - (e) Strobe systems

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (8) Continuous wire runs (ref. schematic diagram) are typically identified by an assigned wire number, i.e. 24-2, from the aircraft battery positive terminal to the starter relay contacts. In cases where wire runs are interrupted by splices, disconnects, fuses etc., the wire number is also assigned a letter, i.e., wire 49-1A from buss to F3, and wire number 49-1B from the opposite end of F3 to wire number 49-1C. The A-B designation indicates wire discontinuities. Typically wire numbers (not letters) sequence through electrical devices, such as lamps, motors, and relays, etc.

6-2. BATTERY

A. General Information

The aircraft is equipped with a 12 volt or 24 volt battery as described below. The following specifications apply to the standard aircraft battery:

	<u>12 VOLT</u>	<u>24 VOLT</u>
Manufacturer	Concorde	Concorde
Type	RG-35A	RG-24-11M
Voltage	12	24
Amp Hours	29	11
Cold Cranking Amperes	390	160
Overall Dimensions (in) (mm)	9.78L x 5.17W x 6.83H (248L x 131W x 174H)	8.65L x 7.31W x 6.73H (220L x 186W x 171H)

B. Battery – Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Battery discharged	Loose or corroded terminals	Clean connections, tighten terminal hardware
	Loose belt	Reference Section 6-3D Alternator Installation

NOTE: Refer to Concorde RG Series Component Maintenance Manual, Document No. 5-0171 for electrical renew test procedure.

C. Battery Master Power – Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Master switch-on, all electrical systems in-operative	Dead battery	Replace or recharge
	Master relay faulty (RL1)* (coil or contacts bad)	Replace master relay
	Overcurrent trip breaker "open" or faulty (CB16)*	Reset overcurrent breaker or replace breaker if faulty
	Inline fuse blown (F18)*	Replace fuse
	Overcurrent breaker faulty (CB17)*	Replace breaker
	Current limiter faulty (F9)	Replace current limiter

* Applies to early F-28F/280F with buss faults breaker protection system.




Fig. 6-1A. Alternator (left) and Starter Installation (right)
(shroud removed for clarity)




Fig. 6-1B. Alternator and Starter Installation (Inactive)

Top - Fan shroud side showing alternator mount pivot slide tension bar and drive belt
Bottom - Underside of engine showing alternator mount position and pivot mount bolts

D. Buss Faults Breaker System

General Description – Early F-28F/280F Series

The battery protection system is designed to remotely sense electrical overloads in the aircraft which cause excessive battery current drain. This system consists of fuse (FIB), overcurrent breaker (CB17) and the "overcurrent trip" breaker (CB16) on the instrument panel. Circuit breaker CB17 (located at the aircraft battery) senses the overload condition, simultaneously trips the dash-mounted overcurrent breaker CB16 and deactivates the master relay. The action removes the battery from the aircraft buss. Battery power cannot be returned to the aircraft buss unless the "overcurrent trip" dash-mounted breaker is first reset. The "overcurrent trip" breaker cannot be reset until the overload condition has been corrected. Repair of this system is limited to replacement of faulty components, and the removal of the overload condition.

Electrical current is distributed via buss bar through individual trip-free circuit breakers. Networks not protected by trip-free breakers contain inline fuses.

General Description – Later F-28F/280FX

The battery and APU buss are protected by a current limiter (F9) which is located at the aft mounted battery box and is installed between the starter relay and the master switch relay which is located on the electrical panel located just inboard of the airbox. The remaining circuits are protected by either switch type circuit breakers or trip free push/pull circuit breakers installed on the lower console switch panel or on the lower avionics panel. Secondary circuits are normally protected by fuses located on a panel which is installed on the left side of the lower instrument panel console. On aircraft (F-28F S/N 833 and subsequent; 280FX S/N 2167) with illuminated panels, all standard equipment (with the exception of the starter stuck relay), is protected by a circuit breaker or switch type circuit breaker (Figure 24-3). Some optional equipment may be protected by an in-line fuse. The starter stuck relay fuse (F25) is an in-line type and is located on the aft side of the battery tray.

6-3. ALTERNATOR

A. General Information

The aircraft alternator is a belt driven type. The alternator output rating is 70 amperes continuous at approximately 12 volts D.C. or 28 volts D.C., depending on the electrical system. Principle components of the alternator are the stator, the rotor, the slip ring end head, the drive end head and the rectifier diodes.

B. Troubleshooting

The following list suggests areas to be investigated should alternator performance be suspect:

- (1) Brushes – Remove and inspect for condition and seating
- (2) Rotor – Test for ground or shorted windings
- (3) Rectifier Diodes – Test for open or shorted diodes
- (4) Stator – Test for open
- (5) Bearings – Check for roughness or excessive clearance.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Housing cleanliness – End housing should be kept clean by wiping with a cloth dampened in solvent

NOTE: It is recommended that the service manual applicable to your alternator type be consulted for detailed repair procedures.

C. Alternator – Removal

- (1) Disconnect battery cables.
- (2) Remove cowling and baggage box.
- (3) Remove jackstrut and pulley assembly. (See Section 11-4 for Jackstrut Removal Procedure).
- (4) Remove the fan assembly exposing the alternator.
- (5) Cut safety wire on bolt securing alternator belt tension arm and remove bolt. Pivot alternator and remove v-belt from alternator pulley.
- (6) Disconnect wires from alternator. Label the wires or note the position of the wire numbers for correct placement on reinstallation.

NOTE: The ground wire is connected to the case of the alternator; not to the AUX terminal.

- (7) Remove the two alternator mount bolts and remove alternator.

D. Alternator – Inspection

- (1) Inspect the alternator I/A/W the manufacturer's instructions.
- (2) Inspect the alternator mount for corrosion, damage, and security.
- (3) Check belt tension slip at 12-14 ft-lbs/16.3-19.0 Nm.

NOTE: It is recommended that the service manual applicable to the alternator type be consulted for detailed repair procedures.

E. Alternator – Installation

CAUTION: Inadvertent engine starting may occur when turning the engine by hand unless precautions are taken. Remove the ignition wires from the spark plugs before manually turning the crank shaft.

NOTE: On new or replacement alternators, remove fan and replace with spacer from removed alternator (Reference SIL 0016).

NOTE: Remove cooling shroud from the aft side of the alternator.

- (1) Align alternator with mount bracket and install the two attachment bolts.

NOTE: Tighten mount bolts finger tight allowing alternator to pivot. (Tighten alternator attachment bolts to take out clearance but allow movement for adjusting tension.)

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Install the alternator adjusting arm and tighten the bolts finger tight to allow the alternator to pivot.
- (3) Install the starter ring gear support (flywheel) on the crankshaft and secure with two, temporary, ½ x 20 x 1 inch bolts installed in the two positions where there are no crankshaft bushings. (It is acceptable to use a ¾ x 6 inch tubular spacer over two of the 28-13306-1 (AN178H bolts).)

CAUTION: Do not install any shims between the flywheel and the crankshaft flange.

- (4) Install the belt over the two pulleys.
- (5) Pivot the alternator and adjust the belt tension until the pulley just slips at 12 ft-lbs/16.3 Nm. (Set tension to 14 ft-lbs/19.0 Nm for new installations.)
- (6) Torque the outboard bolt through the adjustment arm (80-90 in-lb/9.0-10.1 Nm).
- (7) Remove the bolts securing the starter ring gear support and pull off the starter ring gear support and the belt.
- (8) Torque the inboard adjusting arm bolts (80-90 in-lb/9.0-10.1 Nm) and safety wire both bolts (MS20995C32).

CAUTION: Alternator attachment hardware must not be loose.

- (9) Torque the alternator mount bolts (160-190 in-lb/19.1-21.6 Nm) and install the cotter pins.
- (10) Install the starter ring gear support on the flywheel.
- (11) Install the alternator belt over the alternator pulley and turn the crankshaft by hand while guiding the belt onto the pulley.

CAUTION: Connect the ground wire to case ground. Do not connect it to the AUX+ terminal.

- (12) Connect wires to the alternator as previously marked.
- (13) Install and secure the lower access panel on the fan shroud and tighten hardware to standard torque.
- (14) Position auxiliary oil cooler in place and secure with four attachment bolts.
- (15) Install fan assembly and shims on flywheel.
- (16) Install jackstrut and pulley assembly. (See Section 11-4 for jackstrut Installation procedure.)
- (17) Inspect all items for security.
- (18) Install cowling.
- (19) Connect battery cables.

I

INTENTIONALLY LEFT BLANK

NOTE: Updates to lighting, caution/warning annunciators, and electrical schematics are provided in Section 21.

6-4. VOLTAGE REGULATOR

A. General Information

Alternator voltage is controlled by a solid state transistor regulator. The regulator is factory set for proper voltage control and should not normally require field adjustment. Field repair of the regulator is generally not practical and the unit should be replaced in the event of failure.

B. Troubleshooting

Symptoms of a faulty regulator include:

- (1) Continuous discharge on aircraft ammeter.
- (2) Large fluctuations in ammeter needle (needle oscillates from charge to discharge).
- (3) Excessive charging indication on ammeter with fully charged or new battery.
- (4) Ammeter needle drops to discharge position as additional electrical loads are switched on, such as strobes, landing lights, etc.
- (5) Battery frequently requires water indicates overcharging regulator.

NOTE: Solvents and engine cleaning fluid should not be used on the regulator. Cover regulator during engine compartment cleaning.

MAINTENANCE MANUAL

C. Voltage Regulator - Removal

- (1) Open right side engine panel and remove the air filter housing assembly. (See Section 13-7, Primary Airflow System).
- (2) Cut the tie wraps from wires running to the voltage regulator.
- (3) Cut regulator wires at splices.
- (4) Remove screw to disconnect the ground wire. (Black wire).
- (5) Remove the two screws securing voltage regulator and remove regulator.

D. Voltage Regulator - Installation

- (1) Install voltage regulator on firewall panel and secure with two screws.
- (2) Secure black ground wire with screw.
- (3) Connect the remaining regulator wires with new splices and secure in position with tie wraps.
- (4) Install air filter housing assembly. (see Section 13-7 Primary Airflow System).

E. Voltage Regulator - Adjustment

NOTE: If ammeter shows continuous charge or discharge check voltage regulator adjustment. A voltmeter will be required to check the regulator.

- (1) Establish an electrical system load of approximately 15 to 20 amperes.
- (2) Connect voltmeter positive lead to aircraft battery (+) terminal. Connect voltmeter negative lead to battery (-) terminal.
- (3) After one minute of engine operation at proper electrical load, rotate regulator adjustment screw until voltmeter at battery indicates $14.0 \pm .2$ volts for a 12 volt system, or $28.5 \pm .2$ volts for a 28 volt system.

NOTE: Clockwise screw rotation increases voltage. Do not force adjustment screw.

- (4) Disconnect meter from battery and secure battery compartment for airworthiness.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

6-5 OVERVOLTAGE RELAY

A. General Information

This system aids in the protection of auxiliary and standard aircraft electronics in the event of an excessive overvoltage occurrence.

The overvoltage relay system directs power to the regulator through the terminal marked "load" until such time when the terminal marked "battery" senses an overvoltage condition. Upon sensing an overvoltage the regulator power path becomes interrupted, thereby disabling the alternator charging system. The charging circuit is held open (Regulator-Alternator Off) and can be reset only by removal of battery voltage from the overvoltage relay "battery" terminal. This is accomplished by manually cycling the alternator switch (dash switch panel) on and off thereby resetting the overvoltage relay. The overvoltage relay will not reset until the problem causing the overvoltage condition has been corrected.

6-6 STARTER

A. General Information

Components which comprise the starter system include the ignition breaker (CB6), starter switch (S8), starter relay (RL2) and the starter motor (SM).

The starter motor receives power directly from the aircraft battery through relay RLZ. A pushbutton switch located at the throttle end of the collective stick activates the starter relay by drawing power from the main buss thru ignition breaker CB6. The starter relay is located near the aircraft battery.

Troubleshooting this system is best accomplished by component replacement with the exception of the starter motor which can be serviced. Servicing of the starter motor should be performed to manufacturers specification.

MAINTENANCE MANUAL

B. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Starter motor inoperative	Low battery voltage	Charge or replace battery
	Collective start switch 58 defective	Replace switch
	Starter breaker switch open or defective (CB6)	Reset breaker switch or replace if defective
Starter relay does not activate (RL2)	Relay coil "open"	Check continuity of relay coil, replace relay if defective
Starter relay (RL2) activates, starter motor does not run	Relay contacts defective	Replace starter relay
Starter relay OK, sufficient battery voltage at starter motor, starter motor does not run.	Starter motor defective	Rebuild or replace starter motor

C. Starter - Removal (see fig. 6-2)

- (1) Disconnect battery cables.
- (2) Remove cowling and baggage box.
- (3) Remove jackstrut and pulley assembly. (See Section 11-4 for jackstrut removal procedure.)
- (4) Remove fan assembly.
- (5) Remove bolts and strap securing starter housing to alternator housing.
- (6) Remove starter housing bolt from aft side of fan shroud.
- (7) Remove fan shroud access panels from inside engine compartment to aid in starter removal.
- (8) Disconnect power cable from starter.
- (9) Remove the two outboard nuts from starter housing mount pad.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-6-11

MAINTENANCE MANUAL

- (10) Loosen the two inboard nuts from starter housing mount pad and slide starter assembly outward to remove.

NOTE: The starter mount pad is slotted on the inboard side for ease of removal. Do not completely remove the inboard mount nuts. (See fig. 6-2)

- (11) Remove starter shim from mount pad area if applicable.

NOTE: Retain shim for re-installation.

D. Starter - Installation (See Fig. 6-2)

- (1) Align starter housing mount pad slots with inboard studs and slide starter into position.

NOTE: Be sure shim is installed between mount pad and starter housing if applicable.

- (2) Secure starter with mount hardware.
- (3) Install starter housing mount bolt in aft side of fan shroud.
- (4) Install and secure strap between starter housing and alternator housing.
- (5) Connect battery cables and power cable to starter.
- (6) Check starter bendix gear to ring gear clearance as follows:
(Clearance .010-.030 inch)

CAUTION: The starter and the ring gear must be securely mounted before this check can be completed. Install ring gear with two short bolts without fan installed.

- (a) Remove the four lower spark plugs.
- (b) Engage starter momentarily to bring bendix gear in contact with ring gear.
- (c) Check for backlash clearance between the gears at a minimum of four locations on the ring gear (90° apart) by rocking the fan back and forth. If a tight spot is felt or a place of zero backlash is encountered, reshimming of the starter is required.

NOTE: It is also possible to check this clearance with gauge wire or safety wire at the point where the timing holes in the fan dish align with the starter. The clearance check will be between the tip of the bendix gear tooth and the bottom of the ring gear groove.

MAINTENANCE MANUAL

- (7) Safety wire starter mount bolts.
- (8) Remove two short bolts from ring gear hub and install fan assembly.
- (9) Install jackstrut and pulley assembly. (See Section 11-4 for jackstrut installation procedure).
- (10) Install fan shroud access panels in the engine compartment.
- (11) Install baggage box and cowling.

6-7 FUEL BOOST PUMP

A. General Information

The electric fuel boost system consists of the boost pump motor (BM) and the boost pump breaker switch (CB12). Fuel boost pressure is monitored by an independent electric circuit comprised of the fuel pressure switch, red pressure status indicator and a circuit breaker (CB7). Low fuel boost pressure (example: electric boost pump off) will cause the red indicator to be energized. With sufficient fuel pressure (electric boost motor on) the red indicator will be extinguished. The indicator lamp has a press-to-test function for checking lamp filament continuity.

B. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Either or both indicator lamps out, low fuel pressure	Indicator lamp filaments failed (L8 or L9)	Replace lamps
	CB7 instrument breaker failed or open	Reset or replace breaker
	Fuel pressure switch faulty	Replace fuel pressure switch
	Boost pump breaker switch (CB12) open or failed	Reset or replace breaker
	Boost motor (BM) failure	Replace boost motor

MAINTENANCE MANUAL

6-8 LIGHTING

A. Forward Landing Light - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Landing light inoperative	Lamp filament burned out (L14)	Replace lamp
	Landing light breaker (CB5) open or failed	Reset or replace breaker
	Inline fuse (F2) open (F28F only)	Replace fuse
	Landing light relay (RL4) open or shorted, contacts worn (F28F only)	Replace relay RL4
	Cyclic stick forward landing light switch failed (F28F only)	Replace landing light switch

B. Aft Landing Light - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Aft lamp inoperative	Lamp filament burned out (L3)	Replace Lamp (L3)
	Circuit breaker switch CB10 open or failed	Replace or reset breaker switch

C. Panel Lights

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Lights do not dim/lights inoperative	Rheostat (R3) wiper faulty, rheostat windings open	Replace rheostat
	Rheostat (R3) knob loose on rheostat shaft	Tighten set screw of knob
	Panel light breaker switch (CB2) open or faulty	Reset breaker, replace if defective

NOTE: Illuminated legend bar lamps are not easily replaced. Replacement of bar is recommended if lamp failure occurs.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

D. Navigation Lighting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Running lights inoperative (F28F)	Lamp filaments (L5-2) and (L5-1) burned out	Replace lamps
Tail lights inoperative (F28F)	Lamp filaments (L4 or L2) burned out	Replace lamp
All navigation lights inoperative (F28F)	Navigation light circuit breaker tripped or faulty	Reset or replace circuit breaker CB3
Tail light inoperative (280F)	Lamp filament (L1) burned out. Circuit breaker CB3 tripped or faulty	Replace lamp (L1) Reset or replace circuit breaker CB3
Right or left strobe lamps inoperative (L2-1, L2-2) 280F	Burned out lamps	Replace lamps
Right or left strobe lamps inoperative (L2-1, L2-2) 280F	Strobe power supply (SLPS) faulty <u>NOTE:</u> Lamps have separate power supplies.	Repair or replace strobe power supply
Both left-right navigation lights and tail light inoperative (280F)	Navigation light circuit breaker open or faulty	Reset or replace breaker CB3
Both right and left strobe lamps inoperative (280F)	Anti-collision light breaker (CB4) open or faulty	Reset or replace CB4 breaker
Anti-collision lamp inoperative (F28F)	Lamp filament burned out	Replace lamp L11-1, L12-1
Both anti-collision lamps inoperative (F28F)	Circuit breaker CB4 open or tripped	Replace or reset breaker CB4
Both anti-collision lamps inoperative (F28F)	Power supply PSAL faulty	Repair or replace power supply

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-6-15

MAINTENANCE MANUAL

6-9 CLUTCH DISENGAGE WARNING LIGHT

A. General Information

The clutch disengage warning system consists of a red indicator lamp mounted in the instrument panel and a limit switch located on the clutch actuator mechanism. This circuit is protected with an inline fuse located in the instrument panel.

The system provides a visual cockpit warning indication of an improperly positioned clutch overcenter mechanism. The red warning cockpit lamp is illuminated whenever the clutch overcenter mechanism is not properly positioned tightly against the clutch side plates.

Troubleshooting this system consists mainly of clutch rigging checks switch replacement and indicator lamp or fuse replacement.

NOTE: Installation and rigging covered in section 11-1 Belt Drive System.

6-10 MANIFOLD PRESSURE OVERBOOST CAUTION LIGHT

A. General Information

The manifold overboost caution system consist of a pressure activated snap switch and associated amber indicator. System fault protection is provided by a single inline fuse (F17) located in the instrument panel.

Engine manifold pressures near maximum allowable will illuminate the amber caution lamp drawing the operators attention to the manifold gauge for possible corrective action. The lamp activating switch operates from a tap in the aircraft manifold pressure instrument line. Transient pressures from quick throttle inputs may appear to illuminate the lamp at low gauge pressure readings. This occurs due to inherent dampening characteristics of the pressure gauge which prevent the needle from following transient pressures. Lamp filament and fuse continuity can be checked via the indicator press to test feature.

Troubleshooting of this system is generally limited to component replacement such as fuse, switch, lamp, etc.

MAINTENANCE MANUAL

6-11 HOURLMETER

A. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Hour meter inoperative	Inline fuse (FI) open	Replace fuse (FI)
	Oil pressure switch (OPS) failed	Replace oil pressure switch (OPS)
	Hour meter faulty	Replace hour meter (HM)

6-12 TRIM MOTORS

A. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Erratic or no trim motor operation	Lateral limit switch S11 or S12 failed	Replace S11 or S12 limit switch
	Fore-aft limit switch S9 or S10 failed	Replace S9 or S10 limit switch
	Shorted motor TM1 or TM2	Replace trim motor
	Four-way cyclic switch faulty	Replace four-way switch
	Circuit breaker switch CBB open or failed	Reset or replace breaker CBB

6-13 AMMETER - CHARGING SYSTEM

A. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Ammeter shows continuous discharge (engine running)	Regulator failed or out of adjustment	Adjust regulator per recommended specification. Replace if defective.
	Alternator breaker open or defective (CB1)	Reset or replace breaker CB1
	Alternator breaker (CB15) open or defective	Reset or replace breaker CB15
	Overvoltage relay tripped or defective	Reset overvoltage relay. Replace if defective.
	Alternator switch (S6) defective	Replace switch S6.
	Alternator windings shorting	Service alternator per mfg. spec.
	Worn or loosened alternator belt	Replace/tighten belt.

6-14 INSTRUMENT CLUSTER TROUBLESHOOTING

A. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Fuel quantity indicator inoperative or erratic	Instrument breaker CB7 faulty or open	Reset or replace breaker CB7
	Loose, damaged, broken ground wire from sending unit	Inspect sending unit wiring - repair as necessary
	Faulty module electronics	Perform electrical check of module - see Figure 6-7

B. Troubleshooting - Main Rotor Gearbox Temperature

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Erroneous indication or inoperative temperature meter	Instrument breaker CB7 open or faulty	Replace or reset breaker CB7
	Loose, damaged or broken ground wire from sending unit	Inspect sending unit wiring - repair as necessary
	Damaged thermocouple	Replace thermocouple wire. Use type approved for application
	Faulty module electronics	Perform electrical check of module - See Figure 6-6
Needle pegged beyond full scale	Excessive resistance in temperature probe line	Check probe wiring for break and repair as necessary
Needle pegged below zero	Shorted probe wire	Inspect probe wire for improper ground. Replace wire.

MAINTENANCE MANUAL

C. Troubleshooting Amperage Meter

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Meter not operating	Loose connection at meter shunt	Tighten shunt terminals
	Faulty indicator	Perform electrical check of module See Fig. 6-7

D. Oil Temperature Module

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Oil temperature	Breaker CB7 faulty or open	Reset or replace breaker
	Faulty indicator	Perform electrical check of module - see Figure 6-5
Needle pegs	Faulty sending unit ground	Repair or replace defective wiring
	Excessive resistance in temperature probe wiring	Check probe wiring for break and repair as necessary
	Defective sending unit	Replace temperature probe
Needle pegs below zero	Open in probe wiring	Inspect wiring from probe for improper ground. Replace ground wire.

MAINTENANCE MANUAL

E. Cylinder Head Temperature Module Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Cylinder head temperature module inoperative	Circuit breaker CB7 open or faulty	Reset or replace CB7
	Defective temperature probe	Replace temperature probe
Needle pegged at full scale	Excessive resistance in temp probe wiring	Check wiring for break. Repair or replace probe wire.
Needle pegged below zero	Shorted probe wire	Inspect wiring from probe for improper ground. Replace defective wiring.

F. Instrument Cluster Module Check Procedure

This procedure will assist in determining the operational status of the individual instrument modules. The steps do not constitute an instrument calibration procedure. Resistance values given are approximate.

Equipment Required:

- (1) 14 or 28 volt, 2 amp, filtered-regulated power supply.
- (2) Variable power resistor or resistance decade box.
- (3) Test Leads.

Procedure:


- (1) Position rear of module as pictured.
- (2) Connect power and variable resistor per individual diagram.
- (3) Adjust desired resistance level.
- (4) Set power supply for 14 volts D.C. or 28 volts D.C., as appropriate.
- (5) Do not use resistance values lower than those specified in the respective charts, instrument damage may result.
- (6) Pin having "no connection" is 14 or 28 volt lighting.
- (7) All grounds are power supply "negative output" connections.
- (8) Proper instrument operation is observed when resistance values and scale readings correlate. See applicable chart for each module type.

NOTE: Excessive resistance or open in probe wires may cause meter needle to "peg" full scale.

A short or very low resistance in probe wires may cause meter needle to "peg" below zero.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL



ELECTRICAL SYMBOLS

Fig. 6-3

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED




FIGURE 6-5

MAINTENANCE MANUAL

6-15 CHARTS

A. Electrical Loads

The flight ampere load conditions chart describes the typical amperage required to operate specific standard electrical devices in the F28F and 280F aircraft. Total electrical loads (amperes) are shown for various combinations of electrical devices under simultaneous operation. The electrical load totals can be used to estimate the percent reserve power available from the alternator when additional electrical equipment is installed on the aircraft. (Maximum continuous alternator output is 70 amperes).

COMPONENT LOCATION CHART

FUSES

<u>LOCATION</u>	<u>SCHEMATIC ID</u>	<u>DESCRIPTION</u>	<u>F28F</u>	<u>280F</u>
Instrument panel	F1	Hourmeter fuse	X	X
Instrument panel	F2	Forward landing light fuse	X	X
Instrument panel	F3	Utility light fuse	X	X
Instrument panel	F17	Overboost light	X	X
Battery box	F18	Overcurrent system	X	X
Instrument panel	F20	Clutch disengaged system	X	X

RELAYS

<u>LOCATION</u>	<u>SCHEMATIC ID</u>	<u>DESCRIPTION</u>	<u>F28F</u>	<u>280F</u>
Aft firewall co-pilot side	RL1	Master relay	X	X
Battery box	RL2	Starter relay	X	X
Behind seat deck pilot side	RL4	Landing lamp relay		X

SPECIAL SWITCHES

<u>LOCATION</u>	<u>SCHEMATIC ID</u>	<u>DESCRIPTION</u>	<u>F28F</u>	<u>280F</u>
Engine compartment cross tube co-pilot side	FPS	Fuel pressure switch	X	X
Instrument panel	OPS	Oil pressure switch	X	X
Instrument panel	S13	Turbo boost pressure		X
Instrument panel	S13	Turbo boost pressure	X	

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

280F FLIGHT AMPERE LOAD CONDITIONS - 12 VOLT SYSTEM

ELECTRICAL DEVICE	DAY												NIGHT											
	A	B	C	D	E	F	G	H	I	J	K	L	A	B	C	D	E	F	G	H	I	J	K	L
Boost Pump	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5
Longitudinal Trim*	-	6.0	-	6.0	-	-	6.0	-	-	6.0	-	-	6.0	-	-	6.0	-	-	6.0	-	-	6.0	-	-
Laternal Trim*	-	-	6.0	-	6.0	-	-	6.0	-	-	6.0	-	6.0	-	-	6.0	-	-	6.0	-	-	6.0	-	-
Radio Transmit*	-	3.5	3.5	-	-	-	3.5	3.5	-	-	3.5	3.5	3.5	-	-	3.5	3.5	-	-	3.5	3.5	-	-	3.5
Radio Receive	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
Instrument Cluster	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14
Master Relay	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Stroke Kits (Total)	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
Position Lights - Right & Left	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Panel Lights	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Left Position Light	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Forward Landing Light 4509**	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Forward Landing Light (4313)***	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Left Landing Lights**	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	9.64	19.14		15.64	17.24	26.74		23.24		38.11	28.61													

NOTE: Flight condition "A" is day normal cruise
Flight condition "F" is night normal cruise

* Denotes intermittent use

** Denotes short duration use (5 minutes)

*** 4313 Landing lamp acceptable substitute

The above load conditions include typical electrical appliances for 280F series helicopters. If other special equipment is added, the loads for conditions A and F in the above table are to be modified.

MAINTENANCE MANUAL

F-28F FLIGHT AMPERE LOAD CONDITIONS - 12 VOLT SYSTEM

ELECTRICAL DEVICE	DAY							NIGHT						
	A	B	C	D	E	F	G	H	I	J	K	L		
Nav Lights 4 @ 1.61 amps each	-	-	-	-	-	6.44	6.44	6.44	6.44	6.44	6.44	6.44		
Boost Pump	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5		
Longitudinal Trim*	-	6.0	-	6.0	-	-	6.0	-	6.0	-	6.0	-		
Laternal Trim*	-	-	6.0	-	6.0	-	-	6.0	-	6.0	-	-		
Radio - Transmit*	-	3.5	3.5	-	-	-	3.5	3.5	-	-	3.5	-		
Radio - Receive	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6		
Instrument Cluster	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.14		
Master Relay	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0		
Anti-Collision	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0		
Panel Lights	-	-	-	-	-	2.0	2.0	2.0	2.0	2.0	2.0	2.0		
Forward Landing Light 4509**	-	-	-	-	-	-	-	-	-	-	8.23	8.23		
Forward Landing Light (4313)***	-	-	-	-	-	-	-	-	-	-	(20.8)	(20.8)		
Aft Landing Light 4509**	-	-	-	-	-	-	-	-	-	-	8.23	8.23		
Aft Landing Light (4313)***	-	-	-	-	-	-	-	-	-	-	(20.8)	(20.8)		
Landing Light Relay	-	-	-	-	-	-	-	-	-	-	0.21	0.21		
	14.24	23.74		20.24	22.68	32.18	28.68	48.85	39.35	(73.99)	(64.49)			

NOTE: Flight condition "A" is day normal cruise
 Flight condition "F" is night normal cruise
 * Denotes intermittent use
 ** Denotes short duration use (5) minutes)
 *** 4313 Landing lamp acceptable substitute

The above load conditions include typical electrical appliances for F-28F series helicopters. If other special equipment is added, the loads for conditions A and F in the above table are to be modified.

MAINTENANCE MANUAL

F-28F LAMP REPLACEMENT CHART

AMOUNT	LOCATION	ASSEMBLY MANUFACTURER	ASSEMBLY NO.	BULB NO.	
				12 Volt	28 Volt
1	Aft Landing Light	Enstrom		4313 or 4509	4591
1	Forward Landing Light	Enstrom		4313 or 4509	4596
1	Forward, Right Position Light - Green	Grimes	A-1285-G-12	1512	1524
1	Forward, Left Position Light - Red	Grimes	A-1285-R-12	1512	1524
2	Aft Position Lights	Grimes	A-1285-C-12	1512	1524
2	Anti-Collision Lights	Whelen	HDA-14	A469A Flash Tube	A469A
1	Map Light	Grimes	15-007-5	1816	313
2	Post Lights	Grimes	A8970	330	327
8	Eyebrow Lights	Grimes	B4855-B-330	330	327
1	Fuel Boost Light - Red	Dialight	803-1710-0331-504	1815	1819
2	Switch Panel Placard	Enstrom	28-18091-1 (Master Switch, etc)	Replace	
	Lights		28-18091-3 (Alternator, etc)	Assembly	
1	Overboost Caution Light	Dialight		1815	1819
1	Clutch Disengage Warning Light	Dialight	803-1710-0331-504	1815	1819

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

280F LAMP REPLACEMENT CHART

AMOUNT	LOCATION	ASSEMBLY MANUFACTURER	ASSEMBLY NO.	12 Volt	24 Volt	BULB NO.
1	Aft Landing Light	Enstrom		4406	4591	
1	Forward Landing Light	Enstrom		4313 or 4509	4596	
1	Right Side Position	Whelen (modified by Enstrom)	A650PG	W1290-14		W1290-28
1	Light and Strobe	Whelen (modified by Enstrom)	(Enstrom 28-21048-3)	A610 Strobe		A610
1	Left Side Position	Whelen (modified by Enstrom)	A6050PR	W1290-14		W1290-28
1	Light and Strobe	Whelen	(Enstrom 28-21048-1)	A610 Strobe		A610
1	Aft Position Light	Whelen	A555	A508-14		A508-28
1	Map Light	Grimes	15-007-5	1816		313
2	Post Lights	Grimes	A8970	330		327
8	Eyebrow Lights	Grimes	B-4855-B330	330		327
1	Fuel Boost Light - Red	Dialight	803-1710-0331-504	1815		1819
1	Fuel Boost Light - Green	Dialight	804-1710-0332-504	1815		1819
2	Switch Panel Placard	Enstrom	28-18091-1 (Master Switch, etc)	Replace		
1	Lights		28-18091-3 (Alternator, etc)	Assembly		
1	Overboost Caution Light	Dialight		1815		1819
1	Clutch Disengage Warning Light	Dialight	803-1710-0331-504	1815		1819

#2 Rev. 11/18/88

MM-6-29

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

MAINTENANCE MANUAL

SECTION 7

INSTRUMENTS

7-1 INSTRUMENT PANEL (See Figures 7-1 & 7-2)

The instrument panel is centrally located in the front of the cabin for optimum visibility by either pilot or co-pilot. The "F" model instrument panel is mounted at an 8° angle.

NOTE: Instrument panel angle is required when replacing an attitude gyro (horizontal horizon) designed to operate at the same angle.

7-2 ALTIMETER

A. Description

The altimeter indicates the height of the helicopter above sea level. It is operated by static air pressure derived from the airspeed pitot-static system. The altimeter is of the sensitive type that provides a height reading from 0 to 20,000 feet. The long hand reads in increments of 100 feet, the middle hand in increments of 1,000 feet, and the short hand in increments of 10,000 feet. The control knob on the face of the altimeter adjusts the barometric pressure reading to set field altitude.


CAUTION: Never apply positive pressure to static lines with the instruments connected; this will damage the instrument mechanism.

B. Altimeter - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Indicating hands fail to respond.	Static pressure line obstructed.	Disconnect static pressure line from instruments and blow with compressed air.
	Static pressure connection improperly made.	Check static pressure lines and connect correctly.
Indications are obviously incorrect.	Leaks in static pressure line and/or leaks in cases of instruments in same system.	Replace damaged tubing and/or check instruments for leaks.
	Defective instrument.	Replace altimeter.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED


MAINTENANCE MANUAL



F28F
FIG. 7-1. INSTRUMENTS AND INSTRUMENT PANEL

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL



280F
FIG. 7-2. INSTRUMENTS AND INSTRUMENT PANEL

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

B. Altimeter - Troubleshooting (continued)

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Indicator hands vibrate.	Excessive vibration of static pressure tubing.	Anchor tubing with tube clamps.

7-3 AIRSPEED INDICATOR

A. Description

The single scale airspeed indicator is calibrated in miles per hour or knots per hour and provides an indicated airspeed reading at any time during forward flight. The reading is obtained by measuring the difference between impact air pressure and the static vent. The pitot tube, which provides the impact air pressure source, is located on the lower side of the cabin nose section. Static air pressure for instrument operation is derived from two static vents located on either side of the tail cone assembly. The openings in the pitot tube and static vent ports must be maintained obstruction-free and clean at all times for proper instrumentation operation.

CAUTION: Never apply positive pressure to static lines with the instruments connected; this will damage the instrument mechanism.

B. Airspeed Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Airspeed indicator needle fails to respond.	Incorrect pitot tube hookup.	Check tubing connection and make necessary corrections.
	Obstruction in pitot lines.	Disconnect pitot line from pitot head and instruments and static line from fuselage and instrument; clear lines with compressed air. Check pitot tube drain hole.
Oscillation of airspeed indicator.	Leak in pitot or or static lines.	Check all connections and check flexible hoses at back of instrument for leakage.
	Moisture in pitot or static lines.	Disconnect pitot line from instrument and static line from fuselage flanges and instruments; clear lines with compressed air. Check pitot drain hole.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

7-4 ENGINE & ROTOR TACHOMETER

A. Description

The engine and rotor tachometers are combined on a single indicator (twin tach) with concentric scales calibrated in engine and rotor rpm. The needle marked "E" indicates engine rpm, while the needle marked "R" indicates rotor rpm. The tachometer is mechanically connected to the rotor assembly and engine assembly through flexible drive cables.

B. Engine & Rotor Tachometer - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Fluctuating needle(s).	Binding cable.	Lubricate cable.
	Defective instrument.	Replace instrument.
No reading on indicator.	Twisted or broken cable or tach drive belts.	Replace cable or drive belts.
Needles either permanent or intermittent.	Defective instrument.	Replace instrument.
	Reverse installation of cable.	Install cables in correct position.
Needles do not superimpose.	Instrument out of tolerance.	Check tolerance, 2900 ± 25 rpm, 3050 ± 25 rpm, spread between needles 1/4 of needle width maximum.
	Tach drive belts slipping or broken.	Replace drive belts.

7-5 FUEL QUANTITY INDICATOR

A. Description

The fuel quantity gauge continuously indicates the total quantity of fuel. It is electrically actuated by a float type sending unit located in the right-hand fuel tank.

NOTE: See Section 13-16 for gauge calibration procedure and adjustments.

MAINTENANCE MANUAL

B. Fuel Quantity Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Indicator registers "F", or consistently high reading (battery switch on).	Poor connections or sender ground.	Clean and tighten connection.

7-6 ENGINE OIL PRESSURE GAUGE

A. Description

The engine oil pressure gauge indicates the pressure in the engine oil lines in pounds per square inch.

CAUTION: Low oil pressure can result from improper oil level, incorrect oil viscosity, faulty oil pump, or bearing failure.

B. Engine Oil Pressure Gauge - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Low reading on oil pressure gauge.	Kinked tubing or obstruction in tubing.	Replace or clean tubing.
	Instrument out of tolerance.	Replace instrument.
Sticking oil pressure indicator.	Defective gauge.	Replace gauge.
Sluggish oil pressure reading.	Sludge or heavy oil in line.	Bleed line and service with engine oil, or in cold climates use kerosene.
	Safety orifice in engine fitting partially blocked by debris.	Remove engine fitting and blow clear.
Fluctuating oil pressure.	Air in pressure line.	Service oil pressure line with engine oil.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

7-7 MAIN ROTOR TRANSMISSION TEMPERATURE INDICATOR

A. Description

The main rotor transmission temperature indicator is located in the instrument cluster. It is electrically operated by a temperature sensitive heat probe connected to the transmission.

B. Main Rotor Transmission Temperature Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Open circuit - no reading.	Check continuity.	Clean and tighten ground connection.
	Blown fuse.	Replace fuse.

7-8 ENGINE OIL TEMPERATURE INDICATOR

A. Description

The engine oil temperature indicator measures engine oil temperature electrically by means of a resistance probe installed on the left side of the engine aft of the oil filter.

B. Engine Oil Temperature Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
No reading on oil temperature indicator with battery switch on, either constant or intermittent.	Open circuit.	Repair or replace leads.
	Poor ground at panel.	Repair ground.
	Open or short circuit in indicator.	Replace indicator.
Reading off scale at low temperature end or low reading, either constant or intermittent.	Short circuit in leads from resistance probe to indicator.	Make continuity check and repair or replace lead.
	Short circuit in probe.	Replace probe.

NOTE: Do not use thread
tube when installing
new probe.

MAINTENANCE MANUAL

7-9 AMMETER

A. Description

The ammeter indicates the amount of electric current supplied by the alternator to the battery and electrical bus.

B. Ammeter - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
No reading or erratic reading with battery and alternator switch on and engine at idle rpm.	Worn brushes, burned commutator, belt slippage or broken.	Repair or replace alternator, tighten belt, or replace belt.
Ø reading or showing discharge.	Overvoltage relay kicked out.	Reset (see Section 6)
Excessive charge or discharge in excess of 5-10 minute duration.	Faulty voltage regulator.	Replace.
	Looser or corroded connections in VR circuit.	Check as indicated, especially the ground connection.

NOTE: Normal operating system should show a medium to heavy charge rate just after engine is started. If the battery is in good condition it will accept this charge until the set system voltage is reached (14 volts) in approximately 8-10 minutes. At this point the ammeter should drop to about zero or just above, depending on system load.

Ø reading; everything is functional.	Defective meter or connections.	Check out and/or replace meter as required.
--------------------------------------	---------------------------------	---

MAINTENANCE MANUAL

7-10 CYLINDER TEMPERATURE INDICATOR

A. Description

The cylinder temperature indicator measures the cylinder head temperature by means of electric current from a temperature probe located in the bottom of No. 3 cylinder head.

B. Cylinder Temperature Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Temperature reading high throughout scale.	Poor connections or partial break in leads.	Check continuity of leads. Repair or replace faulty leads.
	Defective instrument.	Remove instrument for overhaul.
No reading, either permanent or intermittent.	Break in lead; break in thermocouple.	Repair or replace lead; replace thermal switch.
	Faulty indicator.	Remove instrument for overhaul.
Low reading, either permanent or intermittent.	Poor connection or short circuit.	Clean and tighten connections. Eliminate short circuit.

7-11 EXHAUST GAS TEMPERATURE INDICATOR (EGT)

A. Description

One of the most important factors in flying an aircraft is to maintain the correct fuel/air mixture. Proper mixture to the engine will give maximum range, economical operation, and maximum service life. Improper mixture will prove costly in fuel economy and maintenance costs, as well as shorten the life of the engine. The most accurate method for determining the correct fuel/air ratio is a sensitive and fast responding exhaust gas temperature indicator (EGT). The EGT indicator operates off a heat sensitive probe located in the exhaust system just forward of the turbocharger.

B. EGT Readings at Cruise

Exhaust gas temperature, as shown on the Enstrom EGT indicator, should be used as an aid for fuel mixture leaning in cruising flight at 75% power or less, i.e. 29 inches manifold pressure and 3050 rpm.

MAINTENANCE MANUAL

To obtain a best economy mixture, lean to 1650°F EGT. To obtain a best power mixture, lean to 1550°F EGT. Do not exceed 1650°F EGT. Operation on the lean side of peak EGT is not approved. Also any change in altitude or power will require a recheck of the EGT indication.

Fuel Mixture: Engine may be leaned at 29" MP or below to 1600°F on rich side of peak. Never exceed 1650°F EGT. Mixture must be full rich for landing and takeoff regardless of power for proper engine cooling.

C. EGT - Functional Check

Due to the narrow margin of temperature error allowed while operating at or near 1650°F EGT, it is recommended that at each 100 hour inspection, or at any time an error is suspected, the EGT system be tested for proper calibration.

CAUTION: DO NOT operate above 1600° EGT nor with a fuel flow setting less than 80 pounds per hour at 75% power (28.0 inches MP) until a calibration check has been completed after the EGT system or any part thereof has been replaced.

D. EGT Calibration

Instructions for testing and calibrating of the EGT system may be found in the AlcaI EGT Operating Instruction Manual AR70-155. It is recommended that a log book entry be made during the next flight of the fuel flow reading with the power set at 29" manifold pressure, rpm at 3050, and mixture leaned to 1650° EGT. A normal fuel flow indication would be 83 pounds per hour plus or minus 3 pounds per hour. A variation exceeding this range would indicate that the EGT is reading either high or low respectively.

Example: Mixture normally leaned to 1650° EGT, fuel flow in excess of 86 pounds per hour -- actual EGT temperature is lower than indicated.

This information, if monitored, will give operators sufficient warning if there is a problem developing in either the engine or the EGT system. An EGT reading that varies from normal and is engine related will be apparent by other symptoms.

Example: Partially restricted injector nozzle -- high fuel flow, low EGT with rough running engine.

CAUTION: Do not operate above 1600° EGT nor with a fuel flow setting less than 80 pounds per hour at 75% power (29.0" MP) until a calibration check has been completed after the EGT system or any part thereof has been replaced.

After replacement of broken instrument or at 100 hour inspection, it is recommended that a functional check be made of the system using an ALCOR AlcaI Mark V Calibrator in accordance with these instructions.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

7-12 MANIFOLD PRESSURE & FUEL FLOW INDICATOR

A. Description

The manifold pressure indicator is connected to the primary airflow system at the #3 cylinder and measures power being produced and used. The fuel flow indicator which is mounted in the same instrument is connected to the fuel flow system at the flow divider. It indicates fuel flow in relation to manifold pressure.

B. Manifold Pressure Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Excessive error at existing barometric pressure.	Water or restriction in line between instrument and engine.	Disconnect at instrument and blow out line.
Sluggish operation of needle.	Damaged or restricted line.	Remove line and blow out restriction. Replace line if damaged.
	Defective instrument.	Replace instrument.

NOTE: Restricted fitting just aft of instrument must also be removed before blowing out line.

C. Fuel Flow Indicator - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Low reading on fuel flow indicator.	Kinked tubing or obstruction in tubing.	Replace or clean tubing.
	Leak in fuel nozzle lines.	Repair leak or replace line.
	Instrument out of tolerance.	Replace instrument.
Sticking fuel flow indicator.	Defective instrument.	Replace instrument.

MAINTENANCE MANUAL

7-13 OUTSIDE AIR TEMPERATURE INDICATOR

A. Description

The outside air temperature indicator is a direct reading, bi-metallic instrument with a stainless steel probe. This instrument provides ambient temperature information which, when utilized, will aid in determining performance capability of the helicopter at the existing climatic condition. The indicator is located in the top of the cabin.

7-14 MAGNETIC COMPASS (F-28F)

A. Description

The vertical card compass is a dry compass utilizing eddy current dampening. It consists of a 2" vertical rotating dial and is compared with a fixed miniature airplane (lubber line) to present magnetic heading of the aircraft at all times. Heading information is more natural because the heading is read at the 12 o'clock position and off the nose of the miniature airplane. The compass card rotates and presents all quadrants in their true relation to line of flight. A compass light is furnished for night flying. A compass correction card and card holder is attached to the instrument console.

7-15 MAGNETIC COMPASS (280F)

A. Description

The magnetic compass indicates the heading of the helicopter in relation to magnetic north. It is a direct indicating compass and indicates the heading by means of a floating card element that is against a fixed reference line. The liquid used in the compass dampens the card oscillation. A compass light is furnished for night flying. A compass correction card and card holder is furnished adjacent to the instrument.

7-16 HOURMETER

A. Description

The hourmeter is located inside the right side engine compartment door. It is mounted just forward of the air filter housing. The meter keeps a running log of the total hours on the aircraft.

MAINTENANCE MANUAL

7-17 PITOT STATIC SYSTEM (See Figure 7-3)

A. Description

To operate the airspeed indicator and altimeter, it is necessary to have a static source of air pressure. A pitot-static system has been installed in the aircraft with two static air pressure ports. One is on the left-hand side of the tail cone just aft of the baggage compartment and the other is on the right-hand side of the tail cone. The static pressure ports are interconnected to a single static pressure line which runs up the right side of the pylon and through the seat structure to a tee fitting in the instrument console. It then runs to the altimeter and to one side of the airspeed indicator.

CAUTION: The two static ports should always be checked prior to flight and also at any time the helicopter is operated in dusty or freezing conditions where the small inlet holes may become clogged, which will cause the instruments to be inoperative or inaccurate.

B. Pitot Tube - Description

The pitot tube is located on the lower forward side of the cabin structure. It is a curved aluminum tube secured with mounting plates to the bottom of the fiberglass cabin wall. A flexible rubber hose is routed through the instrument console connecting the pitot tube to the airspeed indicator instrument line.

CAUTION: The pitot tube inlet end should be covered when the aircraft is to be parked for any prolonged period of time to prevent ingestion of dirt or ice that will impair the operation of the airspeed indicator. Use a red cover so it will be noticeable for removal on preflight inspection.

7-18 REPLACEMENT OF INSTRUMENTS

A. Replacement Procedures

NOTE: The following procedures are typical and apply to all instruments installed in the instrument panel.

- (1) Check that all electrical power is off to avoid the possibility of electrical shorts while working in the area of the instrument panel.
- (2) Remove covers from instrument console.
- (3) Disconnect electrical plug, wiring, or tubing as applicable, from the back of the instrument. Install suitable covers over tube fittings, instrument fittings, and loose wire terminals. Tag all connections for reinstallation.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED






FIG. 7-3 PITOT STATIC SYSTEM



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (4) Remove the screws securing the instrument to face of the panel and remove instrument from instrument panel.
- (5) Place replacement instrument into panel in mounting position and secure with mounting screws.
- (6) Connect tubing, electrical plug or wiring as applicable to the back of the instrument. Use care to avoid reversing connections for pitot and static lines.
- (7) Reinstall covers on instrument console.

7-19 INSPECTION OF INSTRUMENTS

A. Inspect as Follows

- (1) Inspect instrument case for dents and cover glass for slippage and cracks.
- (2) Inspect fitting or electrical connector at back of instrument for damaged threads that might prevent proper connection of the tube nut or electrical plug.
- (3) Inspect index markings and numerals on dial face for discoloration and legibility. Inspect pointers for cracked or peeling fluorescent paint.
- (4) Inspect for presence of all required range markings and slippage of any marks, indexes, or scales.

7-20 CALIBRATION OF INSTRUMENTS & INDICATORS

A. General Information

Calibration checks of the instruments are to be performed at qualified instrument calibration facilities.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

SECTION 8

STRUCTURE

TABLE OF CONTENTS

Paragraph	Description	Page
	Table of Contents	MM-8-0
8-1	Cabin	MM-8-1
	Removal	MM-8-1
	Inspection.....	MM-8-2
	Repair	MM-8-2
	Installation.....	MM-8-2
8-2	Windshields and Windows	MM-8-4
	Inspection.....	MM-8-4
	Repair	MM-8-4
	F-28F Windshield	
	Removal	MM-8-4
	Installation.....	MM-8-6
	280F Series Windshield	
	Removal	MM-8-8
	Installation.....	MM-8-8
	Overhead and Lower Windows (All F-28F and 280F/FX)	
	Removal	MM-8-10
	Installation.....	MM-8-11
8-4	Cabin Doors	MM-8-11
	F-28F Cabin Door	
	Removal – Door	MM-8-11
	Inspection – Door	MM-8-12
	Repair – Door.....	MM-8-13
	Installation – Door	MM-8-13
	Removal – Glass.....	MM-8-13
	Installation – Glass.....	MM-8-14
	280F Series Cabin Door	
	Removal – Door	MM-8-14
	Disassembly – Door	MM-8-16.1
	Assembly – Door.....	MM-8-16.1
	Inspection – Door	MM-8-16.2
	Repair – Door.....	MM-8-16.2
	Installation – Door	MM-8-16.2
	Installation – Glass.....	MM-8-16.2
8-5	[Reserved – Original content incorporated into Paragraph 8-4]	
8-6	[Reserved – Original content incorporated into Paragraph 8-2]	
8-7	Seat Belts, Shoulder and Lap Type	MM-8-17
	Removal.....	MM-8-17
	Installation.....	MM-8-17
8-8	Seat Deck Assembly	MM-8-18
	Removal	MM-8-18
	Inspection.....	MM-8-19
	Repair	MM-8-19
	Installation.....	MM-8-19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 8

STRUCTURE

TABLE OF CONTENTS

Paragraph	Description	Page
8-9	Landing Gear	MM-8-19
	Landing Gear Assembly	
	Removal.....	MM-8-19
	Inspection.....	MM-8-21
	Skid Shoes	
	Inspection.....	MM-8-23
	Replacement.....	MM-8-23
	Ground Handling Wheels	
	Operational Description.....	MM-8-23
	Removal.....	MM-8-23
	Installation.....	MM-8-24
	Oleo Struts	
	Removal.....	MM-8-27
	Disassembly.....	MM-8-27
	Inspection.....	MM-8-28
	Assembly	MM-8-28
	Installation.....	MM-8-36
	Landing Gear Fairings (280FX)	
	Removal – Access to Service the Oleo Strut	MM-8-37
	Removal – Access for Oleo Strut Removal.....	MM-8-37
	Inspection.....	MM-8-37
	Assembly – After Oleo Replacement.....	MM-8-37
8-10	Pylon	MM-8-39
	Removal and Installation	MM-8-39
	Inspection.....	MM-8-39
	Repair	MM-8-39
8-11	Baggage Compartment	MM-8-39
	Removal.....	MM-8-39
	Inspection.....	MM-8-41
	Repair	MM-8-41
	Installation.....	MM-8-41
8-12	Tailcone Assembly	MM-8-42
	Removal.....	MM-8-42
	Inspection.....	MM-8-42
	Repair	MM-8-42
	Installation.....	MM-8-42
8-12.1	Tubular Tail Rotor Guard (F-28F Post-1986; 280FX)	MM-8-44
	Removal.....	MM-8-44
	Inspection.....	MM-8-44
	Installation.....	MM-8-45
8-12.2	Tail Rotor Driveshaft Cover (280FX)	MM-8-45
	Cover Opening – Tail Rotor Driveshaft Access.....	MM-8-45
	Inspection.....	MM-8-45
	Cover Closing.....	MM-8-45

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 8

STRUCTURE

TABLE OF CONTENTS

Paragraph	Description	Page
8-13	Torque Tube Extension	MM-8-46
	Removal.....	MM-8-46
	Inspection.....	MM-8-46
	Repair.....	MM-8-46
	Installation.....	MM-8-48
8-14	Horizontal Stabilizers (F-28F Pre-1986)	MM-8-48
	Removal.....	MM-8-48
	Inspection.....	MM-8-48
	Installation.....	MM-8-49
8-15	Horizontal Stabilizers (280F)	MM-8-49
	Removal.....	MM-8-49
	Inspection.....	MM-8-50
	Installation.....	MM-8-50
8-16	Horizontal and Vertical Stabilizers (F-28F Post-1986; 280FX)	MM-8-50
	Removal.....	MM-8-50
	Inspection.....	MM-8-51
	Installation.....	MM-8-51
	Assembly – Endplate.....	MM-8-51
8-17	Airscoop (280FX)	MM-8-59
	Removal – Access (Upper Drive System/Main Rotor Gearbox Removal).....	MM-8-59
	Installation.....	MM-8-59
8-18	Cabin Closeout Panels (280FX)	MM-8-61
	Removal – Left Side Closeout Panel.....	MM-8-61
	Installation – Left Side Closeout Panel.....	MM-8-61
	Removal and Installation – Right Side Closeout Panel.....	MM-8-61

|

INTENTIONALLY LEFT BLANK

SECTION 8

STRUCTURE

NOTE

Section 22 content – supplemental maintenance procedures for models F-28F Post-1986 (S/N 744 and subsequent) and 280FX, has been incorporated into Section 8. Model or S/N effectivity is noted where applicable.

8-1 CABIN

The cabin assembly is constructed of an aluminum sheet metal seat structure which supports an outer cabin shell of reinforced fiberglass. The entire cabin section can be removed from the pylon as a unit

A. Cabin Removal

1. Remove cabin doors and fiberglass seat deck.
2. Remove cowling and disconnect and remove the engine compartment door hinge bracket from cabin.
3. Disconnect and remove air filter housing.
4. Disconnect collective push rod from collective walking beam at the cabin firewall.
5. Disconnect the lateral and longitudinal cyclic push-pull rods at bellcranks on each side of cabin wall.
6. Disconnect the main battery cable inside the engine compartment.
7. Drain fuel from both fuel tanks and remove tanks.

NOTE: Install plugs in fuel line fittings.

8. Disconnect tail rotor control cables at turnbuckle in the engine compartment. See Section 10-7.
9. Disconnect all oil lines, fuel lines, and airspeed static tube at firewall.
10. Disconnect electrical wiring in the engine compartment.
11. Disconnect clutch control cable at turnbuckle in seat structure and at forward clutch cable mount on aft side of firewall. See Section 11-2.
12. Disconnect engine and rotor tachometer cables.
13. Disconnect throttle control cable from injector and pylon mount.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

14. Disconnect mixture control cable from injector and pylon mount.
15. Remove screws connecting fire curtain to firewall.

NOTE: Sealastic bead will peel from firewall to remove.

16. Disconnect fuel shut-off control.
17. Disconnect shoulder harness cables on aft side of cabin back wall and seat belt cables.
18. Disconnect flex hose and control cable from cabin heat duct on aft side of firewall.
19. Support cabin and remove the six cabin attachment bolts. See Figure 8-1 for bolt locations. Lift cabin free of aircraft.

B. Cabin Inspection

1. Inspect the cabin shell for obvious damage, cracks, and the condition and security of the hardware securing the cabin shell to the cockpit bulkhead and cockpit floor.
2. Inspect the cockpit bulkhead and cockpit floor for obvious damage, loose inserts, and the condition and security of the hardware securing the bulkhead to the pylon and the cockpit floor to the keel structure.

C. Cabin Repair

1. Replace damaged or missing hardware.
2. Repair damage to the cabin shell, cockpit bulkhead, or the cockpit floor I/A/W AC 43.13-1B. Contact Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.


D. Cabin Installation

1. Lift cabin and align with pylon mounts. Install the six attachment bolts. Torque bolts. See Figure 8-1.

NOTE: Throttle, mixture and clutch cables must be lined up and guided through firewall.

NOTE: Safety wire the two outboard lower cabin mount after torque.

2. Connect flex hose and cabin heat control cable to duct on aft side of firewall.
3. Connect shoulder harness cables on aft side of cabin.
4. Connect fuel shut-off control cable.
5. Secure fire curtain to firewall using screws and fire barrier sealant CP 25WB+ (3M) or equivalent.
6. Connect mixture control cable and throttle control cable to pylon mounts and injector. See Section 13-12 for proper rigging of the injector and correlator.



NOTE: Some installations may be shimmed at point (B) bottom.

Figure 8-1. Cabin Assembly Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

7. Connect clutch cable at forward pylon mount and at turnbuckle in seat structure. Do a complete clutch cable rigging procedure. See Section 11-1.
8. Connect all electrical wiring in the engine compartment.
9. Connect all oil lines, fuel lines, and air speed static tube at firewall.
10. Connect engine and rotor tachometer cables.
11. Connect tail rotor cables at turnbuckle in engine compartment. Adjust cable tension. See Section 10-7. Check tail rotor rigging per Section 10-1.
12. Install engine compartment door hinge bracket between cabin and bulkhead.
13. Install fuel tanks and connect all fuel lines. Check for leaks after installing fuel.
14. Connect the main battery cable inside engine compartment.
15. Connect the lateral and longitudinal cyclic push-pull rods to bellcranks on each side of cabin wall.
16. Connect the collective push rod to collective walking beam at cabin backwall.
17. Install air filter housing and connections.
18. Check all flight controls for proper operation. Check all items on the Daily Check List and complete a Preflight Inspection. See Section 3 Inspections and Routine Checks.
19. Install cowling and engine compartment doors.
20. Install fiberglass seat deck and cabin doors.

8-2 WINDSHIELDS AND WINDOWS

A. Windshield and Window Inspection

1. Inspect the windshields and windows for cracks, crazing, pits, and scratches.

B. Windshield and Window Repair

1. Damage to the windshields and windows which does not interfere with pilot's line of sight during normal flight and landing attitudes or damage that does not impair structural integrity may be repaired by stop drilling or patching I/AW AC 43.13-1B; however, the windshield or window should be replaced at the earliest opportunity.

C. Windshield Removal (F-28F) (See Figure 8-2)

1. Remove doors.
2. Remove door hinges to provide clearance for windshield installation.

NOTE: Hinge locations must be marked on hinges for proper reinstallation. Hinges will not align for proper fit if positions are altered.




Figure 8-2. F-28F Windshield

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

3. Remove attachment screws around outer edge of windshield.
4. Remove compass from windshield.
5. Cut out and remove center portion of windshield.

NOTE: When cutting center portion, stay approximately 2-3 inches away from cabin frame. Apply two layers of masking tape to cabin adjacent to windshield edge to protect paint.

6. Heat the remaining edge of glass and bonding adhesive using a portable heat gun and peel glass from cabin frame.

NOTE: When bonding adhesive is warm it can be scraped from edge of cabin using a suitable size putty knife.

7. Sand windshield mount area clean and free of old bonding adhesive with a fine sandpaper.

D. Windshield Installation (F-28F) (See Figure 8-2)

1. Clean recessed windshield area of cabin frame with acetone or equivalent.

NOTE: Be sure this area has been sanded smooth and free of old bonding adhesive before wiping with acetone.

2. Position new windshield over cabin and apply tape to temporarily hold windshield in place.
3. Apply 1/4" masking tape following contour of windshield and recessed area of cabin to mark windshield size for cutting.
4. Remove windshield and cut to size on a fine wavy tooth bandsaw or a die grinder with a 1/16 inch cut-off wheel.
5. Sand edges on belt sander for final fit to cabin.

NOTE: Check fit to cabin and re-sand as required.

6. Install windshield and match drill the glass to old screw holes in cabin using a #19 drill or drill new screw holes through windshield and cabin at midpoints between old holes. Countersink holes in windshield with an 82° countersink.

NOTE: Drill bits can be ground to a very sharp point to aid in drilling through plexiglass. Use care when drilling to prevent cracking glass.

7. Drill approximately six or eight holes on upper and lower edge of windshield with a #41 drill for mechanical fasteners (clecos).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

8. Remove windshield. Clean fiberglass recess of cabin with acetone. Lightly sand bonding edge of windshield and clean with acetone.
9. Apply bonding sealant PR-1425 B-2 (or equivalent) to recess in cabin frame using a putty knife. Spread adhesive approximately 1/8" to 3/16" thick.

NOTE: Follow the exact mixing requirements of two-part adhesives and sealants.

10. Install windshield in position and press firmly against adhesive.
11. Temporarily install mechanical fasteners (clecos) to hold windshield in position until PR-1425 B-2 (or equivalent) adhesive is set up.

CAUTION: Allow adhesive to dry approximately 24 hours before installing attachment screws to prevent cracking the glass.

12. Run a #19 drill through screw holes to remove bonding adhesive and install screws into holes. Secure with washers and nuts.

CAUTION: Do not overtorque attachment screws on installation.

13. Remove mechanical fasteners.
14. Install door hinges in position as previously marked in removal procedure.
15. Install compass to windshield as follows: (see Figure 8-2)
 - (a) Install compass to windshield from middle rib of lower door hinges and mark centerline of windshield with a grease pencil.

NOTE: Use cloth type measurement tape if possible to prevent scratching plexiglass.

- (b) Measure up 24½" ± ¼" from bottom edge of windshield and mark a line.
- (c) Clean contact surface of windshield with acetone.
- (d) Apply double back tape (Scotch Brand 4262 Neoprene, or equivalent) to contact area of compass.

NOTE: Tape is not to extend beyond contact surfaces.

- (e) Align top edge of compass to line marked on windshield and press firmly into position. While holding compass on inside have another person rub windshield from outside to remove air bubbles.
- (f) Apply the compass decal over contact surface on outside of windshield.
16. Prepare windshield edges for paint. Repaint outer mount edge.
17. Install doors.

E. Windshield Removal (280F Series) (See Figure 8-3)

NOTE: The 280F windshield consists of two pieces of plexiglass. Windshield halves can be replaced individually.

1. Drill out rivets holding center strip in position and remove strip.
2. Drill out remaining rivets around outer edge of windshield.
3. Cut out and remove center portion of windshield.

NOTE: When cutting center portion, stay approximately 2-3 inches away from cabin frame.

4. Heat the remaining edge of glass and bonding adhesive using a portable heat gun and peel glass from cabin frame.

NOTE: When bonding adhesive is warm it can be scraped from edge of cabin using a suitable size putty knife.

5. Sand windshield mount area clean and free of old bonding adhesive with a fine sandpaper.
6. Remove foam tape from center support brace.

F. Windshield Installation (280F Series) (See Figure 8-3)

1. Clean recessed windshield area of cabin frame with acetone or equivalent.
2. Position new windshield over cabin and apply tape to temporarily hold windshield in place.

NOTE: Use care in aligning windshield to recess in cabin as the plexiglass is formed with a slight indentation along outer edge that must be matched to cabin frame.

3. Apply 1/4" masking tape following contour of windshield and recessed area of cabin to mark windshield size for cutting.
4. Remove windshield and cut to size on a fine wavy tooth bandsaw or a die grinder with a 1/16 inch cut-off wheel.
5. Sand edges on belt sander for final fit to cabin.

NOTE: Check fit to cabin and re-sand as required.

6. Install windshield and match drill to old rivet holes in cabin using a #30 drill, or drill new holes through windshield and cabin at midpoints between old holes.




Figure 8-3. 280F Series Windshield

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

CAUTION: Drill bits can be ground to a very sharp point to aid in drilling plexiglass. Use care in drilling to prevent cracking glass. Do not drill through inner fiberglass interior trim when drilling side and bottom of windshield.

7. Drill approximately six to eight holes through windshield on top and bottom for mechanical fasteners (clecos) using a #41 drill bit.
8. Remove windshield. Clean fiberglass recess of cabin with acetone. Lightly sand bonding edge of windshield and clean with acetone.
9. Apply foam tape to center strip bar of cabin. Use 3M Brand tape #4016 (or equivalent), 1" wide by 1/16" thick.
10. Apply bonding sealant PR-1425 B-2 (or equivalent) to recess in cabin frame using a putty knife. Spread adhesive approximately 1/8" to 3/16" thick.

NOTE: Follow the exact mixing requirements of two-part adhesives or sealants.

NOTE: Do not apply PR-1425 B-2 (or equivalent) to the center strip area.

11. Install windshield in position and press firmly against adhesive.
12. Temporarily install mechanical fasteners (clecos) to hold windshield in position until PR-1425 B-2 (or equivalent) is set up.

CAUTION: Allow adhesive to dry approximately 24 hours before installing rivets to prevent cracking glass.

13. Run a #30 drill through rivet holes to remove bonding adhesive.
14. Drill through all existing rivet holes in plexiglass with a modified #19 drill. See Figure 8-3 for drill modification.

CAUTION: Drill through plexiglass only with #19 drill. Do not drill through fiberglass cabin frame.

15. Apply a small bead of Phenoseal 102 (or equivalent) on each side of windshield center seam and install center strip in position. Secure with rivets.
16. Install and secure rivets in remaining holes.
17. Remove mechanical fasteners (clecos).
18. Prepare windshield edges for paint. Repaint outer mount edge.

G. Overhead and Lower Window Removal (All F/FX)

1. Drill out existing rivets.
2. Remove plexiglass from double backing tape.
3. Remove tape from cabin recessed area.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-10

Rev. 8
Sep 20/17

B. Overhead and Lower Window Installation (All F/FX)

1. Clean recess in cabin with acetone or equivalent.
2. Install double backing foam tape in position. Use 3M Brand tape #4016 (or equivalent), 3/4" wide x 1/16" thick.

NOTE: Install tape with ends meeting at bottom side of window to prevent possible leakage through seam. Do not remove paper backing from outboard side of tape until window has been marked for cutting.

3. Position new plexiglass window over recessed area of cabin and apply masking tape to temporarily hold window in place.
4. Apply 1/4" masking tape following contour of window and recessed area of cabin to mark window size for cutting.
5. Remove window and cut to size on a fine wavy tooth bandsaw or a die grinder with a 1/16 inch cut-off wheel.
6. Sand edges on belt sander for final fit to cabin.

NOTE: Check fit to cabin and re-sand as required.

7. Clean outer edge of window with acetone.
8. Remove paper backing from foam tape and install window in position. Press firmly against tape.
9. Match drill to old rivet holes in cabin using a #30 drill or drill new holes through window and cabin at midpoints between old holes.

NOTE: Drill bits can be ground to a very sharp point to aid in drilling plexiglass. Use care in drilling to prevent cracking glass.

10. Drill through all rivet holes in plexiglass with a modified #19 drill. See Figure 8-3 for drill modifications.
11. Secure window in place with rivets.
12. Prepare window edges for paint. Repaint outer mount edge.

8-4 CABIN DOORS

A. Door Removal (F-28F) (See Figure 8-4)

1. Disconnect lower bungee (1) by removing screw (9) at the forward corner of the door frame.
 - (a) If equipped with a gas spring, remove the safety pin and pull the gas spring off its ball.

2. Pull hinge pins (2) from upper and lower hinges and carefully remove door.

B. Door Inspection (F-28F)

1. Inspect the cabin doors and hinges for condition, damage, and security.
2. Inspect the door latching assembly for condition, damage, and proper operation.
3. Inspect the window and pop-out vent for condition, damage, and security.




Figure 8-4. F-28F Cabin Door

C. Door Repair (F-28F)

1. Repair the door I/A/W AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.
2. Replace the seal strips around the door if deteriorated or damaged. Attach the new seal using trim adhesive 8031 (3M) or equivalent.
3. Replace components of the door latching assembly that are unserviceable.

D. Door Installation (F-28F) (See Figure 8-4)

1. Align door to hinges and install hinge pins (2).
2. Attach lower bungee (1) or gas spring, if equipped, with screw (9) at the forward corner of the door frame.
3. Check operation of the door latch and upper and lower retaining lugs.

E. Door Glass Removal (F-28F) (See Figure 8-4)

NOTE: For installation of door glass on later F-28F model doors (S/N 744 and subsequent), refer to the Enstrom Helicopter Corporation website, 280FX Technical Tips for replacing the door glass. Otherwise, the door should be returned to Enstrom Helicopter Service for glass replacement.

1. Disconnect cables and remove door handle (3).

NOTE: Remove the roll pin from the inboard door handle and separate and remove external door handle.

2. Remove cables (4) and lower bungee (1) from door frame.
3. Mark door hinges (5) as to their position on door frame and remove hinges.

NOTE: Hinges cannot be alternated for upper and lower positions.

4. Remove sliding vent window (6) and snap vents (7).
5. Remove foam strip from outer edge of door frame.
6. Remove screws securing T-molding (8) and remove molding.
7. Remove screws from door glass. Heat bonded area of plexiglass with a portable heat gun and remove glass from door frame.

NOTE: Use care in glass removal to prevent distortion of tubular door frame.

8. Remove excess bonding adhesive from door frame with a putty knife. Sand frame clean.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: When ordering a replacement door glass, be sure to specify if a sliding vent window and/or snap vents are required so they can be installed at the factory.

F. Door Glass Installation (F-28F) (See Figure 8-4)

NOTE: Check fit of door frame to cabin before locating glass on frame.

1. Position new glass on door frame and match drill to screw holes using a #41 drill. Countersink holes using an 82 countersink.

NOTE: Replacement door glass has been rough cut to size. Final sanding of plexiglass to door frame is completed after bonding procedure is done.

2. Remove door glass from frame and clean bonding surfaces of both items using acetone or equivalent.
3. Apply bonding adhesive PR-1425 B-2 (or equivalent) to bonding surface of door frame. Spread adhesive approximately 1/8" to 3/16" thick.
4. Carefully install door glass on door frame.

NOTE: Install enough screws in door glass and frame to hold glass in position. **DO NOT** tighten screws until bonding adhesive is set up (approximately 24 hours).

5. Install screws to secure door glass to frame.
6. Final fit plexiglass to door frame by sanding on belt sander.
7. Install T-molding (8) to door frame and secure with screws.
8. Install foam strip on outer edge of door frame.
9. Install and secure hinges (5) to their previously marked position on door frame.
10. Prepare and repaint door frame.
11. Install and secure door handles (3), cables (4), and latches.
12. Install lower bungee (1) or gas spring at forward corner of door frame, as applicable.
13. Install door on aircraft and check operation of door handle and latch.

G. Door Removal (280F Series) (S/N 2166 and Prior) (See Figure 8-5)

1. Remove screw from door strap (1) on the lower corner of the door.
 - (a) If equipped with a gas spring, remove the safety pin and pull the gas spring off its ball.
2. Remove bolt (2) and spacer (3) from hinge pivot point at top of door.
3. Carefully lift door from cabin frame.





Figure 8-5. 280F Series Cabin Door

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | | |
|-----|---------------------------|-----|--------------------------|
| 1. | Hinge Post | 11. | Screw |
| 2. | Hinge Bushing (hidden) | 12. | Retaining Ring |
| 3. | Clevis Pin | 13. | Cam Roller |
| 4. | Cotter Pin | 14. | Shoulder Screw |
| 5. | Set Screw | 15. | Cam Lever Arm |
| 6. | Door Handle (Interior) | 16. | Lower Bellcrank Assembly |
| 7. | Bushing | 17. | Push-Pull Rod Weldment |
| 8. | Lower Door Cover Assembly | 18. | Upper Bellcrank Assembly |
| 9. | Upper Door Cover | 19. | Lower Dog Pin |
| 10. | Screw | 20. | Upper Dog Pin |

Figure 8-5.1. 280FX Cabin Door

G.1 Door Removal (S/N 2167 and Subsequent) (See Figure 8-5.1)

NOTE: Removal procedures are the same for removing either cabin door.

CAUTION: Support the cabin door when removing the clevis pins to prevent from damaging the doors.

1. Open the door and hold it in the open position.
2. Remove the safety pin from the gas spring and pull the gas spring off its ball.
3. Remove the upper and lower door hinge quick disconnect pins or cotter pins (4) and clevis pins (3), as applicable, and remove the door.

G.2 Door Disassembly – Access to the Latch Mechanism (280FX S/N 2167 and Subsequent)

1. Remove the door (para. G).
2. Loosen set screw (5) to remove the inside door handle (6).
3. Pull off the bushing (7).
4. Remove screws (10) and (11) and remove the lower door cover assembly (8). **DO NOT** remove the two alignment block adjustment screws.
5. Remove screws (10) and (11) and remove the upper door cover (9).

G.3 Door Assembly (280FX S/N 2167 and Subsequent)

1. Install screws (10) and (11) to install the upper door cover. Ensure screw (11) engages the shoulder screw (14).
2. Install screws (10) and (11) to install the lower door cover assembly. Ensure screw (11) engages the shoulder screw (14).
3. Push on the bushing (7).
4. Install the inside door handle (6) and tighten the set screw (5).

H. Door Inspection (280F Series)

1. Inspect the cabin doors, hinges, bronze bushings (Figure 8-5.1, Item 2), and pins for condition, damage, and security.
2. Inspect the door latching assembly for condition, damage, and proper operation.
 - (a) (S/N 2167 and subsequent): For faulty door operation, remove the door bellcrank covers (para. G.2):
 - (1) Inspect the door cam mechanism for missing retaining ring (12), condition of cam roller (13), and condition and security of cam lever arm (15), bellcranks (16) and (18), and push-pull rod (17) attachment fasteners.
 - (b) Inspect the two bellcrank assembly dog pins (19) and (20) for parallel condition.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) If a parallel condition does not exist between the two dog pins (19) and (20), loosen the jam nut(s) on either end of the push-pull rod (17) and turn the rod to align the dog pins (19) and (20). Re-tighten the jam nut(s).
 3. Inspect the window and pop-out vent for condition, damage, and security.
- I. Door Repair (280F Series)
1. Repair the door I/A/W AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.
 2. Replace the seal strips around the door if deteriorated or damaged. Attach the new seal using trim adhesive 8031 (3M) or equivalent.
 3. Replace components of the door latching assembly that are unserviceable.
- J. Door Installation (280F Series)

(S/N 2166 and Prior) (See Figure 8-5)

1. Align bottom pivot peg (4) on lower corner of door with hole in cabin door frame and install door into position.
2. Install spacer (3) and mount hardware in upper hinge. See Figure 8-5 for proper hardware installation.
3. Secure door strap (1) on lower corner of door with screw or install gas spring, as applicable.
4. Check door and door latch for proper operation.

J.1 Door Installation (S/N 2167 and Subsequent) (See Figure 8-5.1)

1. Position the door on the hinges installed on the cabin shell and install the clevis pins and cotter pins.
2. Install the gas spring and the safety pin.
3. Check door and door latch for proper operation.

K. Door Glass Installation (280F Series)

NOTE: Refer to the Enstrom Helicopter Corporation website, 280FX Technical Tips for replacing the door glass. Otherwise, the door should be returned to Enstrom Helicopter Service for glass replacement.

8-7 SEAT BELTS – SHOULDER AND LAP TYPE

A. Lap Belt Removal (Figure 8-6)

1. Remove seat cushions.
2. Disconnect attachment end of the lap belts by applying pressure to the spring loaded "latch", opening it sufficiently to clear the structural attach point as it is lifted.

B. Shoulder Harness Removal (Figure 8-6)

1. Remove the fuel cells (para. 13-10, B, (1)).
2. Remove screws, washers, and nuts (4 places) that attach each shoulder harness to the cabin backwall.

C. Lap Belt Installation

- NOTE:
- a. Lap belts must be connected to the specified structural attach points to insure belt security.
 - b. There are four structural attach points to accommodate two- and three-passenger configurations; (1) left rear cabin wall, (2) right of left center seat beam, (3) right of right center seat beam, and (4) right rear cabin wall.
 - c. Secure the lap belts to the airframe by applying downward pressure on the structural attach point with the "latch" portion of the belt attachment mechanism until it locks in place.

1. Left seat position - install as follows:

- (a) Attach seat belt half with release mechanism to left rear cabin wall structural attach point. See Figure 8-6, Point "A".
- (b) Attach seat belt half with flat tab to structural attach point right of left center seat beam. See Figure 8-6, Point "B".

2. Center seat position (if required) - attach as follows:

- (a) Attach seat belt half with release mechanism to the structural attach point right of left center seat beam. See Figure 8-6, Point "B".

NOTE: Install on right side of left seat position belt.

- (b) Attach seat belt half with flat tab to structural attach point right of right center seat beam. See Figure 8-6, Point "C".

3. Right seat position - attach as follows:

- (a) Attach seat belt half with release mechanism to the structural attach point right of right center seat beam. See Figure 8-6, Point "C".

NOTE: Install on right side of center seat position belt (if installed).

- (b) Attach seat belt half with flat tab to right rear cabin wall structural attach point. See Figure 8-6, Point "D".

D. Shoulder Harness Installation

1. Attach shoulder harness to the cabin backwall with screws, washers, and nuts (4 places).
2. Install the fuel cells (para. 13-10, B, (2)).




Figure 8-6. Seat Belt Attachment

8-8 SEAT DECK ASSEMBLY

A. Seat Deck Removal

1. Remove seat cushions and seat belts.
2. Disconnect cyclic stick canon plugs and remove cyclic boots.
3. Remove screws securing fiberglass cover over pilot's collective stick and remove cover.
4. Remove screws securing fiberglass cover over collective push-pull rod at top of seat deck and remove cover.

5. Remove handles from clutch engagement lever.

NOTE: Handles are screwed together.

6. Release and remove expando pin and remove co-pilot's collective stick.
7. Remove screws from the battery access (or ELT access, if equipped) cover, if installed.
8. Remove screws securing fiberglass seat deck in place and carefully lift seat deck from seat structure.

B. Seat Structure Assembly Inspection

1. Inspect the structure for corrosion, cracks, deformation, evidence of working rivets, and damaged or loose/missing hardware
2. Inspect the pylon attachments for corrosion, damage, proper security of and damage to the attachment hardware.
3. Inspect the cyclic bellcrank brackets (upper cabin mount) at the top backwall structure for corrosion, cracks, deformation, and security (SDB 0126).

C. Seat Structure Repair

1. Replace damaged or missing hardware.
2. Repair damage to the structure I/A/W AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

D. Seat Deck Installation

1. Install fiberglass seat deck over clutch engagement lever and into position. Secure in place with attachment screws.
2. Install co-pilot's collective stick into bellcrank and secure with expando pin.

NOTE: Flip expando pin lever down and check security.

3. Install handles in clutch engagement lever and screw together to secure.
4. Install fiberglass cover over collective push-pull rod at top of seat deck and secure with screws.
5. Install fiberglass cover over pilot's collective stick and secure with screws.
6. Install battery (12V installation only) or ELT (if equipped) access panel and secure with screws, if installed.
7. Install cyclic stick boots and secure the cyclic canon plugs into their receptacles.
8. Install seat belts and seat cushions.

8-9 LANDING GEAR

A. Landing Gear Assembly

1. Landing Gear Removal

- (a) Install sling T-0011 on main rotor hub and hoist helicopter to remove weight from landing gear. See Figure 9-3 in Section 9 for sling installation.




Figure 8-7. Landing Gear to Pylon Attachment

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Remove left and right engine doors and bottom cowling.
- (c) To remove the landing gear assembly as a unit from the pylon, proceed as follows: (See Figure 8-7)
 - 1 Disconnect engine controls, EGT/EDM, heater control and quarter panels.
 - 2 Remove top bolt from pylon mount clamps on cross tubes (4 places).
 - 3 Lower and remove landing gear assembly.
- (d) Remove individual landing gear items as follows: (See Figure 8-8)

NOTE: See individual items B, C, and D for removal or replacement of skid shoes, ground handling wheels, or oleo struts.

- 1 Skid tube (1) - Remove the six attachment bolts from landing gear legs (2). Remove skid tube assembly. Install in reverse order.
- 2 Landing Leg (2) - Remove oleo. Disconnect drag strut (3) from landing gear leg. Remove upper pivot bolt from clamp (8) on cross tube and remove the three lower bolts securing landing leg to skid tube. Remove landing gear leg. Install in reverse order.

2. Landing Gear Inspection

- (a) Cross Tubes:

NOTE: Refer to SDB 0124 for additional inspection criteria for the pylon attachment clamps.

- 1 Cross tubes with bows up to 0.5 inches/12.7mm are serviceable. Replace cross tubes with bends, cracks, or elongated bolt holes
- 2 Replace end caps that are cracked or the bolt holes are elongated. Repair pylon attachment (aft cross tube) or gear leg attachment clamps that are cracked by welding I/AW AC 43.13-1B. Replace pylon attachment (aft cross tube) or gear leg attachment clamps that have elongated bolt holes.

- (b) Landing Gear Legs and Drag Struts:

- 1 Landing gear legs and drag struts that are bent, bowed, or cracked may be repaired I/AW AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.
- 2 Replace landing gear legs and drag struts with elongated bolt holes.

- (c) Skid Tubes:

- 1 Skid tubes that are bent, bowed, dented, or have holes in them are repairable I/AW AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.
- 2 Replace skid tubes with elongated bolt holes.

NOTE: LANDING GEAR BOLTS AT PIVOT POINTS ARE TO BE TORQUED TO 40-60 IN. LBS. TO ALLOW GEAR TO FLEX




Figure 8-8. Landing Gear Assembly Breakdown

B. Skid Shoes

1. Inspection
 - (a) Inspect the skid shoes for cracked or torn mounting straps and for excessive wear.
2. Skid Shoes Replacement (See Figure 8-8)
 - (a) Skid shoes may be replaced by one of the following methods:
 - 1 Jack up landing gear.
 - 2 Install sling T-0011 on main rotor hub and hoist helicopter.
 - 3 With ground handling wheels down, pull down on aft of tailcone.
 - 4 Replace skid shoes (4) or (5) by removal and replacement of the attachment bolts (three forward, two aft) securing them to skid tubes.

C. Ground Handling Wheels

1. Operational Description

Each landing gear skid tube has provisions for easily installed landing gear wheel assemblies. Each assembly has a manually operated over-centering device to lift the skids for installation of the wheels or retract them for flight. The ground handling wheels should be retracted and the helicopter allowed to rest on the skids when the engine run-up is being performed or when helicopter is parked. To raise or lower ground handling wheels, proceed as follows: (See Figure 8-9)

WARNING: Approximately 135 lbs of force is exerted through the wheel bar when raising or lowering wheels. It is important that the wheel bar does not slip off the end of the axle or the operator does not lose his grip on the handle, particularly when removing or replacing the lock pin, or possible injury could result.


- (a) To lower the wheels, the slot in the end of wheel bar should be inserted on the axle with the handle facing forward. Then, keeping the handle aligned on the flats of the axle, apply a constant pressure to the handle and release the retaining pin. An upward and aft lifting motion is applied to the handle until the retaining pin holes line up for pin insertion. Insert pin and remove wheel bar. Keep feet from under skid tubes, stay outside of the skid, and do not straddle during procedure.
 - (b) To raise the wheels the same procedure is used with the exception that the wheel bar is installed with the handle facing aft, and the operator must restrain the wheel bar from rotating downward after the retaining pin is removed.
2. Ground Handling Wheels Removal (See Figure 8-10)
 - (a) Place wheel assembly in retracted position.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Rotate retaining pin ring up from the axle assembly. Remove snap ring (7) and washer (6) from outboard end of axle (4). Pull pin (5) and slide wheel and axle assembly from mount bracket.
 - (c) Remove nut (1) and washer (2) from axle and slide wheel assembly from axle.
3. Ground Handling Wheels Installation (See Figure 8-10)
- (a) Install wheel assembly (3) on axle (4) and secure with washer (2) and nut (1).
 - (b) Inflate tire to 75 psi.


CAUTION: Wheel assembly must be secured on axle before inflating tire to prevent possible separation of the rim.

- (c) Apply lubriplate to axle and slide axle in mount bracket on skid tube with wheel in raised position.
- (d) Install retaining pin (5) and secure with washer (6) and snap ring (7). Rotate retaining pin ring down and around the axle assembly to secure.



WARNING - USE CAUTION WHEN RAISING OR LOWERING WHEELS WITH HANDLE, CARE SHOULD BE TAKEN TO KEEP HANDLE ALIGNED WITH AXLE AND FIRMLY HELD WHILE ENGAGED FOR ROTATION

Figure 8-9. Ground Handling Wheel Operation



CAUTION: WHEEL ASSEMBLY MUST BE SECURED ON AXLE BEFORE INFLATING TIRE TO PREVENT POSSIBLE SEPERATION OF RIM.

Figure 8-10. Ground Handling Wheel Removal and Installation

D. Oleo Struts

1. Oleo Strut Removal (See Figure 8-11)

NOTE: The weight of the aircraft must be removed from oleo struts before strut removal can be accomplished. Install sling T-0011 on main rotor hub and hoist entire helicopter.

- (a) Remove upper and lower attachment hardware from oleo strut at cross tube and landing gear leg.
- (b) Remove oleo assembly.
- (c) Remove bolts securing universal links (1) to oleo strut and remove links.

2. Oleo Strut Disassembly (See Figure 8-12)

- (a) Remove cap from valve (1) and slowly open valve to relieve pressure from oleo strut.
- (b) Remove valve (1) and pour hydraulic fluid from oleo into a pan.
- (c) Use a razor blade or knife to cut the paint line between the seal housing assembly (6) and the cylinder assembly (14) (Figure 8-12).

CAUTION: Do not clamp the cylinder in a vise by the ears at the bottom of the cylinder. Use tool T-0169-1.

- (d) Install tool T-0035 on the seal housing assembly (6) and T-0169-1 between the ears to unscrew the seal housing from the cylinder.
- (e) Slowly pull piston assembly out of cylinder assembly.
- (f) Lay piston shaft assembly with edge of piston (13) on a block of wood, and using a flat punch remove dowel pin (12).

CAUTION: Use care in removing dowel pin to prevent damage to piston (13).

- (f) Remove valve assembly (13) from piston shaft (2).
- (g) Remove rebound rings (11) and spacer (10).
- (h) Slide guide shaft assembly (6) and boot (3) from piston shaft.
- (i) Disassemble guide shaft assembly (6) as follows:
 - 1 Remove O-ring (7) from O.D. of threaded area.
 - 2 Remove O-ring (9) and back-up ring (8) from I.D. of guide shaft assembly.
 - 3 Remove felt wiper (4) from brass guide (5).
 - 4 If brass guide is worn or damaged, it can be removed by tapping out with a nylon drift.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (j) Disassemble valve assembly (13), if required, as follows: (Figure 8-12, View B)

NOTE: Do not disassemble this unit unless damage or wear has occurred to valve (19).

- 1 Remove nuts (15) and washers (16).
- 2 Remove valve pistons (17) and valve springs (18) from shaft (20).
- 3 Carefully press shafts (20) from piston (19).

3. Oleo Strut Inspection

- (a) Inspect the oleos for damage, leakage, proper extension, and freedom of movement.
- (b) When the strut is disassembled inspect in accordance with Table 8-1.

4. Oleo Strut Assembly (See Figure 8-12)

- (a) Assemble piston assembly (13), if required, as follows: (See Figure 8-12, View B)

- 1 Carefully press shafts (20) into the piston (19).

CAUTION: If excessive pressure is used to press shafts into the piston, damage to the valve area of the piston can result.

- 2 Install valve pistons (17) and springs (18) on the shafts.
- 3 Install washers (16) and nuts (15).
- 4 Adjust the valve and spring length to $1.60'' \pm .010''$. Measurement is taken from the inner base of the piston (19) to the outboard edge of the valve piston (17). See Figure 8-12, Valve Setting Dimension.

NOTES:

1. VALVE ORIENTATION: FORWARD OLEOS - VALVE FACES AFT
REAR OLEOS - VALVE FACES AFT
2. AGRICULTURE AND FLOAT SHIP: REAR OLEO - VALVE FACES FORWARD




Figure 8-11. Oleo Strut Installation




Figure 8-12. Oleo Strut Assembly

|

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 8-1. Oleo Strut – Inspection

Part No.	Fig. & Item No.	Part Name	Inspect	Serviceable Limits	Repair Limits	Repair or Action
AN 6287-1 MS28889-2	Fig 8-12 Item 1	Valve	Check valve o-rings for cracks or tears	None allowed	Not repairable	Replace o-rings
28-17146	Fig 8-12 Item 2	Piston Shaft	Shaft dia. 1.2495 to 1.2515	-.0005	-.0001	Return to factory for re-chrome and grind
			Check for nicks	None allowed	Not repairable	Replace piston shaft
			Dowel pin hole dia. .2490 to .2495	+.0005	Not repairable	Replace piston shaft
			Threaded boss – no crossed or missing threads	None allowed	Not repairable	Replace piston shaft
28-17158	Fig 8-12 Item 3	Oleo Boot	Check for cracks or tears	None allowed	Not repairable	Replace boot
28-17144	Fig 8-12 Item 6	Guide Shaft Assembly	Threads – no crossed or missing threads	None allowed	Not repairable	Replace guide shaft
			Brass guide bore dia. 1.256 to 1.258	+.002	Not repairable	Replace brass guide (Part Number 28-17153)

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-32

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 8-1. Oleo Strut – Inspection

Part No.	Fig. & Item No.	Part Name	Inspect	Serviceable Limits	Repair Limits	Repair or Action
28-17149	Fig 8-12 Item 10	Spacer	Check for nicks and scratches	None allowed	.010 deep	Polish and blend
28-17151	Fig 8-12 Item 11	Rebound Rings	Check for cracks or tears	None allowed	Not repairable	Replace rings
28-17147	Fig 8-12 Item 12	Dowel Pin	O.D. dia. -.2505 to .2495	-.0002	Not repairable	Replace pin
28-17140	Fig 8-12 Item 14	Cylinder Assembly	Bore dia. -1.7655 to 1.7645	+0.001	Not repairable	Replace cylinder
			Threads – no crossed or missing threads	None allowed	Not repairable	Replace cylinder
			Mount holes in ears .312 diameter	+0.001	Not repairable	Replace cylinder
28-17145	Fig 8-12 Item 19	Piston	O.D. dia. -1.763 to 1.762	-.001	Not repairable	Replace piston
			Pin hole .2495 to .2490	+0.002	Not repairable	Replace piston
			Check for scratches in O.D.	None allowed	.002 deep	Polish to remove with very fine sandpaper or emery cloth

NOTE: All O-rings should be replaced when rebuilding oleo strut assembly.

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-33

Rev. 8
Sep 20/17

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(b) Assemble the guide shaft assembly (6) as follows:

- 1 Press brass guide (5) into position if previously removed
- 2 Install felt wiper (4) into the brass guide (5).
- 3 Install O-ring (7) on the O.D. of the guide shaft (threaded end).
- 4 Install back-up ring (8), then O-ring (9) into the groove in the I.D. of the guide shaft (threaded end).

CAUTION: The convex side of the back-up ring (8) must face toward the O-ring (9).

(c) Install oleo boot (3) on the piston shaft (2), if required.

(d) Lubricate both ends of the guide shaft assembly in a pan of hydraulic fluid (MIL-PRF- 5606) to provide lubrication for assembly and install the assembly on the piston shaft (2).

(e) Install spacer (10) on the piston shaft (2).

CAUTION: The flanged end of spacer faces toward threads of guide shaft assembly (6).

(f) Install rebound rings (11) - (5 each) on the piston shaft (2).

CAUTION: Notches in the rebound rings must be staggered.

(g) Align the flow passage port on the inner edge of the piston assembly (13) to the flow passage hole in the piston shaft (2) and install the piston assembly.

(h) Secure valve to the piston shaft with dowel pin (12).

CAUTION: The ends of the dowel pin must be seated below the O.D. surface of the piston to prevent possible binding on installation in the cylinder assembly.

(i) Slide the guide shaft assembly (6) and the rebound rings (11) up against the piston (13). Keep the rebound rings staggered.

(j) Clamp the cylinder assembly (14) in a vise using tool T-0169-1 in an upright position. Fill the cylinder to the base of the threads with hydraulic fluid (MIL-PRF-5606).

CAUTION: Do not clamp the cylinder in the vise by the ears at the bottom of the cylinder. Use tool T-0169-1.

CAUTION: Notches in the rebound rings must be staggered.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: The piston must be inserted into the cylinder assembly slowly to allow the hydraulic fluid to work through the staggered notches of the rebound rings and the flow passage in the piston assembly.

- (k) Install the piston and guide shaft assembly into the cylinder assembly. Slowly push the piston to the base of cylinder assembly (collapsed position).

NOTE: The guide shaft assembly will be torqued in a later step.

- (l) Hand tighten the guide shaft assembly (6) to the cylinder assembly (14). Make an index mark from the guide shaft assembly to the cylinder assembly.
- (m) Install and secure oleo valve (1). Safety wire (MS20995C32) valve to mount flange of piston shaft.
- (n) Loosen the air valve.
- (o) Attach one end of a clear plastic hose to the oleo valve and the other end in a container of MIL-PRF-5606.
- (p) Open the air valve. Slowly pump the strut in and out until the hose is free of air bubbles when compressing the oleo assembly.
- (q) Fully collapse the strut, tighten the air valve, and remove the hose.
- (r) Torque the guide assembly using T-0169-1. Using the index mark, torque the guide assembly to the cylinder assembly by turning the index mark on the cylinder assembly approximately ¼ inch past the index mark on the guide assembly.

NOTE: The oleo may be pressurized before or after installation in the helicopter. (If the oleo is not installed, pressurize to 200 psi (1,379 kPa) and check for leaks.)

- (s) Connect the nitrogen pressure line to the oleo valve. Set the nitrogen pressure regulator to 400 psi (2,758 kPa). Remove the oleo from the vise and remove tools T-0035 and T-0169-1.

WARNING: The piston shaft will extend when the oleo valve is opened.

- (t) Slowly open the oleo valve and allow the oleo to fill until the piston shaft is fully extended and the oleo pressure has equalized to the regulator pressure. Close the oleo valve.
- (u) Close the nitrogen tank valve, set the regulator pressure back to zero, and disconnect the nitrogen pressure line from the oleo valve.
- (v) Install the valve cap.
- (w) Inspect the oleo for leaks.

5. Oleo Strut – Installation (see Figure 8-11)

NOTE: Helicopter must be jacked or hoisted with a sling for oleo strut installation.

- (a) Lubricate the attach bolt hardware with LPS 2, ACF 50, or MIL-PRF-81322 grease and install while wet.
- (b) Place a light washer (2) on each side of universal link (1) and install between mount ears on oleo strut (2 places). Secure in place using bolt (5), light washers (3) and nut (4) (Figure 8-11). Note there is no washer under the head of the top inboard attachment bolt (P/N 28-17135-11).
- (c) Place a light washer (2) on each side of universal link (1) and install the oleo assembly between mount ears on cross tube. Secure in place using bolt (5), heavy washers (3) and nut (4). Torque as follows:

NOTE: Install oleo struts with valves facing aft. See the following exception: Agriculture and float ships require rear oleo valves to face forward.

- 1 Connect a spring scale to the bottom hole in the bottom universal link and torque the top attachment hardware until it requires 2 lb force to swing the oleo strut assembly in and out and fore and aft.
- 2 Use a beam type in/lb torque wrench to record the torque on the nut that is installed on the bolt facing aft.
- 3 Place a light washer on each side of the universal link and connect the bottom universal block to the landing gear leg.
- 4 Remove the hardware connecting the top of the oleo to the cross tube. Set the hardware aside in the same position and order for reinstallation.
- 5 Connect the spring scale to the top hole in the top universal link and torque the attachment hardware at the bottom universal block connections with a required 2 lb drag as in step 3 above.
- 6 Reinstall the top universal link to the cross tube. Ensure the hardware is installed in the position and order as previously installed.
- 7 Tighten the nut to the torque setting recorded in step 4.

6. Service the oleos in accordance with Section 4-20.

E. Landing Gear Fairings (280FX)

280FX models are equipped with landing gear fairings on the oleo struts and landing gear legs. These fairings are made of aluminum and fiberglass and are clamped onto the landing gear assembly. To check for proper strut extension, the helicopter should be sitting on level ground. The struts should then be leveled by rocking the helicopter by pushing up and down slightly on the tail cone. For the checking method, see Section 4-20; for proper inflation, see Section 4-20, Item A.

NOTE: For a float installation, the complete fairing assemblies must be removed. Prior to mount clamp removal, their position should be marked for ease of reinstallation.

1. Removal – Access to Service Oleo Strut
 - (a) Remove 3 screws (9) from upper flex boot (6) lower end.
 - (b) Lift flex boot (6) upward to expose oleo valve for required servicing see Section 4-20 Item 1.
2. Removal – Access for Oleo Strut Removal
 - (a) Proceed with paragraph 1, steps (a) and (b).
 - (b) Remove 2 screws (10) front and back, top and bottom of oleo fairing (2).
 - (c) Slip rubber boot (4) at bottom of fairing (2) downward to clear attaching screws.
 - (d) Remove screws (5) from trailing edge of fairing (2).
 - (e) Spread fairing (2) carefully to clear oleo and remove from forward side.
 - (f) Remove 4 screws (7) and bolt (8) from lower fairing (1) or (3).
 - (g) To remove forward fairing (1) carefully spread to clear gear and oleo remove from forward side.
 - (h) To remove aft lower fairing (3) carefully spread to clear gear and oleo and slip forward on drag strut.
 - (i) Remove oleo as described in Section 8-9, paragraph D.
3. Inspection
 - (a) Check for cracked or damaged components and replace as required.
 - (b) Check for missing nut plates and screws replace as required.

4. Assembly – After Oleo Replacement
 - (a) Reverse procedures in paragraph 2 and paragraph 1.
 - (b) Check for proper security.




Figure 8-12.1. Landing Gear Fairings (280FX)

8-10 Pylon

A. Pylon Removal and Installation

The pylon assembly supports all major structural and drive train components of the helicopter. The removal and installation of the pylon is accomplished by completing the removal and installation procedures for the following items:

- | | | |
|-----|-------------------------|------------------|
| (1) | Cabin Assembly | See Section 8-1 |
| (2) | Tailcone Assembly | See Section 8-10 |
| (3) | Main Rotor Transmission | See Section 11-6 |
| (4) | Powerplant | See Section 13-2 |
| (5) | Landing Gear | See Section 8-9 |

B. Pylon Inspection

Inspection is limited to a field survey of the pylon condition. Visually inspect all members of the pylon for the following:

- (1) Cracks and dents
- (2) Integrity of finish
- (3) Evidence of corrosion
- (4) Security of welded joints
- (5) Scuffing and abrasion

C. Pylon Repair

Damage to the pylon section tubes can be repaired in accordance with FAR 43. Special care must be taken during such repairs as not to distort the structure. Remove minor surface corrosion and paint the area using MIL-PRF-23377 primer or equivalent. Repair limit $\leq 10\%$ wall thickness (e.g., .0035" for a .035" thick wall).

8-11 Baggage Compartment

A. Baggage Compartment Removal (See Figure 8-13)

1. Remove baggage compartment door as follows: (See Figure 8-13, View A)
 - (a) Remove panel (1) from kick-in steps.
 - (b) Release fastener screws (2) on upper cowling.
 - (c) Remove the two screws (3), washers, and nuts from upper hinge pin post at top right corner of baggage compartment.
 - (d) Turn key latch and open door.
 - (e) Lift upper cowling to slide it from pivot pins on door and remove door assembly.
2. Remove upper and side cowling.
3. Remove sheet metal flanges (4) from the right side, outboard edges of the baggage compartment.




Figure 8-13. Baggage Compartment Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4. Remove the two attachment screws (5) securing baggage compartment to pylon.
5. Remove attachment bolt (6) from lower left aft corner of baggage compartment.
6. Remove bolt (7) from mount strap on lower left forward corner of baggage compartment.
7. Carefully slide baggage compartment out of pylon structure.

B. Baggage Compartment Inspection

1. Inspect the baggage compartment shelf and bulkheads for obvious damage, loose inserts, and the condition and security of the hardware.
2. Inspect the mounting brackets for damage and security.

C. Baggage Compartment Repair

1. Replace damaged or missing hardware.
2. Repair damage to the baggage compartment shelf, bulkheads, or the mounting brackets I/A/W AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

D. Baggage Compartment Installation (See Figure 8-13)

1. Slide baggage compartment into pylon structure.
2. Install bolt (6) in lower left aft corner of baggage compartment. Torque bolt and safety using .032 safety wire.
3. Install bolt (7) through mount strap and baggage compartment at lower left forward corner. Torque bolt.
4. Install screws (5) securing front of baggage compartment to pylon.
5. Install the sheet metal flanges (4) to front edges of baggage compartment and secure with screws.
6. Install upper and side cowling.

NOTE: Do not secure the fasteners (2) on right side of upper cowling until baggage compartment door has been installed.

7. Lift upper cowling slightly and install baggage compartment door into position. Secure fastener screws (2) in upper cowling.
8. Install kick-in steps panel (1).
9. Close baggage compartment door and check key latch operation.

8-12 Tailcone Assembly

A. Tailcone Removal (See Figure 8-14)

1. Remove wrap-around cowling.
2. Disconnect flex coupling at forward end of tail rotor drive shaft. See Section 10-6, Drive Shaft and Couplings for correct procedure.
3. Remove tach drive cover and O-rings.
4. Disconnect static line from bulkhead fitting (1) on lower right side of tailcone.
5. Disconnect strobe wires (2) at forward end of tailcone.
6. Remove quick disconnect at antenna and rotating beacon, if so equipped.
7. Disconnect the tail rotor cables (3) at control brackets on tail rotor transmission. Attach a string to each individual cable and pull cables through fair leads to forward portion of tail cone assembly. For later ships with pulley fairleads at aft bulkhead, remove inspection panel for access and remove cotter keys from pulleys.

NOTE: Disconnect strings from cables and allow them to remain routed through tailcone to facilitate installation upon assembly of tailcone assembly to pylon.

8. Place two supporting fixtures (4) under fuselage of tailcone to support it during removal. Remove the three attachment bolts (5) and washers (6) securing tailcone to pylon and remove tailcone.

NOTE: If any shims are found they must be used at same points with new tailcone. If the tailcone was replaced, the tailcone alignment must be checked and shimmed accordingly.

NOTE: Use care in removal procedure to prevent possible damage to tail rotor assembly and/or transmission.

B. Tailcone Inspection

1. Inspect the tailcone for buckling, corrosion, cracks, dents, and working rivets.

C. Tailcone Repair

1. Repair damage to the tailcone I/A/W AC 43.13-1B. Contact The Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

D. Tailcone Installation (See Figure 8-14)

NOTE: Realignment is required for a new tailcone installation. Refer to the Technical Tips Work Aid Document (WAD) link at <http://enstromhelicopter.com/wp-content/uploads/2016/11/Tailcone-Alignment-Work-aid-1.pdf>.

1. Align tailcone to pylon mount and install bolts (5), washers (6), and shims if used (3 places). Torque bolts to 240 in-lbs and safety with .032 safety wire.




Figure 8-14. Tailcone Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Tailcone installation requires a person at the aft end to support the tailcone and two people on the forward end to lift and align the tailcone to the pylon.

2. Connect previously routed strings to tail rotor cables (3) and pull cables back through fair leads to aft end of tailcone. Connect cables to tail rotor control brackets on transmission.

NOTE: Check cable tension and adjust if required. See Section 10-7, Tail Rotor Cables.

3. Install quick disconnects at antenna and rotating beacon if so equipped.
4. Connect strobe wires (2) at forward end of tailcone.
5. Connect static line to bulkhead fitting (1) on forward end of tailcone.
6. Install O-rings on tach drive assembly and install tach drive cover.
7. Connect flex coupling at forward end of tail rotor drive shaft. See Section 10-6, Drive Shaft and Couplings.
8. Inspect all wires, cables, and attachment points for security.
9. Install wrap-around cowling.

NOTE: If any area of tail rotor assembly, tail rotor drive shaft, or tail rotor transmission was worked on, see Section 10 for correct installation procedures.

8-12.1 TUBULAR TAIL ROTOR GUARD (F-28F, 280FX)

A. Tail Rotor Guard Removal (See Figure 8-12.2)

1. Remove bolt (13) and associated hardware (14) & (15), remove clamp (12).
2. Remove bolts (16) and (23) with associated hardware (17) & (18).
3. Remove the tail rotor guard assembly (11).

B. Tail Rotor Guard Inspection

1. Inspect tail rotor guard for cracks or other damage.
2. Inspect end fittings for loose or sheared rivets.
3. Inspect end fittings for elongated holes or other damage.
4. Check retention bolts for excessive wear and or thread damage.
5. Inspect security of chafe pads (24) & (25) for tail guard protection.

NOTE: Some isolated cases of water have been found inside of the tail rotor guard assembly, if this condition is present, a 1/8 inch diameter hole may be drilled in the lowest point of tube for drainage.

C. Tail Rotor Guard Installation

1. Position tail rotor guard in forward upper fitting and install bolt (23) and hardware.
2. Install clamp (12) and bolt (13) with associated hardware.
3. Position aft tail rotor guard fitting into tail rotor gear box and install bolt (16) with required hardware, torque all three bolts (13), (16) and (23).

8-12.2 TAIL ROTOR DRIVESHAFT COVER (280FX)

The tail rotor driveshaft cover consists of four pieces of formed aluminum which are attached to the tailcone. This cover helps protect the driveshaft and the bearings from the weather, and also helps streamline the tailcone. The aftmost section of the cover is held in place with two screws and two quarter-turn fasteners. The three forward sections are held in place by hinges on the right side and quarter-turn fasteners on the left side. This provides easy, fast removal of the driveshaft cover for inspection and servicing the driveshaft and bearings. (See Figure 8-14.1.)

A. Cover – Opening for access to the tail rotor drive shaft

1. Unfasten the ¼ turn fasteners (1) thru (4).
2. Lift section (7) up from left side and over.
3. Repeat same procedure for section (8) and (9).

NOTE: This will allow the required access to lubricate the tail drive bearing pillow blocks; the aft two pillow blocks are accessible without removing section (10).

4. Removal of the aft section (10) for complete tail rotor drive shaft exposure can be accomplished by unfastening item (5) both sides and by removing screw (6) both sides.

NOTE: With covers in the condition noted in (1) through (4) allows for complete tail rotor drive removal, if required.

B. Inspection – Cover assembly only (for other requirements, see Sections 4 and 10-6)

1. Check for cracks and missing or damaged fasteners, repair and or replace as required.

C. Cover – Closing

1. Reverse procedures as noted items (4) through (1), paragraph A.
2. Check final security after closing.

8-13 TORQUE TUBE EXTENSION

A. Torque Tube Removal (See Figure 8-15)

1. Disconnect the tail rotor cables and remove the tail rotor assembly and gearbox. See Section 10-5, Tail Rotor Gearbox Removal

NOTE: The tail rotor assembly and gearbox can be removed as a unit.

2. Remove the tail rotor guard (1) to provide clearance for torque tube removal.

NOTE: The tail rotor guard on the 280F series helicopter can remain attached as it does not obstruct torque tube removal.

3. Remove the left horizontal stabilizer to provide access to the inspection plate. See Section 8-14 through 8-16, Stabilizer Removal, as applicable.

NOTE: The stabilizer on the F-28F, post 1986, and 280F series helicopter is mounted forward of the inspection panel and does not require removal.

4. Remove the attachment bolts from aft pillow block (2).
5. Remove the inspection panel (3).
6. Remove the three attachment bolts (4) from forward end of the torque tube inside tailcone. Access is gained through the inspection panel.
7. Remove the bolts from torque tube clamp (5) (4 places). Remove the torque tube (6) by pulling aft with a slight rotating action.

B. Torque Tube Extension Inspection

1. Inspect the extension tube for corrosion, cracks, dents, nicks, scratches, elongated bolt holes, condition and security of the nutplates installed in the end of the tube, and security of the installation.
2. Inspect the extension tube mounting clamp for condition, damage, and security.

C. Torque Tube Extension Repair

1. Corrosion, nicks, and scratches not exceeding 0.008 inch/.2 mm may be polished out. Replace damaged nut plates. Replace the extension tube if cracked, damage exceeds 0.008 inch/.2 mm, or the tail rotor transmission screw holes are elongated.
2. Replace the mounting clamp if cracked or damage makes it unserviceable.
 - a) The mounting clamp is riveted to the aft bulkhead. It is common for the attachment rivets to get loose and smoke. If necessary, the rivets may be replaced by AN525-8-10 or MS27039-() equivalent structural screws and heavy washers. Note: Ensure grip length extends through the clamp mount and bulkhead.




Figure 8-14.1 Tail Rotor Driveshaft Cover (280 FX)




Figure 8-15. Torque Tube Extension

D. Torque Tube Extension Installation

1. Apply Lubriplate 630-AA (MIL-PRF-81322) to the forward end of torque tube (6) and slide tube into tailcone mount. Install bolts (4) through the mount and into the torque tube. Tighten bolts.
2. Install the four attachment bolts into torque tube clamp (5) and torque bolts (50-70 in-lb/5.6-7.9 Nm).

CAUTION: Excessive torque on the torque tube clamp bolts can deform the torque tube.

3. Install the attachment bolts in the aft pillow block (2). Tighten bolts and safety wire (MS20995C32).
4. Install the tail rotor gearbox and the tail rotor assembly as a unit. See Section 10-5 for Gearbox Installation.
5. Install and secure inspection panel (3).
6. Connect and secure the tail rotor cables to the control bracket. See Section 10-7, Tail Rotor Cables.

NOTE: Check that the cable tension is 35-40 lbs.

7. Install the left horizontal stabilizer on F-28F model helicopters. See Section 8-14 or 8-16, Stabilizer Installation, as applicable.
8. Install and secure the tail rotor guard (1) on F-28F and 280 FX model helicopters.
9. Check tail rotor rigging. See Section 10-1, Tail Rotor Assembly.
10. Inspect all connections for security.

8-14 HORIZONTAL STABILIZERS (F-28F Pre-1986)

A. Stabilizer Removal (See Figure 8-16)

1. Remove screw and washers from tab (1) in the aft end of the left hand stabilizer (4).
2. Remove bolts (2) from the left hand stabilizer (5) and spar (3).
3. Slide stabilizer from the spar.
4. Repeat steps 1 through 3 to remove the right hand stabilizer (6).
5. Remove access panel (7) on the left side of tailcone.
6. Remove bolt (4) which secures the spar (3) to the left side spar fitting and slide the spar from the tailcone. spar should be marked to indicate relative location for correct reinstallation and matching to stabilizer mount holes.

B. Stabilizer Inspection (F-28F)

1. Inspect in accordance with Table 8-2.

NOTE: If either stabilizer requires replacement, it shall be necessary to install a new spar, as stabilizers are match-drilled to spar on installation.

C. Stabilizer Installation (F-28F) (See Figure 8-16)

1. Apply lubriplate or equivalent to the spar (3) and slide the spar into the tailcone spar mounts.

NOTE: Install the spar with mount hole for the bolt (4) to the left side of the tailcone.

2. Align bolt hole in the spar with hole in the spar mount located inside the tailcone inspection panel and install bolt (4). Torque bolt.
3. Install and secure access panel (7) on the left side of the tailcone.
4. Apply lubriplate or equivalent to the O.D. of the spar extending from each side of the tailcone.
5. Slide stabilizers (4) and (5) onto the spar (3).
6. Align bolt holes in the stabilizer to the holes in the spar and install bolts (2) in each stabilizer. Torque bolts.

NOTE: When installing a new stabilizer and spar, proceed as follows:

- a) Lubricate and install spar in the tailcone. Secure with bolt (4).
 - b) Lubricate O.D. of the spar and slide the stabilizer in position.
 - c) Align pre-drilled pilot holes (#41 drill size) in the stabilizer to pilot holes in the spar.
 - d) Drill through stabilizer and spar in the pilot hole positions with a #12 drill (.189 diameter).
 - e) Install bolts (2) and torque.
7. Shim between the aft tab (1) and the tailcone with washers and secure with screw.

NOTE: Shim thickness (washers) to equal gap between the inboard end of the stabilizer and tailcone. This dimension may vary from side to side.

8-15 HORIZONTAL STABILIZERS – 280F

A. Stabilizer Removal (280F) (See Figure 8-17)

1. Remove screw and washers from tab (1) in aft end of stabilizer.

2. Remove bolts (2) securing stabilizer to spar.
3. Slide stabilizer off of spar to remove.
4. Separate strobe wires at quick disconnect points to allow complete removal.

B. Stabilizer Inspection (280F)

1. Inspect in accordance with Table 8-3.

C. Stabilizer Installation (280F)

1. Apply lubriplate or equivalent to spar on each side of tailcone.
2. Attach strobe wires at quick disconnect points and slide stabilizer onto spar.
3. Align bolt holes in stabilizer to holes in spar and install bolts (2). Torque bolts.
4. Shim between the aft tab (1) and the tailcone with washers and secure with screw.

NOTE: Shim thickness (washers) to equal gap between inboard end of stabilizer and tailcone. This dimension may vary from side to side.

8-16 HORIZONTAL AND VERTICAL STABILIZERS (F-28F Post-1986; 280FX)

The horizontal stabilizers are aluminum semi-monocoque construction. The vertical endplates are constructed from fiberglass over foam cores, with the anticollision and navigation lights mounted on the outboard side of each end plate. (Ref. Figure 8-18)

A. Stabilizer Removal

1. Remove trailing edge tab screw (6) and washer (7).
2. Remove one through bolt (8) at the outermost end of the spar (3) and washer (9) and nut (10).
3. Loosen the two internal wrenching bolts (20) located under the inboard removable skin plugs (21) on the underside of the stabilizer.
4. Slide stabilizer (4) or (5) about 3 to 4 inches for clearance to disconnect strobe (19) and navigation light wiring.
5. Remove stabilizer.
6. Repeat steps (1) through (4) for removal of opposite assembly.
7. Spar removal (3) open access panel on right side of tail cone aft of spar.
8. Loosen spar clamp bolts (1) at 2 locations.
9. Slide spar (3) outward to remove, note spar should be marked to indicate relative location for correct reinstallation and matching to stabilizer mount holes. Mark with ink brush pen only - do not scribe.

B. Stabilizer Inspection

NOTE: If either stabilizer requires replacement, it shall be necessary to install a new spar, as the stabilizers are match-drilled to the spar on installation.

1. Inspect in accordance with Table 8-4.

C. Stabilizer Installation

1. Apply Lubriplate 630-AA (MIL-PRF-81322) to the spar (3) and slide the spar into the tail cone spar mounts.
2. Install the right hand stabilizer (5) by sliding it on the spar (3) close to the tail cone.
3. Connect the wiring for the navigation lights and slide the stabilizer completely onto the spar.
4. Slide the stabilizer on completely aligning the spar and stabilizer holes for the through bolt (8). Install the bolt (8) through the stabilizer and spar and tighten.
5. Position the spar and the stabilizer until the trailing edge tab fitting is in alignment with the retainer nut plate in the tail cone and the aft tab screw can be installed.
6. Install screw (6) and washer (7).
7. Install the spar clamp mount bolts (1) at two places, torque (50-70 in-lb/5.6-7.9 Nm), and safety wire.
8. Install the screws (20) and washers (26) on underside, and tighten.

NOTE: In some cases an additional washer (7) shim may be required under fitting to reduce bending.

9. Install access panel on tail cone.
10. Install left hand stabilizer assembly by repeating steps 2, 3, 4, 5, 6, and 8.
11. Check bolts and screws for proper torque and security. Unless specified otherwise, use standard torque.

D. Endplate Assembly

NOTE: If endplate is damaged and removal is required it can be accomplished as follows:

1. Remove strobe light assembly, disconnect wiring.
2. Remove (10) number 10 screws and remove endplate assembly.
3. Reinstall by reversing steps (2) and (1).

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 8-2. Horizontal Stabilizer (F-28F Pre 1986, S/N 743 and Prior) – Inspection

P/N	Fig. 8-16 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-20100	5 & 6	Horizontal Stabilizer	Stabilizer Bushings 1.130 dia. ± .001	+ .001	Not Repairable	Replace bushing
			Bolt holes – .189 dia. ± .005	+ .002	Not Repairable	Replace stabilizer
			Stabilizer skin – check for cracks	(See Note)	(See Note)	(See Note)
			Sheet metal (See Note)			
28-11222	3	Cross Spar	O.D. .1.125-1.129 dia.	-.0005	Not Repairable	Replace spar
			Bolt holes - .189 dia. ± .005	+ .002	Not Repairable	Replace spar
			Spar surface – check for nicks, scratches, cracks	None allowed	Not Repairable	Replace spar

NOTE: Structural repairs to be made in accordance with AC 43.13-1B. Contact the Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-53

Rev. 8
Sep 20/17

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 8-3. Horizontal Stabilizer (280F) – Inspection

P/N	Fig. 8-17 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
280-200003	3 & 4	Horizontal Stabilizer	Bolt holes – .189 dia. ± .005	+ .002	Not Repairable	Replace stabilizer
			Stabilizer skin – check for cracks	(See Note)	(See Note)	(See Note)
			Strobe lights – check for cracks in lens cover	None allowed	Not Repairable (See Note)	Replace lens cover
			Sheet metal (See Note)			
280-200000	Not Illustrated	Spar	Bolt holes - .189 dia. ± .005	+ .002	Not Repairable	Replace spar
			Spar surface – check for nicks, scratches, cracks	None allowed	Not Repairable	Replace spar

NOTE: Structural repairs to be made in accordance with AC 43.13-1B. Contact the Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 8-4. Horizontal Stabilizer (F-28F Post-1986 and 280FX) – Inspection

P/N	Fig. # Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-20119-1/-2	Figure 8-18 Item 3	Horizontal Stabilizer (Bolt Mounts)	Stabilizer Bushings 1.130 diam. ± .001	+ .001	Not Repairable	Replace bushing
			Bolt holes – .189 dia. ± .005	+ .002	Not Repairable	Replace stabilizer
28-20119-3/-4	Figure 8-18	(Bolt Mount and Clamps)	Stabilizer skin – check for cracks	None allowed	Repairable (Note)	Replace stabilizer
			Fitting cracks – (sheet metal)	(See Note)	(See Note)	(See Note) As required, replace fittings
			End Plate Damage	None allowed	Not repairable	Replace Endplate
28-11222	Figure 8-18 Item 3	Cross Spar	O.D. -1.125/1.129 diam.	- .0005	Not Repairable	Replace spar
			Bolt holes – .189 dia. ± .005	+ .002	Not Repairable	Replace spar
			Spar surface – check for nicks, scratches, cracks	None allowed	Not Repairable	Replace spar
			Corrosion Pits	- .005 in depth		Blend out and protect

NOTE: Structural repairs to be made in accordance with AC 43.13-1B. Contact the Enstrom Helicopter Corporation Customer Service for detailed damage and repair limitations.

* All dimensions are in inches.


UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-55

Rev. 8
Sep 20/17

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



NOTE: Shim with washers to equal gap between stabilizer and tailcone.


Figure 8-16. Horizontal Stabilizer Installation (F-28F Pre-1986)

MM-8-56

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



NOTE: Shim with washers to equal gap between stabilizer and tailcone.

Figure 8-17. Horizontal Stabilizer Installation (280F)

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-8-57

Rev. 8
Sep 20/17




Figure 8-18. Tubular Tail Rotor Guard and Vertical Stabilizers (F-28F Post-1986; and 280FX)

MM-8-58

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 8
Sep 20/17

8-17 AIRSCOOP (280FX)

The airscoop comprises three separate pieces which are fiberglass construction. These include a nose piece which is attached to the cabin roof, a center duct which is mounted to the top of the fuel tanks, and a large airscoop which is mounted on the wraparound cowl behind the transmission. This airscoop funnels the cooling air around the transmission and into the cooling fan. The large airscoop blends into the tail rotor driveshaft cover. (Ref. Figure 22-1)

A. Removal – For Access to the Upper Drive System or for Main Rotor Gearbox Removal

1. Remove side cowl (9) and opposite side panel (10) then remove 5 each screws (4) on the forward section of airscoop (6) and lift airscoop off.
2. Remove screws (2) 4 places from center duct (7) and nose piece (8).
3. Remove screws (3) from either side of the center duct and remove.

NOTE: The nose piece (8) need not be removed, the assembly should be inspected for damage and/or missing fasteners.

B. Installation

1. Install in reverse order (3) through (1).




Figure 8-19. Three-Piece Airscoop (280FX)

8-18 Cabin Closeout Panels (280FX)

Effective S/N 2168 and subsequent, the cabin closeout installation consists of two removable exterior closeout panels mounted to the bottom of the cabin. The panels provide easier access to portions of the cyclic trim system, which avoids having to access the system from above and the need to remove interior components. The left side closeout panel also includes a housing assembly to accommodate the aft landing light. Refer to Figure 8-20.

A. Removal – Left Side Closeout Panel

NOTE: It is not required to remove the LED light assembly when removing the left side closeout panel. Likewise, it is not required to remove the closeout panel if removing the LED light assembly only. If removing the landing light only, accomplish steps A.1 and A.2. If it is not required to remove the landing light, step A.2 may be omitted. Support the panel during removal to prevent damage to the LED light assembly.

1. Pull the aft landing light circuit breaker (**AFT LDG LTS**, CB46).
2. If required, remove LED light assembly (8):
 - a. Remove four screws (10) and lens clamp (9) from landing light housing (7).
 - b. Remove two terminal post screws to disconnect the ground and power wires from the back of the LED light assembly.
3. Remove twelve screws (2) that attach closeout panel (1) to the cabin shell.
4. Disconnect wire harness connector P339 (3) from J339.
5. Remove closeout panel (1).

B. Installation – Left Side Closeout Panel


1. Connect wire harness P339 (3) to J339.
2. Install closeout panel (1) to the cabin shell with screws (2).
3. If required, install LED light assembly (8):

NOTE: Ensure correct wire polarity when connecting the wires.

- a. Secure the ground and power wires to the back of the LED light assembly (8).
 - b. Install LED light assembly (8) in landing light housing (7). Ensure the alignment key of the LED light assembly fits the notch in the landing light housing.
 - c. Install lens clamp (9) and secure with screws (10).
4. Push in the aft landing light circuit breaker (**AFT LDG LTS**, CB46).

C. Removal and Installation – Right Side Closeout Panel

1. Removal and installation of right side closeout panel (12) is accomplished via ten attachment screws (13).



- | | | | |
|----|-----------------------|-----|------------------------|
| 1. | Closeout Panel (Left) | 8. | LED Landing Light |
| 2. | Screw | 9. | Lens Clamp |
| 3. | Connector (P339) | 10. | Screw |
| 4. | Clamp | 11. | Grommet |
| 5. | Screw | 12. | Closeout Panel (Right) |
| 6. | Screw | 13. | Screw |
| 7. | Landing Light Housing | | |

Figure 8-20. Cabin Closeout Panels and Landing Light Housing (280FX)

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 9

MAIN ROTOR

TABLE OF CONTENTS

Paragraph	Description	Page
9-1	Main Rotor System	MM-9-3
	A. General.....	MM-9-3
9-2	Main Rotor Hub	MM-9-3
	A. Removal	MM-9-3
	B. Disassembly	MM-9-4
	C. Inspection	MM-9-5
	D. Assembly	MM-9-5
	E. Installation	MM-9-10
	F. Preflight Control System Check.....	MM-9-10
9-3	Retention Assembly	MM-9-16
	A. Removal	MM-9-16
	B. Disassembly	MM-9-16
	C. Inspection	MM-9-20
	D. Assembly.....	MM-9-20
	E. Installation (Method 1)	MM-9-22
	F. Installation (Method 2).....	MM-9-24
9-4	Universal Block Assembly	MM-9-31
	A. Disassembly	MM-9-31
	B. Inspection	MM-9-31
	C. Assembly.....	MM-9-31
9-5	Dampers	MM-9-34
	A. General Information.....	MM-9-34
	B. Troubleshooting.....	MM-9-34
	C. Removal	MM-9-34
	D. Disassembly	MM-9-34
	E. Inspection	MM-9-35
	F. Relief Valve Replacement	MM-9-38
	G. Assembly.....	MM-9-38
	H. Installation	MM-9-42
9-6	Main Rotor Blades	MM-9-49
9-7	A. Description.....	MM-9-49
9-8	B. Removal	MM-9-49
9-9	C. Inspection	MM-9-52
9-10	D. Repair	MM-9-62
9-11	E. Refinishing.....	MM-9-74
9-12	F. Corrosion Prevention.....	MM-9-76
9-13	G. Installation	MM-9-76

INTENTIONALLY LEFT BLANK

9-1. MAIN ROTOR SYSTEM

A. General – Main Rotor System

The main rotor system is a three bladed, high inertia, fully articulated rotor system. The main rotor hub assembly is comprised of two opposing forged aluminum hub plates separated by an aluminum cylindrical spacer. Through bolts hold these items together along with steel spline adapters. Three steel universal blocks are mounted in needle roller bearing units that permit flapping and lead-lag motions. Laminated phenolic pads are used to limit blade travel in both the lead-lag and flapping axes. A thrust nut on the bottom of each universal block transfers vertical blade forces to both hub plates through the universal block. The rotor blades are secured to each universal block on the hub through a forged aluminum grip which is in turn secured to a steel spindle assembly through a retention nut and supporting bearings. Blade feathering loads and centrifugal blade loads are carried by Lamiflex elastomeric bearing assemblies or Tension-Torsion (TT) Straps. Closed circuit hydraulic dampers are incorporated between each flapping pin and the rotor hub to limit the lead-lag velocity of the blades.

NOTE: F-28F S/N 832 and subsequent and 280FX S/N 2147 and subsequent are equipped with TT straps from the factory. The TT straps are installed in accordance with STC SR03465CH. Refer to Table 2-2 for publications.

9-2. MAIN ROTOR HUB

A. Removal – Main Rotor Hub

- (1) Remove the main rotor blades (para. 9-8).

CAUTION: Foreign objects dropped down the mast must be immediately removed to prevent damaging the flight controls.

- (2) Remove bolt (3) securing the pitch change bellcrank to the push-pull rod (6) in the mast (3 places) (Figure 9-1).

NOTE: Install a tie wrap to hold the spacer (7) in the push-pull rod (3 places).

- (3) Remove center pivot bolt (4) from the pitch change bellcrank. Pivot the bellcrank from the mounting bracket and allow to hang free on the pitch change link (2) (3 places) (Figure 9-1).

NOTE: Install a tie wrap to hold the spacer (8) in the bellcrank (3 places).

- (4) Remove the safeties from the mast nut (27) (Figure 9-2).

WARNING: The torque of the mast nut can be difficult to break. Use extreme caution when removing the mast nut.

- (5) Remove mast nut (27) and washer (26) from the mast using the torque multiplier tool T-0197-7. If this is not available, install T-0048 tool and use a 3/4" drive

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

electric impact wrench. If a 3/4" drive electric impact wrench is not available, install one main rotor blade and pull the breaker bar against the blade while using a large (2 kg) hammer to shock the tool (T-0048).

- (6) Disconnect the tail rotor drive shaft flex plate at pinion to prevent damage.
- (7) Install the hoist sling (T-0011) so the arms are between the pitch arm and the blade retention assembly, over the lead/lag retaining nut, and outboard of the main rotor damper rod-end. The sling arms are long enough to be double wrapped, if preferred (Figure 4-3).
- (8) Attach the sling to a lifting device and slowly lift the hub assembly from the mast. The hub must be lifted exactly parallel to the mast. If there are any side loads, the hub will stick on the splines and will not come off. If the hub has been installed for a long period of time, the hub puller (T-0174-1) must be used and the control rods must be removed from inside the mast.

NOTE: It may be helpful to put the left-side wheel down to align the mast vertically prior to lifting the hub assembly from the mast.

- (9) Install the hub assembly onto a hub stand.

B. Disassembly – Main Rotor Hub

NOTE: Mark all parts for reassembly in the same respective positions.

- (1) Remove bolt (13) to disconnect the pitch link (2) from the pitch arm (1) (3 places) (Figure 9-1).
- (2) Remove pitch arm (1) from the blade grip (3 places).
- (3) Remove the dampers (para. 9-5, C).

NOTE: To facilitate tracking, mark the hub adapter locations relative to the grip assemblies such that all blade grips and pitch change links are installed in the same location upon reassembly of the main rotor hub. A reused main rotor shaft may have previous markings.

- (4) Remove the retention assemblies (para. 9-3, A).
- (5) Remove bolts (1) and (2) from the bellcrank brackets (3) and remove the brackets (Figure 9-2).
- (6) Remove dust cover (4).
- (7) Bend locking tabs (6) out of the recesses in the retaining nuts (5). Install tool (T-0051-3) on the nuts and remove the nuts and the washers.
- (8) Turn the hub assembly over and remove locking keys (10) from the retaining nuts (9).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (9) Using tool T-0003, remove the nuts, shims (8), and DU washers (7).
- (10) Turn the hub assembly over and remove the hardware (11) from the center hub adapter.
- (11) Remove upper and lower spline adapters (12) and (18) by tapping them from the hub plates with a nylon drift.
- (12) Remove dowel pins (13) from the hub plates (14) and (17) and the center spacer (16) by tapping them through with an aluminum drift.
- (13) Remove grease fittings (19) from the hub plates (6 places).

WARNING: Use extreme caution when removing or installing the blade and grip assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

NOTE: Heating the assembly can be facilitated by using an oven.

- (14) Heat the upper hub plate to approximately 250°F/121°C and lift the hub plate from the universal blocks (U-block) (15). Tap with a plastic mallet if necessary.
- (15) Heat the lower hub plate to approximately 250°F/121°C and tap the universal blocks from the hub plate.

C. Inspection – Main Rotor Hub

- (1) Refer to Table 9-1 for detailed inspection requirements.

D. Assembly – Main Rotor Hub (Figure 9-2)


WARNING: Use extreme caution when removing or installing the blade and grip assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

NOTE: The upper hub plate has helicoil inserts in the outer bosses for the bellcrank mount brackets. The lower hub plate bosses are solid.


- (1) Heat upper hub plate (14) and the lower hub plate (17) to approximately 250°F/121°C.
- (2) Place the lower hub plate on 2" X 4" wood blocks. Lubricate the bearing bores with MIL-PRF-81322.

NOTE: Ensure the DU washers have been installed on the U-blocks with the chamfered side facing the hub plates. The DU washers must be seated in the recessed area of the hub plate.



- | | | | |
|----|------------------------|-----|---------------------|
| 1. | Pitch Arm | 9. | Bolt |
| 2. | Pitch Change Link | 10. | Washer |
| 3. | Bolt | 11. | Nut |
| 4. | Bolt | 12. | Cotter Pin |
| 5. | Pitch Change Bellcrank | 13. | Bolt |
| 6. | Push-Pull Rod Assembly | 14. | Washer (Harper/ECD) |
| 7. | Spacer | 15. | Spacer |
| 8. | Spacer | | |

Figure 9-1. Pitch Change Bellcrank and Pitch Link Installation



- | | | | | | |
|----|---------------|-----|----------------------|-----|----------------|
| 1. | Bolt | 10. | Lock Key | 19. | Grease Fitting |
| 2. | Bolt | 11. | Bolt | 20. | Grease Fitting |
| 3. | Bracket | 12. | Upper Spline Adapter | 21. | Stop Pad |
| 4. | Dust Cover | 13. | Dowel Pin | 22. | Bearing |
| 5. | Retaining Nut | 14. | Upper Hub Plate | 23. | DU Washer |
| 6. | Lock Washer | 15. | Universal Block | 24. | Spacer |
| 7. | DU Washer | 16. | Center Spacer | 25. | Shim |
| 8. | Shim | 17. | Lower Hub Plate | 26. | Hub Spacer |
| 9. | Retaining Nut | 18. | Lower Spline Adapter | 27. | Retaining Nut |

Figure 9-2. Main Rotor Hub Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (3) If required, reinstall the bearings in the U-block assembly and assemble (para. 9-5).
- (4) Install U-block assemblies (15) into the bearing bore of the hub plate with the threaded notched end of the U-blocks down (3 places).
- (5) Place spacer (16) on the lower hub plate and align the bolt holes.
- (6) Lubricate the bearing bores of the upper hub plate and install the upper hub plate onto the U-blocks.

NOTE: The dowel pins must be installed until slightly recessed from face of hub plate surface.

- (7) Lubricate dowel pins (13) and tap pins into the center hole of the 3-hole bolt pattern (3 places).

NOTE: The upper spline adapter has the wider flat surface on the top side of the splines while the lower adapter has a rib extending from the lower end of the splines.

CAUTION: When installing spline adapters, the phasing marks on top of the splines must align with one of the bellcrank mount brackets (3). Using a felt marker, mark a line on outboard edge of hub plate in line with spline phasing marks to aid in the alignment when installing lower spline adapter.

- (8) Insert bolts in upper spline adapter (12) as guides and install spline adapter into upper hub plate (14).

NOTE: To distinguish between spline adapters, the upper spline adapter (12) has the wider flat surface on top side of splines while the lower spline adapter has a rib extending from lower end of spline.

- (9) Carefully turn the hub assembly over and position on wood blocks.
- (10) Install lower spline adapter (18) (aligning the phasing mark with the upper adapter phasing mark) into lower hub plate (17).
- (11) Install center hub bolts (11) in the holes adjacent to the bellcrank bracket mount holes and install washers and nuts. Torque bolts.
- (12) Install bellcrank brackets (3) and secure with bolts (1) and (2). Torque bolts (1) and safety with 0.032 safety wire. Torque bolts (2).
- (13) To set rotational drag of U-blocks (15), proceed as follows:
 - (a) Place the hub assembly on a stand with lower end of U-blocks up.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Install DU washer (7) into recess of hub plate with chamfer in board toward hub plate.
- (c) Install approximately 0.025 shims (8) and lower U-block nut (9). Using tool T-0003, torque nut to 50 ft-lb/67.8 Nm.
- (d) Rotate the U-block to one of the stops and install a hinge pin partially into bearing until it extends 4.75 in/12.1 cm.
- (e) Attach a spring scale to the head of hinge pin and pull to check the drag of the U-block.

NOTE: Drag tolerance with nut torqued is 4 to 10 lb/1.8 to 4.5 kg.

- (f) Add or subtract shims (8) until the proper drag torque is obtained.

NOTE: Nut (9) must be torqued before checking drag.

- (g) Place locking key (10) into the slot of nut (9) aligned with the notch in the U-block and secure the key with screw.
- (h) Adjust the drag of all three U-blocks following steps (b) through (g).

(14) Turn the hub assembly over on the stand.

(15) Install upper U-block nuts (5) as follows:

- (a) Install lockwasher (6) and nut (5) on U-block.
- (b) Torque nut (5) to 20 ft-lb/27.1 Nm using tool T-0051-3.
- (c) Using a plastic mallet, tap down on top of nut and re-torque to seat the upper bearing.

NOTE: Repeat step (c) until nut (5) will not move when being torqued to 20 ft-lb/27.1 Nm.

- (d) Bend tab from lock washer (6) into the slot in nut (5) to secure the nut after torque is completed.
- (e) Install dust cover (4) on the nut and secure with screws and washers.
- (f) Repeat steps (a) through (e) on each U-block.

(16) Install grease fittings (19) into upper and lower hub plates (6 places).

(17) Install the retention assemblies (para. 9-3, E).

(18) Install the damper assemblies (para. 9-5, H).

(19) Install the pitch arms to the blade grips.

(20) Install the pitch link (2) to the pitch arm (1) with bolt (13) and hardware (3 places) (Figure 9-1). Torque and cotter pin.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-9

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

E. Installation – Main Rotor Hub (Figure 9-1, Figure 9-2)

- (1) Locate the spline with phasing mark at top of main rotor shaft and mark it with a black felt marker for alignment ease. Apply a lubricant (MIL-PRF-81322) to the rest of the rotor shaft splines.
- (2) Using sling T-0011 on main rotor hub assembly, carefully lower hub onto main rotor shaft while aligning the phasing marks on lower spline adaptor to phasing mark of rotor shaft spline. Remove sling.

CAUTION: When hub installed, the rotor shaft spline phasing mark must be located between upper spline adapter phasing marks. Check this before installing mast nut and washer.

- (3) Install mast washer (26) with chamfered side down toward splines.
- (4) Install mast nut (27) and torque to 400 ft-lb/542.3 Nm using Digital Mast Torque Multiplier P/N ATP761 or tool T-0048. Lockwire (.041) the mast nut (three places).
- (5) Remove the tie wrap from the spacer (7) in the control rod (6) and connect the control rod (6) and spacer (7) with the bolt (3), nut, and washers.

NOTE: Original control rods with bronze bushings are installed to a lower torque. Control rods with Teflon bushings are installed to standard torque.

- (a) Torque the nut. Ensure that the bellcrank will pivot on the control rod without resistance.
- (6) Remove the tie wrap from the spacer (8) in the bellcrank (5) and connect the spacer (8) with the bolt (4), nut, and washers.
 - (a) Torque the nut. Ensure that the bellcrank will pivot on the control rod without resistance.
- (7) Install the main rotor blade (para. 9-13).
- (8) Inspect all connections for security and proceed to the Preflight Control System check (para. 9-2, F).

F. Preflight Control System Check

NOTE: Whenever a helicopter has had work performed to the flight controls, it is recommended that a flight test be conducted before returning the helicopter to service.

- (1) Check the blade track (para. 12-2).
- (2) Perform a complete Flight Test Procedure (para. 12-13).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-1. Inspection Requirements – Main Rotor Hub Assembly

Part No.	Figure 9-2 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-14202	3	Bellcrank bracket	Deformed or cracked ears	None Allowed	Not Repairable	Replace Bracket
			Security of bushings in bracket – press fit	No Play Allowed	Not Repairable	Replace Bracket
			Nicks, scratches, or corrosion	None Allowed	≤ .010 Deep	Blend and Polish Smooth
28-14227	5	Nut	Threads (rolled or missing)	None Allowed	Not Repairable	Replace Nut
W-09	6	Lockwasher	Tangs (deformed or cracked)	None Allowed	Not Repairable	Replace Lockwasher
28-14236	7	DU washer	Flatness	.005	Not Repairable	Replace Washer
			Thickness .090 to .093	-.003	Not Repairable	Replace Washer
28-14256	9	Nut	Threads (rolled or missing)	None Allowed	Not Repairable	Replace Nut
28-14224	12 (& 18)	Spline Adaptors	Inboard face of adapter perpendicular to O.D.	+.0025 FIM	Not Repairable	Replace Adapter
			O.D. 3.6235 to 3.6245	-.0005	Not Repairable	Replace Adapter
			Spline pitting	.003 Deep	Not Repairable	Replace Adapter
			Spline corrosion	None Allowed	Surface Corrosion	Wire Brush to Remove
			Spline wear	.0015 on Side	Not Repairable	Replace Adapter

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-11

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-1. Inspection Requirements – Main Rotor Hub Assembly

Part No.	Figure 9-2 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-14224	12 (& 18)	Spline Adaptor (continued)	Nicks, scratches, or corrosion	.010 Deep	≤ .010 Deep	Blend and Polish Smooth
			Cracks	None Allowed	Not Repairable	Replace Adapter
28-14280	14	Upper Hub	Spline Adapter Bore 3.624 to 3.625 diameter	+ .0005	Not Repairable	Replace Upper Hub
			U Block Bearing Bore 2.4986 to 2.4994	+ .0008	Not Repairable	Replace Upper Hub
			Recesses for the DU washers parallel to the upper surface within .001	+ .0005	Not Repairable	Replace Upper Hub
			Damper bolt bushings diameter .4995 to .5000	+ .0005	Not Repairable	Replace Bushing
			Threads for bellcrank brackets (crossed or missing).	None Allowed	Not Repairable	Replace Helicoil
			Nicks, scratches, or corrosion	None Allowed	≤ .010 Deep	Blend and Polish Out Smooth
Cracks	None Allowed	Not Repairable	Replace Upper Hub			

UNCONTROLLED COPY WHEN ~~MM-11-12~~ DOWNLOADED OR PRINTED

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-1. Inspection Requirements – Main Rotor Hub Assembly

Part No.	Figure 9-2 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-14117	15	U-Block	Bore Dia. 2.4988 to 2.4996	+ .0002	Not Repairable	Replace U-Block
			Bearing Surface O.D. 1.7488 to 1.7494	- .0002	Not Repairable	Replace U-Block
			Bearing Surfaces concentric	.001 FIM	Not Repairable	Replace U-Block
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace U-Block
			Nicks, scratches, or corrosion	None allowed at the radius of the bearing spindle	≤ .030 deep	Blend and polish out smooth
Cracks	None Allowed	Not Repairable	Replace U-Block			
28-14223	16	Spacer	Dowel Hole Dia. .3125	+ .0005	Not Repairable	Replace Spacer
			Bolt Hole Dia. .313 to .318	+ .002	Not Repairable	Replace Spacer
			Nicks, scratches, or corrosion	.030 Deep	≤ .010 Deep	Replace Spacer
			Cracks	None Allowed	Not Repairable	Replace Spacer
28-14281	17	Lower Hub	Spline Adapter Bore 3.624 to 3.625	+ .0005	Not Repairable	Replace Lower Hub
			U Block Bearing Bores 2.4986 to 2.4994	+ .0008	Not Repairable	Replace Lower Hub

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-13

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-1. Inspection Requirements – Main Rotor Hub Assembly

Part No.	Figure 9-2 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-14281	17	Lower Hub (continued)	Recesses for the DU washers parallel to the lower surface within .001	+ .0005	Not Repairable	Replace Lower Hub
			Damper Bolt Bushing Dia. .4995 to .5000	+ .0005	Not Repairable	Replace Bushing
			Nicks, scratches, or corrosion	None Allowed	≤ 0.10 Deep	Blend and Polish Out Smooth
			Cracks	None Allowed	Not Repairable	Replace Lower Hub
28-14224	18 (& 12)	Spline Adaptor	Inboard face of adapter perpendicular to O.D.	+ .0025 FIM	Not Repairable	Replace Adapter
			O.D. 3.6235 to 3.6245	- .0005	Not Repairable	Replace Adapter
			Spline pitting	.003 Deep	Not Repairable	Replace Adapter
			Spline corrosion	None Allowed	Surface Corrosion	Wire Brush to Remove
			Spline wear	.0015 on Side	Not Repairable	Replace Adapter
			Nicks, scratches, or corrosion	.010 Deep	≤ .010 Deep	Blend and Polish Smooth
			Cracks	None Allowed	Not Repairable	Replace Adapter
28-14251	21	Stop Pad	Visual damage (cracks, chips, etc.)	None Allowed	Not Repairable	Replace Stop

MM-9-14
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-1. Inspection Requirements – Main Rotor Hub Assembly

Part No.	Figure 9-2 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
ECD092-1	22	Bearing	O.D. 2.4994 to 2.5000	No Tolerance Allowed	Not Repairable	Replace Bearing
			I.D. 1.7493 to 1.7500	No Tolerance Allowed	Not Repairable	Replace Bearing
			Ratcheting or roughness	None Allowed	Not Repairable	Replace Bearing
28-13236	23	DU Washer	Flatness	.005	Not Repairable	Replace Washer
			Thickness .090 to .093	-.003	Not Repairable	Replace Washer
28-14235	24	Spacer	Ends parallel	.0015 FIM	Not repairable	Replace Spacer
P/N	Figure 9-3 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits	Repair or Action
28-14233-2	3	Flapping Pin	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Pin
			Damper bolt hole Dia. .5005 to .5015	+.0015	Not Repairable	Replace Pin
			O.D. 1.7486 to 1.7492	-.0005	Not Repairable	Replace Pin
			Longitudinal scores or scratches	.011 deep	≤ .011 deep	Blend and polish out smooth
			Radial Scores	None Allowed	Not Repairable	Replace Pin
28-14233-3	3	Flapping Pin	O.D. 1.7488 to 1.7494	-.0005	Not Repairable	Replace Pin
Inspect the remainder of the flapping pin following the inspection criteria listed for the -2 flapping pin.						

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-15

Rev. 11
Oct 25/19

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

9-3. RETENTION ASSEMBLY

NOTE: F-28F S/N 832 and subsequent and 280FX S/N 2147 and subsequent are equipped from the factory with tension-torsion straps (STC SR03465CH). Refer to Table 2-2 for publications.

A. Removal – Retention Assembly (Figure 9-3)

- (1) Remove the main rotor blade (para. 9-8) from the retention assembly if the hub assembly is installed on the aircraft.
- (2) Remove the main rotor dampers (para. 9-5, C).
- (3) Disconnect pitch change link (2) from the pitch change bellcrank (5) (Figure 9-1).
- (4) Bend the lockwasher tab (4) away from the hinge pin retaining nut (5). Remove the nut using tool (T-0051-3).
- (5) Lift the retention assembly off of the down stop and rotate the grip slightly so that the hinge pin (3) will clear the pitch arm. Slide or tap the hinge pin (3) from the retention assembly and remove the retention assembly from the hub.
- (6) Remove DU washers (1) and shims (2), if any are installed, from both recesses in the universal block. Note the shim position(s) and retain the order for reassembly.

NOTE: If shims are installed behind DU washers, remove, note position, and save for reassembly.


B. Disassembly – Retention Assembly (Figure 9-4)

NOTE: The blade grip, lamiflex bearing, and lamiflex bearing shims can be removed with the retention assembly installed on the hub assembly.

- (1) Remove the main rotor blade (para. 9-8) and disconnect the pitch change link (2) from the pitch change bellcrank (5) (Figure 9-1) if the retention assembly is installed on the hub assembly.

CAUTION: Use brass protector plates on the vise jaws to prevent damage to spindle surface


- (2) Clamp the retention assembly in a vise in a vertical position.
- (3) Remove hardware from the dust cover (18) and remove cover. Inspect for brass residue (chips or flakes) from the lamiflex bearing.
- (4) Remove screw and inboard grease fitting.
- (5) Remove cotter pin (17) from nut (16).
- (6) Install tool T-0013 on nut (16) and remove nut.



NOTE: One shim P/N 28-14019-5 (Item 2) is installed, either the left or right side of the universal block.

- | | | | |
|----|--------------------|----|--------------------|
| 1. | DU Washer | 5. | Nut |
| 2. | Shim | 6. | Retention Assembly |
| 3. | Flapping Hinge Pin | 7. | Pin |
| 4. | Lock Washer | | |

Figure 9-3. Retention Assembly Installation



- | | | | |
|-----|----------------|-----|---------------------|
| 1. | Droop Stop | 12. | O-Ring |
| 2. | Dust Cap | 13. | Blade Grip |
| 3. | Spindle | 14. | Lamiflex Bearing |
| 4. | Flapping Stop | 15. | Shim |
| 5. | Nylatron Strap | 16. | Retaining Nut |
| 6. | Seal | 17. | Cotter Pin |
| 7. | Bearing | 18. | Dust Cover |
| 8. | Spacer | 19. | Blade Retention Pin |
| 9. | Bearing | 20. | Drag Link |
| 10. | Retaining Ring | 21. | Pitch Arm |
| 11. | DU Washer | | |

Figure 9-4. Retention Assembly




Figure 9-5. Lamiflex Bearing Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (7) Remove shims (15), lamiflex bearing (14), and nylatron strap (5).
- (8) Tap blade grip (13) with a plastic mallet to remove.

CAUTION: If lamiflex bearing wears through the nylatron strap, a careful inspection of the spindle is required. The maximum depth allowed for a groove worn in the spindle is .020 inch. Groove must be blended out before installing a new nylatron strap.

- (9) Remove O-ring (12) and DU washer (11) from the spindle.
- (10) Remove retainer ring (10) from the groove in the main rotor spindle (3).
- (11) Remove the hinge pin alignment roll pin from ear of spindle by tapping from the inside out with a small punch; do not drive through.
- (12) Install press tool between seal (6) and bearing (7) on the spindle.
- (13) Place in a hydraulic press and press bearings (7) and (9), and spacer (8) from the spindle (press one bearing at a time).
- (14) Remove seal (6) from the spindle.
- (15) Removal and replacement of retention stops (1) and (4) are necessary only if the stops are damaged or adhesive has loosened.
- (16) Remove cap (2) from the bore of the spindle.

CAUTION: When cleaning parts for inspection do not submerge lamiflex bearing in any type of cleaning solvent or damage to bearing will result. Clean bearing by hand using denatured alcohol.

C. Inspection – Retention Assembly

- (1) Refer to Table 9-2 for detailed inspection requirements.

D. Assembly – Retention Assembly (Figure 9-4)

- (1) If installing new retention stops (1) and (4) proceed as follows:
 - (a) Clean blocks (1) and (4) and spindle (3) with acetone or equivalent.
 - (b) Apply adhesive (DP 420 or equivalent) to the bonding surface of the stop and install the stop into position on the spindle. Install the screws to secure the droop stop.
 - (c) Allow the adhesive to dry until hard.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Apply zinc chromate to the bore of the spindle (3) and install plug (2) in the end of bore.
- (3) Clamp spindle (3) in vise in a vertical position.
- (4) Apply lubrication to seal surface of the spindle (3) and install seal (6).

NOTE: Seal is installed with the spring side of the seal facing toward the ears of the spindle.

- (5) Grease bearings (7) and (9) through the small hole in the bearing.

NOTE: It is helpful to heat the bearings with a heat gun to aid installation.

WARNING: Use protective gloves when handling heated parts.

- (6) Apply lubrication to the bearing surface and press bearing (7) onto spindle.
- (7) Install spacer (8) on spindle.
- (8) Lubricate (MIL-PRF-81322) the bearing surface and press the bearing (9) onto the spindle using a plastic mallet.

NOTE: Be sure bearings (7) and (9) are seated firmly against the shoulders of the spindle.

- (9) Install retainer ring (10) in the groove of the spindle.
- (10) Install DU washer (11) on the spindle (3).

NOTE: DU washer must be installed with the chamfered side of the washer facing inboard toward bearings.

- (11) Install O-ring (12) on the spindle until seated against DU washer (11).
- (12) Install tool T-0036 behind seal (6) with the chamfered side of the tool toward the large radius of the spindle.
- (13) Lubricate (MIL-PRF-81322) the bore of blade grip (13) and install on the spindle and bearings. Tap the grip down with a plastic mallet until seal (6) is seated in the grip.
- (14) Remove tool T-0036 and tap the blade grip down until fully seated.
- (15) Install nylatron strap (5) inside lamiflex bearing (14). Ensure that the ends of the nylatron do not overlap.
- (16) Install lamiflex bearing (14) while aligning tabs to slots in spindle and blade grip.
- (17) Install nut (16) and torque until the grip is fully seated on the spindle. Release the torque on the nut.

- (18) Shim (15) the nut until the cotter pin hole in the nut aligns with the hole in the spindle when the nut is tightened (5-15 in-lb/0.6-1.7 Nm).

NOTE: Add or subtract shims until the cotter pin hole in the nut aligns with the hole in the spindle when the nut is tightened finger tight. Do not under tighten the nut to align the holes. Do not over tighten the nut to align the holes.

CAUTION: The shims must be installed with the O.D. of the shims concentric to the O.D. of the nut and the lamiflex bearing. Improper alignment of these shims can cause wear to the inner surfaces of the main rotor blade grip (Figure 9-5).

- (19) Install nut (16) on the spindle and tighten until finger tight.

- (20) Install cotter pin (17) after nut (16) has been properly shimmed and torqued. Bend the cotter pin ends to secure.

CAUTION: To prevent lamiflex bearing damage, do not over-rotate the grip with the pitch change links disconnected.

- (21) Install dust cover (18) and secure with hardware.

- (22) Install the flapping pin alignment pin into the spindle ear if it was removed.

- (23) Install the pitch arm onto the blade grip. Install the hardware and torque to 75 in-lb/8.5 Nm. Lockwire the hardware (.032) in horizontal pairs.

- (24) If the retention assembly is installed on the hub assembly, connect the pitch link (2) to the pitch change bellcrank (5) (Figure 9-1).

- (24) Install the main rotor blade (para. 9-13).

E. Installation (Method 1) – Retention Assembly (Figure 9-3)

NOTE: Use the following procedure to install a retention assembly if the flapping bearings are installed in the universal blocks using the shimming procedure in paragraph 9-4, C. (If not shimmed per paragraph 9-4, C, use the procedure in paragraph 9-3, F.)

NOTE: Match each retention assembly to the location marked in the upper hub adapter (reference para. 9-2, B (3)).

NOTE: Installing a pilot (Figure 9-6) will keep the spacer and shims in the proper location while installing the hinge pin.

- (1) Lubricate hinge pin (3) with grease (MIL-PRF-81322).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Apply grease (MIL-PRF-81322) to both sides of one DU washer (1) recess and to both sides of a P/N 28-14019-5 shim (2). Install the shim on the greased bearing groove.

NOTE: If installing the shim to the right side of the universal block, then install the shims for the other two universal blocks on the right. Likewise, if installing the shim to the left side, then install all shims to the left of the universal block.

- (3) Install DU washers (1) in each side of U-block with the chamfered side of DU washers facing inboard toward the U-block.

NOTE: Ensure that the correct retention assembly is being installed on the shimmed universal block.

- (4) Carefully slide the retention assembly into position over the DU washer and U-block.

NOTE: Enstrom recommends replacing Flapping Hinge Pin, P/N 28-14233-1, with Flapping Hinge Pin, P/N 28-14233-3, when reinstalling the main rotor retention assemblies after the flapping bearings have been shimmed. The Flapping Hinge Pin, P/N 28-14233-3, is manufactured to closer tolerances for bearing fit and will improve service life. Flapping Hinge Pin, P/N 28-14233-1, is an acceptable alternate and serviceable pins may be reinstalled.

- (5) Twist the grip slightly to allow the hinge pin (3) to be installed; do not over twist to avoid damaging the lamiflex bearing, if equipped. Align the roll pin slot in the hinge pin with the roll pin and seat the hinge pin. Tap the roll pin flush with the hinge pin if it protrudes from the hinge pin.
- (6) Lubricate nut (5) (MIL-PRF-2105, -23699, -81322) in the threads and on the surface of the nut where it will contact the lock washer (4).
- (7) Install the lock washer (4) and nut (5) on the hinge pin (3).
- (8) Insert a long punch into the damper rod-end attach holes in the flapping pin. Torque the nut using tool (T-0051-3) to 150-175 ft-lb/203.4-237.3 Nm. The nut may be torqued to 175 ft-lb/ 238.6 Nm for aligning one of the lockwasher tabs. While torquing the nut, pull against the punch to avoid shearing off the roll pin that locates the head of the pin against the spindle on the pitch arm side of the retention assembly.

CAUTION: Do not proceed unless the universal block has been assembled (shimmed) in accordance with paragraph 9-4, C.

- (9) Check the flapping bearing drag resistance at the blade pin. Initially, the grip should not stay up. Add shim thickness in 0.005 inch increments to achieve sufficient resistance to hold the grip in the up-stop position at 150 ft-lb/203.4 Nm. Remove one shim and verify the flapping bearing moves freely.
- (10) Secure the nut by bending one of the tabs on the lockwasher (4) into a slot in the nut.

- (11) Lubricate the flapping bearings (para. 4-29).
- (12) Repeat the procedure for the remaining retention assemblies.
- (13) Install the main rotor damper (para. 9-5, H), connect the pitch change link to the pitch change bellcrank and the pitch arm, and install the main rotor blade (para. 9-13).
- (14) Perform a maintenance test flight (para. 12-13).

F. Installation (Method 2) – Retention Assembly (Figure 9-3)

NOTE: Use the following procedure to install a retention assembly **until** the flapping bearings are installed in the universal blocks using the shimming procedure in paragraph 9-4, C.

NOTE: Enstrom recommends internal shimming (Method 1) to increase the service life.

NOTE: Match each retention assembly to the location marked in the upper hub adapter (reference para. 9-2, B (3)).

NOTE: Installing a pilot (Figure 9-6) will keep the spacer and shims in the proper location while installing the hinge pin.

- (1) Lubricate hinge pin (3) with grease (MIL-PRF-81322).
- (2) Install DU washers (1) in each side of U-block with the chamfered side of DU washers facing inboard toward the U-block.
- (3) Carefully slide the retention assembly into position over the DU washer and U-block.

NOTE: Enstrom recommends replacing Flapping Hinge Pin, P/N 28-14233-1, with Flapping Hinge Pin, P/N 28-14233-3, when reinstalling the main rotor retention assemblies after the flapping bearings have been shimmed. The Flapping Hinge Pin, P/N 28-14233-3, is manufactured to closer tolerances for bearing fit and will improve service life. Flapping Hinge Pin, P/N 28-14233-1, is an acceptable alternate and serviceable pins may be reinstalled.

- (4) Twist the grip slightly to allow the hinge pin (3) to be installed; do not over twist to avoid damaging the lamiflex bearing, if equipped. Align the roll pin slot in the hinge pin with the roll pin and seat the hinge pin. Tap the roll pin flush with the hinge pin if it protrudes from the hinge pin.
- (5) Install the lock washer (4) and nut (5) on the hinge pin (3).
- (6) Torque the nut to 50-100 ft-lb/68.2-136.4 Nm using tool (T-0051-3). Ensure the retention assembly does not remain in the up-stop position.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (a) Check the flapping bearing drag resistance at the flapping pin. Initially, the grip should not stay up. If the retention assembly stays up, remove shims in 0.005-inch increments until the retention assembly will drop with no resistance when the nut is torqued.

NOTE: Shims may be installed as required on the inboard side of the DU washers to avoid excessive torque in obtaining the flapping preload. All three retention assemblies should have an equal flapping preload.

- (7) Lubricate the U-block lead lag and flapping bearings (Figure 4-2, para. 4-30) and re-check the retention assembly in accordance with step (6). Reshim and retorqued the nut, if required.
- (8) Bend one of the tabs on the lockwasher (4) into a slot in the nut when the proper preload has been obtained.
- (9) Install the main rotor damper (para. 9-5, H), connect the pitch change link to the pitch change bellcrank and the pitch arm, and install the main rotor blade (para. 9-13).
- (10) Perform a maintenance test flight (para. 12-13).

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-2. Inspection Requirements – Retention Assembly

Part Number	Figure 9-4 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-14240-1	1	Droop Stop	General Condition	.003 wear	Not Repairable	Replace Stop
28-14282-13	3	Spindle	Lamiflex bearing tab slot width .187 to .189	+ .002	Not Repairable	Replace Spindle
			Small bearing surface Dia. 1.9996 to 2.0003	- .0003	Not Repairable	Replace Spindle
			Large bearing surface Dia. 2.4996 to 2.5002	- .0003	Not Repairable	Replace Spindle
			Seal surface Dia. 2.872 to 2.878	- .002	Not Repairable	Replace Spindle
			Flapping pin bore Dia. 1.7495 to 1.7500	+ .0005	Not Repairable	Replace Spindle
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Spindle
			Nicks, scratches, or corrosion	None Allowed	≤ .010 deep	Blend and polish out smooth
Cracks	None Allowed	Not Repairable	Replace Spindle			
28-14231-1	4	Up Stop	General condition	.003 wear	Not Repairable	Replace Stop
			Cracks	None Allowed	Not Repairable	Replace Stop
28-14311-1	5	Nylatron Strap	Cracks or worn through	None Allowed	Not Repairable	Replace Strap

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-27

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-2. Inspection Requirements – Retention Assembly

P/N	Figure 9-4 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
40NBC20-52YZP	7	Bearing	O.D. 3.2492 to 3.2500	No Tolerance Allowed	Not Repairable	Replace Bearing
			I.D. 2.4993 to 2.5000	No Tolerance Allowed	Not Repairable	Replace Bearing
			Ratcheting or roughness	None Allowed	Not Repairable	Replace Bearing
28-14261	8	Spacer	Length 3.061 to 3.062	-.001	Not Repairable	Replace Spacer
			Ends parallel	Within .0012 FIM	Not Repairable	Replace Spacer
32NBC20-44YZP	9	Bearing	O.D. 2.7494 to 2.7500	No Tolerance Allowed	Not Repairable	Replace Bearing
			I.D. 1.9993 to 2.0000	No Tolerance Allowed	Not Repairable	Replace Bearing
			Ratcheting or roughness	None Allowed	Not Repairable	Replace Bearing
28-14313	11	DU Washer	Thickness .090 to .093	-.003	Not Repairable	Replace Washer
28-14279	13	Blade Grip	Blade retention bolt bore Dia. .875 to .876	+.0005	Not Repairable	Replace Blade Grip
			Large bearing bore Dia. 3.2512 to 3.2522	+.0018	Not Repairable	Replace Blade Grip
			Small bearing bore Dia. 2.7511 to 2.7519	+.0011	Not Repairable	Replace Blade Grip
			Thru bore Dia. 1.5145 to 1.5165	+.0015	Not Repairable	Replace Blade Grip
			Drag link ear width .745 to .747	-.001	Not Repairable	Replace Blade Grip

MM-9-28
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-2. Inspection Requirements – Retention Assembly

P/N	Figure 9-4 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-14279	13	Blade Grip (Cont'd)	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Blade Grip
			Nicks, scratches, or corrosion	None Allowed	≤ .010 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Blade Grip
28-14320-12, -15	14	Lamiflex Bearing	Thickness .770-.790	(See Note)	Not repairable	Replace lamiflex
			External to internal tab angle 12° (-12)	±1/2°	Not repairable	Replace lamiflex
			External to internal tab angle 15° (-15)	±1/2°	Not repairable	Replace lamiflex
			Column for separations	None allowed	Not repairable	Replace lamiflex
28-14335	16	Nut	Thrust face for flatness	.0015	Not Repairable	Replace Nut
			Threads (rolled or missing)	None Allowed	Not Repairable	Replace Nut
28-14007-1,-3	19	Blade Retention Bolt	O.D. .8738 to .8745 (-1) O.D. .8733 to .8740 (-3)	-.0002	Not Repairable	Replace Bolt

Note: Lamiflex bearings that are found swelled from grease contamination should be cleaned with denatured alcohol and checked for delamination. If the bearing is swelled beyond the limits (.790" thick), they may still be serviceable if they can be reinstalled in accordance with para. 9-3 and do not cause binding in the controls.

Any bearing that shows evidence of bulging around the outer circumference of the elastomer segments, excessive axial swelling, visual delamination of the segments or the expulsion of shim fragments on the outside diameter, should be replaced by an airworthy bearing prior to the next flight.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-29

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-2. Inspection Requirements – Retention Assembly

P/N	Figure 9-4 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-14007 (continued)	19	Blade Retention Bolt (continued)	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Bolt
			Nicks, scratches, or corrosion	None Allowed	≤ .010 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Bolt
28-14283	20	Drag Link	Distance between blade grip ears .748	± .001	Not Repairable	Replace Link
			Distance between blade root ears .564 to .566	± .0005	Not Repairable	Replace Link
			Retention bolt hole Dia. (2 places) .3745 to .3750	-.0002	Not Repairable	Replace Link
			Nicks, scratches, or corrosion	None Allowed	≤ .010 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Link
28-14278	21	Pitch Arm	Pitch change link bolt and mount bolt hole Dia. (5 places) .312 to .315	-.001	Not Repairable	Replace Arm
			Nicks, scratches, or corrosion	None Allowed	≤ 0.10 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Arm

* All dimensions are in inches.

MM-9-30
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 11
Oct 25/19

9-4. UNIVERSAL BLOCK ASSEMBLY

A. Disassembly – Universal Block (Figure 9-2)

- (1) Remove upper and lower bearings (22) and DU washers (23) from U-block (15).
- (2) Press flapping bearings (22), spacer (24), and shims (25) from bore of U-block.

NOTE: Flapping bearings can be removed from the universal blocks using the Flapping Bearing Removal/Installation Tool T-0151-1 when the universal blocks are installed on the aircraft.

- (3) Remove screws and stop blocks (21) if visual damage appears on the blocks.
- (4) Remove grease fittings (20).

B. Inspection – Universal Block

- (1) Refer to Table 9-1 for detailed inspection requirements.

C. Assembly – Universal Block (Figure 9-2, Figure 9-6, Figure 9-7, Figure 9-8, Figure 9-9)

- (1) Install stop blocks (21) and secure with screws.
- (2) Index mark the universal blocks and retention assemblies as sets.
- (3) Measure the stack up of two bearings (22) and one spacer (24) and measure the distance between the spindle fork (refer to Figure 9-6).
- (4) If the bearing and spacer stack up (DIM. X) is less than the distance between the spindle fork (DIM. Y), add shims (25) between the bearings and the spacer to create a zero tolerance fit.

NOTE: Use an arbor press to install the flapping bearings if the main rotor hub is disassembled. If the main rotor hub is assembled, use the Universal Block Bearing Tool, T-0151-1, to install the flapping bearing.

- (5) Lubricate (MIL-PRF-81322) the bore of the U-block and the O.D. of the flapping bearings. Install a DU washer (23) in the recessed area on the "forward" side of the U-block and place the U-block in an arbor press with the "forward side" and DU washer up. Press a flapping bearing (22) into the U-block until it is flush with the DU washer (Figure 9-7).

NOTE: If desired, an alignment/installation pilot (included with the tool, T-0151-1) can be fabricated to aid in the installation of the bearing, spacer, and shims into the universal block (refer to Figure 9-9). This pilot may also be used to aid in installation of the flapping pin when installing the retention assemblies.

- (6) Rotate the U-block in the press and install the spacer (24) and shims (25), if required. Press the other flapping bearing into the bore until seated against the spacer. Ensure that the first flapping bearing is still flush with the DU washer.
- (7) Remove the DU washer.
- (8) Repeat the procedure for the remaining universal blocks.




Figure 9-6. Flapping Bearing and Spindle Dimension Check




Figure 9-7. "Forward" Flapping Bearing Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-8. "Aft" Flapping Bearing and Spacer Installation




Figure 9-9. Flapping Bearing Installation Alignment Tool

9-5. DAMPERS

A. General Information – Dampers

The damper assembly consists of a damper housing, a piston and restrictor assembly, and a reservoir with two relief valves. The damper is used to damp lead-lag movement of the main rotor blades. Proper servicing and maintenance is required to keep the dampers operating at an equal rate.

B. Troubleshooting – Dampers

(1) Refer to paragraph 12-1, for damper-related main rotor system troubleshooting.

(2) Lead-Lag Check

(a) Raise blade off its droop stop.

(b) Move blade slowly fore and aft to cycle damper.

NOTE: The damper should offer resistance through the complete cycle – no undamped motion.

C. Removal – Dampers

(1) Remove the damper as follows (Figure 9-10):

(a) Remove cotter pin (8), nut (7) and washers (6).

(b) Remove bolt (5) and washer (6).

(c) Pivot the damper to remove spacers (9) on top and bottom of damper rod end.

NOTE: If the bolt is installed in the reverse direction, the bolt (4) and hardware must be removed to facilitate removal of the inboard damper pivot bolt.

(d) If required, remove the center bolt (4) and hardware of the pitch change bellcrank (Figure 9-1).

(e) Remove nut (4) and washer (3) from inboard damper pivot bolt (1) and remove bolt (1) and washer (2).

(f) Remove the damper from the hub assembly.

D. Disassembly – Dampers (Figure 9-11)

(1) Remove the damper from the helicopter (para. 9-5, C).

(2) Disengage the locking feature on the rod end (20), as applicable:

(a) Straighten the locking washer tabs (29) (-1 and -5 dampers) or remove the safety wire from the locking key (18).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(3) Loosen jam nut (19) and remove the rod end (20) from the piston (6) or (30):

(a) Use tool T-0005 to hold the piston.

(4) Remove reservoir plugs (26) and pour the damper fluid from the reservoir.

(5) Remove reservoir plugs (23) and O-rings (24).

(6) Remove bolts (28) and washers (16) securing the reservoir to the damper and remove the reservoir.

(7) Remove sleeves (27) and O-rings (25).

(8) If troubleshooting indicates a malfunctioning relief valve, remove the relief valve (22) using a 9/16" deep-well socket. Refer to paragraph 9-5, F for replacement instructions.

CAUTION: The relief valve pressure has been preset at the factory and cannot be adjusted in the field. Return a faulty valve to Enstrom Helicopter Service for inspection and valve adjustment/exchange.

(9) Remove bolts (17) and washers (16) from the damper housing and cap (10).

(10) Rotate end cap (10) approximately 45° using a soft mallet, and remove the end cap by tapping outward on its corners.

NOTE: Remove all burrs from piston shaft to prevent damage to the brass sleeve and seals during end cap removal.

(11) Pour the damper fluid from the damper housing.

(12) Tap piston (6) or (30) out of housing with a nylon drift and remove O-ring or seal pack (9) from the piston.

CAUTION: Do not damage the I.D. of the sleeves during seal and wiper removal.


NOTE: Remove the brass sleeve assemblies only if the seals are going to be replaced so as to reduce wear on the cover (10) and damper housing (1) bore.

NOTE: Threadlocker is applied to the sleeves (5) and (12) upon initial installation at the factory. Heating the housing and the end cap to 250°F/121°C may aid removal of the sleeves.

(13) Press the brass sleeves (5) and (12) from the end cap (10) and the damper housing (1). Remove seals (14) and wipers (13) from the brass sleeves. If evident, remove threadlocker residue with a suitable hand tool (pick).

(14) Install tool T-0095 between ears of damper housing and press bushing (3) out using a suitable size drift.


(15) Inspect the face of the bushings (2) for fretting and wear. DO NOT remove the bushings unless replacement is required. Upon replacement, bushings must be reamed with a 1/2" line reamer.



- | | | | |
|----|--------------------|----|------------|
| 1. | Inboard Pivot Bolt | 6. | Washer |
| 2. | Chamfered Washer | 7. | Nut |
| 3. | Washer | 8. | Cotter Pin |
| 4. | Nut | 9. | Spacer |
| 5. | Bolt | | |

Figure 9-10. Damper Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | |
|------------------------|----------------------------|---------------------|
| 1. Damper Housing | 11. O-Ring | 21. Reservoir |
| 2. Bushing | 12. Sleeve | 22. Valve Assembly |
| 3. Bushing | 13. Wiper | 23. Cap Plug |
| 4. O-Ring | 14. Seal | 24. O-Ring |
| 5. Sleeve | 15. O-Ring | 25. O-Ring |
| 6. Piston | 16. Washer | 26. Plug |
| 7. Restrictor Sleeve | 17. Bolt | 27. Sleeve |
| 8. Set Screw | 18. Lock Key | 28. Bolt |
| 9. O-Ring or Seal Pack | 19. Jam Nut | 29. Washer |
| 10. End Cap | 20. Damper Rod End Bearing | 30. Piston (-1, -5) |

Figure 9-11. Hydraulic Damper Assembly

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-37

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

E. Damper – Inspection

- (1) Refer to Table 9-3 for inspection criteria.

F. Relief Valve Replacement (Figure 9-11)

NOTE: The relief valve pressure has been preset at the factory and cannot be adjusted in the field. Return faulty valves to Enstrom Helicopter Service for inspection and valve adjustment/exchange.

- (1) Remove damper from the aircraft (para. 9-5, C).
- (2) Remove plugs (26) and O-rings (25).
- (3) Drain the damper fluid.
- (4) Remove plugs (23) and O-rings (24).
- (5) Remove relief valve (22) through the open ports with a 9/16" deep-well socket.
- (6) Install new relief valve (22). Torque 350 in-lb/39.8 Nm.
- (7) Install O-rings (24) and plugs (23). Torque plugs 350 in-lb/39.5 Nm.
- (8) Fill reservoir with fluid (SF96-20) through the top bleeder ports.
- (9) Install O-rings (25) and plugs (26). Torque plugs 40-60 in-lb/4.5-6.8 Nm
- (10) Follow the servicing procedure to ensure all air is purged from the damper (para. 4-18).
- (11) Safety wire the plugs.

G. Assembly – Dampers (See Figure 9-11)

CAUTION: Do not damage the I.D. of the sleeves during seal and wiper installation.

- (1) Install O-rings (4) and (11) on the sleeves (5) and (12).
- (2) Install the sleeves (5) and (12) as follows:
 - (a) Install seals (14) in the inboard groove of the sleeves with the O-ring side toward the piston. Ensure that the seal (14) has the O-ring installed in it.
 - (b) Install wiper (13) in the outboard groove of the sleeves with the lip of the wiper facing outboard.
- (3) Press sleeve assemblies into the end cap (10) and the damper housing (1).
- (4) If bushings (2) were removed, apply a small bead of Loctite 277 around the O.D. of the bushing (2) and install tool (T-0095) between the ears of the damper housing. Using an arbor press, install the bushings into the housing. If new bushings are installed, they must be line reamed with a ½ in. line reamer.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (5) Place the damper housing in a vise with the bore up.

CAUTION: Ensure components are free of dirt or other contaminants prior to assembly.

CAUTION: Do not damage the O-rings or seals during the assembly process.

- (6) Lubricate (SF96-20) the bore of the housing and the I.D. of the seal (14) of the installed sleeve assembly.

- (7) Install O-ring or seal pack (9) using the following procedure:

- (a) Lubricate O-ring or seal pack (9) with damper oil and install on the piston (6) or (30). Use tool T-0160 to install the seal pack.
- (b) Install piston (6) or (30) into damper housing by gently tapping with a plastic mallet until piston is bottomed out. Tool T-0160-1 installation collar, or equivalent, must be used to install the piston if a seal pack is used.

NOTE: Threaded end of piston must face the end cap (10).

- (8) Fill damper housing (1) with SF96-20 damper oil and install O-ring (15) into the recess of the damper housing (1).

- (9) Lubricate the I.D. of the seal (14) in end cap (10) with SF96-20 oil and gently slide the end cap over the end of piston (6) or (30). Tap gently to seat the end cap into the damper housing.

NOTE: Care must be used not to cut O-rings and seals on installation.

- (10) Secure end cap (10) to the housing with bolts (17) and washers (16). Torque the bolts using cross pattern tightening sequence (50-70 in-lb/5.6-7.9 Nm).

- (11) If relief valve (22) has been removed for cleaning or replacement, re-install the valve in the reservoir (21) using a 9/16" deep well socket. Torque the valve to 350 in-lb/39.8 Nm.

- (12) Reposition the damper to horizontal position in a vise with the reservoir parts up.

- (13) Install O-rings (25) onto sleeves (27) and insert sleeves into ports in the damper housing.

- (14) Align reservoir (21) with sleeves (27) on the damper housing and position the reservoir in place. Secure with bolts (28) and washers (16) and torque bolts (50-70 in-lb/5.6-7.9 Nm).

- (15) Place O-rings (24) on plugs (23) and install the plugs into the reservoir. Torque plugs 350 in-lb/39.5 Nm and safety.

- (16) Reposition the damper in vise with bleeder ports up. Move the damper piston approximately 2 inches off bottomed out position.

- (17) Fill the reservoir with SF96-20 damper oil and install O-rings (25) and plugs (26). Torque plugs 40-60 in-lb/4.5-6.8 Nm and safety.

- (18) Install the damper rod end bearing assembly (20).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: The rod end bearing assembly may have been previously treated with ACF-50 or MIL-PRF-23377 Type I Class 2C or Class N epoxy primer corrosion inhibitor per SDB 0127. If continuing use of ACF-50, removal of prior ACF-50 application is unnecessary. If changing from ACF-50 to epoxy primer, ACF-50 residue must be removed before reinstallation. For helicopters S/N 833 (F-28F) and subsequent and S/N 2157 (280FX) and subsequent, the rod ends are treated with epoxy primer at the time of manufacture.

- (a) Remove jam nut (19).
- (b) For new epoxy primer application, remove any ACF-50 residue from the threads of the rod end and the interior threads of the piston with a suitable solvent.
- (c) If applying a touch-up of epoxy primer, remove any loose epoxy primer residue from the threads of the rod end and the interior threads of the piston with a brush and a small amount of solvent.

CAUTION: Do not allow the epoxy primer to dry prior to assembly of the rod end.

CAUTION: Mask the bearing area prior to applying epoxy primer to avoid damaging the bearing.

NOTE: Follow the manufacturer's instructions for corrosion inhibitor application.

- (d) Apply the applicable corrosion inhibitor to the entire thread length of the rod end, as required.

NOTE: Installing the jam nut will tend to wipe away corrosion inhibitor that was freshly applied. Re-apply to ensure complete coverage.

- (e) Install jam nut (19) and locking key (18) or flat lock washer (29), as applicable.
- (f) Re-apply corrosion inhibitor to the threads below the jam nut, as required.
- (g) Install the damper rod end bearing assembly (20) into the damper piston (6) or (30) until the correct rod end dimension is obtained (Figure 9-12):
 - (i) (-1 and -5 dampers) Dimension equals $0.975 \text{ in} \pm .025 \text{ in} / 26.7 \text{ mm} \pm .13 \text{ mm}$ from centerline of rod end to outboard edge of jam nut (19).
 - (ii) (-3, -7, -101, and -105 dampers) Dimension equals $1.050 \text{ in} \pm .005 \text{ in} / 26.7 \text{ mm} \pm .13 \text{ mm}$ from centerline of rod end to outboard edge of jam nut (19).

NOTE: Locking key (18) must be aligned into piston slots before jam nut will seat against end of piston (-3, -7, -101, and -105 dampers).

- (h) Re-apply corrosion inhibitor to the threads above the jam nut, as required.




Figure 9-12. Damper Rod End Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(19) Hold the rod end with a wrench or tool T-0005 and tighten the jam nut (19) when the correct position is set.

(i) (-1 and -5 dampers) Bend the locking washer tabs (29).

(ii) (-3, -7, -101, and -105 dampers) Position the locking key toward the top of the damper. Safety wire the jam nut (19) to locking key (18).

(20) Bleed the dampers and safety (para. 4-18).

H. Installation – Damper (Figure 9-10)

NOTE: Refer to SDB 0127 regarding rod end inspection.

NOTE: The bellcrank center attachment bolt is installed in the reverse direction as the other two bolts (Figure 9-1).

(1) Install damper assembly on main rotor hub.

NOTE: The slotted-style rod end using the locking key (tang) must be installed with the slot facing up. This position for the locking key prevents interference with the hinge pin.

(2) Install chamfered washer (2) on inboard damper bolt (7).

NOTE: Chamfered side of washer must go against bolt head.

(3) Install inboard bolt (7) through the hub plates and the damper. Install the bottom washer (3) and nut (4).

(4) Torque the bolt to 190 in-lb/21.5 Nm.

(5) Ensure that the damper will pivot on the inboard bolt and bushing.

(6) Pivot the damper to align the rod end with the hole in the hinge pin.

(7) Install spacers (9) on each side of the rod end and slide the rod end into the hinge pin while aligning the spacers with the hole.

(8) Install washer (6) on the bolt (5) and install the bolt through the hinge pin and the rod end. Install two washers (6) and locknut (7) on bolt.

(9) Torque the bolt (5) to 450-500 in-lb/50.8-56.5 Nm while aligning cotter pin hole. Install the cotter pin (8).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-3. Inspection Requirements – Damper Assembly

Part Number	Figure 9-11 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-14357-5 28-14357-3 28-14357-1	1	Housing	Sleeve fore Dia. 1.1250 to 1.255	+ .0002	Not Repairable	Replace Housing
			Flanged bushings in the ears for excessive fretting	1/3 of total face light fretting	½ of total face light fretting	Blend and polish out smooth
			Obstruction in the flow ports	None Allowed		Clear with compressed air
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Housing
			Security of chrome sleeve in bore of the Housing	No movement allowed	Not Repairable	Replace Housing
			Surface scratches	None Allowed	≤ .020 deep	Blend and polish out smooth
28-14277-1	3	Bushing	O.D. .4995 to .5005	- .0005	Not Repairable	Replace Bushing
			I.D. .3747 to .3757	+ .0005	Not Repairable	Replace Bushing
			Nicks and scratches	.005 deep	≤ .005 deep	Blend and polish out smooth
28-14359-17			O.D. .4994 to .4999	- .0005	Not Repairable	Replace Bushing
			I.D. .3765 to .3775	+ .0005	Not Repairable	Replace Bushing
			Nicks and scratches	.005 deep	≤ .005 deep	Blend and polish out smooth

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-43

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-3. Inspection Requirements – Damper Assembly

Part Number	Figure 9-11 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-14356-5	5 and 12	Sleeve	O.D. 1.1260 to 1.1265	-.0002	Not Repairable	Replace sleeve
			Piston shaft bore Dia. .749 to .751	+.002	Not Repairable	Replace sleeve
			O.D. to I.D. concentricity	.002 FIM	Not Repairable	Replace sleeve
28-14370-17 28-14370-15 28-14267-13	6, 30	Piston	Piston shaft O.D. .746 to .748	-.001	Not Repairable	Replace Piston
			Concentricity	.001 TIR	Not Repairable	Replace Piston
			Obstruction in the flow restrictor	None Allowed		Clear with compressed air
			Nicks or scratches in surface	None Allowed	≤ .5" long and ≤ .005 deep	Blend and polish out smooth
			Threads	No crossed or missing threads	Not Repairable	Replace Piston
28-14265-3 28-14265-1	10	End Cap	Sleeve bore dia. 1.1250 to 1.1255	+.0002	Not Repairable	Replace Cap
			Obstruction in the fluid port	None Allowed		Clear with compressed air
			Surface for nicks and scratches	None Allowed	≤ .020 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Cap

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 9-3. Inspection Requirements – Damper Assembly

Part Number	Figure 9-11 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
ECD091-1	20	Damper Bearing	Radial Play	.007	Not Repairable	Replace Bearing
			Axial Play	.005	Not Repairable	Replace Bearing
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Rod End
28-14366-1	21	Reservoir	Obstruction in the flow ports	None Allowed		Clear with compressed air
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Reservoir
			Nicks, scratches, or corrosion	.020 deep	≤ .020 deep	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Reservoir
			If the valves are removed, valve threads and ports for contamination	None Allowed		Flush with cleaning solvent and dry with compressed air
28-14368-2	23	Plug	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Plug
AN814-2DL	26	Plug	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Plug
28-14369-1	27	Sleeve	O.D. and I.D. for nicks or scratches	None Allowed	Not Repairable	Replace Sleeve
			All O-Rings, Wiper, and Seals	Inspect for obvious defects	None Allowed	Not Repairable

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-45

Rev. 11
Oct 25/19

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

INTENTIONALLY LEFT BLANK

I

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-46

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Figure 9-13 through Figure 9-15 are reserved for future use.

INTENTIONALLY LEFT BLANK

9-6. Main Rotor Blades

9-7. Description – Main Rotor Blades (Figure 9-16)

The main rotor blades are of hollow construction. Upper and lower skins are bonded to the extruded leading edge spar which is twisted 7.25°. Doublers are bonded to the root end of the blade for retaining the blades to the main rotor hub. The blades are retained by a single retention pin to the blade grip and a non-adjustable drag brace connected to the trailing edge of the blades. Provisions for spanwise and cordwise balance weights are provided in the tip caps that are bonded in the tip end of the blades. Two tracking tabs are riveted to the trailing edge of each blade.

9-8. Removal – Main Rotor Blades (Figure 9-17)

NOTE

Lifting the tip of the blade until the blade is parallel to the retention assembly will allow the retention bolt and the drag brace bolt to be easily removed and will allow the blade to be removed from the blade grip without spreading the ears of the grip.

- A. Remove the bolt (1) securing the drag link to the rotor blade.
- B. Remove the blade retention bolt (2).
- C. Carefully slide the blade from the grip.
- D. Place the blade into a blade rack or on a suitable device that will prevent the blades from being damaged.
- E. Repeat the process for the other 2 blades.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-16. Main Rotor Blade

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED




Figure 9-17. Main Rotor Blade Installation

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

9-9. Inspection – Main Rotor Blades

A. Inspect the paint finish of the blades for blistering, erosion, cracking, chipping, peeling, and overall oxidation.

B. Inspect the main rotor blade spar (especially on blades that have erosion of the paint finish) for slivering or flaking of the exposed spar surface, and for a grainy surface appearance (Figure 9-19).

C. Inspect the spar bond lines for raised sections or voids, dark deposits, and bubbly or scaly paint (Figure 9-20). Use the coin tap method to inspect suspect areas for voids.

D. Inspect the trailing edge bond lines for voids or openings, dark deposits, and bubbly or scaly paint (Figure 9-20). Use the coin tap method to inspect suspect areas for voids. Use only plastic shim stock (.001"/.025 mm) for determining the depth of voided areas.

E. Inspect the bond lines at the root doubler and retention plate edges for paint cracking or scaling, dark deposits, and void in the fairing compound (Figure 9-20). Use the coin tap method to inspect suspect areas for voids. Use only plastic shim stock (.001"/.025mm) for determining the depth of the voided areas.

F. Inspect the main rotor blade spar (Figure 9-21 and Figure 9-22), skins, trim tabs, retention plates, drag link fittings, and root doublers for nicks, scratches, dents, and cracks.

G. Inspect the blade tip rib, trim tabs and drag link fittings for loose rivets.

NOTE

Normal service life for the blade tape is 200 - 300 hours; however, if the aircraft is operated in rain, service life for the tape can be considerably shortened.

NOTE

Visually inspect the blade tape for security and damage after the aircraft is operated in rain.

H. If installed, inspect the main rotor leading edge blade tape for security of installation, tears or punctures, and bubbles or lumpy surface.




Figure 9-18. Main Rotor Blade Leading Edge Definition

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-19. Main Rotor Blade Spar Corrosion Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-20. Main Rotor Blade Bond Separation Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL





Figure 9-21. Main Rotor Blade Leading Edge Damage Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



Sheet 2 of 2

Figure 9-21. Main Rotor Blade Leading Edge Damage Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-57

Rev. 4
Jun 21/12

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-22. Main Rotor Blade Spar Damage Limits
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-23. Main Rotor Blade Leading Edge Repair Limits
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 9-24. Main Rotor Blade Spar Repair Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED




Figure 9-25. Main Rotor Blade Trailing Edge Repair Limits

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

9-10. Repair – Main Rotor Blades

- A. Repair small areas of the paint finish using the following:

NOTE

Refinish the blades equally if refinishing a larger area (outboard leading edge for example) to maintain the continuity of the weight between the blades.

- (1) Work the area lightly with medium grit aluminum oxide abrasive paper/cloth.
- (2) Wash the area with mild soap and water.

WARNING

Acetone and Methylethylketone (MEK) are toxic and must be used with extreme caution. Make sure adequate ventilation is provided. Repeated or prolonged contact with the skin should be avoided. A low-volatile substitute, such as Extreme Simple Green, is a preferred solvent.

- (3) Degrease the area with denatured alcohol, Extreme Simple Green, or equivalent.

NOTE

Application of the chemical conversion coating is only required if the bare metal is exposed on the main rotor blade.

WARNING

Use the proper protective equipment when working with the metal prep. Observe the precautionary information and instructions provided with the metal prep.

- (4) Treat the repaired area of the blade with a metal prep. Flush thoroughly with fresh water and allow to dry.

WARNING

Use the proper protective equipment when working with the chemical conversion coating. Observe the precautionary information and instructions provided with the chemical conversion coating.

- (5) Treat the blade as required with a chemical conversion coating complying with MIL-DTL-5541/MIL-DTL-81706 or equivalent.
- (6) Clean the area with Extreme Simple Green, or equivalent.
- (7) Apply a coat of Desoto # 593 X 300 epoxy primer or equivalent and allow to dry.
- (8) Finish the area with a flat acrylic aerosol paint.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

B. Repair blade spars with flaking or slivering less than .032"/0.8 mm in depth or a light grainy surface as follows:

NOTE

Contour the reworked area evenly along the blade and rework the blade set equally to maintain the blade weight continuity of the blade set.

NOTE

Use care when removing the corrosion contamination to prevent from contaminating other areas or blades.

- (1) Remove the surface corrosion from the area using medium grit aluminum oxide abrasive paper/cloth or an aluminum oxide flapping wheel.
- (2) Wash the reworked area thoroughly with mild soap and water, flush thoroughly.

WARNING

Use the proper protective equipment when working with the metal prep. Observe the precautionary information and instructions provided with the metal prep.

- (3) Treat the repaired area of the blade with a metal prep. Flush thoroughly with fresh water and allow to dry.

WARNING

Use the proper protective equipment when working with the chemical conversion coating. Observe the precautionary information and instructions provided with the chemical conversion coating.

- (4) Treat the blade as required with a chemical conversion coating complying with MIL-DTL-5541/MIL-DTL-81706 or equivalent.
- (5) Refinish the area either using the small area repair in paragraph 9-10, A, or if the entire blade needs refinishing, use paragraph 9-11.

C. Repair blade spars with flaking or slivering exceeding .032"/0.8 mm in depth but not the limits in Figure 9-19 as follows:

- (1) Apply corrosion inhibitor to the affected area daily.
- (2) Contact the Enstrom Customer Service Department for further instructions.

NOTE

Main rotor blades with intergranular spar corrosion (exfoliation) exceeding the limits of Figure 9-19 must be rejected as unairworthy.

D. Repair voids in the spar to skin bond lines that do not exceed the limits of Figure 9-20 as follows:

NOTE

Bond separations (voids) in the main rotor blade bond joints cannot be repaired/rebonded. The following repair provides corrosion treatment and sealing of the voided area until the void exceeds the allowable limits and the main rotor blade must be rejected as unairworthy.

- (1) Remove the paint and or surface corrosion from the voided area with aluminum oxide abrasive paper.
- (2) Degrease the area with denatured alcohol, Extreme Simple Green, or equivalent.

CAUTION

Do not heat the bond line to more than 250°F/121°C.

- (3) Warm the area to approximately 180-200°F/82-93°C to evacuate any residual moisture.
- (4) Apply corrosion inhibitor and allow to dry for 30 minutes.
- (5) Wipe the area with denatured alcohol, Extreme Simple Green, or equivalent.
- (6) Seal the area with Hysol Type EA 9309.2NA epoxy sealant.
- (7) Refinish the area in accordance with paragraph 9-10, A, above or paragraph 9-11 depending on the paint condition of the rest of the blade.
- (8) Enter into the maintenance log book the main rotor blade serial number and the location of the repair.
- (9) Visually inspect the repaired area for further growth of the bond separation during the preflight check or daily inspection. Inspect the repaired area for further growth of the bond separation using the coin tap method at 25 hour intervals.

E. Repair voids in the trailing edge bond lines not exceeding the limits in Figure 9-20 using the procedure in paragraph 9-10, D, except for the following:

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) Inspect repairs outboard of Sta. 101 using the coin tap method at the normal periodic inspection interval.
- (2) Inspect repairs inboard of Sta. 101 using the coin tap method at 25 hour intervals.

F. Repair voids in the root doubler and retention plate edge bond lines not exceeding the limits in Figure 9-20 using the procedure in paragraph 9-10, D.

G. Damage to the blade spar not exceeding the limits in Figures 9-21 and Figure 9-22 must be repaired I/A/W Figure 9-23 and Figure 9-24. Reject any blades that have damage exceeding the limits in Figures 9-21 and Figure 9-22.

H. Reject blades with the following blade skin damage:

- (1) Punctures in the blade skin.
- (2) Sharp dents with a width to depth ratio less than 3:1 and deeper than .020"/.51 mm.
- (3) Smooth dents which have resulted in permanent skin deformation greater than .060"/1.5 mm in depth.
- (4) Nicks and scratches in the cordwise direction greater than .010"/.25 mm in depth.
- (5) Nicks and scratches orientated within $\pm 30^\circ$ of the spanwise direction greater than .020"/.51 mm in depth.
- (6) Trailing edge cordwise dents or nicks deeper than .20"/5.1 mm.
- (7) Trailing edge flapwise kinks extending more than .20"/5.1 mm.
- (8) Cracks.

I. Repair blade skins with damage not exceeding the limits in paragraph 9-10, H, above as follows:

- (1) Buff out all light scratches.
- (2) Polish out nicks, scratches, and sharp dents and blend the area to approximately .50"/13 mm around the damaged area.
- (3) Repair damage to the trailing edge in accordance with Figure 9-25.
- (4) Smooth dents that do not exceed the damage limits are acceptable and no repair is required.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE

Refinish the repaired area in accordance with paragraph 9-10, A, or paragraph 9-11 depending on the condition of the rest of paint finish.

J. Reject blades with the following root doubler damage:

- (1) Nicks, scratches, and sharp dents in the cordwise direction greater than .010"/.25 mm in depth.
- (2) Nicks, scratches, and sharp dents orientated within $\pm 30^\circ$ of the spanwise direction greater than .020"/.51 mm in depth.
- (3) Smooth dents deeper than .020"/.51 mm.
- (4) Cracks.

K. Repair blade doublers with damage not exceeding the limits in paragraph 9-10, J, as follows:

- (1) Buff out all light scratches.
- (2) Polish out nicks, scratches, and sharp dents and blend the area to approximately .50"/13 mm around the damaged area.
- (3) Smooth dents that do not exceed the damage limits are acceptable and no repair is required.

NOTE

Refinish the repaired area I/A/W paragraph 9-10, A, or paragraph 9-11 depending on the condition of the rest of paint finish.

L. Reject blades with the following blade retention plate damage:

- (1) Nicks, scratches, and sharp dents greater than .050"/1.3 mm in depth.
- (2) Cracks.

M. Repair blade retention plates with damage not exceeding the limits in paragraph 9-10, L, as follows:

- (1) Buff out all light scratches.
- (2) Polish out nicks, scratches, and sharp dents and blend the area to approximately 2.0"/5.1 cm diameter area.

NOTE

Refinish the repaired area I/A/W paragraph 9-10, A, or paragraph 9-11 depending on the condition of the rest of paint finish.

NOTE

Do not paint the blade grip mating surface of the retention plates.

N. Repair trim tabs as follows:

- (1) Flatten dents or kinks and polish out scratches and nicks.
- (2) Drill out and replace loose rivets.

O. Reject blades with the following drag link fitting damage:

- (1) Nicks or scratches greater than .010"/.25 mm deep.
- (2) Cracks.
- (3) Loose rivets.

P. Repair drag link fittings with damage not exceeding the limits in paragraph 9-10, O, as follows:

- (1) Buff out all light scratches.
- (2) Polish out nicks, scratches, and sharp dents.

NOTE

Refinish the repaired area I/A/W paragraph 9-10, A, or paragraph 9-11 depending on the condition of the rest of paint finish.

NOTE

Do not paint the drag link mating surface of the drag link fittings.

Q. Reject blades that have a cracked tip rib. Replace loose rivets.

R. Install the leading edge blade tape as follows (for blade tape repairs, go to step S):

NOTE

Prior to installation of the blade tape, the spar should be inspected according to paragraph 9-9, B.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

CAUTION

New blade tape should not be installed without proper leading edge preparation and paint cover (paragraph 9-10, A or B). Do not install blade tape on blades with leading edge/spar corrosion without first treating the corrosion.

- (1) Clean the blade with a mild soap and water solution, and rinse with fresh water.
- (2) Allow the blade to dry.
- (3) Coat the area to be taped with MIL-PRF-23377 epoxy primer or equivalent or quality top coat paint such as Sherwin-Williams "Acry Glo" or similar.
- (4) Mark and mask the non-blade tape area as follows:

NOTE

The blade surface area adjacent to the taped area must be masked to avoid sanding the non-taped area.

- a. Measure 108.4" from the end of the blade tip, mark with a pencil, and apply masking tape at this measurement from the spar edge to at least 0.100" beyond the spar seam. Measure, mark, and mask the bottom side of the blade as well.
 - b. Apply masking tape along the blade length from the blade tip to the pencil marks at a distance of 0.100" from the spar seam.
- (5) Sand the exposed area to be taped with 400 grit sand paper or Scotch Brite 7447B to produce a smooth surface. Remove the masking tape after sanding is completed.

NOTE

The blade tape is installed in three 36-inch long sections.

- (6) Mark the area for blade tape as follows:
- a. Measure a distance of 0.100" from the blade tip. This marks the start of the blade tape.
 - b. Measure a distance of 108.4" from the blade tip. This marks the end of the blade tape.
 - c. Measure from the leading edge of the blade back on the topside of the airfoil $\frac{1}{2}$ the distance of the width of the tape (2 $\frac{1}{2}$ inches) and mark the surface with a pencil. Do this at the tip of the blade and toward the root end of the blade at the 108.4" mark.
- (7) Above the marks, stretch a length of masking tape from the blade tip to the 108.4" mark to create a straight reference line.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (8) Butt the top edge of three 8681HS tape sections against the masking tape reference line applied in step (7) above and use 1 inch long tabs of masking tape to hold it in place. Maintain a 0.100" gap between each section of 8681HS tape.
- (9) Apply another 1 inch wide strip of masking tape along the entire top edge of the 8681HS tape to form a soft hinge (Figure 9-26, a).
- (10) Fold the 8681HS tape back onto the top of the blade (Figure 9-26, b).
- (11) Apply 3M Adhesion Promoter # 86A to the entire area that will be covered by 8681HS tape. Use pre-wetted wipes or the adhesion promoter P/N 86 A and clean cheese cloth to apply the 86A and rubber gloves to protect hands. Apply only enough to wet the surface, so it appears shiny. Wipe off any excess to ensure no runs or drips. Allow to dry for 10 to 20 minutes or until the surface does not appear shiny.
- (12) Spray the surface of the treated area of the blade with a previously prepared solution of water, isopropyl alcohol, and detergent.
 - a. Solution: Mix 70% water with 30% isopropyl alcohol in a 1 pint spray bottle. Add 4 drops of a non-ionic detergent such as Joy brand dish detergent.
- (13) Beginning at the edge of the blade tape, remove the first protective liner strip from the blade tape nearest the soft hinge. Spray the sticky side of the tape with solution from step 12(a). There are four protective liner strips for each 36-inch long section. Fold the tape down onto the blade and allow it to float into its favored location (Figure 9-26, c).
- (14) Use a soft plastic squeegee to force the liquid out from behind the tape, starting at the hinge corner and working forward (Figure 9-26, d). Carefully work to end of the tape section. Repeat steps (13) and (14) for the remaining three protective liner strips.
 - a. Avoid touching the exposed adhesive tape surface.
 - b. Use a dry towel to mop up excess solution on the back edge.
 - c. Carefully work around the leading edge and around toward the trailing of the tape on the other side.
 - d. If a bubble of liquid or air is trapped under the tape, pull the tape back up to free the bubble, re-spray the area and squeegee to make it smooth and bubble free. DO NOT puncture bubbles to relieve entrapped air or liquid, especially on the leading edge.

NOTE

A smooth, continuous taped surface is necessary for optimal blade performance.

- e. Repeat the process for the remaining two 36-inch long tape sections.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (15) Remove the "hinge" tape on the top edge and squeegee out excess fluid, while mopping excess up with a dry towel. Minute quantities of fluid which may be trapped, such as around fasteners, dissipate quickly.
- (16) Seal the space between the ends of the sheets and the trailing edges with 3M DP190 epoxy adhesive using the following procedure:
 - a. Mask off both sides of the 8681HS tape approximately 1/16" from the edge with "3M Fine Line" tape.
 - b. Apply sealant between the masked off area and use a stiff applicator to screed off the excess. Remove the strips of masking tape within a few minutes, before complete gelling has occurred, to allow the sealant to flow to a nice tapered edge. DP190 will gel in 90 minutes at 72°F and full cure will be achieved in about 8 hours. It will cure faster in warmer temperatures, slower in cooler temperatures. In warm weather it helps to allow the top surface to cure before turning the blade over to seal the second side so that the sealer does not form a bulge.
 - c. After the sealant is cured, inspect the sealant bead at the tape joints and the trailing edge.
- (17) Lightly sand excess sealant to match the blade contour.

NOTE

A sealant bead flush with the blade contour is necessary for optimal blade performance.

- a. Mask the sealant line around the area to be sanded. Lightly sand the contour using 3M 214U 80 grit and then 3M 214U 150 grit to blend the edges.




Photo a: Applying masking tape to provide the soft hinge (step 9).

Photo b: Folding the blade tape back (step 10) in preparation for blade surface treatment (steps 11 and 12).

Photo c: Positioning the blade tape for application (step 13).

Photo d: Applying blade tape to the blade top side and using a squeegee to remove liquid from under the tape as the tape is applied around the forward edge of the blade (step 14).

Figure 9-26. Blade Tape Installation

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

- S. Repair the leading edge blade tape as follows:

CAUTION

The blade must be inspected and certified to be in airworthy condition prior to installation or repair of the tape. The area where the tape will be applied must be smooth and clean. New blade tape should not be installed without proper leading edge preparation and paint cover. Refer to the paragraph 9-10, A or B, for repair and refinish instructions prior to tape application. The area to be taped will be coated with MIL-PRF-23377 epoxy primer or equivalent or quality top coat paint such as Sherman-Williams "Acry Glo" or similar.

- (1) Mark a line on the blade on either side of the damaged section at right angles to the edge of the tape line (Figure 9-27, a).

WARNING

Use extreme care not to cut into or nick the blade under the tape when cutting out the damaged section of tape. Nicking the spar could lead to catastrophic blade failure.

- (2) Use a razor blade to cut the tape along this line.
- (3) Carefully remove the section of tape between the cut lines.
- (4) Use a sharp blade or knife to scrape the gray epoxy edge sealer from the top and the bottom of the blade tape line. Take care not to damage the paint on the blade.
- (5) Use sandpaper (400 grit) to remove any corrosion on the blade and treat as follows:
- a. Coat blade tape repair area with MIL-PRF-23377 epoxy primer, or equivalent, or quality top coat paint such as Sherman-Williams "Acry Glo", or similar, prior to application (Figure 9-27, b).
- (6) Stretch a piece of masking tape along the forward edge of the epoxy tape sealer on the top of the blade.
- (7) Cut a repair piece of tape from the 8681HS tape that is a total of 1/8 inch (.318 cm) shorter than the area of the tape that has been cut out for repair.
- (8) Butt the top edge of the 8681HS tape against the forward edge of the already installed masking tape and apply a second length of masking tape along the aft edge of the patch to form a soft hinge.
- (9) Fold the 8681HS tape back onto the top of the blade.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (10) Apply the 3M adhesion Promoter #86A to the entire area of the blade that will be covered by the 8681HS tape. Use pre-wetted wipes or the adhesion promoter P/N 86A applied to clean cheese cloth (use rubber gloves for protection). Apply only enough to wet the surface so it appears shiny. Wipe off any excess to ensure no runs or drips. Allow to dry for 10 to 20 minutes or until the surface does not appear shiny.
- (11) Remove the protective liner from the adhesive surface of the blade tape and spray the adhesive surface of the tape and the treated area of the blade with a wetting solution of water and isopropyl alcohol (step R, (1), a).
- (12) Fold the 8681HS tape down onto the blade and allow it to float into position. The top and bottom of the tape should be butted against the line where the epoxy adhesive DP190 has been scraped off. There should be approximately a 1/16 inch (.157 cm) gap between both sides of the patch and the already installed leading edge tape.
- (13) Remove the "hinge tape" on the top edge and use a soft plastic squeegee to force the liquid out from behind the 8681HS tape, starting at the leading edge and working back towards the trailing edge on both the top and the bottom of the blade. Use a dry towel to mop up excess solution at the edges of the tape.

NOTE

If a bubble of liquid or air is trapped under the tape, pull the tape back up to free the bubble, re-spray the area and squeegee the tape back down to make it smooth and bubble free. DO NOT puncture bubbles to relieve entrapped air or liquid, especially on the leading edge.




Photo a: Marking area for repair (step 1).

Photo b: Applying epoxy primer (step 5, a).

Photo c: Sealant applied to repair area (step 14).

Figure 9-27. Blade Tape Repair

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-9-73

Rev. 4
Jun 21/12

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (14) Seal the space between the patch and the older pre-existing leading edge tape, and the trailing edges of the patch with the DP190 epoxy adhesive using the following procedure (Figure 9-27, c):
 - a. Mask off both sides of the edge of the patch, all the way around the patch, with masking tape approximately 1/16 inch (.157 cm) from the edge of the patch. Use fine line tape or equivalent.
 - b. Apply sealant between the masked off area and use a stiff applicator, or your finger, to screed off the excess sealant. Immediately remove the strips of masking tape to allow the sealant to flow to a nice tapered edge. DP190 will gel in 90 minutes at 72° and full cure will be achieved in about 8 hours. It will cure faster in warmer temperatures and slower in colder temperatures.
- (15) After full cure, check the sealant to see how much bulge remains. If the bulge is higher than the sealer at the aft edge of the original tape, use a sharp blade to scrape the top of the bulge down so it is flush with the existing sealer.

9-11. Refinishing – Main Rotor Blades

WARNING

Use the proper protective equipment when working with the paint stripper. Observe the precautionary information and instructions provided with the paint stripper.

NOTE

The main rotor blades are treated with a chemical conversion coating (alodine) during the manufacturing process. Attempt to preserve the coating as much as possible during the paint removal process.

- A. Apply Eldorado PR-3500 paint stripper or other suitable stripper to the blade. Remove the paint residue with a plastic (body putty) spatula when the paint starts to wrinkle. Apply additional stripper as required. Finish cleaning the main rotor blade using water and a Scotch-Brite™ Pad (7447B).
- B. Inspect the blade I/AW paragraph 9-9 (tail rotor blade para. 10-1, F).
- C. Repair the blade I/AW paragraph 9-10 (tail rotor blade para. 10-1, F).
- D. Wash the blade with mild soap and water and flush thoroughly.

WARNING

Use the proper protective equipment when working with the metal prep. Observe the precautionary information and instructions provided with the metal prep.

- E. Treat the repaired area of the blade with a metal prep. Flush thoroughly with fresh water and allow to dry.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

WARNING

Use the proper protective equipment when working with the chemical conversion coating. Observe the precautionary information and instructions provided with the chemical conversion coating.

F. Treat the blade as required with a chemical conversion coating complying with MIL-DTL-5541/MIL-DTL-81706.

G. Wipe the blade with Extreme Simple Green, or equivalent using clean rags.

NOTE

Do not paint the drag link mating surface of the drag link fittings.

H. Apply DeSoto Epoxy Polyamide Primer 513 X 390 (MIL-PRF-23377) or other suitable epoxy primer as follows:

NOTE

Apply the primer in thin, even coats.

NOTE

It is important that the trailing edges of the main and tail rotor blades have good coverage.

(1) Apply two coats to the spar and feather the coats past the spar to skin bond lines. Apply two coats to the trailing edge straight on. Apply the third coat to the whole blade.

(2) The application is the same for the tail rotor blades except that the whole blade gets all three coats.

I. Paint the finish coat with any good quality flat or satin finish polyurethane paint.

CAUTION

Refinishing main rotor blades will require retracking the main rotor system. The rotor system may also be dynamically balanced using a Chadwick Balancing System.

CAUTION

Tip weight changes must be made to keep 75% of the blade tip weight in the forward pocket to maintain the cordwise balance.

CAUTION

Refinished tail rotor blades will be required to be statically and dynamically rebalanced.

9-12. Corrosion Prevention – Main Rotor Blades

A. Refer to paragraph 4-83 and SIL 0170 for the application of corrosion prevention compound to the main rotor blades.

9-13. Installation – Main Rotor Blades (Figure 9-17)

WARNING

Do not align the holes in the grip and blade by placing your finger in the retention bolt hole.

NOTE

Lifting the tip of the blade so the blade is parallel to the retention assembly will allow easy installation of the blade into the blade grip, installation of the blade bolt, and the drag brace bolt. If desired, use the main rotor blade bolt guide bullet, T-0009, to aid installation of the blade bolts.

- A. Install the root end of the blade into the blade grip.
- B. Align the retention bolt hole in the grip with the hole in the blade. Install the bolt (2), washer, and nut. Torque the nut to 600 in-lbs/68.2 Nm.
- C. Connect the drag link to the trailing edge of the blade and secure with the hardware (1). Torque the nut to 140 in-lbs/15.9 Nm.
- D. Repeat the process for the other blades.
- E. Perform a maintenance test flight if maintenance was performed on the main rotor blades.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 10 TAIL ROTOR TABLE OF CONTENTS

Paragraph		Page
<u>10-1</u>	Tail Rotor Assembly	MM-10-3
	A. General Description	MM-10-3
	B. Troubleshooting	MM-10-3
	C. Removal	MM-10-4
	D. Disassembly.....	MM-10-4
	E. Cleaning	MM-10-7
	F. Inspection.....	MM-10-7
	G. Repair	MM-10-7
	H. Refinishing	MM-10-9
	I. Assembly	MM-10-11
	J. Pitch Link Inspection, Repair, Assembly, and Installation	MM-10-13
	K. Installation	MM-10-17
<u>10-2</u>	Static Balance	MM-10-25
	A. Balance Procedure	MM-10-25
<u>10-3</u>	Tracking and Dynamic Balance	MM-10-27
	A. Tracking and Balancing Equipment Installation.....	MM-10-27
	B. Tail Rotor Balance Procedure.....	MM-10-29
	C. Clock Angle Correction Procedure	MM-10-31
	D. Teeter Trunnion Shimming Procedure.....	MM-10-36
<u>10-4</u>	Tail Rotor Pitch Control Assembly	MM-10-37
	A. Removal	MM-10-37
	B. Disassembly.....	MM-10-37
	C. Inspection.....	MM-10-39
	D. Assembly	MM-10-39
	E. Installation	MM-10-40
<u>10-5</u>	Tail Rotor Gearbox	MM-10-45
	A. General Description	MM-10-45
	B. Troubleshooting	MM-10-45
	C. Removal	MM-10-45
	D. Inspection.....	MM-10-46
	E. Installation	MM-10-46
	F. Input Seal Replacement	MM-10-47
	G. Output Seal Replacement.....	MM-10-49
	H. Output Shaft Runout	MM-10-51
<u>10-5.1</u>	Tail Rotor Gearbox Chip Detector.....	MM-10-52
	A. Removal	MM-10-52
	B. Installation	MM-10-52
<u>10-6</u>	Tail Rotor Driveshaft	MM-10-54
	A. Alignment	MM-10-54
	B. Removal	MM-10-55
	C. Disassembly.....	MM-10-55
	D. Inspection.....	MM-10-56
	E. Installation	MM-10-56

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 10

TAIL ROTOR

TABLE OF CONTENTS – CONTINUED (PAGE MM-10-2)

Paragraph	Page
<u>10-6.1</u> Tail Rotor Driveshaft Flex Coupling	MM-10-60
A. General Information	MM-10-60
B. Removal	MM-10-60
C. Inspection.....	MM-10-60
D. Installation	MM-10-61
<u>10-6.2</u> Tail Rotor Driveshaft Pillow Block	MM-10-65
A. Disassembly.....	MM-10-65
B. Inspection.....	MM-10-65
C. Assembly	MM-10-65
<u>10-6.3</u> Tail Drive Pulley Guard	MM-10-65
A. Modification	MM-10-65
<u>10-7</u> Tail Rotor Control System	MM-10-67
A. Tension Adjustment	MM-10-67
B. Rigging	MM-10-67
<u>10-8</u> Tail Rotor Control Cables	MM-10-70
A. Inspection.....	MM-10-70
B. Replacement.....	MM-10-71

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

10-1 TAIL ROTOR ASSEMBLY

A. General Description – Tail Rotor Assembly

The tail rotor assembly consists of two blade and grip units mounted on a common spindle by the use of a pair of matched DT ball bearings and one needle bearing per grip. This rotating assembly is teeter-mounted on a center hub by the use of two roller bearings. The center hub is splined to match the tail rotor gearbox output shaft for positive mounting and driving. The control of this assembly is blade to pitch link, to sliding pivot yoke, to cables, cables to bell crank and bell crank to foot pedals in the cockpit.

B. Troubleshooting – Tail Rotor Assembly

NOTE: Previous tail rotor assembly P/N 28-150050 is superseded and replaced by P/N 28-150079.

Problem	Possible Cause	Required Action
Foot pedal controls are binding	Pivot bolts on tail rotor bracket overtorqued	Loosen pivot bolts and retorque.
	Improper assembly of pitch links to pitch arm	Install spacers properly to allow for needed clearance on each side of pitch links.
	Tail rotor misaligned on output shaft, causing pitch links to bind	Remove tail rotor and reinstall using correct alignment. Refer to Fig. 10-6.
Noticeable dead spot in tail rotor	Improper tension on control	Check rigging procedure and adjust cables to 35-40 lb/15.9-18.1 kg pedal control cables.
	Feathering bearings worn or rubber bumper shifted and binding	Disconnect pitch links and rotate grips to determine problem blade. Replace faulty or worn parts.
Tail rotor vibration	Out of balance	Dynamic balance.
	Excessive axial play in the hub teeter bearings (P/N 28-150079 tail rotor assembly)	Reshim (Para. 10-1.I.(1)(h)) or replace the teeter bearings (Para. 10-1.G).
	Tail stringer clamp loose on aft bulkhead	Replace clamp attaching hardware, as required or replace bulkhead.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Problem	Possible Cause	Required Action
Tail rotor vibration (continued)	Excessive end play in teeter bearings, creating out of balance condition (P/N 28-150050 tail rotor assembly)	Remove tail rotor assembly and retighten retainer caps until hub rotates firmly by hand with no end play. Grease and static balance. NOTE: If teeter bearings are bad, they may be replaced without removing blade and grip assemblies.
	Improper lubrication	Both grips must be greased each time tail rotor is lubricated or an out of balance condition will result.

NOTE: The following instructions pertain to tail rotor assembly P/N 28-150079. Tail rotor assembly P/N 28-150050 is no longer supported.

C. Removal – Tail Rotor Assembly

NOTE: Refer to Fig. 10-1 for numbered items.

NOTE: Index mark (color code) the pitch change links to the pitch change plates.

NOTE: Retain the order of the hardware stack-up for ease of installation.

- (1) Remove bolt (1), washers (5), (13), and (8), spacers (10) and (9), and nut (6) to disconnect pitch change links from the pitch plates (horn) (Fig. 10-3, left).
- (2) Remove safety wire from the tail rotor retention bolt. Remove bolt (31), washer (30), and teeter stop (29).

NOTE: Index mark hub and shaft splines for ease of installation.

- (3) Carefully slide tail rotor assembly from the transmission output shaft.
- (4) Temporarily install teeter stop (29), washer (30), and bolt (31) or a PD-40 (-4 plug) into the transmission output shaft to prevent oil leaking from the gearbox.


D. Disassembly – Tail Rotor Blade Assembly

NOTE: The removal procedures are the same for both blade and grip assemblies.

CAUTION: USE BRASS PROTECTOR PLATED IN THE VISE JAWS TO PREVENT FROM DAMAGING THE TAIL ROTOR SPINDLE OR INSTALL SPINDLE ON TOOL T-0168-1.

- (1) Clamp tail rotor assembly in a vise so that the blades can be rotated.
- (2) Remove retention bolt safety wire from around center hub.
- (3) Remove bolts (26), washers (27), and nuts (28) from the pitch change plates (11).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | | |
|-----|--------------------|-----|-------------------------|
| 1. | Tail Rotor Spindle | 17. | Lock Washer |
| 2. | Tail Rotor Hub | 18. | Bumper |
| 3. | Washer | 19. | Blade and Grip Assembly |
| 4. | Bearing Journal | 20. | Dowel Pin |
| 5. | Teeter Bearing | 21. | Lubrication Fitting |
| 6. | Seal | 22. | Strike Indicator |
| 7. | Thrust Bumper | 23. | Washer |
| 8. | Shims | 24. | Screw |
| 9. | End Plate Assembly | 25. | Bolt |
| 10. | Retaining Ring | 26. | Bolt |
| 11. | Pitch Change Plate | 27. | Harper Washer |
| 12. | Bearing Sleeve | 28. | Nut |
| 13. | Bearing | 29. | Teeter Stop |
| 14. | Bearing Retainer | 30. | Washer |
| 15. | Thrust Bearing Set | 31. | Bolt |
| 16. | Nut | | |

Figure 10-1. Tail Rotor Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (4) Remove safety wire and bolts (25) from the pitch change plates.

NOTE: Remove the lubrication fitting (21) from the blade grip to ease removal and installation of the blade and grip assembly.

CAUTION: DO NOT TAP ON THE ROOT OF THE BLADE DURING THE REMOVAL PROCESS OR REMOVE THE BLADE FROM THE BLADE GRIP. THEY ARE MATCH DRILLED WHEN ASSEMBLED.

- (5) Use a rubber hammer to tap retention plate (11) to loosen it from the blade grip.

WARNING: USE EXTREME CAUTION WHEN REMOVING OR INSTALLING THE BLADE AND GRIP ASSEMBLIES TO PREVENT FROM INJURING PERSONNEL. USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.

NOTE: A deflector may be used as an aid during heating the grip.

- (6) Loosen blade retention bolt nuts slightly (sufficient to remove the torque and clearance is observed between the nut and the grip) and heat blade grip to approximately 250°F/121°C.
- (7) Remove blade and grip assembly (19) by pulling on the blade with one hand and tapping on the blade bolt nuts with a nylon hammer. If required, rotate tail rotor assembly and remove the opposite blade and grip assembly.
- (8) Remove bumper (18) from the end of the spindle.
- (9) Remove lock washer (17) by prying up on the tabs with a screw driver.
- (10) Remove nut (16) from spindle using tool T-0056-3 or T-0056-1 if available. If tangs on the nut are damaged, T-0056-1 can be used with an impact wrench to remove the nut.

NOTE: The thrust bearings are matched sets. Keep together.

- (11) Remove thrust bearings (15) from spindle.
- (12) Remove bearing retainer (14) and bearing (13).
- (13) Remove bearing sleeve (12).
- (14) Remove pitch change plate (11).
- (15) Remove retaining rings (10), end plates (9), shims (8), thrust bumpers (7) and seals (6) from the spindle.

CAUTION: WHEN PRESSING THE BEARINGS OUT OF THE SPINDLE, DO NOT ALLOW THE HUB TO BOTTOM AGAINST THE SPINDLE.

- (16) Using tool kit T-2893 or other suitable device with a properly sized dowel, press hub (2) toward one side of the spindle until the hub is about to contact the spindle. Turn the spindle over and press the hub and opposite needle bearing in the same manner.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (17) Move hub to the opposite side of the spindle as the bearing to be removed and insert the split pressing tools from the tool kit onto the journal (4). Press needle bearing (5) from the spindle. Insert the T-2893 split pressing tools onto the opposite side of the hub and press out the remaining needle bearing.

NOTE: The journals are installed with Loctite 277 (red). It will be necessary to heat the journals to 250°F to soften the Loctite and remove the journals.

- (18) Using the tool kit or other suitable device, remove one of the journals from the hub. Remove the hub from the spindle and remove the remaining journal and the washers (3).

E. Cleaning – Tail Rotor Assembly

NOTE: Care should be used in cleaning the tail rotor to prevent scratching or damaging parts.

- (1) Wash parts in cleaning solvent.
- (2) Wash bearings in clean solvent to prevent contamination of the bearings.

F. Inspection – Tail Rotor Assembly

- (1) See Table 10-1 for detailed inspection requirements for the tail rotor assembly.
- (2) Inspect paint finish of the blades for blistering, erosion, cracking, chipping, peeling, and overall oxidation.
- (3) Inspect trailing edge bond lines for voids or openings, dark deposits, and bubbly or scaly paint.
- (4) Inspect spar bond lines for raised sections or voids, dark deposits, and bubbly or scaly paint.
- (5) Inspect bond lines at the doubler edges for paint cracking or scaling, dark deposits, and void in the fairing compound.
- (6) Inspect tail rotor blade skins, abrasion strip, retention plates, and root doublers for nicks, scratches, dents, and cracks.
- (7) Inspect blade tip rib for loose rivets.

G. Repair – Tail Rotor Assembly

CAUTION: THE TAIL ROTOR ASSEMBLY MUST BE STATICALLY AND DYNAMICALLY REBALANCED AFTER ANY REPAIR.

NOTE: Refinish the repaired area in accordance with Para. 9-10.A, or Para. 9-11 depending on the condition of the rest of paint finish.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) Repair small areas of the paint finish (Para. 9-11).
- (2) Reject tail rotor blades with the following bond line separations or voids:
 - (a) Trailing edge separations deeper than .050 inch/1.3 mm or more than 2.0 inch/5.1 cm in length.
 - (b) Stainless steel abrasion strip separations more than 2.0 in/5.1 cm from the tip of the blade or deeper than .062 inch/1.6 mm.
 - (c) Root doubler separations closer than 2.0 in/5.1 cm from the tip of the doubler under which the separation appears, or greater than 1.0 in/2.5 cm in length, or deeper than .062 in/1.6 mm.
- (3) Repair voids and separations of the tail rotor blade bond lines that do not exceed the limits step (2) above, in accordance with Para. 9-10.D.
- (4) Reject tail rotor blades with the following blade skin damage:
 - (a) Scratches, nicks, or sharp dents deeper than .010 in/.25 mm.
 - (b) Nicks in trailing edge deeper than .100 in/2.5 mm.
 - (c) Smooth dents exceeding .025 in/0.6 mm.
 - (d) Cracks or punctures.
- (5) Repair damage to the blade skins not exceeding the limits in step (4) above as follows:
 - (a) Buff out all scratches not deep enough to penetrate the clad material.
 - (b) Blend scratches, nicks, or sharp dents out smooth over a 2.0 in/5.1 cm diameter area.
 - (c) Blend out nicks in the trailing edge in accordance with Fig. 10-2.
 - (d) No repair required for smooth dents.
- (6) Reject tail rotor blades with the following abrasion strip damage:
 - (a) Nicks and scratches deeper than .005 in/0.13 mm.
 - (b) Dents deeper than .040 in/0.1 mm.
 - (c) Cracks, punctures, or erosion penetration of the stainless steel.
- (7) Repair damage to the abrasion strip not exceeding the limits in step (6) above, as follows:
 - (a) Blend nicks and scratches out smooth over an area 1 in/2.5 cm long (parallel to the leading edge) by .50 in/0.13 mm wide.
 - (b) No repair required for smooth dents.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (8) Reject tail rotor blades with the following root doubler damage:
 - (a) Nick, scratches, or sharp dents deeper than .010 in/.25.
 - (b) Smooth dents deeper than .020 in/5.1 mm.
 - (c) Cracks.
- (9) Repair damage to the root doublers not exceeding the limits in step (8) above, as follows:
 - (a) Blend nicks, scratches, or sharp dents out smooth to approximately .50 in/13 mm on either side of the damaged area.
 - (b) No repair required for smooth dents.
- (10) Reject tail rotor blades with the following retention plate damage:
 - (a) Nick, scratches, or sharp dents deeper than .030 in/0.8 mm.
 - (b) Cracks.
- (11) Repair damage to the retention plates not exceeding the limits in step (10) above as follows:
 - (a) Blend nicks, scratches, or sharp dents out smooth to approximately 1.0 in/2.5 cm in diameter.
- (12) Reject tail rotor blades with cracked tip ribs.
- (13) Replace loose rivets.

H. Refinishing – Tail Rotor Assembly

- (1) Remove tail rotor assembly and disassemble.
- (2) Index mark hardware in the blade and grip assembly.
- (3) Remove hardware from the blade and grip assemblies and separate the blades from the grips.
- (4) Refinish blades (Para. 9-11).
- (5) Reinstall blades into the grips. Torque blade retention bolt nuts to 75 in-lb/8.5 Nm (140 in-lb/15.9 Nm if the blade and grip assembly has been factory repaired and 5/16 inch bolts installed).
- (6) If required, reassemble tail rotor assembly.
- (7) Statically balance tail rotor assembly (Para. 10-2).




Figure 10-2. Tail Rotor Blade Trailing Edge Repair Limits

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

I. Assembly – Tail Rotor Assembly (Fig. 10-1)

(1) Install hub (2) into spindle (1) using the following procedure:

- (a) Install one of the washers (3) onto the hub with the chamfer toward the center of the hub.
- (b) Apply a light coating of Loctite® 277 (red) to the inside diameter of one of the journals (4). Install the journal onto the hub (2) with the large chamfer outboard. Remove any excess Loctite®.
- (c) Install hub (2) into the spindle (1) and install the other washer (3) and journal (4) in the same manner.

NOTE: Position teeter bearing (5) such that the end with the printed manufacturer data is facing outboard.

NOTE: Use ultra fine crocus cloth to eliminate interference fit between the hub journal and the bearing journal.

- (d) Position one of the teeter bearings (5) at the teeter bearing bore of the spindle and using the installation tool from the tool kit T-2893 press the bearing into the spindle.

NOTE: Install the teeter bearing (5) into the spindle (1) to a depth of .191/.193 inch if not using tool kit T-2893.

CAUTION: ENSURE THE HUB AND JOURNAL ARE ALIGNED WITH THE REMAINING NEEDLE BEARING DURING INSTALLATION TO PREVENT ANY DAMAGE.

- (e) Turn spindle over and insert hub (2) into teeter bearing (5) that was just installed. Install the remaining teeter bearing (5).

- (f) Check that the hub rotates freely in the bearings. Determine the cause if the hub does not rotate freely.

- (g) Install seal (6), thrust bumper (7) with the lubrication grooves toward the hub, end cap (9), and retaining ring (10) in both sides of the spindle.

NOTE: Ensure the retaining ring is fully seated after installation.

- (h) Determine amount of shims (8) required to remove end play from the hub. Add an additional .004 to .005 in/0.10 to 0.13 mm of shims to each side for preload.

- (i) Remove retaining rings (10) and end plates (9) from the spindle. Divide the shims into two equal amounts. Install the shims between the thrust bumpers (7) and the end caps (9). Reinstall the end caps and retaining rings. If the caps or retaining rings do not seat properly in the spindle, use a pair of non-marring pliers to rotate the cap to seat it properly.

- (j) Check that the hub still rotates freely in the spindle. There should be a slight preload (1/2-1 lb/0.22-.45 kg, 6 in/15.2 cm from the hub) on the hub but the hub should still be able to be rotated.

- (k) Purge lubricate teeter bearings (5) (MIL-G-25537 (preferred) or MIL-PRF-81322).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: The installation procedures are the same for both blade and grip assemblies.

CAUTION: USE BRASS PROTECTOR PLATED IN THE VISE JAWS TO PREVENT FROM DAMAGING THE TAIL ROTOR SPINDLE.

- (2) Place spindle into a vise so that the blade and grip assemblies can be rotated when installed or use tool T-0168-1.
- (3) Install pitch change plate (11) on the spindle with the machined clearance surface of the pitch arm facing outboard.
- (4) Lubricate (MIL-G-25537 or MIL-PRF-81322) inner diameter of the bearing sleeve (12) and install bearing sleeve onto spindle.
- (5) Lubricate (MIL-G-25537 or MIL-PRF-81322) outside of the bearing (13) and press into bearing retainer (14).

NOTE: Install bearing (13) and retainer (14) on spindle with closed end of the retainer facing outboard toward the thrust bearings.

- (6) Install the thrust bearings (15) in matched sets with the closed side of the bearing facing inboard toward the hub. This side of the bearing will also have the word "thrust" imprinted on the face of the outer race. Most of these bearing sets will be scribed with a "V" on the outer races pointing toward the center hub.
- (7) Install retaining nuts (16) using tool T-0056 and torque to 80-90 ft-lb/109.1-122.7 Nm.
- (8) Align and install lock washer (17).
- (9) Clean surface of the bumper (18) and end of the spindle with acetone or equivalent. Apply a small amount of MIL-G-25537 or MIL-PRF-81322 onto the end of the bumper and the end of the spindle and attach the bumper to the end of the spindle. (The plastic disk on the side of the bumper fits into the bearing retaining nut lockwasher (17).)
- (10) Lubricate (MIL-PRF-81322) the O.D. of the bearings (15).

WARNING: USE EXTREME CAUTION WHEN REMOVING OR INSTALLING THE BLADE AND GRIP ASSEMBLIES TO PREVENT FROM INJURING PERSONNEL. USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.

- (11) Using a heat gun, heat blade grip (19) to approximately 250°F/121°C.
- (12) Place a dab of grease (MIL-G-25537 or MIL-PRF-81322) onto the outboard surface of the bumper (18).
- (13) Lubricate (MIL-G-25537 or MIL-PRF-81322) bore of the blade grip. Quickly slide blade and grip assembly onto the spindle. Align the pitch link hole in the pitch change plate to the leading edge of the blade. Leave about 1/8 inch between the grip and the retention plate.

NOTE: Alternately tighten the bolts 1 to 2 turns to pull the pitch change plate and grip straight together.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (14) Start three bolts (25) into the grip, each closest to a dowel pin (20), and tighten to pull the grip and the pitch change plate together.
- (15) Install remaining bolts (25). After blade and grip assembly has cooled, torque bolts to 50-70 in-lb/5.7-8.0 Nm and safety wire (.032) in pairs.

NOTE: Ensure the safety wire does not interfere with the pitch change link hardware when the blades are alternately pitched.

- (16) Torque blade retention bolt nuts to 75 in-lb/8.5 Nm (140 in-lb/15.9 Nm if the blade and grip assembly has been factory repaired and 5/16 inch bolts installed) after the blade grip has cooled.
- (17) Install grease fitting (21) into grip and lubricate grip (Para. 4-31) until grease purges from the pitch change plate from around the spindle.
- (18) If required, install the opposite blade and grip assembly.
- (19) Statically balance tail rotor (Para. 10-2).
- (20) Install bolts (26), washers (27), and nuts (28) onto the pitch arms, if not installed.

NOTE: Complete static balance procedure before installing the tail rotor on helicopter.

J. Inspection, Repair, Assembly, and Installation – Pitch Link Assembly

NOTE: Pitch change links P/N 28-16345-11 or P/N 28-16391-1 must be installed as same part number pairs (either two P/N 28-16345-11 or two P/N 28-16391-1). Pitch change links P/N 28-16391-3 or P/N 28-16391-5 may be installed in combination with each other but not in combination with P/N 28-16345-11 or P/N 28-16391-1. For the barrel type, the pitch change link length and rod end orientation has been set at the factory. Do not disassemble unless the rod ends need replacement. If replacement is necessary, follow steps (3) through (6) (Refer to Fig. 10-5 for pitch link configurations).

- (1) Inspect pitch change links for cracks, corrosion, bends, damage, and proper and secure installation.

NOTE: The following step requires disconnecting the pitch change link from the pitch arm. Keep bolt and washer stack up together.

- (2) Inspect bolts, spacers, O-rings, and washers for wear. Observe if any distinct wear pattern is evident through the cad-plate and into the base material.
- (3) Corrosion, nicks, or scratches in the solid link, barrel, or rod end outer race not exceeding 0.010 in/0.25 mm deep may be burnished out. Replace the solid link, barrel, or rod end if cracked or damage exceeds 0.010 in/0.25 mm deep. Replace the rod end if its axial play is exceeds 0.005 in/0.13 mm.
- (4) Inspect pitch arm for damage. Replace pitch arm if cracks are detected or the pitch link bolt hole exceeds 0.251 in/6.38 mm diameter. Edge nicks may not exceed 0.005 in/0.13 mm deep. Polish and blend locally to a maximum 0.008 in/0.20 mm deep.

NOTE: Steps (5) through (8) and (11) apply to the barrel type pitch change links only.

- (5) Install lock nuts on rod ends.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Apply VC-3 Loctite to threads of rod ends.
- (7) Turn right hand rod end into barrel until threads just cover the witness hole in the barrel.
- (8) Turn left hand rod end into barrel until overall length of pitch link measures 4.260 in \pm 0.005 in/10.82 cm \pm 0.13 mm.

NOTE: Replacing pitch links or rod ends requires checking tail rotor balance.

NOTE: Steps (9) through (12) are to be completed after installation of tail rotor on transmission.

NOTE: For aircraft manufactured or modified with P/N 28-16391-3 or 28-16391-5 pitch link assemblies, the rod end labeled "T/R \uparrow BLADE," must be installed in the proper orientation (Fig. 10-3, (4)).

NOTE: Refer to Fig. 10-3 and Fig. 10-4 for the following steps unless stated otherwise.

- (9) Install inboard-hand thread rod end of the pitch change link and spacers (3) into the retainer. Install bolts (1) so that heads are in the direction of rotation, washers (2) and (5), and nuts (6). Torque nuts and install the cotter pins (7).
- (10) Connect outboard-hand thread rod ends to the pitch arms with the hardware in the following sequence: bolt (1) (bolt head installed in direction of rotation), washer (8), thin spacer (9), O-ring (11), pitch change link rod end (4), thick spacer (10), washer (13), pitch arm, washer(s) (5) (use stack-up retained in Para. C.(1)), and nut (6). Torque the nuts (55-75 in-lb/6.2-8.5 Nm) and install the cotter pins (7).

NOTE: For washers (5) and (13), replace any AN960 with the equivalent size NAS1149C04XXR (passivated stainless steel).

NOTE: A pre-existing spacer may have been wider or narrower than a replacement spacer. Adjust the number of washers under the nut (6) to account for the dimensional difference.


NOTE: Any modification must be made to both sides to maintain the dynamic balance of the tail rotor.

- (11) Adjust length of assembly by rotating barrel until pitch link assembly measures 4.260 in \pm 0.005 in/10.82 cm \pm 0.13 mm. Holding barrel with wrench, tighten lock nuts in place. Recheck length of assembly to be sure it is still 4.260 in \pm 0.005 in/10.82 cm \pm 0.13 mm (Fig. 10-5).

CAUTION: USING A PIECE OF 0.025 SAFETY WIRE, INSERT WIRE IN WITNESS HOLE OF BARREL TO BE SURE RIGHT HAND THREAD ROD END IS STILL TURNED IN PAST HOLE.

- (12) If rod ends were replaced or if changes were made to the tail rotor rotating controls assembly hardware as a result of incorporating missing hardware, dynamic balance tail rotor assembly (Para. 10-3).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



* WASHER THICKNESS, MATERIAL, AND QUANTITY MAY VARY DEPENDING ON DYNAMIC BALANCE REQUIREMENTS FOR THE TAIL ROTOR ASSEMBLY. REPLACE ANY AN960 WASHER WITH EQUIVALENT SIZE NAS1149C04XXR WASHER.

** INSTALL PITCH CHANGE LINK ROD END WITH ARROW POINTING TOWARD THE TAIL ROTOR BLADE (APPLICABLE TO AIRCRAFT MANUFACTURED OR MODIFIED WITH P/N 28-16391-3 OR P/N 28-16391-5 PITCH CHANGE LINK ASSEMBLY)

*** REPLACE AN960 WASHER WITH EQUIVALENT SIZE NAS1149C04XXR WASHER.

- | | | | |
|----|---------------------------|-----|--|
| 1. | Bolt | 8. | Washer |
| 2. | Washer | 9. | Spacer |
| 3. | Spacer | 10. | Spacer |
| 4. | Pitch Change Link Rod End | 11. | O-ring |
| 5. | Washer | 12. | Pitch Change Link
(28-16391-3 or -5 are shown in Fig. 10-4) |
| 6. | Nut | 13. | Washer |
| 7. | Cotter Pin | | |

Figure 10-3. Tail Rotor Pitch Change Link Installation



Figure 10-4. Pitch Change Link Installation





Figure 10-5. Tail Rotor Pitch Change Link

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

K. Installation – Tail Rotor Assembly

- (1) Start a .041 wrap of safety wire around the hub.

NOTE: The tail rotor assembly may be rotated 180° or the center hub may be pivoted 180° to obtain the proper installation position of the tail rotor assembly.

NOTE: See Fig. 10-6. A line drawn through the grease fittings of either end of the teetering hub (tail rotor hub pivot center line) should align with the lagging ears of the pitch link retainer. If the tail rotor hub pivot centerline is centered between the ears of the pitch link retainer, rotate the teeter trunnion 180° to obtain the correct 8° alignment.

- (2) Install tail rotor assembly onto transmission output shaft. Ensure center line of the tail rotor hub pivot axis aligns with the inboard side of the pitch change link retainer ear that lags in the direction of rotation.
- (3) Feed safety wire through the hole in the teeter stop and install teeter stop so that the rubber bumpers align with the flats of the spindle.
- (4) Install retention bolt and washer into teeter stop. Torque the retaining bolt to 300 in-lb/34.1 Nm and complete the safety.
- (5) Connect pitch change links to the pitch change plates (Para. 10-1.J.(8)).
- (6) Dynamically balance the tail rotor (Para. 10-3).




Figure 10-6. Tail Rotor Installation Orientation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-1. Inspection Requirements – Tail Rotor Assembly

Part Number	Fig. 10-1 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-150074-11, -13	1	Spindle	Surface scratches, nicks, or corrosion	None Allowed	≤ .001 deep	Polish with Scotch Brite pad or equivalent
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Spindle
			Feathering bearing shaft O.D. .7864 to .7868	-.0002	Not Repairable	Replace Spindle
			Teeter bearing bore Dia. 1.0002 to 1.0007	-.0002	Not Repairable	Replace Spindle
			Cracks	None Allowed	Not Repairable	Replace Spindle
28-150067-15	2	Hub	Splines (pitted or wicked)	None Allowed	Not Repairable	Replace Hub
			Teeter bearing shaft Dia. .4989 to .4994	-.0002	Not Repairable	Replace Hub
			Nicks, scratches, or corrosion	None Allowed	≤ .005	Blend out smooth
			Cracks	None Allowed	Not Repairable	Replace Hub
			Threads (stripped or missing)	None Allowed	Not Repairable	Replace Hub

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-19

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-1. Inspection Requirements – Tail Rotor Assembly

Part Number	Fig. 10-1 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-150076-15	4	Journal	Journal I.D. .4995 to .4998	+ .0002	Not Repairable	Replace Journal
			Journal O.D. .7509 to .7511	- .0002	Not Repairable	Replace Journal
B-1210	5	Needle Bearing	Bearing O.D. 1.000	- .0002	Not Repairable	Replace Bearing
			Visible wear of the needles	None Allowed	Not Repairable	Replace Bearing
28-150076-13	7	Thrust Bumper	Thickness .123 to .125	- .002	Not Repairable	Replace Bumper
28-150060-11	11	Pitch Change Plate	Nicks in edge of plate	None Allowed	≤ .005 deep	Polish and blend locally not to exceed .008
			Pitch link bolt hole Dia. .250 to .251	+ .0005	Not Repairable	Replace pitch change plate
			Corrosion	None Allowed		Return to the factory for inspection and replating, or replace pitch change plate
			Cracks	None Allowed	Not Repairable	Replace pitch change plate
28-150063-11, -13	12	Sleeve	Sleeve I.D. .7878 to .7882 (-11)	+ .0002	Not Repairable	Replace Sleeve
			Sleeve I.D. .7872 to .7876 (-13)	+ .0002	Not Repairable	Replace Sleeve
			Sleeve O.D. 1.1245 to 1.1250	- .0002	Not Repairable	Replace Sleeve

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-1. Inspection Requirements – Tail Rotor Assembly

P/N	Fig. 10-1 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
MR-18, ECD001-11	13	Bearing	Bearing O.D. 1.6250	+0.0000 -0.0005	Not Repairable	Replace Bearing
			Visible wear of the rollers	None Allowed	Not Repairable	Replace Bearing
28-150055-13, -15	14	Retainer	Retainer I.D. 1.6250 to 1.6255 (-13)	+0.0005	Not Repairable	Replace Retainer
			Retainer I.D. 1.6240 to 1.6247 (-15)	+0.0005	Not Repairable	Replace Retainer
			Retainer O.D. 2.043 to 2.044	-0.001	Not Repairable	Replace Retainer
ECD002-11, -13, -15, -17	15	Bearing	Bearing O.D. 2.0467 to 2.0472	-0.0002	Not Repairable	Replace Bearing
			Bearing Bore Dia. .7870 to.7874	+0.0002	Not Repairable	Replace Bearing
			Preload to the trust side and check for roughness or ratcheting	None Allowed	Not Repairable	Replace Bearing
SL61N5P SL61N5F	16	Nut	Threads (rolled or missing)	None Allowed	Not Repairable	Replace Nut
			Nicks and burrs on O.D.	None Allowed	≤ .10 deep	Blend and polish out smooth
			Rounded or burred locking tabs	Max. 2 slightly rounded tabs	To allow use of the locknut wrench	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Nut

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-21

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-1. Inspection Requirements – Tail Rotor Assembly

P/N	Fig. 10-1 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
SL61W5P	17	Lockwasher	Nicked locking tabs	None Allowed	≤ .005 deep	Blend and polish out smooth
			Bent locking tabs	> 10° from parallel to the bore	≤ 10° from parallel to the bore	Bend the tabs until parallel to the bore
			Serrated splines (smooth or rolled)	None Allowed	Not Repairable	Replace Lockwasher
28-15033	18	Bumper	Both sides for friction wear	Surfaces must be smooth	Not Repairable	Replace Bumper
			Cracks	None Allowed	Not Repairable	Replace Bumper
28-150001-5	19	Blade and Grip Assembly Note 1	<u>Blade Grip:</u>			
			Bearing bore Dia. 2.0454 to 2.0466	+ .0005	Not Repairable	Replace Blade and Grip Assembly
			Nicks, scratches, or corrosion in the bearing housing area of the grip	.020 deep	≤ .020 deep	Blend and polish out smooth, treat with chemical conversion coating
			Nicks, scratches, or corrosion in the blade retention area or the grip	.010 deep	≤ .010 deep	Blend and polish out smooth, brush with iridite finish
		Cracks	None Allowed	Not Repairable	Replace blade and grip assembly	

UNCONTROLLED COPY WHEN ~~MM-10-22~~ DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-1. Inspection Requirements – Tail Rotor Assembly

P/N	Fig. 10-1 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-150001-5	19	Blade and Grip Assembly (Cont'd) Note 1	<u>Blade:</u>			
			Doubler Separation	None Allowed	See Para.10-1.G	See Para.10-1.G
			Leading edge bond separations	None Allowed	See Para.10-1.G	See Para.10-1.G
			Trailing edge bond separations	None Allowed	See Para.10-1.G	See Para.10-1.G
			Sharp dents or scratches in the blade skin	None Allowed	See Para.10-1.G	See Para.10-1.G
			Smooth dents in the blade skin	.020 deep, not to exceed 1.0" in Dia.	See Para.10-1.G	See Para.10-1.G
			Bent, distorted or rippled blades	None Allowed	Not Repairable	Replace Blade
			Smooth dents in the leading edge	Not to exceed .020 deep	See Para.10-1.G	See Para.10-1.G
		Sharp dents or scratches in the leading edge	None Allowed	See Para.10-1.G	See Para.10-1.G	
28-15030-1	29	Teeter Stop	Rubber bumpers for deterioration or cracks	Excessive cracking or deterioration	Not Repairable	Replace Bumper
			Nicks, scratches, or corrosion	.010 deep	≤ .010 deep	Replace Teeter Stop

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-23

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Note 1 - If the blade is attached to the grip using 1/4" bolts, a new grip or blade can be installed by Enstrom. The blade and grip assembly will have 5/16"bolts installed. Both of the blade and grip assemblies must have the same size retaining bolts. Do not intermix blade and grip assemblies that have different size retaining bolts.

* All dimensions are in inches.

UNCONTROLLED COPY WHEN ^{MM-10-24}DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

10-2 STATIC BALANCE

A. Balance Procedure

NOTE: Refer to Fig. 10-1 for numbered items.


- (1) Remove bolt (26), washers (27), and nut (28) from the pitch arms if installed.
- (2) Install balance mandrel, T-0087-15, through the hub (2). Align plates of the mandrel with the flats of the spindle and with the recesses in the plates in toward the hub.
- (3) Rotate blades so that the leading edge of the blades align with the teeter bearings in the spindle (1).
- (4) Align pitch arm plates (11) with hole in mandrel and install the bolt through the pitch arms and mandrel. Install the nuts finger tight and ensure the bolt is centered when finished.
- (5) Install assembly onto the balancing stand in the vertical position to obtain the chordwise balance (Fig. 10-7).
- (6) Determine which direction the lower blade tends to rotate. Rotate the assembly 180° and repeat.

NOTE: If the trailing edge of the blade rises, this is the light blade. If the leading edge of the blade rises, this is the heavy blade.

- (7) Rotate assembly 180° and repeat.
- (8) Install a short plug screw in the root end of the heavy blade.
- (9) Install the length of screw and as many AN960-10 or -10L washers as required in the root of the light blade until the assembly will remain stationary in the vertical position.

NOTE: The maximum length of the screw is 3 inches and maximum washer stack up is .5 in/12.7 mm.

- (10) If tail rotor assembly will not balance with the maximum weight allowed, adjust the shimming of the center hub (2) by removing a shim (8) from under the teeter bearing end cap (9) on the side of the heavy blade and installing it on the side with the light blade. Use the thinnest shim installed and repeat the chordwise balancing procedure.
- (11) Place assembly in the horizontal position to obtain the spanwise balance (Fig. 10-7).
- (12) Install a short screw in the heavy blade.
- (13) Install the length of screw and amount of washers required until the assembly will remain stationary in the horizontal position. Rotate the assembly 180° and recheck.




CORDWISE BALANCING

NOTE:

IF THE TRAILING EDGE OF THE BOTTOM BLADE RISES, IT IS THE LIGHT BLADE. IF THE LEADING EDGE OF THE BOTTOM BLADE RISES, IT IS THE HEAVY BLADE.

INSTALL A SHORT SCREW IN THE ROOT END OF THE HEAVY BLADE. REFER TO FIGURE 10-1

USE SCREWS AND WASHERS IN THE ROOT END OF THE LIGHT BLADE FOR CORDWISE BALANCE.



SPANWISE BALANCING

NOTE:

INSTALL A SHORT SCREW IN THE TIP OF THE HEAVY BLADE. REFER TO FIGURE 10-1

USE SCREWS AND WASHERS IN THE TIP OF THE LIGHT BLADE FOR SPANWISE BALANCE.

Figure 10-7. Tail Rotor Static Balancing

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (14) Recheck static balance at the vertical and 45° positions.
- (15) Install strike tabs and tighten all screws.
- (16) Remove assembly from the balance fixture and remove the balancing mandrel.
- (17) Install bolt (26), washers (27), and nut (28) into pitch arm plate (11). Ensure the head of the bolt is on the inboard side of the plate.
- (18) Assembly is ready for installation on the aircraft.

NOTE: It is recommended that all tail rotor assemblies be dynamically balanced on the helicopter.

10-3 TRACKING AND DYNAMIC BALANCE

NOTE: It is not necessary to track the tail rotor blades on Enstrom tail rotor assemblies. Earlier tail rotor assemblies with the 3 piece pitch links should be set to an overall length of 4.26 in/10.82 cm in accordance with Fig. 10-5.

NOTE: The Honeywell-Chadwick 2000 system is described in the following instructions. Follow the operating instructions for the equipment being used if different than the following instructions.

NOTE: The procedure below should work for any of the digital balance systems but if the Velocimeter is installed in the vertical orientation, the polar chart will have to be rotated to compensate.

A. Tracking and Balancing Equipment Installation:

- (1) Install optical sensor into the tail rotor balance fixture T-0152.
- (2) Install velocimeter onto the right side of the tail rotor transmission under the tail rotor guard mounting nut. The velocimeter should be in a horizontal position with the connector pointing aft (Fig. 10-8).
- (3) Connect velocimeter and optical sensor cables and wrap the cable around the stinger tube, around the right side horizontal stabilizer, the right rear oleo, and then into the right side cabin door. Secure the cables to the stinger tube, tailcone, and landing gear with tape.
- (4) Install a 1.5 inches piece of reflective tape on one of the grips lengthwise. This will be the target blade (Fig. 10-9).
- (5) Connect velocimeter and optical sensor cables to the Balancer box in accordance with the manufacturer's instructions.



Figure 10-8. Velocimeter and T-0152 Installation




Figure 10-9. Reflective Tape Installed on the Target Blade

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

B. Tail Rotor Balance Procedure:

WARNING: THE FOLLOWING STEPS ARE TO BE PERFORMED BY AUTHORIZED PERSONNEL.

- (1) Position helicopter so the tail rotor transmission output shaft is pointing into the wind (either upwind or downwind).
- (2) Ground run the aircraft at 350 main rotor RPM with the tail rotor pedals neutral.
- (3) Using the procedures provided by the operation instructions, obtain a clock angle and ips reading from the balance box.
- (4) End ground run to stop the blades from turning.
- (5) Plot ips reading and clock angle on the tail rotor balance chart (Fig. 10-10).

NOTE: If more than five washers are required on the pitch change link bolts, the teeter hub can be shifted to move the balance fulcrum (Para. 10-3.D). On early production tail rotors, with KP8A or KRP8A() bearings, the tail rotor must be removed to shift the teeter hub. On current production tail rotors, the teeter trunnion can be shifted without removing the tail rotor from the helicopter.

CAUTION: IF ADDING OR SUBTRACTING WASHERS FROM THE PITCH CHANGE LINK BOLTS, ENSURE THE CORRECT GRIP LENGTH BOLT IS INSTALLED AND ACCOUNT FOR THE WEIGHT CHANGE OF THE BOLT DURING THE BALANCING PROCEDURE.

NOTE: If the tail rotor is difficult to balance, plot the move lines for both the tip weights and the pitch link weights. If the two move lines are parallel or don't intersect, then remove the tail rotor from the gearbox, turn it 180° and re-install it. It will also be necessary to rotate the trunnion 180° to maintain the 8° lag of rotation (Fig. 10-6).

- (6) Add weight in accordance with the chart (Fig. 10-10) and check the clock angle and ips reading of the tail rotor. If the move line of the weight change does not coincide with the move lines on the chart, use the "Clock Angle Correction" procedure (Para. 10-3.C).
- (7) Continue tail rotor balance procedure until the ips reading is 0.2 ips or less.
- (8) Remove tracking and balancing equipment from the aircraft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 10-10. Tail Rotor Balancing Chart

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-30

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

C. "Clock Angle Correction" Procedure

- (1) Obtain ips reading and clock angle using the procedure in Para. B.
- (2) As an example, the following results were obtained: Run 1, ips .55 @ 4:30 clock angle.
- (3) Plot Run 1 on the tail rotor polar chart (Fig. 10-11).
- (4) Add a small washer (AN960-10L) to the tip at "B".
- (5) Run helicopter again and record the ips reading and clock angle. In this example the following results were obtained: Run 2, 4.5 ips @ 6:30 clock angle.
- (6) Plot Run 2 on the chart (Fig. 10-12).
- (7) Since the move line between Run 1 and Run 2 did not follow the chart in the expected direction, a correction must be made to the positions of the tip weight line and pitch link weight line relative to the clock orientation.
- (8) Drawn a line between plot 1 and plot 2. Label the line "add B".
- (9) Rotate tip weight line approximately 45° clockwise to reflect the actual results of the first weight change.
- (10) The relationship between the tip weight line and the pitch link weight line should remain constant; therefore, the pitch link weight line can be rotated 45° clockwise (Fig. 10-13).
- (11) Re-plot original target reading (Fig. 10-14).
- (12) Remove the AN960-10L washer from tip B and add three 1/4 harper washers to the pitch link position C.
- (13) Run helicopter again and record the ips reading and clock angle. The following results were obtained: Run 3, .18 @ 6:00 clock angle (Fig. 10-14).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 10-11. Tail Rotor Clock Angle Correction Example




Figure 10-12. Tail Rotor Clock Angle Correction Example





Figure 10-13. Tail Rotor Clock Angle Correction Example

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



RUN	IPS/CLOCK	CORRECTIVE ACTION
# 1	5.5 @ 4:30	add AN960-10L to B
# 2	4.5 @ 6:30	
clock angle correction 45° CW		
# 1	5.5 @ 4:30	remove washer from B, add 3 washers to C
# 2	.18 @ 6:00	




Figure 10-14. Tail Rotor Clock Angle Correction Example

D. Teeter Trunnion Shimming Procedure

NOTE: Refer to Fig. 10-1 for numbered items.

NOTE: If more than five harper washers are required to balance the tail rotor in the chordwise axis, it may be necessary to shift the teeter hub to move the balance fulcrum.

NOTE: This procedure can be completed with the tail rotor installed on the helicopter and it is not necessary to disconnect the pitch change links from the tail rotor retention plate.

(1) From the previous example (Para. 10-3.C.(12)), the out-of-balance could be corrected by shifting the teeter hub (changing the balance fulcrum) rather than adding weight to the pitchlink.

(2) The chart calls for adding weight to the pitchlink at point A, which indicates that C is the heavy side of the blade in the vertical (chordwise) balance axis.

NOTE: This procedure can be completed with the tail rotor installed on the helicopter and it is not necessary to disconnect the pitch change links from the tail rotor retention plate.

(3) Remove retaining ring (10) from the tail rotor spindle at the position closest to point C.

(4) Remove end cap (9) and the seal (6). Use caution not to drop the thrust bumper (7) and the shims (8) as they may remain in the cap or stuck to the spindle.

(5) It may be necessary to insert a sharp hooked pick into the center hole of the thrust bumper (7) to withdraw it from inside the cap.

(6) Remove a 0.002 inch or 0.003 inch shim (8) from under the cap and carefully set it aside.

(7) Install shims (8), seal (6), cap (9), and the retaining ring (10) back into the spindle.

(8) Add the 0.002 inch or 0.003 inch shim previously removed from the C side to the shims (8) on the A side of the tail rotor spindle and reassemble the spindle.

(9) Ensure retaining ring is securely seated in the grooves on both sides of the spindle and there is no end play.

(10) Continue with balance procedure.

10-4 TAIL ROTOR PITCH CONTROL ASSEMBLY

NOTE: Refer to Fig. 10-15 for numbered items unless stated otherwise.

A. Removal – Pitch Control

- (1) Disconnect pitch change links from pitch link retainer (18).
 - (a) Remove bolt (1), washer (2), spacers (3), washer (5), and nut (6) to disconnect the pitch change link (4) (Fig. 10-3, right).
- (2) Remove tail rotor assembly (Para. 10-1.C).
- (3) Remove bolt (5), washers (6) and (8), and nut (9) from the pitch control and control brackets (1) and (2).

NOTE: The stainless steel washers (6) located between the control brackets and iolite bushings of pitch control assembly must be saved for reinstallation.

NOTE: Extra force may be required to slide the pitch change mechanism off the tail rotor output shaft because the keys will force the seal retainer from the pitch change bearing.


- (4) Slide pitch control assembly off of chrome sleeve on the tail rotor transmission output shaft.
- (5) Remove keys (11), seal retainer (13) and seal (12), from the sleeve.
- (6) Disconnect tail rotor control cables from pivot brackets (Fig. 10-30).
- (7) Remove bolts (3) and washers (4) securing the pivot brackets (1) and (2) together. Remove the brackets from the transmission.

B. Disassembly – Pitch Control

- (1) Remove cotter pins (20) from the retainer (18).
- (2) Place pitch link retainer (18) in a small arbor press and press dowel pin (19) through retainer and pitch control bearing (14).
- (3) Rotate the retainer and repeat for the opposite pin.

CAUTION: USE A PRESS TOOL THAT EXACTLY FITS THE BRONZE PITCH CONTROL BEARING OR DAMAGE WILL OCCUR TO THE BEARING. HEAT THE BEARING HOUSING AND PITCH CHANGE RETAINER TO 230°F/110°C WITH A HEAT GUN BEFORE ATTEMPTING TO PRESS THE PITCH CONTROL BEARING FROM THE BEARING HOUSING AND THE PITCH CHANGE RETAINER.

- (4) Gently press pitch control bearing (14) from the pitch link retainer (18), wave spring washers (17), and bearing (15).
- (5) Remove seal (12) from the outboard end of the pitch control bearing (14).
- (6) Remove retaining ring (16).



- | | | | |
|-----|-----------------|-----|-----------------------|
| 1. | Upper Bracket | 11. | Key |
| 2. | Lower Bracket | 12. | Seal |
| 3. | Screw | 13. | Seal Retainer |
| 4. | Washer | 14. | Pitch Control Bearing |
| 5. | Bolt | 15. | Bearing |
| 6. | Washer | 16. | Retaining Ring |
| 7. | Bearing Housing | 17. | Spring Washer |
| 8. | Washer | 18. | Pitch Link Retainer |
| 9. | Nut | 19. | Pin |
| 10. | Cotter Pin | 20. | Cotter Pin |

Figure 10-15. Tail Rotor Pitch Control Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

WARNING: USE EXTREME CAUTION WHEN REMOVING OR INSTALLING THE BLADE AND GRIP ASSEMBLIES TO PREVENT FROM INJURING PERSONNEL.

WARNING: USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.

- (7) Heat bearing housing (7) to approximately 250°/121°C. Gently tap the bearing (15) from the housing.
- (8) Clean parts for inspection.

C. Inspection – Pitch Control

- (1) See Table 10-2 for the detailed inspection requirements for the tail rotor pitch control assembly.

D. Assembly – Pitch Control

WARNING: USE EXTREME CAUTION WHEN REMOVING OR INSTALLING THE BLADE AND GRIP ASSEMBLIES TO PREVENT FROM INJURING PERSONNEL.

WARNING: USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.

- (1) Heat bearing housing (7) to approximately 250°F/121°C. Install bearing (15) into the housing with the slots for removing the inner bearing section facing outboard towards the pitch change link retainer and oriented 90° to the pivot arms of the bearing housing.
- (2) Install retaining ring (16) with opening in line with one of the bearing housing (7) pivot arms.
- (3) Press pitch control bearing (14) into the bearing (15) in the outboard direction.
- (4) Install two wave spring washers (17) onto the pitch control bearing (14).

NOTE: Assembly of the pitch link retainer and bearing can be facilitated by using alignment pins (0.75 in/1.9 cm max. length) fabricated from 1/4 inch bolts (1.5 in long bolt; head and threads removed).

CAUTION: USE GLOVES WHEN HANDLING HEATED PARTS.

- (5) Heat pitch link retainer (18) to approximately 230°F/110°C and slide it over the bearing (15). Insert the two alignment pins to align the bearing with the pitch link retainer. When the retainer has cooled, push the alignment pins into the inside of the bushing to remove.

NOTE: If pin holes do not completely line up, gently tap the ear of the pitch link retainer with a plastic mallet until the holes line up.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Press dowel pin (19) into pitch link retainer (18). Rotate retainer and repeat.

NOTE: Seat dowel pins into the pitch link retainer far enough that the cotter pins can be installed. The pins must not extend through the pitch control bearing.

NOTE: Installation of the dowel pins may distort the bottom surface of the pitch control bearing. Check that the inside bearing surface is free of distortion after installing the pins.

- (7) Install cotter pins (20) into pitch link retainer (18).
- (8) Install the pitch change assembly onto the tail rotor gearbox output shaft to ensure that it will slide on the chrome shaft without binding. It is common for the bronze pitch control bearing (5) to be slightly distorted on the inside in the area of the pins. If this is the case, use a fine tooth (1/2) round file to dress the bearing so it will slide freely.
- (9) Install seal (12) into outboard groove of pitch control bearing (14).

E. Installation – Pitch Control

- (1) Install pivot brackets (1) and (2) onto the tail rotor transmission. Install bolts (3) and washers (4), torque, and lockwire (.025).

CAUTION: THE CONNECTING LINKS MUST PIVOT FREELY AT THE CABLE CONNECTIONS AND AT THE BELLCRANK AND PITCH CONTROL ASSEMBLY CONNECTIONS.

- (2) Connect tail rotor control cables to the pivot brackets.
- (3) Slide seal retainer (13) and seal (12) onto the chrome sleeve.
- (4) Install keys (11) in slots of sleeve.
- (5) Align keyway in pitch control bearing (14) with keys (11) and slide the pitch control assembly onto the chrome sleeve.
- (6) Install stainless steel washers (6) between the pivot brackets and the arms of the bearing housing.
- (7) Install pivot bolts (5) connecting the brackets to the bearing housing. Install the washers (8) (typically one AN960-6 and one AN960-6L) and locknuts (9). Torque the nuts and align the cotter pin holes. Install the cotter pins (10) and cycle the pivot brackets to check for interference.
- (8) Cycle control brackets ensure the pitch control assembly pivots and slides freely.

NOTE: The heads of the pivot bolts must rotate when control brackets are moving. If they do not rotate, check for binding in the bushings.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (9) Install seal (12) into the seal retainer (13). Install the seal retainer into the recessed area of pitch control bearing (14) using tool T-0140. Alternatively, the seal may be installed by tapping it with a small punch.
- (10) Install tail rotor assembly (Para. 10-1.K).
- (11) Connect pitch change links to the pitch change retainer (Para. 10-1.J.(7)).

NOTE: Omit steps (12) and (13) if no major components of the pitch control assembly were replaced.

- (12) Check tail rotor control rigging (Para. 10-7.A).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

INTENTIONALLY LEFT BLANK

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-42

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-2. Inspection Requirements – Tail Rotor Pitch Control Assembly

Part Number	Fig. 10-15 Item Number	Part Name	Inspect*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16331-1	7	Bearing Housing	Bearing bore 2.6774 to 2.6779	+ .0002	Not Repairable	Replace Housing
			Oilite bushing I.D. .3755 to .3765	+ .0005	Not Repairable	Replace Housing
			Surface nicks and scratches	None Allowed	≤ .020 deep	Blend and polish out smooth
T-533-023, TS-023	12	Seal	Visual for cuts or tears	None Allowed	Not Repairable	Replace Seal
28-16394-2, -11	14	Pitch Control Bearing	Bronze O.D. 1.3777 to 1.3781	- .0005	Not Repairable	Replace Bearing
			Bore Dia. 1.079 to 1.081	+ .001	Not Repairable	Replace Bearing
			Keyway width .1875 to .1895	+ .0005	Not Repairable	Replace Bearing
			Dowel pin holes .2450 to .2470 (-2)	+ .003	Not Repairable	Replace Bearing
			Dowel pin holes .2490 to .2495 (-11)	+ .0005	Not Repairable	Replace Bearing
Distortion of bore	None Allowed	Not Repairable	Replace Bearing			

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-43

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 10-2. Inspection Requirements – Tail Rotor Pitch Control Assembly

Part Number	Fig. 10-15 Item Number	Part Name	Inspect*	Serviceable Limits*	Repair Limits*	Repair or Action
107-KSZZ6, ECD016-11	15	Bearing	O.D. 2.6772	+ .0000/- .0005	Not Repairable	Replace Bearing
			I.D. 1.3780	+ .0005/- .0000	Not Repairable	Replace Bearing
			Axial movement of the inner race to the outer race	.002	Not Repairable	Replace Bearing
			Ratcheting or roughness	None Allowed	Not Repairable	Replace Bearing
5002-268-PP	16	Retaining Ring	Check for flatness	No Distortion	Not Repairable	Replace Retaining Ring
W1819-020	17	Wave Spring Washer	Check for wave contour	No Flat Spots	Not Repairable	Replace Washer
28-16392-13	18	Pitch Link Retainer	Bore 1.3782 to 1.3787	+ .0002	Not Repairable	Replace Retainer
			Dowel pin holes .2490 to .2495	+ .0002	Not Repairable	Replace Retainer
			Pitch link retainer bolt holes .250 to .251	+ .0005	Not Repairable	Replace Retainer
			Surface nicks and scratches	None allowed	≤ .010 deep	Blend and polish out smooth
28-16397-11	19	Dowel Pin	O.D. .2495 to .2505	- .0005	Not Repairable	Replace Pin

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-10-44

Rev. 13
Jan 5/24

10-5 TAIL ROTOR GEARBOX

A. General Description – Tail Rotor Gearbox

The tail rotor gearbox consists of an aluminum cast housing for a 90° degree miter gear drive, with integral cast mount and control pivot bosses. The gearbox mechanical input is an independently mounted shaft and gear assembly that is retained by a matched pair of duplex ball bearings. The gearbox output to the tail rotor assembly is an internally mounted shaft and gear assembly that is retained by another pair of matched duplex ball bearings.

The tail rotor gearbox is equipped with a magnetic chip detector located in the rear of the bottom of the gearbox. This unit comprises a magnetic plug which locks into a self-sealing base. If the tail rotor gearbox chip light illuminates, follow the procedures in Para. 4-62.B. See Para. 10-5.1 for instructions for removing and inserting the magnetic plug.

B. Troubleshooting – Tail Rotor Gearbox

Problem	Possible Cause	Required Action
Gearbox running hot	Low on oil	Add oil, check sight plug for proper level
	Bad internal bearing	Return to factory or overhaul facility for inspection
Oil leakage	Worn input or output seal shaft	Replace seal
Roughness in bearing operation	Worn or pitted bearings	Return to factory or overhaul facility for inspection
Excessive TIR check on output shaft (.005 max.)	Gearbox sudden stoppage or tail rotor strike	Return for gearbox overhaul
Tool T-0068 installed	Improper spline alignment of chrome sleeve to output shaft	Rotate chrome sleeve at 90° intervals until runout falls in tolerance
Excessive metal particles on mag plug	Large pieces or slivers of metal flaking from gears or bearings	Refer to Para. 4-62.B and 4-62.C
	Fine powdery-type metal can result from normal gear break-in	

C. Removal – Tail Rotor Gearbox

NOTE: It is not necessary to remove the tail rotor assembly from the helicopter for this procedure.

- (1) Remove tail rotor assembly, if required (Para. 10-1.C).
- (2) Disconnect tail rotor pitch change cables at the gearbox or remove the pivot control brackets (Fig. 10-15) from the tail rotor gearbox with the cables attached.
- (3) Disconnect electrical wiring for the chip detector.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (4) On flex coupling, remove the two bolts from aft coupling half only.
- (5) Disconnect or remove tail rotor guard.
- (6) Remove the safety wire and six screws or bolts, as applicable, that secure gearbox to extension tube.
- (7) Remove gearbox by pulling the unit aft with a slight rotational motion.

D. Inspection – Tail Rotor Gearbox

- (1) Remove top visual inspection plug and inspect gears and gearbox internally for damage and condition. Install and secure top visual inspection plug (20-60 in-lb/2.3-6.8 Nm).
- (2) Rotate output shaft and inspect for any bearing roughness, if any roughness, return transmission for overhaul.
- (3) Inspect input shaft taper pin hole for elongation or cracks; return transmission for overhaul if either condition is found.
- (4) Inspect input and output shaft seals for leakage. Replace seals if leaking (Para. 10-5.F or Para. 10-5.G, as applicable).
- (5) Inspect chip detector for accumulation of metal particles (Para. 10-5.1, Para. 4-62.B.(3)).

E. Installation – Tail Rotor Gearbox

- (1) Apply Lubriplate 630-AA (MIL-PRF-81322) to transmission mount.
- (2) Insert chip detector wiring through hole in transmission mount.
- (3) Install transmission in extension tube. Install mounting bolts and torque to 25 in-lb/2.8 Nm. Lockwire (.032") bolts.
- (4) Connect flex pack coupling to drive hub (Para. 10-6.D).
- (5) Connect electrical wiring to the chip detector.
- (6) Connect tail rotor guard to the transmission.
- (7) Connect tail rotor control cables to pitch control assembly (Para. 10-4.E).
- (8) Install tail rotor assembly (Para. 10-1.K).

NOTE: Omit steps 9 and 10 if the transmission and tail rotor control assembly being installed are the same ones that were removed.

- (9) Check tail rotor control cable tension (Para. 10-7.A).
- (10) Check tail rotor control rigging (Para. 10-7.B).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

F. Input Seal Replacement – Tail Rotor Gearbox

NOTE: Refer to Fig. 10-17 for numbered items unless stated otherwise.

- (1) Drain oil from tail rotor transmission (Para. 4-16.A through C).

NOTE: Omit steps 2 through 3 if the transmission is not installed on the aircraft.

NOTE: Failure to align the index marks or to return the shims to the original position will require realignment of the tail rotor drive shaft.

- (2) Disconnect the aft three drive shaft bearing assemblies (Fig. 10-25) from the tail cone.
 - (a) Mark drive shaft bearing assemblies and tail cone with an index mark so that the bearing assemblies are installed in the identical lateral positions as previously installed.
 - (b) Remove hardware securing aft three drive shaft bearing assemblies to the tail cone.
 - (c) Tape shims and hardware to the tail cone to facilitate reinstallation of the drive shaft bearing assemblies in the same position (returns the tail rotor driveshaft to the same position vertically).

NOTE: Failure to align the index marks or to return the shims to the original position will require realignment of the tail rotor drive shaft.

WARNING: DISPLACE THE TAIL ROTOR DRIVE SHAFT THE MINIMUM AMOUNT NECESSARY AS DAMAGE TO THE DRIVE SHAFT MAY RESULT. WHEN REMOVING THE FLEX COUPLING, RETAIN THE ORDER OF THE HARDWARE AND SPACERS FOR RE-INSTALLATION OF THE FLEX COUPLING.

- (3) Remove bolts (10) securing flex pack coupling to the aft drive hub (Fig. 10-18). Index mark the drive hub and the flex plate coupling so that the flex pack coupling is installed in the identical position as previously installed.
- (4) Remove taper pin (6) (Fig. 10-18) next to the rain slinger (18) (Fig. 10-17) using tool T-0092-5 and remove slinger.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Earlier version gearboxes will have two tab washers securing the input seal into the gearbox housing. Later manufactured gearboxes use a retaining ring.

- (5) Remove seal retaining ring (15) or two retaining tabs (16), as applicable.
- (6) Using an awl or small screwdriver, carefully remove the input shaft seal, (14) (P/N 1539-001). Note the part number on the seal. Use the same part number for the seal, when installing the new seal.

NOTE: Do not remove the screws that secure the bearing housing to the gearbox housing. Do not remove the lead seal from the input shaft assembly. Removal of the seal will void the warranty on the tail rotor transmission.

- (7) Clean tail rotor transmission seal surface and the O.D of new seal (14).
- (8) Install seal (14).
 - (a) Apply a small amount of MIL-PRF-2105 to the O.D. and I.D. of the seal and the seal lip.
 - (b) Wrap stainless steel shim stock around the input shaft nut to protect the seal lip during installation.
 - (c) Use a soft plastic or rubber hammer or other suitable press tool to tap the seal into place.
- (9) Install retaining ring (15) or the retaining tab washers (16), as applicable.
 - (a) Torque tab washer screws to 25 in-lb/2.8 Nm and lockwire if using the retaining tabs.
- (10) Install slinger (18) and taper pin (6) (Fig. 10-18). Torque to 25 in-lb/2.8 Nm.
- (11) Install flex coupling. Install all hardware, spacers, and washers in the same position as previously installed.
- (12) Install three drive shaft bearing assemblies.

NOTE: Install the bearing assemblies to the index marks (as previously installed). If not properly marked for reinstallation, the tail rotor drive shaft will require alignment.

- (a) Use same shims, spacers, and bolts (retained in place with tape) for each bearing assembly.
 - (b) Align bearing assemblies laterally to the index marks.
 - (c) Torque bolts to 35 in-lb/4.0 Nm.
- (13) Service tail rotor transmission (Para. 4-15).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

G. Output Seal Replacement – Tail Rotor Gearbox

- (1) Drain oil from tail rotor transmission (Para. 4-16.A through C).
- (2) Remove tail rotor assembly (Para. 10-1.C; omit step 4).
- (3) Remove pitch control bearing assembly (Fig. 10-15).

NOTE: Retain all hardware together for re-installation.

- (a) Disconnect bearing housing (7) from pivot brackets (1) and (2) by removing bolts (5), washers (6) and (8), nut (9), and cotter pins (10) (Fig. 10-15).
- (b) Index mark the position of the sleeve as installed on the output shaft.
- (c) Slide pitch control assembly off of the sleeve of the tail rotor transmission output shaft.
- (d) Remove keys (11), seal (12), and seal retainer (13).

- (4) Remove retaining ring (20) from output shaft seal (19) (Fig. 10-17).

NOTE: As the seal (19) is removed from the output shaft, the sleeve (21) will also be removed with it. Wrapping the end of the output shaft with masking tape may help prevent the sleeve from being displaced when the seal is removed. Clean the area prior to applying tape.

Otherwise, mark the sleeve spline to the output shaft spline so as to install the sleeve in the same location on the output shaft on reassembly.

- (5) If preferred, wrap the end of the output shaft with masking tape, otherwise clean the spline edges of the output shaft and sleeve and apply a paint stripe across the splines.
- (6) Using an awl or small screwdriver, carefully remove the seal (19). Note the part number on the seal. Use the same part number for the seal, when installing the new seal.
- (7) Install new seal (19).

NOTE: It may be necessary to chamfer the inboard edge of the new seal using 200 grit sandpaper, or equivalent, for ease of installation.

- (a) Clean tail rotor transmission seal surface and O.D. of new seal.
- (b) Lubricate (MIL-PRF-2105) the O.D. and inside lip of new seal.

CAUTION: BE CAREFUL NOT TO TEAR THE NEW SEAL WHEN TAPPING THE SEAL INTO PLACE.

- (c) Use a soft plastic or rubber hammer or other suitable press tool to tap seal into place.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Positioning the sleeve on the output shaft in a location different than previously installed may affect the runout (TIR) and negatively affect the rail rotor balance. Output shaft runout may be checked in accordance with Para. 10-5.H.

- (8) If required, install sleeve (21). Match spline mark of the sleeve to the spline mark on the output shaft.
 - (a) Lubricate (MIL-PRF-2105) seal end of sleeve (21).
 - (b) Use a bushing driver or equivalent press tool, push the sleeve (21) into the seal (19). The seal seats in a groove of the sleeve (21).
- (9) Install retaining ring (20).
- (10) Place seal retainer (13) and seal (12) onto output shaft.
- (11) Install two keys (17) into key slots in sleeve (21).
 - (a) Lubricate (MIL-PRF-81322) keys (17) during installation and prior to installing pitch control assembly.

NOTE: Take care to align the pitch control assembly to the index marks. If the pitch control assembly cannot be realigned to the original index marks, the tail rotor assembly must be dynamically balanced.

- (12) Install pitch control assembly (Fig. 10-15).
 - (a) Align pitch control assembly to the index marks on the sleeve and slide the assembly onto the tail rotor transmission output shaft.
 - (b) Insert seal (12) into the groove in the pitch control bearing (14).

CAUTION: BE GENTLE WHEN INSERTING THE SEAL RETAINER (13). EXCESSIVE FORCE WILL DAMAGE THE SEAL RETAINER.

- (c) Use a small straight screwdriver or punch and a small hammer to tap the seal retainer (13) into the groove in the pitch control bearing (14).
- (13) Install pivot brackets (Fig. 10-15).

NOTE: Washer (6) must be installed between the upper pivot bracket (1) and the bearing housing (7).

- (a) Install bolts (5), washers (6) and (8), and nut (9).
 - (b) Torque nuts to 60-85 in-lb/6.8-9.6 Nm and install new cotter pins (10).
- (14) Install tail rotor blade assembly (Para. 10-1.K).
- (15) Install bottom plug (Para. 4-16.D) and service tail rotor transmission (Para. 4-15).

H. Output Shaft Runout – Tail Rotor Gearbox

- (1) Runout of the output shaft is checked as follows: (.005-inch Total Indicated Runout (TIR) maximum.) (Fig. 10-16)
 - (a) Secure gearbox in a vise if removed from the helicopter.
 - (b) Install sleeve T-0068 on output shaft. Install spacer T-0068 and torque bolt to 300 in-lb/34.1 Nm.
 - (c) Position height gauge and dial indicator with indicator arm on outboard diameter of T-0068.
 - (d) Zero dial indicator and rotate the input shaft. Note output shaft TIR.
 - (e) If runout exceeds .005 TIR, remove bolt and tool. Remove output seal. Reposition sleeve on output shaft in one spline intervals until runout falls within tolerance.

NOTE: If the tail rotor components are installed in the exact position as removed, the dynamic balance step (Para. 10-3) may be omitted

NOTE: If the tail rotor components are not installed in the exact position as removed, the tail rotor must be balanced.




Figure 10-16. TIR Indicator for the Output Shaft

10-5.1 TAIL ROTOR GEARBOX CHIP DETECTOR

NOTE: The following procedure applies to gearbox installations having the self-sealing base for the magnetic plug (Fig. 10-17, Detail A).


NOTE: Refer to Para. 4-62.B.(3) for metal particle criteria limits.

A. Removal – Tail Rotor Gearbox Chip Detector

- (1) Do not disconnect the wire.
- (2) Grasp the magnetic plug (11) and push upward. While holding upward pressure, begin turning plug counter-clockwise.
- (3) Turn plug (11) counter-clockwise one-quarter turn.
- (4) Pull plug (11) out of the socket in the base fitting (27).

B. Installation – Tail Rotor Gearbox Chip Detector

- (1) After inspection and after determining that the transmission is airworthy, clean the magnetic plug (11) with a soft cloth or with a strong magnet attached to a pointed object or use compressed air. Use caution to avoid scratching the magnetic plug.
- (2) Insert plug (11) into the socket in the base fitting (27).
- (3) Align lugs in the plug (11) with the slots in the base fitting (27).
- (4) Push plug (11) upward while turning the plug clockwise (approximately one-quarter turn).
- (5) When plug (11) stops turning, pull downward.
- (6) Check plug (11) to ensure that it is locked in the base (27).



- | | | | |
|-----|-----------------------------|-----|-------------------------------|
| 1. | Tail Rotor Gearbox Assembly | 13. | Nut |
| 2. | O-Ring | 14. | Seal |
| 3. | Bolt | 15. | Retaining Ring |
| 4. | O-Ring | 16. | Tab (omitted if (15) is used) |
| 5. | Plug | 17. | Screw |
| 6. | O-Ring | 18. | Slinger |
| 7. | Plug | 19. | Seal |
| 8. | O-Ring | 20. | Retaining Ring |
| 9. | Sight Plug | 21. | Sleeve |
| 10. | Gasket (Crush Washer) | 22. | Bolt |
| 11. | Magnetic Plug/Chip Detector | 23. | Washer |
| 12. | O-Ring | 24. | Chip Detector Base |

Figure 10-17. Tail Rotor Transmission Assembly

10-6. TAIL ROTOR DRIVESHAFT

A. Alignment – Tail Rotor Driveshaft

- (1) (280FX) Remove aft tail rotor drive shaft cover and open remaining covers.
- (2) Clamp piano wire attachment tools T-0088 to each end of the driveshaft. Attach the piano wire between the tools and center it vertically down the centerline of the driveshaft.

NOTE: If the alignment tools differ in height greater than allowable, it is not possible to obtain proper alignment of the tail rotor drive shaft.

- (3) Verify alignment tool heights are within $\pm.001$ inch at the forward and aft positions as follows:
 - (a) Using a set of calipers, measure the distance between the wire and short shaft approximately 1 inch aft of the forward alignment tool.
 - (b) Measure distance between the wire and the long shaft 1 inch forward of the aft alignment tool.
 - (c) The difference between the two previous measurements should be no greater than .002 inch.
 - (d) If the alignment tool heights are outside allowable limits, it will be necessary to file the high/tall alignment tool saddle (the location where the piano wire rests in the alignment tool) to obtain the proper height. File the saddle and measure per step c) until the proper tolerance of $\pm.001$ inch is obtained.
- (4) Starting at the forward drive shaft bearing assembly, measure the distance between the drive shaft and the piano wire. Repeat this for the remaining drive shaft bearing assemblies. The vertical difference at any position should be within $\pm.012$ inch. If the difference is greater than $\pm.012$ inch, add or subtract shims under the bearing assembly to bring the shaft into proper alignment. Tighten the hardware and recheck the alignment after each adjustment.

NOTE: Ensure the tail rotor drive shaft bearing hardware is properly torqued before taking measurements and after each adjustment.

- (5) When proper vertical alignment is achieved, rotate the tail rotor drive shafts 90° to check the lateral alignment.
 - a) Starting at the forward drive shaft bearing assembly, measure the distance between the drive shaft and the piano wire. Repeat this for the remaining drive shaft bearing assemblies. The lateral difference at any position should be within $\pm.012$ inch. If the difference is greater than $\pm.012$ inch, loosen the bearing assembly hardware and shift the position of the bearing assembly. Tighten the hardware and recheck the alignment.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) (280FX) Check the drive shaft cover bracket alignment by temporarily installing the drive shaft aft cover. Adjust the bracket, if required.
- (7) Torque the drive shaft bearing assembly mount bolts to 20-25 in-lbs/2.3-2.8 Nm and recheck the vertical and lateral alignment. Adjust as required.
- (8) Lockwire (MS20995C32) the aft drive shaft bearing assembly mounting hardware. Route the lockwire under the bearing assembly to avoid interfering with the drive shaft.
- (9) Remove the alignment tools from the drive shafts.
- (10) (280FX) Close the drive shaft covers and install the aft cover.

B. Removal – Driveshaft

- (1) (280 FX) Remove the aft tail rotor drive shaft cover and open the remaining covers.
- (2) Remove the upper cowling and the side cowling from one side.
- (3) Remove tach drive cover and remove O-rings from pulley. (See Para. 10-6.3 for optional tach drive cover modification.)
- (4) Disconnect the forward and aft couplings (Para. 10-6.1.B.(1) through (2)).
- (5) Remove the anti-collision light from top of tailcone, if required.
- (6) (280F) Remove the top vertical stabilizer from aft end of tailcone.
- (7) Mark the pillow blocks to the tailcone to assist with alignment during installation.
- (8) Remove bolts and washers attaching pillow blocks to tailcone.

NOTE: Save shims for reinstallation. Temporarily tape the shims to the tailcone in the respective positions.

- (9) (280FX) Remove the drive shaft cover bracket from under the aft drive shaft bearing assembly.
- (10) Remove the driveshaft assembly from tailcone.

C. Disassembly – Driveshaft

- (1) Remove the taper pins and couplings from forward and aft ends of driveshaft. Use tool T-0092-5 to remove the taper pins.
- (2) Slide the tach drive cover and O-rings from the shaft.
- (3) Separate and remove the tach drive pulley.
- (4) Apply lubricant (soapy water) to the driveshaft and slide the pillow blocks from the shaft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

D. Inspection – Driveshaft

- (1) Straightness. Sharp kinks or bends that exceed .030 inch per foot section/.76 mm per 1 meter section are cause for rejection.
- (2) Nicks and scratches.
 - (a) Examine the driveshaft surface for nicks and scratches. Include inspection of the circumference of the driveshaft where the driveshaft passes through the tach drive pulley guard hole.
 - 1 Nicks or scratches not deeper than 0.030 inch/0.76 mm may be blended out. Apply corrosion protection after repair.
 - 2 Nicks or scratches in excess of 0.030 inch/0.76 mm are cause for rejection.
 - (b) If either conditions 1 or 2 are present as a result of contact with the pulley guard, proceed as follows:
 - 1 Verify driveshaft straightness (step (1)) and alignment (Para. 10-6.A).
 - 2 Inspect pulley guard installation for mount, security, and damage. Replace a damaged pulley guard.
 - 3 (Optional) Modify the tach drive cover in accordance with Para. 10-6.3.
- (3) Taper pin holes for elongation, excessive diameter, and cracks. Any are cause for rejection.
- (4) Corrosion or rust, especially under rubber inserts. Pits that exceed .030 inch/.76 mm in depth are cause for rejection.

E. Installation – Driveshaft

NOTE: Procedure steps (1)-(12) applies to installing a replacement driveshaft. Fabrication of a replacement drive shaft requires additional skill and equipment. It is recommended to contact Enstrom for a replacement driveshaft assembly.

NOTE: If re-installing a removed driveshaft, proceed to step (13).

NOTE: When installing a tail rotor driveshaft, both the main rotor and tail rotor gearbox must be installed on aircraft. Install a coupling half secured with a taper pin in each gearbox.

- (1) Ream the bore on one end of driveshaft with a .640-inch straight reamer to remove paint. Ream 2" into bore and deburr the end of the shaft.
- (2) Clean the bore ends of the driveshaft and O.D. of aluminum plugs with Loctite Primer T.
- (3) Apply epoxy prime (MIL-PRF-23377 Type I Class 2C or Class N) to the O.D. of aluminum plug, heat driveshaft to approximately 250°F/121°C and tap plug into driveshaft until it is flush with the end of the shaft.
- (4) Drill the aft coupling as follows: (see Fig. 10-18)
 - (a) Mark a line on the driveshaft 7/8" from the end of the shaft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Slide the coupling on the shaft until even with the 7/8" line.
- (c) Mark and center-punch Point "A" of Fig. 10-18 using dimensions given.
- (d) Drill through the coupling and driveshaft with a "D" size drill (\varnothing .2460 inch).

NOTE: Drilling must be done in a drill press to assure that drilled hole is perpendicular to the driveshaft.

- (e) Ream the hole with a #2 tapered reamer to fit an AN386-2-8A taper pin very carefully so as not to over ream.

NOTE: If over-reaming of a tapered hole occurs, use P/N 28-13623-11 through -17 taper pins as required.

NOTE: Taper pins should be seated by tapping into place and then secured with the nut.

- (f) Install the taper pin through the coupling. Install cup washer (7) or washer (8), and nut (9). Torque nut (25 in-lb/2.8 Nm) (Fig. 10-21).

- (5) Temporarily slide forward coupling half on the forward end of the driveshaft and place the driveshaft on the tailcone.
- (6) Reassemble the couplings together such that the flanges are in alignment. Install equal thickness spacers between the flex pack and the flanges. An alternate method is to use a .235-inch aluminum block. Refer to Fig. 10-19 for either option.
- (7) Mark the location of the forward coupling on the driveshaft using a felt marker and mark the location of the pillow blocks on the driveshaft.
- (8) Remove the driveshaft from the tailcone.
- (9) Remove the forward coupling from the driveshaft.
- (10) Add 7/8" from the mark on the driveshaft and mark a new line for the end of the driveshaft. Cut the shaft to length.

NOTE: Do not cut the driveshaft at the initial coupling position mark.

- (11) Ream the forward end of the driveshaft with .640-inch reamer to remove paint.
- (12) Drill the forward coupling to the driveshaft following the procedure in step (4) (Fig. 10-18).
- (13) Install the driveshaft on the tailcone and connect both couplings per step (6) (Fig. 10-21).

NOTE: Taper pins on both the main rotor and the tail rotor gearbox sides of the coupling are AN386-2-7A.

- (14) Mark the driveshaft for the pillow block alignment to the mount holes in the tailcone.

NOTE: Place a 3/4-inch block of wood under the driveshaft to remove the bow in shaft while marking the pillow block areas.




Fig. 10-18




Figure 10-19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (15) Remove the driveshaft and the forward coupling.
- (16) Wipe the driveshaft with liquid detergent and slide the pillow blocks into the marked positions. See Fig. 10-20 for the direction of the pillow blocks on the driveshaft.

NOTE: The forward pillow block is installed with the closed end facing aft.
- (17) Place the driveshaft back on the tailcone and connect the couplings to the transmissions.
- (18) Align the pillow blocks with the mount holes in the tailcone.
- (19) Install the tach drive pulley on the driveshaft.
- (20) Disconnect the forward coupling and install the tach drive O-rings and cover. Connect the coupling.
- (21) (280FX) Install the driveshaft cover bracket and shims under the aft drive shaft bearing assembly. Temporarily install the bearing shim stack-ups and mounting hardware.
- (22) Align the tail rotor driveshaft (Para. 10-6.A).
- (23) (280F) Install the vertical stabilizer.
- (24) If required, install the anti-collision light on top of the tailcone.
- (25) Install cowling.
- (26) (280FX) Close the drive shaft covers and install the aft cover.




Figure 10-20. Pillow Block Orientation

10-6.1 TAIL ROTOR DRIVESHAFT FLEX COUPLING

A. General Information – Flex Coupling

The alignment of the tail rotor flex couplings is a very important factor in achieving the full service life of the flex pack. Large offsets on the tension side of the pack usually indicate improper spacing of the coupling sections and will promote premature distortion or degradation of the flex pack. A nominal device life for the flex pack has been established to ensure component integrity. The flex packs must be replaced after 1200 hours of service with new flex packs.

B. Removal – Flex Coupling (Fig. 10-21)

NOTE: Washers (11) are located between the flex coupling washers (16) and the coupling hub flanges (2) and (3) for the purpose of centering and aligning the flex elements (13) between the coupling hub flanges. Note their location before disassembly.

- (1) Remove the bolts (10), washers (11) and flex coupling washers (16) which connect the coupling hubs (2) and (3) to the flex elements (3).
- (2) Remove the flex elements (13).
- (3) Remove the taper pins (5) and (6) and remove the coupling hubs from gearbox and driveshaft.

C. Inspection – Flex Coupling (Figs. 10-22 through 10-25)

NOTE: Fig. 10-22 shows a tail rotor driveshaft coupling installation with the tension and compression sides labeled. There are two types of flex pack distortion which are typically encountered and which are allowable IF THEY ARE WITHIN THE LIMITS listed in this section.

- (1) The first type of flex element distortion typically encountered is a simple bow of the elements as shown in Fig. 10-23. This distortion is allowable ONLY as long as the coupling meets the following requirements:
 - (a) The bend is smooth and gradual, no kinks, etc.
 - (b) The elements are all deformed evenly, with no separation or voids between the elements.
 - (c) The bow, as measured in Fig. 10-23, is less than .080 inch deep on the compression side, and less than .060 inch deep on the tension side.
- (2) The second type of flex element distortion typically encountered is an offset bend as shown in Fig. 10-24. This type of distortion usually occurs because the coupling halves are not running parallel with each other. This type of distortion is allowable ONLY as long as the flex elements meet the following requirements:
 - (a) The bend is smooth and fair, with no kinks, etc.
 - (b) The elements are all deformed evenly, with no separation or voids between the elements.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (c) The offset is less than .060 inch as shown in Fig. 10-24.
- (3) The coupling hubs which hold the flex elements must be flat within .010 inch as shown in Fig. 10-25. Any hubs **deformed** beyond this limit **MUST** be replaced before further flight.
- (4) Whether the distortions described in the preceding inspections are present or not, the couplings are **UNSERVICEABLE** at any time the following conditions exist:
 - (a) Elements have kinks or sharp bends.
 - (b) Separations or voids occur between any of the elements.
 - (c) Non-uniform or non-fair bends.
 - (d) Cracked or broken elements.
 - (e) Elongated bolt holes.
 - (f) Kinks or deformation adjacent to the flex coupling washers.

D. Installation – Flex Coupling (Fig. 10-21)

NOTE: Proper attention during installation and alignment must be taken to permit couplings to operate to full capacity and provide good service life.

- (1) Install rain slinger on tail rotor gearbox (Fig. 10-17).
- (2) Install coupling hub (3) on gearbox and coupling hub (2) on driveshaft.

NOTE: Taper pins should be seated by tapping into place and then secured with the nut.
- (3) Install taper pins (5) and (6), cup washers (7) or washers (8), and nuts (9). Torque nut (25 in-lb/2.8 Nm).
- (4) Install a washer (11) on each bolt and insert through the coupling hub (2) or (3).
- (5) Install washer(s) (11), flex coupling washers (16), flex pack (13), flex coupling washers (16), washer (11), and nut (12) on each bolt. Torque 70 in-lb/7.9 Nm.

CAUTION: HEAVY OR LIGHT WASHERS (11) CAN BE USED WITH FLEX COUPLING WASHERS TO EQUALLY SPACE FLEX ELEMENTS BETWEEN THE COUPLING HUBS. THE CURVED SIDE OF THE FLEX COUPLING WASHERS MUST FACE AGAINST THE FLEX ELEMENTS.


NOTE: Install the heavy and light washers in the same order and position as previously installed, if applicable.

- (6) Place washers (11) on remaining two bolts and insert through the coupling hub (2) or (3), as applicable.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL


- (7) Install washer(s) (11) and flex coupling washers (16) on bolts and insert through the flex pack (13).
- (8) Install flex coupling washers (16), washer (11), and nut (12) on each bolt. Torque 70 in-lb/7.9 Nm.

NOTE: With all bolts torqued, the flex elements (13) should be straight and equally spaced between coupling hub flanges.




- | | | | |
|----|-----------------------------------|-----|--------------------------------|
| 1. | Tail Rotor Driveshaft | 9. | Nut |
| 2. | Coupling Hub | 10. | Bolt |
| 3. | Coupling Hub | 11. | Washer |
| 4. | Sleeve | 12. | Nut |
| 5. | Taper Pin | 13. | Flex Pack |
| 6. | Taper Pin | 14. | Cable Tie |
| 7. | Cup Washer | 15. | Plug |
| 8. | Washer (If Item 7 is not present) | 16. | Flex Coupling Washer (Beveled) |

Figure 10-21. Flex Coupling Installation



NOTE: Tie-wraps eliminated for clarity.

Figure 10-22. Tail Rotor Drive Shaft Coupling Installation, Rear Coupling Shown; Forward Coupling Similar



NOTE: Tie-wraps eliminated for clarity.

Figure 10-23. Acceptable Limits of Bowed Flex Packs




Figure 10-24. Acceptable Limits for Flex Packs with Offset Bends




Figure 10-25. Acceptable Limits for Bent Coupling Hub Flanges

10-6.2 TAIL ROTOR DRIVESHAFT PILLOW BLOCK

A. Disassembly – Pillow Block

- (1) Remove the rubber insert.
- (2) Remove the snap ring.
- (3) Heat the housing to approximately 250°F/121°C and gently tap bearing to remove.

B. Inspection – Pillow Block

- (1) Bearing condition - no ratchety feeling.
- (2) Bearing housing - no cracks, nicks, corrosion.
- (3) Rubber insert - no tears or rubber deterioration.

C. Assembly – Pillow Block

- (1) Heat bearing housing to approximately 250°F/121°C.
- (2) Lubricate the bore of the housing and install the bearing into position.

NOTE: The open side of the bearing is installed inboard toward the grease fitting. On new bearings, one shield must be removed.

- (3) Install the snap ring and allow to cool.
- (4) Install the rubber insert.

10-6.3 TACH DRIVE PULLEY GUARD

NOTE: The following modifications are optional. Use caution while modifying the pulley guard to avoid damaging the tail rotor driveshaft. Refer to Fig. 10-25.1 for numbered items. Note S/N effectivity

A. Modification – Tach Drive Pulley Guard

NOTE: F-28F, S/N 829 and prior, and 280FX, S/N 2134 and prior, are eligible for the following modification if the pulley guard is original and has not been modified in accordance with SDB 0111. F-28F, S/N 830 and subsequent, and 280FX S/N 2135 and subsequent, are exempt from this modification as these S/N were equipped with the modified pulley guard from the factory.

NOTE: This modification removes material between the clips of the pulley guard to simplify maintenance operations pertaining to the rotor tach assembly or the tail rotor driveshaft and increases the hole diameter to add clearance between the driveshaft and the pulley guard. This modification may be performed with the rotor tach assembly left intact.

NOTE: Refer to Fig. 10-25.1.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) Remove pulley guard attachment hardware (2), (3), and (4) and slide guard (1) forward for access. Note the placement and number of washers used for shimming.
- (2) Using a suitable metal cutting tool, cut out the area of the pulley guard between the clips.
- (3) Remove the pulley guard by slipping it off the driveshaft via the cutout area. Avoid scratching the driveshaft. It will be necessary to twist the guard to provide additional clearance with the driveshaft.
- (4) The pulley guard hole may be machined to a maximum 1.125 inch/28.58 mm diameter.
- (5) Deburr and apply corrosion protection (epoxy primer) to all newly cut surfaces.
- (6) Reinstall the pulley guard.
- (7) Check the pulley guard clearance with the driveshaft and the pulley belts. Adjust the number of shimming washers, if necessary.
- (8) If there is evidence of contact between the upper cowling and the pulley guard, install a Nitrile rubber pad, or equivalent, on top of the pulley guard to provide surface abrasion protection and vibration dampening properties.

NOTE: Select either a 1/16 inch/1.58 mm or 1/8 inch/3.17 mm to match the gap distance between the pulley guard and the cowling. A one square inch piece will be adequate.

- (a) Remove contamination from the pulley guard surface with a clean shop rag wetted with an appropriate solvent.
- (b) Install the rubber pad with Loctite 4212 adhesive, or equivalent.




Figure 10-25.1. Tach Drive Pulley Guard Modifications

10-7 TAIL ROTOR CONTROL SYSTEM

A. Tension Check – Tail Rotor Cable Control System

(1) Install the tail rotor rigging tool T-0080 (0.590 in/15 mm side) between the bearing retainer and the output shaft seal retainer to hold the tail rotor pitch controls in the neutral position (Fig. 10-26). Secure the pitch control assembly in this position by installing wooden wedges between the pitch control assembly and the transmission on the right side of the transmission (Fig. 10-27).

(2) Verify that the pilot and co-pilot pedals are in alignment to each other.

(3) If the pedals are not even, adjust the tension as follows:

(a) Remove the wraparound cowl and baggage box, if necessary.

CAUTION: TURNBUCKLES MAY NOT HAVE MORE THAN THREE THREADS SHOWING AT EACH END.

NOTE: Use a cable tensiometer for making cable tension adjustments.

(b) Remove the safety clips or the turnbuckle safety wire. Tighten one turnbuckle and loosen the other to align the pedals and keep the tension at 35-40 lb/5.9-18.1 kg.

(c) Remove the rigging tool T-0080 and wedges from the tail rotor transmission, then cycle the pedals back and forth a few times after each adjustment to equalize the tension between the two cables.

(d) Repeat from step (1) as required.

(4) Check complete rigging of tail rotor (Para. 10-7.B), if adjustments were made.

(5) Install safety clips in the turnbuckles when the cable tension is set.

(6) Install the baggage box and the wraparound cowl.

B. Rigging – Tail Rotor Cable Control System

NOTE: Check three-piece pitch link length at 4.260 in/10.8 cm, if installed.

NOTE: Inspect control cable barrels to ensure locking clips are installed.

(1) Verify the cable tension is set (Para. 10-7.A).

(2) If required, remove the wraparound cowl and baggage box, if necessary.

(3) Remove the seat cushions, seat deck (Para. 8-8.A), and the left floor panel.

(4) Install the tail rotor rigging tool T-0080 (0.590 in/15 mm side) between the bearing retainer and the output shaft seal retainer to hold the tail rotor pitch controls in the neutral position (Fig. 10-26). Secure the pitch control assembly in this position by installing wooden wedges between the pitch control assembly and the transmission on the right side of the transmission (Fig. 10-27).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (5) Verify that the pedals are in alignment. If not aligned, adjust the cable tension in accordance with Para. 10-7.A.
 - (6) Remove the rigging tool T-0080 and wedges from the tail rotor transmission, then cycle the pedals and look for interference between the pitch control assembly pivot brackets and the tail rotor transmission.
 - (7) Move the pedals to the full left position. Insert the tail rotor rigging tool T-0080 (narrow profile) between the output shaft seal housing and the face of the brass bushing in the pitch control assembly (Fig. 10-26). The rigging tool should just fit in when the pedals contact the left stop. Adjust the "left pedal adjustment stop" until the pedal and the control assembly make contact at the same time (Fig. 10-28).
 - (8) Move the control pedals to the the full right position. Insert the tail rotor rigging tool T-0080 (widest profile) between the output shaft seal housing and the face of the brass bushing in the pitch control assembly (Fig. 10-26). The rigging tool should just fit in when the pedals contact the right stop. Adjust the "right pedal adjustment stop" until the pedal and the control assembly make contact at the same time (Fig. 10-28).
- NOTE:** Control brackets should not stop against tail rotor gearbox. Pedals must stop against stop bolts on forward bellcrank.
- (9) Install the wraparound cowl and the baggage box, if removed.
 - (10) Install the left floor panel, seat deck (Para. 8-8.D), and seat cushions.




Figure 10-26. Rigging Tool T-0080 Installation





Figure 10-27. Wooden Wedges Installed



NOTES:

1. AT ALL DOUBLE LOCKING LOCATIONS, NO MORE THAN ONE THREAD OF BOLT TO BE BELOW SURFACE OF JOINT.
2. UP TO 3 WASHERS TOTAL MAY BE USED UNDER BOLT HEAD AND NUT TO ENSURE PROPER ENGAGEMENT OF COTTER PIN IN NUT CASTELLATION.
3. BOLTS OF NEXT DASH NO. IN LENGTH MAY BE SUBSTITUTED AS LONG AS REQUIREMENTS OF NOTE 2 ARE MET.
4. ALL CHECK NUTS TO BE TREATED WITH VIBRA-TITE (VC-3).
5. BELLCRANK HARDWARE TYPICAL 2 PLACES.

Figure 10-28. Tail Rotor Pedal Adjustment Stops

10-8 TAIL ROTOR CONTROL CABLES

A. Inspection – Tail Rotor Cable

- (1) Remove the wraparound cowling and baggage box, if required.
 - (2) Remove the seat cushions, seat deck, and the floor panels on the left side of the cabin.
- NOTE: Stabilizer removal is not required on 280F models.
- (3) Remove the left side horizontal stabilizer and remove the inspection panel on the tailcone.
 - (4) Inspect the cables and cable ends for corrosion, wear, broken strands or strand separations, and fraying.

CAUTION: USE OF PVC TAPE TO COVER OR WRAP THE EXPOSED CABLE ENDS IS PROHIBITED. REMOVE ANY PVC TAPE FROM THE CABLES IF PRESENT.

- (5) Visually inspect the cable pulleys for wear and security.
 - a) Disconnect the tail rotor cables from the tail rotor pitch change assembly and attach strings to the end of the cables.
 - b) Partially pull the tail rotor control cables out of the tailcone through the access opening and inspect the areas of the tail rotor control cables that pass over the pulleys and inspect the pulleys in accordance with FAA Advisory Circular 43.13-1B, Para. 7-149, Cable System Inspection. If the pulleys are rubbing on the mounting brackets, AN960-10L, NAS1149F0316P, or NAS1149F0332P washers may be used as shims to eliminate the interference.

CAUTION: IN OLDER AIRCRAFT, TURNBUCKLES LOCATED NEAR THE TURBOCHARGER HAVE A HIGH SUSCEPTIBILITY TO RAPID DETERIORATION. IT IS RECOMMENDED THAT THE LOCATION OF THE TURNBUCKLES BE REPOSITIONED UNDER THE BAGGAGE BOX. SEE SIL 0192 FOR PART NUMBER INFORMATION.

- (6) Inspect the turnbuckles hardware for corrosion and security.
- (7) Replace and reinstall the tail rotor cables and/or pulleys if an unsatisfactory condition, as described in steps 4 through 6, is evident.
- (8) Check cable tension 35-40 lb/15.9-18.1 kg with cable tensiometer and tail rotor rigging (Para. 10-7.A).
- (9) Install the left side horizontal stabilizer, if removed, and install the inspection panel on the tailcone.
- (10) Install the left side floor panel, seat deck, and seat cushions.
- (11) Install wraparound cowling and the baggage box, if removed.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

B. Replacement – Tail Rotor Cable (Fig. 10-29)

(1) Replace the aft section of the tail rotor cable as follows:

(a) Remove the wraparound cowl and the baggage box, if required.

NOTE: Stabilizer removal is not required on 280F models.

(b) If required, remove the left side horizontal stabilizer and remove the inspection panel on the tailcone.

(c) Remove the cotter pins from the aft cable guide pulley.

(d) Remove pivot hardware from the cable links at the aft control brackets (Detail A).

(e) Cut the tail rotor cable aft of the turnbuckle in the engine compartment or aft pylon area, as applicable.

(f) Attach a string to the forward end of the cable and pull the cable out through the aft end of tailcone.

NOTE: String will follow routing through pulleys and eyelets to aid in installation of the new cable.

(g) Attach a new tail rotor cable to the string and pull it back through the tailcone eyelets and cable pulleys.

NOTE: Check that the cable is properly routed and riding on the pulleys (Detail C and Detail D).

(h) Clamp the tail rotor pedals in neutral position using two wood blocks and C-clamps.

(i) Install the tail rotor rigging tool T-0080 (0.590 in/15 mm) between the bearing retainer and the output shaft seal retainer to hold the tail rotor pitch controls in the neutral position (Fig. 10-26). Secure the pitch control assembly in this position by installing wooden wedges between the pitch control assembly and the transmission on the right side of the transmission (Fig. 10-27).

NOTE: If rigging tool is not available, install a spacer measuring 0.590 in/15 mm between the brass bushing and the seal housing.

(j) Connect the aft end of tail rotor cable to the cable links and the tail rotor control brackets. Torque the pivot bolts and install cotter pins.

CAUTION: CABLE LINKS MUST PIVOT FREELY ON THE CONTROL BRACKETS AND AT THE CABLE CONNECTIONS.

(k) Adjust the turnbuckle so only one thread of rod ends is showing at each end of turnbuckle.

(l) Position the new cable through the cable eye on the turnbuckle rod end.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (m) Pull the cable taut and swedge in this position. Allow 2 to 3 inches of cable extending from swedge and cut excess cable to leave approximately a 1 inch tail.

CAUTION: TURNBUCKLES MAY NOT HAVE MORE THAN THREE THREADS SHOWING AT EACH END.

- (n) Using a cable tensiometer, adjust the turnbuckles until the cables read 35-40 lb/15.9-18.1 kg.
- (o) Remove the clamps from the tail rotor pedals.
- (p) Check the rigging and cable tension (Para. 10-7.A).
- (q) Cycle tail rotor pedals to check for binding.
- (r) Install pulley cotter pins and check pulley for binding.
- (s) Install the inspection panel on the tailcone.
- (t) Install the horizontal stabilizer, if removed.
- (u) Install wraparound cowling and the baggage box, if removed.

- (2) Replace the forward section of the tail rotor cable as follows (Fig. 10-29):

- (a) Remove the seat cushions and the seat deck (Para. 8-8.A).
- (b) Remove the floor panels on the left side of the cabin.
- (c) Disconnect the cable from the forward tail rotor pedal bellcrank (Detail F).
- (d) Cut the cable forward of the turnbuckle in the engine compartment or aft pylon area, as applicable (Detail B).

NOTE: It is not necessary to remove the pulley cotter pins.

- (e) Attach a string to the aft end of the cable and pull it out forward through the firewall and the seat assembly.
- (f) Attach a new cable to the string and pull it back through the firewall.

NOTE: Check that cable is properly routed and riding on pulley on forward side of firewall (Detail E).

- (g) Install spacers on each side of the cable and insert into the forward bellcrank. Secure with hardware (Detail F).
- (h) Clamp the tail rotor pedals in neutral position using two wood blocks and C-clamps.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (i) Install the tail rotor rigging tool T-0080 (0.590 in/15 mm) between the bearing retainer and the output shaft seal retainer to hold the tail rotor pitch controls in the neutral position (Fig. 10-26). Secure the pitch control assembly in this position by installing wooden wedges between the pitch control assembly and the transmission on the right side of the transmission (Fig. 10-27).

NOTE: If a rigging tool is not available, install a spacer measuring 0.590 in/15 mm between the brass bushing and the seal housing.

- (j) Adjust the turnbuckle in the engine compartment or aft pylon area, as applicable, so only one thread of the rod ends is showing at each end of the turnbuckle.
- (k) Position the new cable through the cable eye on the turnbuckle rod end.
- (l) Pull the cable taut and swedge in this position. Allow 2 to 3 inches of cable extending from swedge and cut excess cable to leave approximately a 1 inch tail.

CAUTION: TURNBUCKLES MAY NOT HAVE MORE THAN THREE THREADS SHOWING AT EACH END.

- (n) Using a cable tensiometer, adjust the turnbuckles until the cables read 35-40 lb/15.9-18.1 kg.
- (o) Remove the clamps from the tail rotor pedals.
- (p) Check the rigging and cable tension (Para. 10-7.A).
- (q) Cycle tail rotor pedals to check for binding.
- (r) If previously removed, install cotter pins and check pulley for binding.
- (s) Install the floor panel, seat deck (Para. 8-8.D), and cushions.




Figure 10-29. Tail Rotor Cables

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 11 BELT DRIVE SYSTEM TABLE OF CONTENTS

Paragraph	Page
General Information	MM-11-3
11-1 Clutch Control and Belt Tension Rigging	MM-11-3
A. Static Inspection	MM-11-3
B. Rigging Procedures	MM-11-5
11-2 Clutch Cable	MM-11-10
A. Removal	MM-11-10
B. Installation	MM-11-11
11-3 Clutch Control Lever	MM-11-13
A. Removal	MM-11-13
B. Inspection	MM-11-13
C. Installation	MM-11-13
11-4 Jackstrut and Pulley Assembly	MM-11-14
A. Removal	MM-11-14
B. Disassembly	MM-11-14
C. Cleaning	MM-11-15
D. Inspection	MM-11-15
E. Assembly	MM-11-15
F. Installation	MM-11-16
G. Pulley Alignment Procedure	MM-11-17
11-5 Drive Belt	MM-11-21
A. Troubleshooting	MM-11-21
B. Tracking	MM-11-21
C. Removal	MM-11-24
D. Inspection	MM-11-24
D.1. Repair	MM-11-27
E. Installation	MM-11-33
11-6 Main Rotor Transmission	MM-11-36
A. General Description	MM-11-36
B. Removal	MM-11-36
C. Seal Replacement	MM-11-37
D. Installation	MM-11-39
11-6.1 Main Rotor Chip Detector	MM-11-41
A. Removal	MM-11-41
B. Installation	MM-11-41
11-7 Overrunning Clutch and Pulley Assembly	MM-11-42
A. Troubleshooting	MM-11-42
B. Servicing and Inspection	MM-11-42
C. Removal	MM-11-43
D. Disassembly	MM-11-44
E. Cleaning	MM-11-44
F. Inspection	MM-11-44
G. Assembly	MM-11-44
H. Installation	MM-11-45

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 11

BELT DRIVE SYSTEM

TABLE OF CONTENTS – CONTINUED (PAGE MM-11-2)

Paragraph	Page
<u>11-7.1</u> Upper Jackstrut Bearing	MM-11-47
A. Removal	MM-11-47
B. Cleaning	MM-11-47
C. Inspection	MM-11-47
D. Installation	MM-11-47
<u>11-8</u> Idler Pulley Assembly	MM-11-53
A. Troubleshooting	MM-11-53
B. Removal	MM-11-53
C. Disassembly	MM-11-53
D. Cleaning	MM-11-54
E. Inspection	MM-11-54
F. Assembly	MM-11-54
G. Installation	MM-11-55
<u>11-8.1</u> Yoke End Assembly	MM-11-56
A. Removal	MM-11-56
B. Disassembly	MM-11-56
C. Inspection	MM-11-56
D. Assembly	MM-11-56
E. Installation	MM-11-57
<u>11-8.2</u> Actuator Arm Assembly and Snubber Roller Assembly	MM-11-58
A. Removal	MM-11-58
B. Disassembly	MM-11-58
C. Cleaning	MM-11-58
D. Inspection	MM-11-58
E. Assembly	MM-11-59
F. Installation	MM-11-59
<u>11-9</u> Belt Tension Assembly	MM-11-71
A. Troubleshooting	MM-11-71
B. Removal	MM-11-71
C. Disassembly	MM-11-71
D. Cleaning	MM-11-72
E. Inspection	MM-11-72
F. Repair	MM-11-72
G. Assembly	MM-11-72
H. Installation	MM-11-74
I. Replacement – Spring Capsule Bushing	MM-11-74
J. Assembly – Spring Capsule	MM-11-76

SECTION 11

BELT DRIVE SYSTEM

General Information

The belt drive system consists of a jackstrut and pulley assembly, idler pulley assembly, belt tension assembly, and a clutch engagement lever which is controlled from the cabin. The jackstrut pulley, which is bolted to the engine, drives the main rotor gearbox through a main drive belt. By engaging the clutch lever, the belt tension assembly pulls the idler pulley into the drive belt. Belt tension is maintained by properly rigging the system. Correct rigging and maintenance are very important to keep this system working properly and extends component service life.

11-1 CLUTCH CONTROL AND BELT TENSION RIGGING

NOTE: The clutch control and belt tension rigging static inspection assists in determining if the drive belt tension, belt tension mechanism, actuator, and clutch control handle are rigged properly and in the proper operating position.

NOTE: Inspection is to be completed in the sequence listed and with the engine off.

WARNING: EXTREME CAUTION SHOULD BE USED WHEN BELT TENSION MECHANISM IS IN ENGAGED POSITION. KEEP HANDS AWAY FROM THIS MECHANISM WHEN ENGAGING OR DISENGAGING CLUTCH, OR PERSONAL INJURY COULD OCCUR.

A. Static Inspection

- (1) Pull clutch handle up a couple inches and SLOWLY return lever to CLUTCH DISENGAGED position (Fig. 11-1, Detail d).

NOTE: The clutch lever must be placed in the disengaged position gently (and the guide bushings must be snug enough) so that momentum will not continue movement of the bellcrank and give a false indication of the 1/16 to 1/8 inch/1.6-3.3 mm gap.

- (a) The threaded shaft (6) should be within 1/16 to 1/8 inch/1.6-3.3 mm of the lower pivot spacer of bellcrank (2) (Fig. 11-2, Detail a).

1 If measurement is outside the limits, adjust spring capsule clearance (Para. 11-1.B.(4)).

- (b) Verify guide bushings (8) (Fig. 11-18) are snug on bracket (9) (Fig. 11-3, Detail c).

1 If the guide bushings are not snug on the brackets, adjust clutch capsule slide connection (Para. 11-1.B.(3)).

- (2) ENGAGE clutch and STOW clutch lever (Fig. 11-1, Detail a).

- (a) The clutch lever should lie flat on the floor (Fig. 11-1, Detail a). Movement of the handle should have no effect on the bellcrank (Fig. 11-1, Detail f).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Use the shank of a 1/8 drill bit or a #30 drill bit to verify that there is approximately .125-inch (3.2 mm) space between the clutch lever and the spacer in the bellcrank (Fig. 11-1, Detail e).
- 1 If the clearance between the handle and the spacer is not correct the clutch system will require rigging (Para. 11-1.B).
- (c) Viewing the belt tension mechanism, check that the overcenter stop (8) is tightly against side plates (9) (Fig. 11-3, Detail b), and the clutch engage warning light is out.
- (d) Viewing the top of the spring capsule, inspect for wear (Fig. 11-3.1) between the adapter (3) and the bushing (5) (Fig. 11-19). It may help to push the top of the capsule inboard while watching for movement between the adapter and the bushing.
- 1 If bushing is loose, replace the bushing (Para. 11-9.I).




Figure 11-1. Clutch Rigging

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (e) View spring capsule adapter (6) (Fig. 11-3).
- 1 The proper extension of adapter (6) is 1-5/8 to 1-3/4 inches/41.3-44.5 mm from top of spring capsule to bottom of adapter nut (Fig. 11-3, Detail d).
 - a If the adapter extension is not correct, adjust the extension (Para. 11-1.B.(5)).

NOTE: Adjusting the adapter extension will require rigging the adapter extension and the snubber roller adjustments.

NOTE: Rigging between clutch control handle and the belt tension mechanism will usually remain constant unless some portion of this system is removed or replaced.
 - 2 The bellcrank should be horizontal to slightly below horizontal (Fig. 11-3, Detail e).
- (f) Inspect for contact between the anchor (14) (Fig. 11-19) and the pylon tube.
- 1 If contact is evident, chamfer the anchor (Para. 11-9.F).
- (g) Check clearance between the snubber roller and the back side of the belt for 0.38 inch/9.5 mm gap and parallelism to the belt.
- 1 If clearance is insufficient, adjust roller (Para. 11-5.B.(11)).
 - 2 Inspect the snubber roller for wear (grooves). Wear of the snubber roller from the belt indicates contact from the belt during operation and that the gap between the belt and the roller is not sufficient.

B. Rigging Procedures

WARNING: EXTREME CAUTION SHOULD BE USED WHEN BELT TENSION MECHANISM IS IN ENGAGED POSITION. KEEP HANDS AWAY FROM THIS MECHANISM WHEN ENGAGING OR DISENGAGING CLUTCH, OR PERSONAL INJURY COULD OCCUR.

NOTE: Para. 11-1.B.(5), Belt Tension Adjustment, will have to be re-checked after belt replacement or drive system disassembly to assure proper belt tension and rigging.

NOTE: The clutch is rigged in the following steps. Rigging is to be completed in the sequence listed, with the engine off.

(1) Preliminary Clutch Lever Adjustment

NOTE: The clutch lever must be placed in the disengaged position gently (and the guide bushings must be snug enough) so that momentum will not continue movement of the bellcrank and give a false indication of the 1/16 to 1/8 inch/1.6-3.3 mm gap.

- (a) Place clutch in ENGAGED position (Fig. 11-1, Detail b). With clutch engaged, lift and release clutch lever to stowed position (Fig. 11-1, Detail a). Adjust turnbuckle (3) until the clutch lever will lie flat on floor and that there is approximately 0.125 inch/3.2 mm clearance between the handle and the spacer (Fig. 11-1, Detail e).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(2) Preliminary Belt Tension Mechanism Check

(a) Check the following items before proceeding with clutch rigging.

- 1 Clutch cable is to have one thread exposed above jam nut (11) (Fig. 11-3).
- 2 Engage the clutch lever (Fig. 11-1, Detail b) and check that belt tension assembly is locked over center with stops (8) contacting side plates (9), and the clutch engage warning light is out (Fig. 11-3, Detail b).
- 3 Disengage the clutch (Fig. 11-1, Detail d).

(3) Spring Capsule Slide Connection Adjustment

- 1 With the clutch disengaged, remove the bolt (18) securing the clutch cable (15) to the clutch actuator bellcrank (13) (Fig. 11-3).
- 2 Pull clutch handle up 2 inches/50 mm to move the cable out of the way at the clutch capsule.
- 3 Loosen the torque on nuts (7) that secure the capsule assembly (6) into the guide brackets (9) so that the nylon guides (8) are loose (Fig. 11-18).
- 4 Connect a fish scale to the clutch capsule bellcrank assembly and measure the force required to start the bellcrank moving (Fig. 11-2, Detail b).
- 5 Incrementally re-tighten the nuts securing the capsule to the brackets until the force required to move the bellcrank is the original scale reading plus 3 lb/1.4 kg.
- 6 Connect the clutch cable rod end (10) to the bellcrank (13) and torque nut to 30-40 in-lb/3.4-4.5 Nm (Fig. 11-3, Detail a).

(4) Spring Capsule Clearance Adjustment

NOTE: Adjust spring capsule clearance with clutch disengaged.

- (a) Loosen jam nut (5) (Fig. 11-2) and turn spring capsule adapter (4) in or out of spring capsule to obtain 1/16 to 1/8 inch/1.6-3.3 mm clearance between threaded shaft and lower pivot spacer of bellcrank (2) (Fig. 11-2, Detail a).

NOTE: After each adjustment of the adapter, the clutch handle must be pulled up a few inches and SLOWLY returned to the full down position.

- (b) Re-check clearance after engaging and disengaging clutch.
- (c) Lock jam nut (5) against adapter (4).

(5) Belt Tension Adjustment

- (a) ENGAGE the clutch assembly.
- (b) Measure the exposed surface of the adapter (6) (Fig. 11-3, Detail d).

NOTE: Ensure measurement is taken from the bottom of the adapter nut (4), NOT the jam nut (5) on top of adapter nut (4) (Fig. 11-3, Detail d).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (c) The length of exposed spring capsule adapter (6) should be 1-5/8 to 1-3/4 inches/41.3-44.5 mm. If length is not correct, proceed as follows:
- 1 Loosen jam nut (5).
 - 2 DISENGAGE clutch assembly.
 - 3 Disconnect rod end (1) from bellcrank (2).
 - 4 Adjust shaft (3) in or out of yoke (4). Each turn of shaft (3) will change the exposed section of the adapter (6) by approximately 0.1 inch/2.4 mm.
 - 5 Connect rod end (1) to bellcrank (2) and ENGAGE clutch to recheck adjustment of adapter (6).
 - 6 Continue the adjustment process until the exposed surface of the adapter (6) is 1-5/8 to 1-3/4 inches/41.3-44.5 mm.

- (d) Continue to check the following with clutch assembly ENGAGED:

- 1 The top edge of bellcrank (2) should be horizontal to slightly below horizontal (i.e., parallel) to the lower aft pylon cross tube (Fig. 11-3, Detail e).
- 2 The snubber roller should be parallel to the back side of the belt with 0.38 inch/9.5 mm clearance.

NOTE: After final adjustment of the idler pulley track, loosen the aft nut on the "snubber" roller and allow the roller to self-align on the idler straps. Torque the aft nut to 95-110 in-lb/10.8-12.5 Nm.

- (e) Secure rod end (1) to bellcrank (2). Torque nut (30-40 in-lb/3.4-4.5 Nm).


- (f) Secure yoke jam nut (5) against yoke (4) (40-45 ft-lb/4.5-5.1 Nm).

- (g) Apply Vibra-Tite VC-3 to the following:

- 1 Spring capsule adapter (6) jam nuts.
- 2 Yoke jam nut (5).
- 3 Clutch cable rod end jam nut (12).

- (6) Final Clutch Lever Adjustment Check

- (a) With the clutch engaged and clutch lever in stowed position, the clutch lever should lie flat on the floor (Fig. 11-1, Detail a). Movement of the handle should have no effect on the bellcrank (Fig. 11-1, Detail e and Detail f).
- (b) Use the shank of a 1/8 drill bit or a #30 drill bit to verify that there is approximately 0.125-inch (3.2 mm) space between the clutch lever and the spacer in the bellcrank (Fig. 11-1, Detail e).
- (c) Check that the nuts on the turnbuckles and all other check nuts in the system are torqued.
- (d) Check that the clutch is over center with the stops contacting the side plates and that the clutch light is out.




(Clutch Disengaged)

- | | | | |
|----|------------------------|----|------------------------|
| 1. | Rod End | 4. | Spring Capsule Adapter |
| 2. | Bellcrank | 5. | Jam Nut (2 places) |
| 3. | Turnbuckle (Fig. 11-1) | 6. | Shaft |

Figure 11-2. Clutch Rigging – Spring Capsule Adjustments

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



(Clutch Engaged)

- | | |
|---------------------------|-----------------------------|
| 1. Rod End Bearing | 11. Jam Nut |
| 2. Bellcrank | 12. Jam Nut |
| 3. Shaft | 13. Bellcrank |
| 4. Yoke | 14. Mount Block |
| 5. Nut | 15. Cable |
| 6. Spring Capsule | 16. Nut (bolt head forward) |
| 7. Spring Capsule Housing | 17. Nut (bolt head forward) |
| 8. Stop | 18. Bolt |
| 9. Bracket (side plate) | 19. Spacer |
| 10. Rod End | 20. Flanged Bushing |

Figure 11-3. Clutch Rigging – Belt Tension Assembly Adjustment



Figure 11-3.1 Spring Capsule Wear Inspection Area

11-2 CLUTCH CABLE

A. Removal – Clutch Cable

NOTE: Refer to Fig. 11-3 for numbered items unless stated otherwise.

- (1) Disconnect clutch cable (15) at bellcrank arms (13).
- (2) Loosen jam nut (12) and remove rod end (10) and spacer from end of cable (15).
- (3) Remove rubber dust covers from cable.
- (4) Remove upper jam nut (11) from mount block (14).
- (5) Remove two bolts from mount block (14).
- (6) Slide mount block (14) over the end of cable (15).
- (7) Disconnect three clamps holding cable to pylon.
- (8) Remove forward jam nut from pylon mount (Fig. 11-4).
- (9) Remove fiberglass seat deck (Para. 8-8.A).
- (10) Loosen jam nuts from turnbuckle (3) barrel (Fig. 11-1).
- (11) Turn turnbuckle barrel to disconnect clutch cable.
- (12) Remove jam nut and rubber dust cover from forward end of cable.
- (13) Slide clutch cable aft through pylon mount and remove.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

B. Installation – Clutch Cable

NOTE: Refer to Fig. 11-3 for numbered items unless stated otherwise.

- (1) Remove rubber dust cover and outside jam nut from forward end of clutch cable.
- (2) Remove clutch cable heat shield.
- (3) Remove Adel clamps that secure cable to the pylon.
- (4) Slide cable through pylon mount (Fig. 11-4). Position forward as far as possible.
- (5) Install large jam nut, rubber dust cover, and small jam nut on cable.
- (6) Connect clutch lever linkage and cable with turnbuckle (3) barrel (Fig. 11-1).
- (7) Place clutch lever in engaged position. Lift and release clutch lever to stowed position. Adjust turnbuckle (3) until the clutch lever will lie flat on floor and there is 0.125 inch/3.2 mm clearance between the back side the handle and the spacer (Fig. 11-1, Detail e).
- (8) Torque (175-200 in-lb/19.8-22.6 Nm) pylon mount jam nuts. Approximately two threads should extend between aft jam nut and grease fitting.
- (9) Remove rubber dust cover and upper jam nut from aft end of clutch cable (15).
- (10) Slide mount block (14) down over end of cable (15).
- (11) Install mount block (14) bolts and washers.
- (12) Install nuts and torque (12-15 in-lb/1.4-1.7 Nm).
- (13) Install jam nut (11) and rubber dust cover.
- (14) Install rod end jam nut (12) and rod end (10) on cable (15).

NOTE: Turn rod end on cable until it bottoms out, then back it off one-half turn.

- (15) Slide spacer (19) into rod end (10) and place a heavy washer on each side of rod end. Install between bellcrank arms (13) of belt tension assembly.
- (16) Install washer on bolt (18) and slide belt through bellcrank arms (13) and rod end (10).
- (17) Install washer and nut on bolt (18) and torque (30-40 in-lb/3.4-4.5 Nm).
- (18) Torque (80 in-lb/9.0 Nm) jam nut (12) against rod end (10).
- (19) Torque (200 in-lb/22.6 Nm) the fitting (14) jam nuts with approximately two threads located above upper jam nut (11).
- (20) Install three clamps securing clutch cable to pylon.

NOTE: Before tightening the turnbuckle jam nuts, complete the rigging procedure (Para. 11-1.B).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (21) With jam nuts torqued and rigging complete, lubricate clutch cable. See Table 4-1 chart for proper grease. Grease fittings are located on aft side of pylon mount and below belt tension assembly mount block.
- (22) Engage and release clutch to check for freedom of movement in the system.




Figure 11-4. Forward End of Clutch Cable




Figure 11-5. Aft End of Clutch Cable

11-3 CLUTCH CONTROL LEVER

A. Removal – Control Lever

- (1) Remove fiberglass seat assembly (Para. 8-8.A).
- (2) Loosen jam nuts on turnbuckle (3) and rotate to disconnect clutch lever linkage from cable (Fig. 11-1).
- (3) Remove hardware that attaches bellcrank to the seat section.
- (4) Remove clevis pin on the bottom of the bellcrank to remove linkage.
- (5) Remove lever and bellcrank assembly.
- (6) Remove spacer from oilite bushings.

B. Inspection – Control Lever

- (1) Inspect bellcrank bushings for excessive wear.
- (2) Inspect roll pins and spacers in the bellcrank for security and wear.

C. Installation – Control Lever

- (1) Attach linkage to the bottom of the bellcrank and install clevis pin and cotter pin.
- (2) Install spacer in oilite bushings of bellcrank.
- (3) Install a light washer on mount bolt and, with head of bolt inboard, slide bolt through one side of seat section.
- (4) Install three washers (1/4 Harper), bellcrank and spacer assembly, and then two washers (1/4 Harper) on bolt.
- (5) Slide bolt through second side of seat section and install a light washer and nut. Torque nut (30-40 in-lb/3.4-4.5 Nm).
- (6) Attach clutch lever linkage to the clutch cable with turnbuckle.

NOTE: Adjust rigging per instructions (Para. 11-1.B).

- (7) Tighten turnbuckle jam nuts.
- (8) Inspect installation and engage and disengage the clutch to check freedom of operation.
- (9) Reinstall fiberglass seat deck (Para. 8-8.D).

11-4 JACKSTRUT AND DRIVER PULLEY ASSEMBLY

A. Removal – Jackstrut and Driver Pulley

NOTE: Refer to Fig. 11-6 for numbered items.

- (1) Remove wraparound cowl and baggage compartment (Para. 8-11.A).
- (2) Remove four bolts (20) and (23) connecting upper end of jackstrut (11) to bearing housing assembly (17).

NOTE: Keep shims (16) together. Temporarily install a screwdriver through bearing housing and jackstrut to keep the strut from falling and cocking the bearing in lower drive pulley.

- (3) Cut safety wire and remove the six bolts (10) from the driver pulley (2).
- (4) Carefully pull driver pulley (2) and strut assembly (11) from the mount flange end and lift free of the belt.

NOTE: Keep shims (1) together. Shims (1) and (16) must be kept for reinstallation as they are required to properly align the drive pulley to the driven pulley.

CAUTION: Exercise care not to cock the self-aligning bearing (5) in the pulley (2) by letting the jackstrut (11) deflect. If bearing should get cocked, don't force it straight. Slowly rotate the pulley until it aligns itself.

B. Disassembly – Jackstrut and Driver Pulley

NOTE: Refer to Fig. 11-6 for numbered items.

- (1) Remove grease fitting (14) and relief valve (15) from driver pulley (2).
- (2) Place pulley (2) face down on work bench with jackstrut (11) extended horizontally. Place blocks beneath strut to keep it from cocking the self-aligning bearing.

NOTE: A suggested method for heating the bearing housing is to use a fabricated oven of cinder blocks or bricks. Suspend the pulley such that the jackstrut is 2 or 3 inches from the floor. Then use a heat gun or torpedo heater and heat the assembly until the jackstrut assembly drops out of the pulley.

NOTE: Do not use blunt force, i.e., hammer, on the pulley flange surface when removing or installing the pulley.

- (3) Heat pulley to approximately 250°F/121°C and, using a soft mallet, gently tap the jackstrut on lower side to remove strut and bearing assembly from pulley.
- (4) Remove nut (3) and washer (4) from strut.
- (5) Remove washer (12) and bolt (13) from bore.
- (6) Place seal retainer (8) in press and press strut through bearing (5), seal (6) and spacer (6A), and retainer.
- (7) Press inner race of seal (6A) from retainer (8) and remove O-ring (7).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

C. Cleaning – Jackstrut and Driver Pulley

- (1) The pulley, washers, seal retainer and jackstrut should be washed in a cleaning solvent before inspection.
- (2) The seal (6) and spacer (6A) should be cleaned with a damp, lint-free cloth.
- (3) Clean bearing (5) in accordance with Para. 11-7.1.B.

D. Inspection – Jackstrut and Driver Pulley

- (1) See Table 11-1 for detailed inspection requirements of the jackstrut and driver pulley assembly.

E. Assembly – Jackstrut and Driver Pulley (Fig. 11-6)

NOTE: Refer to Fig. 11-6 for numbered items.

NOTE: The seal, shim, and spacer are supplied as an assembly due to the spacer being critical to the fit of the assembly. Contact customer support if the clearance between the seal and the spacer needs to be measured or adjusted.

- (1) Apply grease (MIL-PRF-81322) to O.D. of spacer (6A) and press seal into retainer (8) with conical side of spacer facing forward.
- (2) Install O-ring (7) on seal retainer (8).
- (3) Install seal retainer (8) on jackstrut (11).
- (4) Apply grease (MIL-PRF-81322) to I.D. of male half of seal (6) and with conical side facing aft, install seal on jackstrut (11).
- (5) Apply grease (MIL-PRF-81322) to I.D. of bearing (5) and press on jackstrut (11).
- (6) Install washer (12) on bolt (13) and position in bore of jackstrut with bolt extending through bearing (5).
- (7) Install washer (4) on bolt (13) with undercut side of washer mounted in bearing bore (5).
- (8) Install nut (3) and torque to 300 in-lb/33.9 Nm.
- (9) Heat driver pulley (2) to approximately 250°F/121°C.
- (10) Lubricate bore of pulley and O.D. of bearing (5) with grease (MIL-PRF-81322) or equivalent.
- (11) While holding jackstrut, visually align bearing (5) with pulley bore and drop into place.

CAUTION: Do not hammer or force bearing into pulley as serious damage could result to pulley and bearing. If bearing stops while only partially into bore, remove by gently tapping up on bottom side of jackstrut and repeat steps 9, 10 and 11.

- (12) Install washers (9) onto bolts (10) and lubricate bolt shanks with grease (MIL-PRF-81322).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (13) Align holes in seal retainer (8) with bolt holes in pulley and install bolts (10).

CAUTION: Exercise care not to cock the self-aligning bearing during handling.

- (14) Install grease fitting (14) and relief valve (15) in driver pulley (2). Torque 40-44 in-lb/4.5-5.0 Nm.

NOTE: The grease fitting hole has a small diameter hole at base extending to the bottom of the bearing bore. The relief valve hole has an equal diameter hole extending to one-half depth of the bearing bore.

CAUTION: Exercise care not to cock the self-aligning bearing during handling.

F. Installation – Jackstrut and Driver Pulley (Fig. 11-6)

NOTE: Refer to Fig. 11-6 for numbered items.

NOTE: To prevent pulley misalignment, the original shims (1) and (16) must be used on reinstallation.

NOTE: Shim (1) is designed with one of the six holes larger for proper locating onto the engine crankshaft.

NOTE: There is a 0.125 shim between the engine flywheel and fan that always stays in place. Only shim between the fan and pulley for pulley alignment.

CAUTION: Do not install an extra shim between the crankshaft and the engine flywheel.

- (1) Install shims (1) on engine crankshaft between fan and pulley (2).

- (2) Carefully install driver pulley (2) on crankshaft flange while aligning belt and secure with bolts (10) as follows:

NOTE: The pulley may only be installed on the crankshaft flange in one position as one bushing is larger than the other.

NOTE: Temporarily install screwdriver or alignment aid through jackstrut upper bearing housing (17) and jackstrut (11) to keep bearing from cocking.

- (a) Install pulley (2) with 2 bolts (10) 180° apart. Torque (50 ft-lb/67.8 Nm).
- (b) Install screwdriver or alignment aid through upper jackstrut (11) and shims (16) and hold together with c-clamp or vise grip. Check alignment and change shimming as required. Pulley must be engaged while checking alignment.
- (c) After alignment is acceptable, install remaining bolts (10) and torque (50 ft-lb/67.8 Nm) in cross pattern.
- (d) Install 2 bolts (20), (23) through upper jack strut and main rotor gearbox.
- (e) Safety wire bolts in pairs using .041 wire.

NOTE: Do not safety across the relief valve (15).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (3) Install shims (16) between jackstrut (11) and jackstrut upper bearing housing assembly (17).
- (4) Install four bolts (20) and (23) and washers (19) and (22) through jackstrut (11) and jackstrut upper bearing housing assembly (17).
- (5) Install nuts (18) and (21) and torque.
 - (a) Bolt (20) and nut (18): 50-70 in-lb/5.6-7.9 Nm.
 - (b) Bolt (23) and nut (21): 160-190 in-lb/18.1-21.5 Nm.
- (6) Remove relief valve (15) and lubricate driver pulley bearing (5) until grease appears through relief valve hole. See Table 4-1 for proper grease.
- (7) Install relief valve (15) in driver pulley. Torque 40-44 in-lb/4.5-5.0 Nm.


G. Pulley Alignment Procedure

NOTE: If main rotor gearbox, engine, pulleys, or shims have been changed, it is required to check upper and lower pulley alignment using tool T-0044. Adjustments are made with engine off.

- (1) Engage clutch and place tool T-0044 against aft face of upper or lower pulley. Pulleys should be parallel with a maximum gap of .010 inch or less between tool and second pulley.
- (2) If pulleys are parallel but have a gap exceeding .020 inch, the shims (1) between fan and lower pulley must be changed. Add shims to bring lower pulley aft and remove shims to move pulley forward. Repeat this step until parallel gap is in tolerance.
- (3) If pulleys are not parallel, add or subtract shims (16) between jackstrut upper bearing housing assembly (17) and jackstrut (11). Adding shims brings lower face of pulley towards engine and subtracting shims brings face aft.

NOTE: If shims have been changed, belt adjustment must be checked (Para. 11-1.A) and the belt track needs to be checked (Para. 11-5.B).

- (4) Install baggage compartment (Para. 8-11.D) and wraparound cowl.



- | | | | |
|-------|--------------------|-----|--------------------------|
| 1. | Shim | 12. | Washer |
| 2. | Driver Pulley | 13. | Bolt |
| 3. | Nut | 14. | Grease Fitting |
| 4. | Washer | 15. | Relief Valve |
| 5. | Bearing | 16. | Shim |
| 6/6A. | Seal and Spacer | 17. | Bearing Housing Assembly |
| 6B. | Shim, if equipped | 18. | Nut |
| 7. | O-Ring | 19. | Washer |
| 8. | Bearing Retainer | 20. | Bolt |
| 9. | Washer | 21. | Nut |
| 10. | Bolt | 22. | Washer |
| 11. | Jackstrut Assembly | 23. | Bolt |

Figure 11-6. Jackstrut Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-1. Inspection Requirements – Jackstrut and Pulley Assembly

Part Number	Fig. 11-6 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13273-1, -13	2	Driver Pulley	(-1) Bearing Bore Dia. 3.3447 to 3.3453	+ .0008	Not Repairable	Replace Pulley
			(-13) Bearing Bore Dia. 3.3447 to 3.3459	+ .0008	Not Repairable	Replace Pulley
			Cracks	None Allowed	Not Repairable	Replace Pulley
			Nicks, scratches, or corrosion	.030 deep	≤ .030 deep	Polish and blend out smooth
			Depth of grooves	≤ .176	Not Repairable	Replace Pulley
			Nicks and gouges in belt grooves	None Allowed	≤ .25 long and ≤ .025 deep	Polish and blend out smooth
			Concentricity	.001 TIR	Not Repairable	Replace Pulley
Threaded Holes	No crossed or missing threads	Not Repairable	Replace Pulley			
28-13210-13	4	Washer	Visual check for defects			Replace if required
ECD020	5	Bearing	O.D. 3.3459 to 3.3465	None Allowed	Not Repairable	Replace Bearing
			I.D. 1.7712 to 1.7717	None Allowed	Not Repairable	Replace Bearing
			Axial play	None Allowed	Not Repairable	Replace Bearing
28-13319	6, 6A	Seal	Outer race on O.D. for galling	None Allowed	Not Repairable	Replace Seal
			Condition of Teflon, race and O-ring (no cuts or scratches)	None Allowed	Not Repairable	Replace Seal
			Spherical steel portion of seal (no scratches)	None Allowed	Not Repairable	Replace Seal

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-19

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-1. Inspection Requirements – Jackstrut and Pulley Assembly

Part Number	Fig. 11-6 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13305	8	Bearing Retainer	Seal bore dia. 3.065 to 3.069	-.005	Not Repairable	Replace Retainer
			Cracks	None Allowed	Not Repairable	Replace Retainer
28-13227-5	11	Jackstrut	Bearing surface dia. 1.7715 to 1.7721	-.0003	Not Repairable	Replace Strut
			Inspect bond for security around strut	If bond appears loose, insert .032 safety wire into loose area. Maximum depth wire can be inserted is 0.75.	In excess of .75 looseness	Replace Strut
			Dents in strut tubing	Dia. ≤ .50 and ≤ .0625 deep, maximum of one dent	Not Repairable	Replace Strut
28-13212	12	Washer	Corrosion	None Allowed	Not exceeding 15% of surface	Remove corrosion and touch up with brush-on cad plate

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-20

Rev. 13
Jan 5/24

11-5 DRIVE BELT

A. General Information and Troubleshooting

The drive belt is a one piece synthetic rubber Poly-V belt with a series of parallel V-ribs molded lengthwise around the inside circumference with Kevlar tension cords that makes it extremely strong, stable, and fail safe. The Kevlar cord runs in a continuous fashion around the circumference of the belt and is imbedded in a fiber reinforced rubber compound backed by 3 ply fabric for maximum cord support and adhesion. The rubber compound is both heat and oil resistant and is also used to form the rubber ribs. This composite construction holds the belt in position to make the gripping force on the pulleys to transmit the torque. The belt diameter, width, and number of grooves are all computed for stress in relation to the amount of horsepower required. Once the clutch engaged, the belt is under a constant static tension of 1400 pounds/635 kg.

Refer to the following table for troubleshooting.

Problem	Possible Cause	Action
Cuts, damage, or blisters on back of belt.	Possible separation of fabric plies.	Remove belt and inspect. Replace if plies are peeling or separating.
Fraying on edge of belt.	Belt out of track rubbing idler straps. Interference problem in belt alignment.	Track belt (Para. 11-5.B). Check upper and lower pulley alignment, idler straps, and belt track.
Pieces of rib section missing.	Rib cracking.	See Belt Inspection (Para. 11-5.D).
Belt vibration.	Large pieces of belt missing causing dynamic unbalance (Fig. 11-8.1, D, E). Belt roller improperly adjusted	Replace belt. Adjust roller to belt.
<p>NOTE: With engine off, engage clutch and check for proper rigging. Adjust belt roller to 0.38 inch/9.5 mm clearance between roller and belt before tracking belt.</p>		

B. Tracking – Drive Belt

- (1) Remove upper cowling.

NOTE: Refer to Fig. 11-7 for location and sequence of locking points used during belt tracking.

Point 1 - Belt mounting support shaft strap to pylon.

Point 2 - Nut on forward end of idler shaft.

Point 3 - Nut on aft end of idler shaft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Decrease the torque on the bolt and nuts at Points 1 through 3. The bolts and nuts at points 2 and 3 should be snug enough that they require force to turn but not be "loose." Point 1 must be loose enough to allow the idler stabilizer strut to slide as the idler support shaft is turned.
- (3) Rotate the idler support shaft using a wrench so that Point 3 is at the highest position. Then rotate the shaft approximately 75° towards the right side of the aircraft (clockwise looking forward) before starting the engine and engaging the belt drive system.

WARNING: USE CAUTION WHEN ADJUSTING THE IDLER PULLEY TRACK WITH THE ENGINE RUNNING AND THE BELT DRIVE SYSTEM ENGAGED.

- (4) Start engine and slowly engage rotor system while observing idler pulley track on belt. During engagement, use a 7/8" wrench to rotate the idler shaft as necessary to keep the belt aligned.
- (5) When clutch is fully engaged at idle, use 7/8" wrench and turn idler support shaft until the belt is centered on the pulley and between the actuator arm assemblies.

NOTE: When pulley is tracked it will be centered on belt.

- (6) When pulley is centered, tighten bolt at pylon strap (Point 1).
- (7) Holding idler support shaft with wrench, tighten forward idler shaft nut (Point 2) (50-65 ft-lb/68-88 Nm).
- (8) While holding idler shaft, tighten aft nut (Point 3) (24-34 ft-lb/33-46 Nm).
- (9) Increase engine to 2000 rpm and check track.
- (10) If belt track is good at 2000 rpm, gradually increase to 3050 rpm while constantly watching belt track under increased power.
- (11) Observe the belt "snubber" roller. While running the engine at 3050 rpm, there should be approximately 0.38 inch/9.5 mm clearance between the belt surface and the roller.

NOTE: If vibration is felt upon engaging the clutch, check that the clearance between with the belt is at least 0.38 inch/9.5 mm.

WARNING: SHUT DOWN THE ENGINE BEFORE MAKING ANY ADJUSTMENTS TO THE BELT ROLLER.

- (a) If roller adjustment is required, disengage clutch, and shut off the engine.
- (b) Engage clutch and adjust the belt "snubber" roller so that it is parallel to the belt surface and has 0.25-0.38 inch/6.4-9.5 mm clearance between the belt surface and the roller.
- (c) After final adjustment of the idler pulley track, loosen the aft nut on the "snubber" roller and allow the roller to self-align on the idler straps. Torque the aft nut to 95-110 in-lb/10.8-12.5 Nm.
- (d) Disengage clutch.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

WARNING: EXTREME CAUTION SHOULD BE USED WHEN BELT TENSION MECHANISM IS IN ENGAGED POSITION. PERSONAL INJURY COULD OCCUR.

(e) Start engine, engage rotor system, and verify that the belt "snubber" roller clearance (0.38 inch/9.5 mm) is correct.

(12) Inspect assembly for security before installing cowling.




Figure 11-7. Idler Stabilizer and Belt Tracking Adjustment Points

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

C. Removal – Drive Belt

- (1) Remove cowling.
- (2) Remove jackstrut and driver pulley assembly (Para. 11-4).
- (3) Disconnect the flex coupling (Fig. 11-9) as follows:
 - (a) Remove the bolts (5), washers (6), beveled washers (2), and nuts (7) connecting aft hub (1) of coupling to flex element (3).
- (4) Loosen aft nut (14) on belt roller (11) (Fig. 11-14).
- (5) Remove hardware attaching aft actuator arm (10) to idler yoke assembly (8) and idler yoke end (15). Let the actuator arm assembly hang in a vertical position on the belt roller (11).
- (6) Remove bolts from the forward drive shaft three bearing assembly mounts to avoid bending the shaft. Push the drive shaft to one side to clear the pulley and then secure with safety wire.

NOTE: Mark location of bearing assemblies before removal.

NOTE: Use care to avoid causing a bend or bow in the driveshaft.

NOTE: The F-28F models may be equipped with a strobe mounted over the drive shaft. Remove the strobe mount, if installed.
- (7) Ease the belt off of the top pulley and, with drive shaft to one side, slide the belt between the coupling halves to remove.

D. Inspection – Drive Belt

NOTE: Drive belt conditions that could be identified during an inspection are described as follows.

Rib cracking is a normal occurrence on this belt. The cracks normally extend to the base of the rib and go no further. Numerous cracks of this type are not significant. The belt should be examined for cracks which have extended below the base of the ribs and, if this has occurred, the belt should be removed. This is very important if the cracks extend to the cord line and the cord is exposed when the crack is opened. Loss of small pieces or rib section may accompany the rib cracking. This is normally a random occurrence. The belt should be replaced if there is a loss of three or more adjacent ribs for a length of two inches or more. The belt should be replaced if there is any piece of rib missing which is of sufficient depth to leave the cord exposed. A missing belt rib piece can eventually cause the belt to slip. Usually, the belt will cause vibrations because it becomes unbalanced, and these vibrations are noticed a long time before the belt starts to slip.


ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

The back of the belt should be examined for cuts or damage and blisters which may indicate separation of the fabric plies. The belt should be replaced if there is any damage which appears to penetrate the fabric cover or if any blisters are present. A small crack in the back of the belt at the fabric splice is not significant, and often this is the fabric overlap created during manufacture of the belt. The belt should be replaced, however, if there is any loosening or peeling of the fabric in the splice area. The backing will take a long time to peel and, if this happens, it will cause vibrations, make a mess, and probably cause a "burning rubber" odor. The vibrations and the flapping backing material might damage some of the surrounding parts but normally not to the point where they will fail. This will also happen a long time before the belt fails completely.

The edge of the belt should be examined for emerging cord, cord damage or damage that extends beyond the first "V" groove. Also, the belt edge should be examined for signs of rubber separation. The belt should be replaced if there is any sign of emerging cord, cord damage, damage beyond the first "V" groove, or rubber separation from the cord. If any of these conditions are present, the cord can get torn and pulled out at the sides. When this happens, the belt will start to "unwind." The cord will normally break before it unwinds very far, the pilot will smell "burning rubber" and a vibration will be felt. A pilot will normally have ample time to make a precautionary landing. This is the most serious of the possible failure modes. The belt is 6 inches (15 cm) wide. Tests performed at the factory have proven that 1.5 inches (3.5 cm) is more than enough to fly the helicopter at full power.

Perform an as-installed belt inspection with cowling removed and the clutch disengaged. Slowly rotate the belt around the diameter of the upper pulley by placing a hand flat against the belt surface, as shown in Fig. 11-8 – *Proper Method*.

WARNING: DO NOT GRIP EDGE OF BELT TO ROTATE (Fig. 11-8 – *Improper Method*). GRIPPING THE EDGE MAY RESULT IN FINGERS BEING PINCHED IN BOTTOM PULLEY, CAUSING SERIOUS INJURY.



Proper Method –
Hand flat against belt surface



Improper Method –
DO NOT grip edge of belt

Figure 11-8. Belt Inspection – Safe and Unsafe Methods

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(1) Belt Rib Surface:

- (a) Examine the belt for cracks which have extended below the base of the ribs. If this has occurred, and the cords are exposed, the belt should be removed. Examples of rib cracks are depicted in Fig. 11-8.1. Photographs A, B, and C are examples of serviceable belts.

- 1 Replace the belt if rib cracks extend below the base of the ribs.
- 2 Replace the belt if it has been determined that cord failure exists.

- (b) Examine the belt for loss of small pieces of rib section that may accompany the rib cracking. Examples of loss of pieces of rib section are depicted in Fig. 11-8.1. Photographs D, E, and F are examples of unserviceable belts which should be replaced.

- 1 Replace the belt if there is a loss of three or more adjacent ribs for a length of two inches or more.
- 2 Replace the belt if there is any piece of rib missing which is of sufficient depth to leave the cord exposed.
- 3 Replace the belt when missing pieces of the "V" area becomes large enough to cause vibration in the drive system.
- 4 Replace the belt if it has been determined that cord failure exists.

(2) Back of Belt:

- (a) Examine the back of the belt for cuts or damage and blisters. Replace the belt if there is any damage which appears to penetrate the fabric cover or if any blisters are present.
- (b) Examine the back of the belt for a crack at the fabric splice. The belt should be removed if there is any loosening or peeling of the fabric in the splice areas. Examples of fabric splices are depicted in Fig. 11-8.2. Photograph G and Photograph H are examples of a serviceable belt. Photograph I is an example of an unserviceable belt.

(3) Edges of Belt:

- (a) Examine the edge of the belt for signs of wear. This does not affect the belt directly but would indicate that there is a tracking or interference problem. An example of light wear (cord fraying) is depicted in Fig. 11-8.3. Examples where the belt comes into close contact with adjacent structures, such as the lower pulley assembly is depicted in Fig. 11-8.4.
- 1 Replace the belt whenever the operator deems it necessary.
 - 2 The presence of rubber residue at the forward and aft edges of the center pulley may indicate interference and breakdown of the belt. Check belt tracking (Para. 11-5.B).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Examine the forward and aft side belt edges for adhesive-sealed edges and signs of separation or deterioration. Examples of sealed belt edges are depicted in Fig. 11-8.5. Examples of deteriorated sealed belt edges are depicted in Fig. 11-8.6.
- 1 If the belt edge was previously sealed but the belt edge has deteriorated as shown in Fig. 11-8.6 (damage goes beyond the first “V” groove) or if any loose or protruding cords are found, remove the belt, and send back to Enstrom for warranty.
 - 2 If the belt edge was previously sealed but portions of adhesive are missing, repair the belt in accordance with Para. 11-5.D.1. Continue the belt inspection requirements as follows before proceeding with repairs.
- (c) Examine the forward and aft side belt edges for exposed or loose cord. An example of exposed cord is depicted in Fig. 11-8.7. Exposed cord limits are explained in the figure.
- 1 Replace the belt if it has been determined that cord failure exists.
 - 2 Remove the belt if any portion of exposed cord is greater than 40% of the cross section thickness. Seal those portions of exposed cord in accordance with Para. 11-5, D.1 and return the belt to service.
- (d) Examine the belt edge for a cord tail. An example of a cord tail is depicted in Fig. 11-8.9.
- 1 Remove the belt if it has cord tail. Trim the cord tail, repair the belt in accordance with Para. 11-5.D.1, and return the belt to service.


D.1 Repair – Drive Belt

- (1) Authorized materials used in the procedure to seal the belt edge are listed as follows:

Denatured alcohol (solvent)
3M 847 Nitrile High Performance Rubber and Gasket Adhesive
Clean shop cloths

- (2) Surface preparation:
- (a) Clean the belt surface using a cloth wetted with solvent.
 - (b) Trim loose fabric threads on fabric backing only.
- (3) Adhesive application:
- (a) Prepare the 3M 847 adhesive in accordance with the manufacturer’s instructions.
 - (b) Apply a bead of 3M 847 on the belt edge surface ensuring the exposed Kevlar cord is covered with adhesive.
 - (c) Remove any adhesive from the rib edge and the back of belt using a clean cloth wetted with solvent.


ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



A through C – Serviceable

D through F - Unserviceable


Figure 11-8.1 Drive Belt Visual Inspection – Ribs



G - Serviceable



H - Serviceable, Monitor Every 50 Hours



I - Unserviceable

Figure 11-8.2 Drive Belt Visual Inspection – Fabric Back




Figure 11-8.3 Drive Belt Visual Inspection – Edge Cord Fraying



Inspection point – Center pulley, forward edge



Inspection point – Center pulley, aft edge

Figure 11-8.4 Adjacent Structure Inspection for Belt Residue





Figure 11-8.5 Drive Belt Visual Inspection – Sealed Belt Edges



NOTE: Enstrom Turbine Model Drive System Shown

Figure 11-8.6 Drive Belt Visual Inspection – Deteriorated Sealed Belt Edges




Figure 11-8.7 Drive Belt Visual Inspection – Exposed Cord




Figure 11-8.8 Drive Belt Visual Inspection – Exposed Cord Limit Criteria



Figure 11-8.9. Drive Belt Visual Inspection – Cord Tail

CAUTION: Failure to remove excess adhesive from the rib edge or from the back of belt may impair smooth belt operation.

- (d) Allow the adhesive to dry for three hours, turn over and repeat the application for the edge on the other side of the belt.
- (e) Hang the belt on a rack and allow the adhesive to cure for a minimum 12 hours.

NOTE: Finished sealed belt edge surface will appear similar to the sealed edge surface depicted in Fig. 11-8.5 (photograph on the left).

E. Installation – Drive Belt


NOTE: Refer to Fig. 11-14 for numbered items unless stated otherwise.

- (1) Slide the belt between the drive shaft and forward coupling half and ease belt on top of the upper pulley.
- (2) Pivot aft actuator arm assembly (10) back into position.
- (3) Install bolts (19) and (20), washers (21) and (22), and nut (23). Torque (12-15 in-lb/1.4-1.7 Nm) and safety (.032).
- (4) Install bolt (24), washer (25), bushing (9) from the inside of the actuator arm assembly (10). Install the aft washer (25) and the nut (27). Torque nut (50-70 in-lb/5.6-7.9 Nm) and install cotter pin (28).
- (5) Ensure nut (14) torque (95-110 in-lb/10.7-12.4 Nm).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Return the drive shaft pillow blocks to the original position and install bolts. Use the same shims as originally installed under the block. Torque bolts (20-25 in-lb/2.3-2.8 Nm).
- (7) Flex Coupling – Proceed as follows: (see Fig. 11-9)
 - (a) Align aft coupling hub (1) with flex element (3). With curved side of flex coupling washers (2) against flex element, install mounting hardware.

NOTE: Washers (6) may be used between the flex coupling washers (2) and coupling hub flanges (8) to align and center the flex elements.
 - (b) Torque the coupling hub bolts (50-70 in-lb/5.6-7.9 Nm).
- (8) Install jackstrut and pulley assembly (Para. 11-4).
- (9) Engage clutch and check rigging (Para. 11-1).
- (10) Check belt roller clearance (0.38 inch/9.5 mm) between belt surface and roller.
- (11) Track drive belt (Para. 11-5.B).
- (12) Inspect entire belt drive system (Para. 11-1.A; Para. 11-8.2; Para. 11-9.E).
- (13) Install cowling.



→ | ← THESE AREAS REQUIRE SHIMMING TO EQUALLY SPACE FLEX ELEMENTS

- | | | | |
|----|--------------------------------|----|------------|
| 1. | Pinion Shaft | 5. | Bolt |
| 2. | Flex Coupling Washer (Beveled) | 6. | Washer |
| 3. | Flex Pack | 7. | Nut |
| 4. | Aft Hub | 8. | Hub Flange |

Figure 11-9. Flex Coupling Installation

11-6 MAIN ROTOR TRANSMISSION

A. General Description

The main rotor transmission (gearbox) is a 90° drive unit powered from the engine by a belt drive system. The internal ring gear and pinion are machined to precision tolerances, heat treated, and shot peened to provide maximum life. Because of the high contact ratio which can be obtained by the spiral angle gear, the overlap of contact contributes to smooth and quiet operation. A wet sump splash system is utilized to provide adequate lubrication to the ring and pinion gears. This eliminates the need for a gear-driven oil pump. A magnetic chip detector is located in the sump, and can be removed to inspect for metallic particles. (Note: The chip detector was not standard for early F-28F helicopter transmissions.) An oil temperature probe is mounted either in the bottom of the gearbox or at the bottom of the pinion case of older transmissions. The probe is connected to a transmission temperature gauge on the instrument panel. Also, a sight gauge is located on the right rear side of the gearbox to check the oil level. The gearbox incorporates an overrunning clutch in the upper pulley assembly which is mounted on the pinion shaft. The overrunning clutch unit provides a disconnect from the engine in the event of a power failure and permits the main and tail rotors to rotate to accomplish safe autorotative landings.

B. Removal – Main Rotor Transmission

NOTE: If the rotor hub is to be removed, it is recommended to break the mast nut torque before removing the main rotor blades (use tool T-0197-7 or digital torque multiplier ATP761).

- (1) Remove the main rotor blades (Para. 9-8).
- (2) Drain fuel and remove the fuel tanks (Para. 13-10).
- (3) Remove the wraparound cowling.
- (4) Remove the bulkhead that crosses over the gearbox pinion area.
- (5) Remove baggage box (Para. 8-11).
- (6) Disconnect the lateral and longitudinal push-pull rods from the lower swashplate (Para. 12-10.A.4 and A.5).
- (7) Remove the fiberglass cover above the seat deck inside the cabin and disconnect the collective push-pull rod from the collective walking beam (Para. 12-11.A.4).
- (8) Disconnect the following:
 - (a) Temperature probe adapter from the fitting on bottom of gearbox.
 - (b) Chip detector.
 - (c) Low rotor warning magnetic pick-up.
- (9) Remove jackstrut and pulley (Para. 11-4).
- (10) Remove the idler assembly with the drive belt as follows:

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (a) Remove bolt (41) and hardware to disconnect rod end (38) from the bellcrank (Fig. 11-14).
- (b) Remove nut (63) and washer (64) from shaft (62) (Fig. 11-16).
- (c) Remove bolt (51) and washer (51) to disconnect idler stabilizer strut (49) from the brace assembly (57) (Fig. 11-16).

NOTE: Index the shaft (62) to the main rotor transmission before removal to aid in tracking the belt on reassembly.

NOTE: It may be necessary to rotate the shaft (62) while withdrawing the assembly from the transmission so the idler yoke clears the pylon brace assembly (57).

- (d) Remove the idler pulley assembly with shaft (62) and drive belt.

NOTE: The gearbox can be removed by leaving mast nut loosely secured and lifting hub and gearbox as a unit using sling T-0011.

NOTE: If it is preferred to remove the main rotor hub, refer to Para. 9-2.A for hub removal procedures. Tool T-0017 is necessary if this method is used.

- (10) Remove mount bolts from the gearbox (4 places).

NOTE: A 7/16" wrench (12 point) will have to be ground thinner for installation on the aft left gearbox mount bolt.

- (11) Using a hoist, carefully lift gearbox from pylon mount.

NOTE: For swashplate removal see Section 12, Flight Controls.

NOTE: Gearboxes being returned for overhaul should include the pinion half of the driveshaft coupling, the bearing adapter (2), and the nut (1) (Fig. 11-10). The nut should be torqued against a spacer to protect the gears during shipping.

C. Seal Replacement – Main Rotor Transmission

NOTE: This procedure can be accomplished with the transmission installed.

- (1) Upper mast seal replacement:

- (a) Remove the main rotor hub (Para. 9-2.A).
- (b) Remove the slinger from the mast.
- (c) Remove the seal from the transmission housing.

NOTE: Wrap a piece of shim stock around the upper portion of the mast to protect the seal from damage during installation. Reposition the shim stock to the lower end of the mast when installing the seal into the transmission housing.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (d) Lubricate the lip of the new seal (MIL-PRF-81322). Install the seal into the transmission housing. Tap the seal into the housing, as required, to seat the seal.
- (e) Install the slinger into position and secure in place using RTV-732 sealant, or equivalent general purpose silicone adhesive.
- (f) Install the main rotor hub (Para. 9-2.E).

(2) Pinion seal replacement:

NOTE: This procedure can be accomplished with the transmission installed.

- (a) Remove the upper pulley assembly (Para. 11-7.C).
- (b) Raise the aircraft using the ground handling wheels. Block the aft end of the skid tubes so the aircraft will not rock back onto the tail rotor guard.

NOTE: Later production transmissions incorporate a seal retainer with a retaining ring to secure the pinion seal. Transmissions returned to Enstrom for overhaul/repair will have the new seal retainer incorporated. If the gearbox does not have the seal installed from the aft side with the retainer ring, contact Enstrom Customer Support.

- (c) Remove the retaining ring and pinion seal from the seal retainer.

NOTE: Wrap a piece of shim stock around the bearing adapter in the pinion assembly to protect the seal from damage during installation.

- (d) Lubricate the lip of the new seal (MIL-PRF-81322). Install the seal onto the pinion shaft and install the seal into the seal retainer. Tap the seal in the retainer, as required, to seat the seal.
- (e) Reinstall retaining ring.
- (f) Install the upper pulley assembly (Para. 11-7.H).

(3) Lower mast seal replacement:

NOTE: It is necessary to remove the main rotor transmission from the aircraft to replace the lower mast seals. It is not necessary to remove the hub from the transmission.

- (a) Remove the transmission (Para. 11-6.B).

CAUTION: Use extreme care when removing the nuts that secure the seal retainer. The transmission will have to be returned for repair if any of the retaining bolts are pushed into the transmission.

CAUTION: Use extreme care when removing the seal retainer from the bottom of the transmission. If the shim(s) located between the seal retainer and spacer are damaged, they must be replaced with the correct thickness of shims.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: When ordering a replacement, note that the seal and seal retainer must be ordered as a complete assembly and will include a set of shims. (Ref. P/N 28-13122-991)

WARNING: USE EXTREME CAUTION WHEN HANDLING HEATED PARTS TO PREVENT FROM INJURING PERSONNEL. USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.

- (b) Disconnect the upper walking beams from the control rods (Para. 12-11.A.10).
- (c) Remove walking beam from the pivot straps (Para. 12-11.A.5).
- (d) Remove bolts that secure the upper swashplate to the gearbox (Para. 12-11.A.12) and withdraw the upper and lower swashplate as an assembly with control rods and walking beam attached.
- (e) Remove the nuts securing the seal retainer.
- (f) Heat the seal retainer to weaken the adhesive bond and use a wedge-type tool to pry off the retainer with the old seals from the transmission housing.
- (g) Lubricate the lips of the new seals and pack the area between the two seal lips with grease (MIL-PRF-81322). Apply a bead of sealant (Loctite 587, or equivalent) to the seal retainer flange.
- (h) Replace any damaged shims with new shims.

NOTE: Wrap a piece of shim stock around the mast retaining nut to protect the seal from damage during installation.

- (i) Paint the mating surfaces of the transmission spacer and the seal retainer with Loctite SI 5900, or equivalent.
- (j) Install the seal retainer (supplied with new seals).
- (k) Install the nuts and torque in a crossing pattern (50-70 in-lb/5.6-7.9 Nm).
- (l) Install the swashplate assemblies and control rod assembly (Para. 12-11.F.3), walking beam (Para. 12-11.F.7), and connect walking beams (Para. 12-11.F.9).
- (m) Install the main rotor transmission (Para. 11-6.D).

D. Installation – Main Rotor Transmission

- (1) If required, install main rotor hub on gearbox (Para. 9-2.E).

CAUTION: Hub must be installed with index marks on spline adapters aligned to properly phased spine on rotor shaft, or serious flight control problems will result.

- (2) If required, install the flight control assemblies, as applicable.

- (a) Install the swashplate assemblies and control rod assembly (Para. 12-11.F.3), walking beam (Para. 12-11.F.7), and connect walking beams (Para. 12-11.F.9).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (3) Lightly coat the top of the pylon mount pads and the shank of the mount bolts with grease (MIL-PRF-81322).
- (4) Using sling T-0011, lift gearbox into position on pylon.
- (5) Install gearbox mount hardware (4 places) including the shoulder harness support assembly cables. Torque bolts (240 in-lb/27.1 Nm).

NOTE: Install the shoulder harness support cable attachments between the washers above the nut.

NOTE: Hardware with the self-locking feature may be reused in accordance with Table 2-12.
- (6) Install idler assembly with drive belt:
 - (a) Install the idler pulley assembly (Para. 11-8.F.(3) through (5)).
 - (b) Install yoke rod end (38) (Para. 11-8.J.(2) and (3)).
- (7) Install jackstrut and pulley assembly (Para. 11-4.F).
- (8) Connect the following:
 - (a) Temperature probe adapter to fitting on bottom of gearbox.
 - (b) Chip detector.
 - (c) Low rotor warning magnetic pick-up.
- (9) Install fiberglass cover above seat deck.
- (10) Install baggage box (Para. 8-11).
- (11) Install bulkhead over gearbox pinion area.
- (12) Install fuel tanks and connect fuel lines (Para. 13-10.B.(2)).
- (13) Service main rotor transmission (Para. 4-12).
- (14) Check all connections for security.
- (15) Install main rotor blades.
- (16) Service the fuel tanks (Para. 4-4).
- (17) Track drive belt (Para. 11-5.B).
- (18) Install wraparound cowling.
- (19) Perform preliminary flight test procedure (Para. 12-13.A).
- (20) Track main rotor blades (Para. 12-2).

11-6.1 MAIN ROTOR CHIP DETECTOR

A. Removal – Chip Detector (Fig. 4-1, View E)

NOTE: Later F-28F helicopters and all 280FX helicopters are equipped with the main rotor transmission chip detection system. Refer also to Para. 4-62 for main rotor chip indication procedures.

NOTE: Do not disconnect the wire unless removing the chip plug.

WARNING: DO NOT OPERATE THE HELICOPTER WITH THE CHIP DETECTOR REMOVED AS SEVERE LUBRICATION LOSS MAY OCCUR.

- (1) Remove the access panel below the left fuel tank.
- (2) Grasp the chip detector plug and push upward.
- (3) While holding upward pressure, begin turning the plug counterclockwise.
- (4) Turn the plug counterclockwise 1/4 turn.
- (5) Pull the plug out of the socket in the base fitting.
- (6) Inspect the plug for chips (Para. 4-62.A).
- (7) After determining that the transmission is airworthy, clean the magnetic plug with a soft cloth or with a strong magnet attached to a pointed object or use compressed air. Use caution to avoid scratching the magnetic plug.

B. Installation – Chip Detector

- (1) Insert the plug into the socket in the base fitting.
- (2) Align the lugs in the plug with the slots the base fitting.
- (3) Push plug upward while turning plug clockwise (approximately 1/4 turn).
- (4) When the plug stops turning, pull downward.
- (5) Check the plug to ensure that it is locked in the base and that there is no leakage.

11-7 OVERRUNNING CLUTCH AND UPPER PULLEY ASSEMBLY

A. Troubleshooting – Clutch and Upper Pulley

Problem	Possible Cause	Required Action
Rotor and engine rpm needles do not split when power is cut back.	OVERRUNNING CLUTCH LOCKUP.	Replace clutch.
Erratic needle movement - engine tach seems to climb.	Clutch slipping. Internal clutch malfunction.	Replace clutch.
	Tach drive O-rings (belts) slipping	Clean or replace belts.
	Worn upper or lower belt pulley grooves	Replace pulley.
	Hard bend or pressure on the clutch cable by adjacent components.	Check cable routing for condition and adjust routing and/or secure as required.
	Clutch end play exceeding .050 inch.	Internal wear of clutch.
Excessive noise on run-down.	Internal wear.	Replace clutch.
Upper pulley TIR exceeding .009 inch. Check while holding pulley stationary and rotating gearbox with clutch disengaged.	Clutch faces worn from loss of pinion nut torque.	Replace clutch.
	NOTE: If excessive TIR still exists after replacing clutch, the problem could be internal wear in main rotor gearbox. Gearbox should be returned to factory or authorized overhaul facility for inspection.	
	Remove upper pulley assembly inspect the condition of the bearing adapter and clutch inner race	Contact Customer Support if galling is evident.

B. Servicing and Inspection – Clutch

CAUTION: Before servicing, determine the type of oil previously used. If unable to determine, it is recommended that the clutch be drained, purged with kerosene and then serviced per instructions. Clutches leaving the factory have been serviced with Aeroshell 560 turbine oil. See Table 4-1 for other approved oil.

(1) Refer to Para. 4-10 for servicing the overrunning clutch.

(2) Overrunning Clutch – Inspection

NOTE: A significant portion of fluid can be lost very quickly through a leaking seal. The clutch area should be looked at frequently to determine if any leaks exist.

(a) Monitor oil level (Para. 4-10).

(b) If clutch has been subjected to rapid or instantaneous rotor engagements or loss of oil is suspected, follow steps below:

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (1) Rotate the upper pulley in reverse direction by hand to check for roughness or noise. If abnormality is detected, unit should be replaced.
- (2) Maximum clutch axial play is .050 inch.
- (3) If clutch is serviceable but has a leaking seal, contact Enstrom Helicopter Customer Service.
- (4) Service clutch (Para. 4-10).
- (5) Ground run helicopter until normal operating temperatures are reached.
- (6) Increase power until the tachometer shows 350 rotor rpm. Split needles and allow rotor RPM to drop to 200. Re-engage normally and repeat a minimum of three times, observing clutch response.
- (7) If all functions are normal, inspect for leakage and proper oil level before returning helicopter to service.

C. Removal – Clutch and Upper Pulley

NOTE: While the belt can be changed with only deflecting the TR drive shaft, removal of the jack strut support bearing and the upper pulley assembly require removing the TR driveshaft to prevent bowing or bending the shaft. However, removal of the tail rotor drive shaft is not necessary if the bolts are removed from the first 3 pillow blocks (after marking position of the pillow blocks) and move shaft out of the way.

- (1) Remove cowling.
- (2) Remove jackstrut and pulley assembly (Para. 11-4.A).
- (3) Remove the hardware connecting the drive shaft flex plates from the forward and aft transmission couplings.
- (4) Separate coupling halves on forward end of drive shaft.
 - (a) Flex Couplings – Remove the two bolts connecting forward coupling hub (4) to flex element (3) (Fig. 11-9). Remove forward taper pin from coupling hub (4) and pinion. Remove coupling hub.
- (5) Remove tach drive cover and O-rings.

NOTE: The F-28F models may be equipped with a strobe mounted over the drive shaft. Remove the strobe mount, if installed.

NOTE: Use extreme care to avoid causing a bend or bow in the driveshaft. Do not allow it to bend or bow when carrying it.

NOTE: Mark the pillow block location for ease of installation.

- (6) Remove the drive shaft assembly from the helicopter and store it so that it is not bowed.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (8) Remove the drive belt (Para. 11-5.C).
- (9) Remove nut (1) using an impact wrench to break the torque.
- (10) Install tool T-0114 in the end of the pinion.
- (11) Install a two-jaw puller with jaws attaching behind face of bearing housing (8) and adjustable shaft located in end of tool T-0114 (Fig. 11-11.a). Hold jaws together with "C" clamp.
- (12) Pull the bearing housing (8) from the pinion.
- (11) Slide clutch (11) and pulley assembly (12) off pinion.

NOTE: Refer to Para. 11-6.C.(2), for pinion seal replacement procedures.

NOTE: If the clutch (11) will not slide off, install tool T-0114 back in the aft of the pinion. Place the jaws of the puller in the groove of the clutch (11) (Fig. 11-11.b). Clamp in place and pull clutch (11) and pulley assembly (12) from pinion.

- (12) Remove key (14) from pinion. If the key was shimmed on assembly, save shim.

D. Disassembly – Clutch and Pulley

NOTE: Refer to Fig. 11-10 for numbered items.

(1) Clutch and Pulley – Disassembly

- (a) Remove nuts (13) from bolts (9).
- (b) Remove bolts (9) and washers (10).

NOTE: Remove one of the servicing bolts in the clutch to allow clutch oil to seep from hole. Heat expansion causing internal pressure could cause damage to seal if bolt is not removed. Allow clutch and pulley to cool before servicing.

- (c) Heat pulley (12) to approximately 250°F/121°C and remove clutch (11).
- (d) Clean and inspect components.

E. Cleaning – Clutch and Pulley

- (1) Clutch – If clutch is determined serviceable, wash O.D. with kerosene, toluol or equivalent cleaning solvent. Avoid using excessive solvent in seal area. DO NOT vapor degrease clutch as damage could result to seal.

F. Inspection – Clutch and Pulley

- (1) See Table 11-2 for detailed inspection requirements of the clutch and pulley assembly.

G. Assembly – Clutch and Pulley

NOTE: Refer to Fig. 11-10 for numbered items.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Remove one of the servicing bolts in the clutch to allow clutch oil to seep from hole. Heat expansion causing internal pressure could cause damage to seal if bolt is not removed. Allow clutch and pulley to cool before servicing.

- (1) Heat pulley (12) to approximately 250°F/121°C.
- (2) Apply grease (MIL-PRF-81322) to the bore of the pulley. Using two bolts (9) for alignment, drop clutch (11) into pulley (12).
- (3) Install servicing bolt back into clutch and service clutch (Para. 4-10).
- (4) Install bolts (9) through washers (10) and through clutch (11) and pulley (12).
- (5) Install washers (10) and nuts (13) on bolts.
- (6) Torque nuts (13) (60-85 in-lb/6.8-9.6 Nm), alternating sides during torque process.
- (7) Service clutch (Para. 4-10).

H. Installation – Clutch and Pulley

NOTE: Refer to Fig. 11-10 for numbered items.

- (1) Before installing key (14) into pinion, check to see that the key slides freely through the keyway in the clutch. If it does not slide through, the key must be filed slightly on one side to allow proper fit. A clearance of 0.0005 inch to 0.001 inch between key and clutch keyway is required. If the key is loose in the pinion keyway, proceed to (a) through (e) below.
 - (a) Install key (14) in pinion and using a feeler gauge, measure the gap between the side of the key and the pinion keyway.
 - (b) Divide the measurement in half to get the thickness of the stainless steel shim stock required.
 - (c) Cut a shim 2 in/51 mm long and 1 1/4 in/32 mm wide.
 - (d) Wrap the shim around the key and, with the chamfered side of the key down, tap the key and shim into the pinion keyway.
 - (e) Using a razor knife, trim the shim stock along the sides of key flush with the pinion. The key must be secure in the pinion.

NOTE: Do not allow grease to contaminate the races between the MRGB and the clutch, and the clutch and upper jackstrut bearing. Remove any grease from the forward side of the bearing housing assembly (7).

- (2) Apply grease (MIL-PRF-81322) to the bore of the clutch (11) and slide clutch and pulley assembly (12) on the pinion.
- (3) Heat (if necessary) the inner race of upper jackstrut bearing (6) and slide the bearing housing assembly (8) on the pinion until it is flush against clutch (11).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(4) Install tool T-0133-1 (Fig. 11-12). The long arm on this tool slides into forward end of pulley and the short arm hooks under the idler arm mount to hold pinion from rotating when applying torque to pinion nut (1). Include a shim on T-0133-1 to avoid damaging the gearbox flange.

(5) Install nut (1) on pinion and torque (250 ft-lb/339.0 Nm) using tool T-0135.

NOTE: The nut should be rechecked after 25 hours of service and at 100 hour intervals thereafter.

(6) Install the drive belt over the upper pulley (12).

(7) Reinstall the tail rotor driveshaft but do not torque mounting bolts.

(8) Slip tach drive O-rings over driveshaft.

(9) Connect coupling halves:

(a) Flex Coupling

1 Install the coupling hub into the pinion and install taper pin. Taper pins must be tapped into place and secured with nut (not seated in place by the nut). Install washer, and nut and torque (25 in-lb/2.8 Nm).

2 Align the forward and aft coupling hub with the flex element (Fig. 11-9). With the curved side of the flex coupling washers (2) against the flex element, install the mounting hardware (bolts (5) and nuts (7)) and torque (50-70 in-lb/5.6-7.9 Nm).

NOTE: Washers (6) may be used between flex coupling washers (2) and coupling hubs to align and center the flex elements.

(10) Return the forward tail rotor drive shaft pillow blocks to the original position and install bolts. Use the same shims as originally installed under the block.

(11) Safety the nut (1) to the coupling taper pin (MS20995C40).

(12) Install O-rings over pulleys and install tach drive cover.

(13) Install jackstrut assembly (Para. 11-4.F).

(14) Check clutch control rigging (Para. 11-1.A).

(15) Service the upper jackstrut bearing (Para. 4-36).

(16) Inspect entire drive system.

(17) Track drive belt (Para. 11-5.B).

(18) Perform a final inspection of the entire drive system.

(19) Replace cowling.

11-7.1 UPPER JACKSTRUT BEARING

A. Removal – Upper Jackstrut Bearing

NOTE: Refer to Fig. 11-10 for numbered items.

- (1) Remove housing and bearing assembly (Para. 11-7.C).
- (2) Remove retaining ring (3).
- (2) Remove seal retainer (4) and seal (5) from bearing housing (8).
- (3) Heat bearing housing (8) to 250°F/121°C and gently tap bearing (6) with bearing adapter (2) from the housing.
- (4) Remove shield (7) from housing (8).
- (5) Press bearing adapter (2) from bearing (6).
- (6) Clean (Para. 11-7.1.B) and inspect bearing housing, shield, and seal (Para. 11-7.1.C).

B. Cleaning – Upper Jackstrut Bearing

- (1) Upper Jackstrut Bearing – Carefully remove seal from the bearing. Wash and flush old grease from bearing using fresh cleaning solvent, kerosene, toluol or vapor degrease. Apply a light oil (10W) to bearing and spin bearing by hand to determine if it is serviceable. The bearing should rotate smooth with no ratchety feeling. See Table 4-1 for required intervals and grease to repack bearing.

C. Inspection – Upper Jackstrut Bearing

- (1) See Table 11-2 for detailed inspection requirements of the clutch and pulley assembly.

D. Installation – Upper Jackstrut Bearing

- (1) Lubricate (MIL-PRF-81322) the inside of the bearing housing.
- (2) Install shield (7) into bearing housing (8) and center the shield as closely as possible to the inside of the housing.
- (3) Lubricate (MIL-PRF-81322) the bore of bearing housing (8) and the O.D. of bearing (6).
- (4) Remove the aft side seal from the replacement bearing and pack bearing (6) with grease (MIL-PRF-81322). Do not reinstall the shield that was removed in this step.

WARNING: USE EXTREME CAUTION WHEN HANDLING HEATED PARTS TO PREVENT FROM INJURING PERSONNEL. USE PROTECTIVE GLOVES WHEN HANDLING HEATED PARTS.


- (5) Heat bearing housing (8) to approximately 250°F/121°C.
- (6) Install bearing (6) into bearing housing (8) with the open side of the bearing facing aft.
- (7) If required, press seal (5) into seal retainer (4).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (8) Apply a light coat of grease (MIL-PRF-81322) on the lip side of seal retainer (4) and install with seal (5) facing the open side of bearing (6) (forward).


NOTE: Do not use a threadlocker on the inside diameter of bearing adapter or on the threads of pinion retention nut. If threadlocker is used on the outside diameter of the bearing adapter to improve fit into the bearing, ensure the bearing adapter is fully seated into bearing. Any excess residue must be removed prior to curing to preclude improper clamp up of the final assembly stack upon torquing the pinion nut.

- (9) Press bearing adapter (2) into the aft side of bearing (6).
- (10) Install retaining ring (3) into bearing housing (8).
- (11) Install bearing housing assembly (Para. 11-7.H.(3) to end).




- | | | | |
|----|----------------------|-----|-----------------------|
| 1. | Pinion Retention Nut | 8. | Bearing Housing |
| 2. | Bearing Adapter | 9. | Bolt |
| 3. | Retaining Ring | 10. | Washer |
| 4. | Seal Retainer | 11. | Clutch |
| 5. | Seal | 12. | Driven Pulley (Upper) |
| 6. | Bearing | 13. | Nut |
| 7. | Shield | 14. | Key |

Figure 11-10. Clutch and Upper Pulley Assembly



I

a. Upper Jackstrut Bearing Housing Removal



b. Clutch and Upper Pulley Removal

Figure 11-11




Figure 11-12. Upper Pulley Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-2. Inspection Requirements – Clutch and Upper Pulley Assembly

Part Number	Fig. 11-10 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13184-11	1	Retention Nut	Threads (no rolled or missing threads)	None Allowed	Not Repairable	Replace Nut
			Cracks	None Allowed	Not Repairable	Replace Nut
28-13323-11	2	Bearing Adapter	(28-13323-11) O.D. 1.5746 to 1.5749	-.0002	Not Repairable	Replace Adapter
28-13129-13	(28-13323-11) I.D. 1.3116 to 1.3118		+.0002	Not Repairable	Replace Adapter	
	(28-13129-13) O.D. 1.5740 to 1.5745		-.0005	Not Repairable	Replace Adapter	
	(28-13129-13) I.D. 1.3110 to 1.3125		+.0005	Not Repairable	Replace Adapter	
	Fretting wear on end surfaces		None Allowed	Not Repairable	Replace Adapter	
ECD014-11 ECD014-13	6	Bearing	Roughness, spalling, pits, or corrosion	None Allowed	Not Repairable	Replace Bearing
28-13215-1, -3	8	Bearing Housing	I.D. 3.5428 to 3.5434	+.001	Not Repairable	Replace Housing
	Cracks		None Allowed	Not Repairable	Replace Housing	
	Nicks, scratches, or corrosion		.030 deep	≤ .030 deep	Blend out smooth	
28-13401-2, -4	11	Clutch	O.D. 4.2490 to 4.2500	-.0002	Not Repairable	Replace Clutch
	Bore dia. 1.5630 to 1.5640		+.0003	Not Repairable	Replace Clutch	
	Inner race axial play (end play)		.050	Not Repairable	Replace Clutch	
(continued next page)						

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-51

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-2. Inspection Requirements – Clutch and Upper Pulley Assembly

Part Number	Fig. 11-10 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13401-2, -4	11	Clutch	(continued from previous page)			
			Inner race faces perpendicular to bore	.0005 TIR	Can be faced	Contact Enstrom
			Inner race rotation to be smooth with no noise or roughness	None Allowed	Can be rebuilt	Return to Enstrom Factory for Evaluation
			Seal – leakage	None Allowed	None Allowed	Replace Seal
			Oil level			Service (Para. 4-10)
28-13271	12	Pulley	Bore dia. 4.2490 to 4.2495	+ .0003	Not Repairable	Replace Pulley
			Cracks	None Allowed	Not Repairable	Replace Pulley
			Concentricity	.001 TIR	Not Repairable	Replace Pulley
			Depth of grooves	≤ .176	Not Repairable	Replace Pulley
			Nicks and gouges in belt grooves	None Allowed	≤ .25 long and ≤ .025 deep	Blend out smooth
28-13142	14	Key	Width .3105 to .3125	-.001	Not Repairable	Replace Key
			No visible wear on side of key	None Allowed	Not Repairable	Replace Key
SLW 3045	15	Locking Ring	Locking tabs not bent or broken	None Allowed	Not Repairable	Replace Locking Ring
SLN 3045	16	Nut	Threads (no rolled or missing threads)	None Allowed	Not Repairable	Replace Nut
			Tightening tabs (not rounded or bent)	None Allowed	Not Repairable	Replace Nut
			Cracks	None Allowed	Not Repairable	Replace Nut

* All dimensions are in inches.

MM-11-52
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

11-8 IDLER PULLEY ASSEMBLY

A. Troubleshooting – Idler Pulley Assembly

Problem	Possible Cause	Action
End play in roller assembly.	Worn bearings.	Replace bearings.
Excessive belt vibration at low power settings.	Improperly adjusted belt roller.	Adjust roller to a 0.38 inch/9.5 mm gap between belt and roller with clutch engaged.
Play in idler actuator arm.	Worn oilite bushings.	Replace bushings.
Play in over-center bellcrank.	Worn oilite bushings in bellcrank.	Replace bushings.
	Worn rod end.	Replace rod end.
Idler pulley rotates by hand.	Ratchety idler bearings.	Replace bearings.
Over-center bellcrank not parallel to shaft with clutch engaged.	Improper rigging.	Check rigging (Para. 11-1.B).

B. Removal – Idler Pulley

NOTE: Refer to Fig. 11-16 for numbered items unless stated otherwise.

- (1) Remove baggage compartment top and side cowling. Remove baggage box.
- (2) Remove bolts (24) to disconnect the actuator arm assemblies (10) from the pulley yoke assembly (Fig. 11-14).
- (3) Remove bolt (50) and washer (51) to disconnect the idler stabilizer strut (49) from the brace assembly (57).
- (4) Loosen nut (48) to allow the idler stabilizer strut (49) to pivot.
- (5) Remove nut (63) and washer (64).
- (6) Push the belt away from the idler pulley (7) and remove the idler pulley assembly with attached stabilizer strut (49) and shaft (62) from the transmission housing.

C. Disassembly – Idler Pulley

NOTE: Refer to Fig. 11-13 for numbered items unless stated otherwise.

- (1) Remove cotter pin and nut (6) from shaft (1).
- (2) Remove spacer (5) from shaft.
- (3) Remove snap rings (2) from yoke (8).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (4) Install tool T-0029B against bearing (3) with head of shaft (1) inside the tool.
- (5) Place the pulley assembly (7) in an arbor press and using tool T-0029B-1 against threaded end of shaft (1), press the shaft through the bearings (3) and the pulley. Remove the shaft.

NOTE: Hold tool T-0029B-1 in bearings and pulley to keep pulley from falling out of yoke.

- (6) Place assembly on bench and remove tool T-0029B-1. Remove pulley (7) and spacers (4).
- (7) Heat pulley yoke (8) to approximately 250°F/121°C and gently tap bearings (3) out.
- (8) Carefully remove seals from both sides of the bearings (3).
- (9) Clean idler pulley components (Para. 11-8.D).

D. Cleaning – Idler Pulley

- (1) Idler Pulley Bearings: Wash and flush old grease from the bearing using fresh cleaning solvent, kerosene, toluol or vapor degrease. Apply a light oil (10-W) to bearing and spin the bearing by hand to determine if it is serviceable. The bearing should rotate smooth with no ratchety feeling. See Table 4-1 for required intervals and grease to repack bearing. Install seals.

E. Inspection – Idler Pulley Assembly

- (1) See Table 11-3 for detailed inspection requirements.

F. Assembly – Idler Pulley

NOTE: Refer to Fig. 11-13 for numbered items unless stated otherwise.

- (1) Spray bearing bores of yoke (8) and O.D. of bearings (3) with activator (Loctite primer 7649 or equivalent).
- (2) Heat bearing area of yoke (8) to approximately 250°F/121°C. Apply a small amount of Loctite 277 to O.D. of bearing (3) and install into yoke (8). Repeat on the opposite bearing.

NOTE: T-0029A-1 can be used if the bearings (3) require pressing into the yoke (8).

- (3) Place spacers (4) and pulley (7) in yoke.

NOTE: The small end of the spacer faces against bearings (3).

- (4) Install tool T-0029B-1 through bearings (3), spacers (4) and pulley (7).
- (5) Place tool T-0029A-1 against aft bearing (3) and install in a press while holding tool T-0029B-1 and pulley in place.

NOTE: Tool T-0029B-1 is used for alignment and will be pressed out while pressing shaft (1) in.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Apply grease (MIL-PRF-81322) to the bearing surface of shaft (1) and carefully press through bearings and pulley.

NOTE: Shaft (1) should be installed with threaded end facing aft when installed on helicopter.

- (7) Remove from the press and install retaining rings (2) in the bearing bores.
- (8) Install spacer (5) on threaded end of shaft (1) with the chamfer facing inboard.
- (9) Install nut (6). Torque (24-34 ft-lb/33-46 Nm).
- (10) Install cotter pin through the nut (6).

G. Installation – Idler Pulley Assembly

NOTE: Refer to Fig. 11-16 for numbered items unless stated otherwise.

- (1) Install spacer (45) on the long end of shaft (62). The chamfered hole of spacer (45) must be installed against the wrench boss of shaft (62).

- (2) Install the yoke (8) over shaft (62) and against the spacer (45).

NOTE: It may be necessary to rotate the pulley rotating shaft as the shaft is inserted into the transmission so the idler yoke will clear the idler support strut.

- (3) Insert yoke (8) and shaft (62) into the transmission boss. It may be necessary to rotate the shaft to facilitate installation.

- (4) Install the idler stabilizer strut (49) to the brace assembly with bolt (50) and washer (51).

NOTE: It is recommended to torque all hardware installations. If required, loosen and re-torque as required during the tracking process.

- (5) Install washer (64) and nut (63). Torque (50-65 ft-lb/68-88 Nm).

- (6) Tighten nut (48). Torque (24-34 ft-lb/33-46 Nm).

- (7) Connect actuator arm assemblies (10) to pulley yoke (8) with bolts (24), washers (25), and nuts (27) (Fig. 11-14). Torque 30-40 in-lb/3.4-4.5 Nm.

NOTE: Head of bolt and washer are installed from the inboard side of actuator arm assembly. Place washer (25) and nut (27) on outboard end of the bolt (24).

- (8) Install cotter pins (28) (Fig. 11-14).

11-8.1 YOKE END ASSEMBLY

A. Removal – Yoke End Assembly

- (1) Remove the idler pulley assembly (Para. 11-8.B).
- (2) Remove bolt (41) and hardware to disconnect rod end (38) from the over-center bellcrank (Fig. 11-14).
- (3) Remove bolts (19) (20) and hardware to disconnect the actuator arm assemblies (10) from the yoke end (15).

B. Disassembly – Yoke End Assembly

- (1) Remove shaft (18), nut (17) and washer (16) from yoke end (15) (Fig. 11-14).
- (2) If rod end bearing assembly (38) needs replacing, cut safety wire and break torque on nut (37).
- (3) Carefully back out the jam nut (37) and withdraw the lock key (36) from the shaft (18).
- (4) Remove the rod end bearing assembly (38).

C. Inspection – Yoke End Assembly

- (1) See Table 11-4, Table 11-5, and Table 11-6 for detailed inspection requirements.
- (2) Inspect idler yoke S/N 14-001-06 to 14-077-06 per SDB 109, latest revision.

NOTE: Unless initially complied with and documented in maintenance records, SDB 0118, latest revision, is still in effect.

D. Assembly – Yoke End

- (1) Install the rod end bearing assembly (38) (Fig. 11-14).

NOTE: The rod end bearing assembly (38) may have been previously treated with ACF-50 or MIL-PRF-23377 Type I Class 2C or Class N epoxy primer corrosion inhibitor per SDB 0127. If continuing use of ACF-50, removal of prior ACF-50 application is unnecessary. If changing from ACF-50 to epoxy primer, ACF-50 residue must be removed before reinstallation.

NOTE: For helicopters S/N 833 (F-28F) and subsequent and S/N 2157 (280FX) and subsequent, the rod ends are treated with epoxy primer at the time of manufacture.

- (a) For new epoxy primer application, remove any ACF-50 residue from the threads of the rod end and the interior threads of the piston with a suitable solvent.
- (b) If applying a touch-up of epoxy primer, remove any loose epoxy primer residue from the threads of the rod end and the interior threads of the piston with a brush and a small amount of solvent.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

CAUTION: Do not allow the epoxy primer to dry prior to assembly of the rod end.

CAUTION: Mask the bearing area prior to applying epoxy primer to avoid damaging the bearing.

NOTE: Follow the manufacturer's instructions for corrosion inhibitor application.

- (c) Apply a coat of corrosion inhibitor to the top 0.50 in/13 mm of threads of the bearing (closest to the uni-ball bearing).

NOTE: Installing the nut will tend to wipe away corrosion inhibitor that was freshly applied. Re-apply to ensure complete coverage.

- (d) Install the lock pin (36) and the jam nut (37) and position as close as possible to the uni-ball bearing.

- (e) Apply corrosion inhibitor to the remaining threads below the jam nut (37).

- (f) Install rod end bearing assembly (38) into shaft (18).

- (2) Turn the rod end bearing assembly (38) into the shaft until the measurement from the end of the shaft to centerline of the rod end ball is 6.75 inches.

- (3) Torque (300 in-lb/34 Nm) jam nut and safety wire the locking key (36) to the jam nut (37).

- (4) Re-apply corrosion inhibitor to the threads above the jam nut (37), as required.

- (5) Install nut (17) and washer (16) on shaft (18) (Fig. 11-14).

- (6) Apply lubrication (MIL-G-25537 or MIL-PRF-81322) to the threads of the shaft (18) and turn into yoke (15) until approximately 1/2 inch of the threads extend beyond the jam nut.

- (7) Torque nut (17) (40-45 ft-lbs/4.5-5.1 Nm).

E. Installation – Yoke End Assembly

- (1) Place yoke end (15) between actuator arm assemblies (10) and install mount bolts (19) and (20) and washers (21) and (22), and nuts (23). Torque (12-15 in-lb/1.4-1.7 Nm) (Fig. 11-14).

- (2) Install spacer (40) in rod end bearing assembly (38) and place spacers (39) on each side of the rod end (Fig. 11-14).

- (3) Insert rod end (38) with spacers (39) into over-center bellcrank and install bolt (41), washers (42) and nut (43), and partially tighten. Torque (30-40 in-lb/3.4-4.5 Nm) and install cotter pin (44) after belt tension is rigged.

- (4) Install the idler pulley assembly (Para. 11-8.G).

- (5) Verify belt clutch adjustment (Para 11-1.A).

11-8.2 ACTUATOR ARM ASSEMBLY AND SNUBBER ROLLER ASSEMBLY

A. Removal – Snubber Roller

NOTE: It is not necessary to remove the forward actuator arm assembly if only removing the “snubber” roller.

NOTE: Refer to Fig. 11-14 for numbered items.

- (1) Remove the yoke end assembly (Para. 11-8.1.A).

NOTE: If the belt roller assemblies are installed in the helicopter, it is only necessary to remove the aft strap assembly (10) to remove the snubber roller

- (2) Disconnect actuator arm assemblies (10) from yoke end (15) and from the pulley yoke (8) by removing bolts (19), (20), and (24). Remove spacers (9), washers (21) and (25), and nuts (27).
- (3) Remove nuts (14) and washers (13) to remove roller assembly (11) from the actuator arm assemblies. Remove spacers (12).

B. Disassembly – Snubber Roller

- (1) Using a plastic mallet, tap end of shaft (33) to remove bearing housing (30) and bearing (31) from one end of roller (Fig. 11-14).
- (2) Reinstall shaft (33) in opposite bearing and tap to remove bearing.
- (3) Remove shaft (33) and sleeve (32). Save shims (34) located behind bearing for reassembly.
- (4) Press bearings (31) from bearing housings (30).
- (5) Clean roller assembly components in accordance with Step C.

C. Cleaning – Actuator Arm Assembly and Snubber Roller

- (1) Parts should be washed in toluene, kerosene, or an equivalent solvent. They may also be vapor degreased before inspection.
- (2) Do not submerge the roller assembly into cleaning solvent as a unit. Clean the outer surfaces of the roller with a cleaning brush and solvent. If the unit is disassembled, clean the bearings in accordance with Step D.

D. Inspection – Actuator Arm Assembly and Snubber Roller

- (1) See Table 11-4 and Table 11-5 for detailed inspection requirements.
- (2) Inspect the edges of the washer (13) area (inside the groove) on the actuator arm assembly for cracks and inspect the outside edges of the actuator arm above and below the washer (13) area (Fig. 11-15).
- (3) Inspect the interior aluminum plate of the actuator arm assembly for damage.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

E. Assembly – Snubber Roller

NOTE: Parts identified in steps (1)-(3) are installed with 277 Loctite (red). Use only a small amount.

- (1) Apply a small amount of 277 Loctite to bearings (31) and press bearings (31) into end caps (30) (Fig. 11-14).
- (2) Apply a small amount of 277 Loctite to one end cap (30) and press one end cap (30) into roller (29).
- (3) Apply a small amount of 277 Loctite to sleeve (32) and install sleeve (32) into I.D. of roller (29) and align into end cap (30) assembled in step 2.

NOTE: Parts identified in steps (4)-(5) are installed with Aeroshell 22 (MIL-PRF-81322). Do not use Loctite.

- (4) Lubricate (MIL-PRF-81322) and install shaft (33) into roller (29) and bearing (31).
- (5) Lubricate (MIL-PRF-81322) and press opposite end cap (30) into roller (29).
- (6) While holding roller (29) stationary in vertical position, install dial indicator on end of shaft (33) and move shaft up and down to check end play.

NOTE: Shimming is required to remove end play and preload bearings. Shaft end play measurement plus .002 equals shims required.

Example: End play .022 + .002 = .024 (shims required).

- (7) Using a plastic mallet, tap end of shaft (33) to remove bearing (31) from the cap with the (MIL-PRF-81322).
- (8) Reinstall shims (34) on bearing surface of shaft (33).
- (9) Press bearing (31) into end cap (30).
- (10) Rotate shaft (33). The inner race of bearings (31) should rotate with the shaft and no end play should exist.

NOTE: If the inner race of the bearing does not turn with the shaft or if end play still exists, there is not enough preload on the bearings. Install additional shims as required. Recheck assembly.

F. Installation – Actuator Arm Assembly and Snubber Roller

- (1) If required, install forward actuator arm assembly (10) (Fig. 11-14).
 - (a) Install mount bolts (19) and (20) and washers (21) and (22), and nuts (23). Torque (12-15 in-lb/1.4-1.7 Nm).
 - (b) Safety wire bolt (20) and one of the (19) bolts that attach the forward actuator arm assembly to yoke end (15) with 0.032 wire.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL


(c) Install bolt (24), washers (25), and nut (27). Torque 30-40 in-lb/3.4-4.5 Nm.

NOTE: Head of bolt and washer are installed from the inboard side of actuator arm assembly. Place washer (25) and nut (27) on outboard end of the bolt (24).

NOTE: Actuator arm assemblies are to be installed with the flange of oilite bushing (26) facing outboard. The roller assembly (11) is installed with grease fitting end of roller facing aft as installed on helicopter.

- (2) Install spacers (12) and washers (13) on roller assembly (11).
- (3) Install roller assembly (11) onto forward actuator arm assembly (10). Loosely install forward washers (13) and nut (14).
- (4) Install aft actuator arm assembly (10) on roller assembly (11) against the inboard washers.
- (5) Loosely install outboard washers (13) and nuts (14) on the roller (11).
- (6) Install mount bolts (19) and (20) and washers (21) and (22), and nuts (23). Torque (12-15 in-lb/1.4-1.7 Nm).
- (7) Safety wire bolt (20) and one of the (19) bolts that attach the forward actuator arm assembly to yoke end (15) with 0.032 wire.
- (8) Install spacers (9) into oilite bushings (26) of aft actuator arm assembly (10).
- (9) Install bolt (24), washers (25), bushing (9), and nut (27). Torque 30-40 in-lb/3.4-4.5 Nm.
- (10) Install cotter pin (28) in actuator arm assembly pivot bolt (24), as applicable.
- (11) Adjust snubber roller to 0.38 inch/9.5 mm clearance and parallel to the back side of the belt.
- (12) Torque nuts (14) (95-110 in-lb/10.7-12.4 Nm).
- (13) Service the roller assembly.
- (14) Ground run helicopter and verify snubber roller clearance and parallel to the drive belt.


NOTE: After final adjustment of the idler pulley track, loosen the aft nut on the "snubber" roller and allow the roller to self-align on the idler straps. Torque the aft nut to 95-110 in-lb/10.8-12.5 Nm.



- | | | | |
|----|----------------|----|----------------------|
| 1. | Idler Shaft | 5. | Washer |
| 2. | Retaining Ring | 6. | Nut |
| 3. | Bearing | 7. | Idler |
| 4. | Spacer | 8. | Pulley Yoke Assembly |

Figure 11-13. Idler Pulley and Pulley Yoke Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | | | | |
|-----|-----------------------|-----|------------|-----|------------------|
| 9. | Spacer | 21. | Washer | 33. | Shaft |
| 10. | Actuator Arm Assembly | 22. | Washer | 34. | Shim |
| 11. | Roller Assembly | 23. | Nut | 35. | Lock Washer |
| 12. | Spacer | 24. | Bolt | 36. | Lock Key |
| 13. | Washer (Harper) | 25. | Washer | 37. | Nut |
| 14. | Nut | 26. | Bushing | 38. | Rod End Assembly |
| 15. | Yoke End | 27. | Nut | 39. | Washer |
| 16. | Washer | 28. | Cotter Pin | 40. | Spacer |
| 17. | Nut | 29. | Roller | 41. | Bolt |
| 18. | Shaft Assembly | 30. | End Cap | 42. | Washer |
| 19. | Bolt | 31. | Bearing | 43. | Nut |
| 20. | Bolt | 32. | Sleeve | 44. | Cotter Pin |

Figure 11-14. Actuator Arm, Yoke End, and Belt Roller Assemblies






Figure 11-15. Actuator Arm Inspection



- | | | | |
|-----|---------------------------------|-----|----------------|
| 45. | Spacer | 54. | Washer |
| 46. | Bearing (Part of Yoke Assembly) | 55. | Washer |
| 47. | Washer | 56. | Nut |
| 48. | Nut | 57. | Brace Assembly |
| 49. | Idler Stabilizer Strut | 58. | Bolt |
| 50. | Bolt | 59. | Washer |
| 51. | Washer | 60. | Washer |
| 52. | Clamp Half | 61. | Nut |
| 53. | Bolt | 62. | Shaft |

Figure 11-16. Idler Pulley and Support Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-3. Inspection Requirements – Idler Pulley and Yoke Assembly

Part Number	Fig. 11-13 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13230	1	Shaft	Bearing surface dia. .5908 to .5903	-.0002	Not repairable	Replace Shaft
			Concentricity	.001 TIR	Not repairable	Replace Shaft
			Threads (no crossed or rolled threads)	None Allowed	Not repairable	Replace Shaft
N5000-137-S-PP	2	Snap Ring	Visual flatness check	None allowed	Not repairable	Replace Snap Ring
ECD018-11	3	Bearing	Bearing O.D. 1.3780	+ .0000/- .0005	Not Repairable	Replace Bearing
			Bearing I.D. .5906	+ .0000/- .0003	Not Repairable	Replace Bearing
			Rotate (no ratchety feeling)	None Allowed	Not Repairable	Replace Bearing
			Hours – Limited life bearing 600 hours	None allowed		Replace Bearing
28-13233	4	Spacer	Width .250	±.003	Not Repairable	Replace Spacer
28-13234	5	Washer	Width .125	±.005	Not Repairable	Replace Washer
28-13229	7	Idler Pulley	Shaft bore .5898 to .5908	+ .0002	Not Repairable	Replace Pulley
			Shaft bore to O.D. concentricity	.001 TIR	Not Repairable	Replace Pulley
			Belt wear in O.D.	.020 deep	Maximum .040 deep	Replace Pulley
			Cracks	None Allowed	Not Repairable	Replace Pulley

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-65

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-3. Inspection Requirements – Idler Pulley and Yoke Assembly

Part Number	Fig. 11-13 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13292	8	Pulley Yoke	Bearing bore dia. 1.3781 to 1.3786	+ .0002	Not Repairable	Replace Yoke
			Nicks and scratches	None Allowed	Maximum .008 deep	Polish to remove. Finish with #180 Emery cloth
			Brass bushing bore dia. .627 to .628	+ .0005	Not Repairable	Replace bushings and line ream to size
			Actuator arm assembly mount hole dia. .250 to .251	None Allowed	Not Repairable	Replace Yoke
			Cracks	None Allowed	Not Repairable	Replace Yoke

* All dimensions are in inches.

MM-11-66
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-4. Inspection Requirements – Idler Actuator Arm Assembly and Roller Assembly

Part Number	Fig. 11-14 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-132008-11	9	Spacer	Length .350 to .353	-.0005	Not Repairable	Replace Spacer
			Bore dia. .250 to .254	+.0005	Not Repairable	Replace Spacer
			Ends perpendicular to bore within .001	None Allowed	Not Repairable	Replace Spacer
28-13318-7	10	Actuator Arm Assembly	Inspect for belt wear on side of arm	None Allowed	Not Repairable	Replace Arm
			Slot width .380 ± .010	+.003	Not Repairable	Replace Arm
			Notch worn in roller slot	.015 deep	Not Repairable	Replace Arm
			Brass bushing bore .3755 to .3765	+.001	Not Repairable	Replace Bushing
			Cracks	None Allowed	Not Repairable	Replace Arm
28-13245-901	11	Roller Assembly	Bearings (rotate free with no ratchety feeling)	None Allowed	Not Repairable	Replace Bearings
			Shaft (no end play)	None Allowed	.030 end play	Disassemble and shim to preload bearings
			Shaft threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Shaft
28-13278	12	Spacer	Length. .260 +.000/-.005	None Allowed	Not Repairable	Replace Spacer
			O.D. .62 ± .015	None Allowed	Not Repairable	Replace Spacer
			I.D. .472 +.005/-.000	None Allowed	Not Repairable	Replace Spacer

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-67

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-4. Inspection Requirements – Idler Actuator Arm Assembly and Roller Assembly

Part Number	Fig. 11-14 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13299-1, -3	15	Belt Tension Assembly Yoke	Shaft threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Yoke
			Bolt holes .191 diameter	± .005	Not Repairable	Replace Yoke
			Cracks	None Allowed	Not Repairable	Replace Yoke
28-132005-11	18	Shaft	Threads – I.D. and O.D. (no crossed or missing threads)	None Allowed	Not Repairable	Replace Shaft

* All dimensions are in inches.

MM-11-68
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-5. Inspection Requirements – Belt Roller Assembly

Part Number	Fig. 11-14 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13297	29	Roller	End cap bore dia. 1.8115 to 1.8120	None Allowed	Not Repairable	Replace Roller
			Nicks and scratches in O.D.	None Allowed	.005 deep	Polish to remove
28-13296	30	End Cap	O.D. dia. 1.8120 to 1.8125	None Allowed	Not Repairable	Replace End Cap
			Bearing bore dia. 1.2591 to 1.2586	None Allowed	Not Repairable	Replace End Cap
			Tube bore dia. 1.004 to 1.006	None Allowed	Not Repairable	Replace End Cap
ECD036-11	31	Bearing	Bore .4724, +.0000/-.0003	None Allowed	Not Repairable	Replace Bearing
			O.D. 1.2598, +.0000/-.0005	None Allowed	Not Repairable	Replace Bearing
			Check bearing for smooth rotation (no ratchet feeling)	None Allowed	Not Repairable	Replace Bearing
28-13248	32	Sleeve	Length 5.525	±.005	Not Repairable	Replace Sleeve
28-13246	33	Shaft	Bearing surface .469 to .471	-.0003	Not Repairable	Replace Shaft
			Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Shaft
			All radii to be free of nicks and scratches	None Allowed	Not Repairable	Replace Shaft

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-69

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-6. Inspection Requirements – Upper Bellcrank Assembly

Part Number	Fig. 11-14 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
ECD091-1, 09455-01-824- 08E-011, MTK8, ASMK8T, 01- 824-08E-011, M81935/1-08K, MS21242S8K, MXJKR-8R, or 01-691-08	38	Rod End Bearing Assembly	Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Rod End
			Threads (corrosion)	None Allowed	Not Repairable	Replace Rod End
			Axial play of swivel ball	.007 clearance	Not Repairable	Replace Rod End
28-132009-11	39	Spacer	Bore .500 to .505	None Allowed	Not Repairable	Replace Spacer
			Width .090	±.005	Not Repairable	Replace Spacer
28-132006-11	40	Spacer	Length .765 to .785	None Allowed	Not Repairable	Replace Spacer
			O.D. .4935 to .4965	-.0003	Not Repairable	Replace Spacer

* All dimensions are in inches.

MM-11-70
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

11-9 BELT TENSION ASSEMBLY

A. Troubleshooting – Belt Tension Assembly

Problem	Possible Cause	Action
Clutch lever sticks when releasing from engaged position.	Notches worn in lower end of in brackets, causing nylon bushings to stick in slots.	Notches which do not exceed .050 inch deep may be polished and blended until clutch releases smoothly. Replace brackets if notch exceeds .050 inch deep.
Excessive play in slider bolt area (bottom bolt through spring capsule). Maximum play .025 inch.	Nylon bushings worn. (Check by holding each end of bolt and pulling in and out.)	Replace bushings. (Tighten nuts until there is a slight amount of drag in the movement of the nylon bushing in the slots).
Excessive side play in spring capsule piston.	Worn DU bushing in capsule end cap.	Remove belt tension assembly and remove spring capsule. Replace bushing.
Excessive play in over-center bellcrank	Worn oilite pivot bushings in bellcrank.	Replace bushings.
Excessive play at spring capsule end cap (clutch engaged)	Worn bushing	Replace bushing. (Para. 11-9.1.B)

B. Removal – Belt Tension Assembly (Fig. 11-17)

NOTE: Refer to Fig. 11-17 for numbered items unless stated otherwise.

- (1) Remove left side aft cowling.
- (2) Disconnect the micro-switch wiring.
- (3) Remove bolt (1) and hardware that secures spring capsule rod end (5) to bellcrank (3).
- (4) Remove bolt (8) and hardware that secures clutch cable rod end (12) to bellcrank (14).
- (5) Remove bolts (12) and hardware that secures mount block (14) to belt tension assembly brackets (9) (Fig. 11-18).
- (6) Remove bolts (15) and hardware that secures the belt tension assembly to the pylon (2 places).
- (7) Remove the belt tension assembly.

C. Disassembly – Belt Tension Assembly

NOTE: Refer to Fig. 11-18 for numbered items.

- (1) Remove bolt (20) from brackets (9) and remove spacers (21), (22) and (23).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (2) Remove bolts (16) and spacers (19) from pivot straps (3).
- (3) Remove bellcranks (18) and spacers (17).
- (4) Remove bolt (1) from spring capsule (6) and remove pivot straps (3), spacers (4) and spacer (5).
- (5) Remove nuts (7), washers (11) and nylon washers (10) from spring capsule slider bolt.
- (6) Remove bolts (12) from brackets (9) and clutch cable mount block (14). Remove block (14).
- (7) Remove brackets (9) from spring capsule (6).

D. Cleaning – Belt Tension Assembly

- (1) Parts should be washed in toluene, kerosene, or an equivalent solvent. They may also be vapor degreased before inspection.

NOTE: The nylon bushings and washers may be deformed from the heat of a vapor degreaser and should be cleaned separately.

E. Inspection – Belt Tension Assembly

- (1) See Table 11-7 for detailed inspection requirements of the belt tension assembly.
- (2) Visually inspect the pylon area adjacent to the belt tensioning assembly mounting bracket for cracks, wear caused by interference with the bottom of the capsule (14) Fig. 11-19), and other damage.
- (3) Replace bushing (5), if wear exceeds 0.020 inch/0.5 mm.

F. Repair – Belt Tension Assembly

- (1) If contact between anchor (14) (Fig. 11-19) and pylon is observed, the bottom edge of the anchor may be chamfered (0.050 inch/1.3 mm maximum).

G. Assembly – Belt Tension Assembly

NOTE: Refer to Fig. 11-18 for numbered items.

- (1) Install spacer (5) into ear of spring capsule assembly (6).
- (2) Install bolt (1) through washer (2), strap (3), spacer (4), strap (3), and washer (2).
- (3) Insert bolt through spacer (5) in the spring capsule assembly with the head of the bolt facing forward as installed in the helicopter.
- (4) Install another washer (2), strap (3), spacer (4), strap (3), washer (2), and nut (7). Tighten nut to remove side play but do not torque at this point.
- (5) Install nylon guide (8) on threaded shaft of spring capsule. Repeat on the opposite side.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Install brackets (9) on spring capsule with nylon guide (8) extending through the slots in the bracket.
- (7) Install nylon washer (10) on nylon guide (8) flush against bracket (9).
- (8) Install washer (11) and nut (7) on threaded shaft against the nylon washer. Partially tighten nuts until approximately two threads extend beyond the nut.
- (9) Place mount block (14) between brackets (9) and install bolts (12) with washers (13) and nuts (15). Tighten bolts but do not torque at this time.
- (10) Install spacer (17) in the center hole of bellcrank (18).
- (11) Place bellcrank between straps (3) and insert bolt (16) through the straps and bellcrank with the head of the bolt inboard.
- (12) Install washer (2), spacer (19), another washer (2) and nut (7) on bolt (16). Torque bolt (30-40 in-lb/3.4-4.5 Nm).
- (13) Repeat steps 10 through 12 on opposite bellcrank (18).

NOTE: Straps (3) and bellcrank (18) should pivot freely at this point.

- (14) Place spacer (22) between bellcranks (18) and insert spacer (23) through both bellcranks and spacer (22).
- (15) Install spacers (21) on outboard ends of spacer (23).
- (16) Place spacer stack-up between brackets (9) and insert bolt (20) through brackets and spacers using washers (2) and nut (7). The head of the bolt should be forward as installed in the helicopter. Partially tighten nut.
- (17) Place unit on a flat surface so brackets (9) are standing flat and parallel to each other. Torque all bolts at pivot points and at mount block (14).
 - (a) AN4 bolts (1) and (20): 30-40 in-lb/3.4-4.5 Nm
 - (b) AN3 bolts (12): 12-15 in-lb/1.4-1.7 Nm

NOTE: Do not overtorque nuts against nylon washer and guide as spring capsule will not slide freely. You should be able to rotate the Harper washer (11) by hand after torque of nut. No side play should exist between nut and washer.

- (18) Holding brackets (9) by hand, slide spring capsule assembly back and forth. Unit should slide with noticeable drag yet not bind in the pivot points or bracket slider.
- (19) Place spacers (24) on each side of rod end and install bellcrank (28).
- (20) Insert bolt (25) through bellcrank (28), spacers (24) and rod end using washers (26) and nuts (27).
- (21) Install spacer (29) into bellcrank oilite bushings.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

H. Installation – Belt Tension Assembly

NOTE: The heads of all bolts in the belt tension assembly and bellcrank connections should be facing forward with the nuts on the aft side.

- (1) Install belt tension assembly to the pylon mounts (Fig. 11-17):
 - (a) Install washers (16) between pylon mounts and belt tension brackets (18). Insert bolts (15) with washers (16) through the brackets and pylon mounts.
 - (b) Install washers (16) and nuts (17) and torque (12-15 in-lb/1.4-1.7 Nm).
- (2) Install clutch cable mount block (14) (Fig. 11-18):
 - (a) Slide clutch cable and retention block (14) into the belt tension brackets (9) and install bolts (12) (Fig. 11-18).
 - (b) Install washers (13) and nuts (15) and torque (12-15 in-lb/1.4-1.7 Nm).
- (3) Install the clutch cable rod end (12) (Fig. 11-17):
 - (a) Install washer (9) on bolt (8) and slide bolt through bellcrank arms (14), washers (10), spacer (11), and rod end (12).
 - (b) Install washer (9) and nut (13) and torque (30-40 in-lb/3.4-5.6 Nm).
- (4) Install the rod end (5) of the spring capsule (7) (Fig. 11-17):
 - (a) Install washer (2) on bolt (1) and slide bolt through bellcrank arms (3), spacers (4), and rod end (5).
 - (b) Install washer (2) and nut (6) and torque (30-40 in-lb/3.4-5.6 Nm).
- (5) Inspect the clutch control and belt tension mechanism rigging (Para. 11-1.A).
- (6) Inspect all connections for security and check that all cotter pins are installed in double-locking hardware.
- (7) Connect wiring for the micro-switch.
- (8) Install left side aft cowling.

I. Replacement – Spring Capsule Bushing

- (1) Spring Capsule Disassembly and Assembly

NOTE: The bushing (5) (Fig. 11-19) in the top of the spring capsule is a normal wear item. If the bushing is allowed to wear through the Teflon coating it will damage the adapter (3) requiring replacement of both the bushing and adapter.

NOTE: This procedure is written with the belt tension assembly installed.

NOTE: Ensure that the belt clutch is disengaged.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (a) Remove the left side cowling.
- (b) Remove hardware (24), (25), (26), and (27) (Fig. 11-18) connecting the spring capsule rod end (1) (Fig. 11-19) to the bellcrank (28) (Fig. 11-18).
- (c) Remove screws (12) and washers (11) from the spring housing (13) (Fig. 11-19).
- (d) Withdraw spring assembly (1) through (10) from spring housing (13).
- (e) Remove the cotter pin through the rod end bearing (1) and loosen the two check nuts (2).
- (f) Insert a flat screwdriver blade into the bottom end cap (8) to prevent nut (10) from turning and remove rod end (1) and the two check nuts (2) from the shaft (7).
- (g) Measure the length of the exposed threads on rod (7) for reassembly.
- (h) Remove adapter (3).
- (i) Press the bushing (5) from the top of end cap (4).
- (j) Insert a new 07DU08 bushing (5) into the top of end cap (4).
- (k) Measure the adapter (3) to verify that it is within limits (Table 11-8).
- (l) Install the adapter (3) and set it back to the same measurement obtained in step (g).
- (m) Insert the two check nuts (2).
- (n) Install the rod end (1). Line up the cotter pin hole and install the cotter pin.
- (o) Apply grease (MIL-PRF-81322) liberally to the spring (6).
- (p) Insert the spring assembly (1) through (10) back into the spring housing (13).
- (q) Install the screws (12) and washers (11). Torque screws (20-25 in-lb/2.3-2.8 Nm).
- (r) Safety wire the screws as a set of three around the outboard edge of the capsule. Do not run the safety wire around the inboard side of the capsule as the safety wire will contact the pylon when the clutch is engaged.
- (s) Install spring capsule rod end attachment hardware (24) through (27) (Fig. 11-18). Torque nut (27) (50-70 in-lb/5.6-7.9 Nm) and install cotter pin (27).
- (t) Verify that the clutch adjustment is correct (Para. 11-1).
- (u) Torque jam nuts (2) (30-40 in-lb/4.3-4.5 Nm).
- (v) Install cowling.


ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

J. Assembly – Spring Capsule Assembly

NOTE: Refer to Fig. 11-19 for numbered items.

- (1) Press anchor (14) on spring housing (13) while aligning holes for shaft (15).
- (2) Press retainer (16) into spring housing (13) while aligning holes for the shaft.
- (3) Press shaft (15) through anchor, housing, and retainer until threads of shaft are equally spaced in the housing.
- (4) Install lock nut (10) on shaft (7) until slot in the lock nut aligns with the cotter pin hole in the shaft. Install cotter pin.
- (5) Install washer (9) and retainer (8) on shaft (7) with recess in the retainer covering nut (10).
- (6) Install spring (6) over shaft (7) and seat on the retainer.
- (7) Press bushing (5) into end cap (4).
- (8) Install adapter (3) through end cap and bushing (5).
- (9) Turn adapter (3) onto shaft (7) and compress spring until unit will slide into spring housing (13) without bottoming against retainer (16).
- (10) Apply grease (MIL-PRF-81322) to spring and to wall of spring housing (13) and insert spring assembly into housing assembly.
- (11) Insert screws (12) through washers (11). Turn into end cap (4). Torque screws (20-25 in-lb/2.3-2.8 Nm).
- (12) Safety wire screws in set of three with 0.032 wire.
- (13) Install both jam nuts (2) on shaft (7).
- (14) Install rod end (1) on shaft (7) until hole in rod end aligns with hole in shaft.
- (15) Install cotter pin through rod end.
- (16) Lock upper jam nut (2) against rod end (1).


ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | |
|-----------------------------|----------------------------|---------------|
| 1. Bolt | 7. Spring Capsule Assembly | 13. Nut |
| 2. Washer | 8. Bolt | 14. Bellcrank |
| 3. Bellcrank | 9. Washer | 15. Bolt |
| 4. Spacer | 10. Washer | 16. Washer |
| 5. Rod End (Spring Capsule) | 11. Spacer | 17. Nut |
| 6. Nut | 12. Rod End (Clutch Cable) | 18. Bracket |


Figure 11-17. Belt Tension Assembly Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | | | | |
|-----|-------------------------|------|---------------------|-----|--------------------|
| 1. | Bolt | 11. | Washer (1/4 Harper) | 20. | Bolt |
| 2. | Washer | 12. | Bolt | 21. | Spacer |
| 3. | Strap | 13. | Washer | 22. | Spacer |
| 4. | Spacer | 14. | Mount Block | 23. | Spacer |
| 5. | Spacer | 15. | Nut | 24. | Spacer |
| 6. | Spring Capsule Assembly | 16. | Bolt | 25. | Bolt |
| 7. | Nut | 17. | Spacer | 26. | Washer |
| 8. | Nylon Guide | 18. | Bellcrank | 27. | Nut |
| 9. | Bracket | 19. | Spacer | 28. | Bellcrank Assembly |
| 10. | Nylon Washer | 19A. | Spacer | 29. | Spacer |

Figure 11-18. Belt Tension Assembly



- | | | | |
|----|---------|-----|----------------|
| 1. | Rod End | 9. | Washer |
| 2. | Jam Nut | 10. | Nut |
| 3. | Adapter | 11. | Washer |
| 4. | End Cap | 12. | Screw |
| 5. | Bushing | 13. | Spring Housing |
| 6. | Spring | 14. | Anchor |
| 7. | Shaft | 15. | Shaft |
| 8. | Cap | 16. | Retainer |

Figure 11-19. Spring Capsule Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-7. Inspection Requirements – Belt Tension Assembly

Part Number	Fig. 11-18 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13268	3	Strap	Bolt hole dia. .257	±.005	Not Repairable	Replace Strap
			Nicks and scratches	None Allowed	Not Repairable	Replace Strap
28-13277	4	Spacer	Width .125 to .130	None Allowed	Not Repairable	Replace Spacer
			I.D. .257	±.005	Not Repairable	Replace Spacer
28-13285-6	5	Spacer	Length .434 to .440	None Allowed	Not Repairable	Replace Spacer
			O.D. .3745 to .3755	None Allowed	Not Repairable	Replace Spacer
28-13264	8	Nylon Guide	I.D. .250 to .251	None Allowed	Not Repairable	Replace Nylon Guide
			Sliding surface, O.D. .3730 to .3740 .355 minimum	-.020	Not Repairable	Replace Nylon Guide
			Wear (sliding surface)	No flat areas allowed	Not Repairable	Position to non-flat area
28-13283	9	Bracket	Slot width .376 to .378	None Allowed	Not Repairable	Replace Bracket
			Notch wear in bottom end of slot	None Allowed	Notch .050 deep maximum	Polish and blend to remove deep radius into notch.
			Bolt hole dia. .191	None Allowed	Not Repairable	Replace Bracket
			Bolt hole dia. .249 to .251	None Allowed	Not Repairable	Replace Bracket
			Nicks and scratches in bracket	None Allowed	.005 deep max.	Polish and blend to remove
28-13265	10	Nylon Washer	Width .058 to .063	None Allowed	Not Repairable	Replace Washer
			I.D. .374 to .376	+.001	Not Repairable	Replace Washer
28-13269	14	Mount Block	Bore dia. .72	±.010	Not Repairable	Replace Block
			Bolt hole dia. .191	+.006	Not Repairable	Replace Block
28-13285-7	17	Spacer	Length .130 to .135	None Allowed	Not Repairable	Replace Spacer
			Bore dia. .3745 to .3755	None Allowed	Not Repairable	Replace Spacer

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 13
Jan 5/24

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-7. Inspection Requirements – Belt Tension Assembly

Part Number	Fig. 11-18 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13274	18	Bellcrank	Spacer hole dia. .376 to .378	+ .0005	Not Repairable	Replace Bellcrank
			Bolt hole dia. .257	± .0005	Not Repairable	Replace Bellcrank
28-13267-1,	19	Spacer	(-1) Length .40	± .010	Not Repairable	Replace Spacer
28-13267-11	19A		(-11) Length 1.13 to 1.14	None Allowed	Not Repairable	Replace Spacer
			I.D. .250 to .252	± .001	Not Repairable	Replace Spacer
28-13280-3	21	Spacers	-3 Length .365 to .370	None Allowed	Not Repairable	Replace Spacer
28-13280-4	22		-4 Length .750 to .755	None Allowed	Not Repairable	Replace Spacer
			I.D. (both spacers) .376 to .380	+ .001	Not Repairable	Replace Spacer
28-13285-5	23	Spacer	Length 1.750	None Allowed	Not Repairable	Replace Spacer
			I.D. .257	± .005	Not Repairable	Replace Spacer
28-16520	24	Spacer	Length .192 to .195	None Allowed	Not Repairable	Replace Spacer
			I.D. .249 to .250	± .001	Not Repairable	Replace Spacer
28-13260-1	28	Bellcrank	Bushing dia. .3755 to .3770	None Allowed	Not Repairable	Replace bushings and line ream to size
			Security of bellcrank sides to center spacer	No Looseness Allowed		Remove loose side and apply Loctite 277 to spacer. Replace bellcrank side. Note: Place ¼" bolts through holes for proper alignment.
28-13284	29	Spacer	Length 1.243 to 1.248	None Allowed	Not Repairable	Replace Spacer
			O.D. .3745 to .3755	None Allowed	Not Repairable	Replace Spacer

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-81

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-8. Inspection Requirements – Spring Capsule Assembly

Part Number	Fig. 11-19 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
02-691-04	1	Rod End	Axial clearance	.007	Not Repairable	Replace Rod End
			Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Rod End
28-13263	3	Adapter	O.D. .4360 to .4370	-.020	Not Repairable	Replace Adapter
			Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Adapter
			Radial wear between Item 3 and Item 5	-.020		
28-13255	4	End Cap Assembly	O.D. 1.315 to 1.318	-.0005	Not Repairable	Replace End Cap
			Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace End Cap
			Bushing wear (See Item 5 below)			
07DU08	5	Bushing	O.D. .530	±.005	Not Repairable	Replace Bushing
28-13279	6	Spring	Free length 12.4 to 12.6	None Allowed	Not Repairable	Replace Spring
			Visual inspect side of spring for wear caused by rubbing.	.010	Not Repairable	Replace Spring
28-13256	7	Shaft	Threads (no rolled or missing threads)	None Allowed	Not Repairable	Replace Shaft
			Straightness (check with straight edge)	None Allowed	Not Repairable	Replace Shaft
28-13252	8	Spring Cap	O.D. 1.280	±.005	Not Repairable	Replace Cap
			Note: This dimension wears oval-shaped from rubbing against the housing walls.	Maximum .005 out of round	Not Repairable	Replace Cap

Rev. 13
Jan 5/24

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 11-8. Inspection Requirements – Spring Capsule Assembly

Part Number	Fig. 11-19 Item Number	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-13253	13	Spring Housing	Ends of housing bored for end cap assembly, bore dia. 1.319 to 1.320	+ .0002	Not Repairable	Replace Housing
			Housing wall thickness .030 to .040, inspect for wear in the I.D.	Max. .005 wear allowed		
			Shaft hole dia. .249 to .251	+ .0005	Not Repairable	Replace Housing
28-13250-1, -11	14	Anchor	Bushing hole dia. .377 to .378	+ .0003	Not Repairable	Replace Anchor
			Shaft hole bore dia. 1.376 to 1.380	+ .0005	Not Repairable	Replace Anchor
			Bottom edge (nearest to the pylon)		.050 (1.3 mm)	Chamfer as required for clearance with pylon
28-13254	15	Shaft	Shaft O.D. .250	±.0005	Not Repairable	Replace Shaft
			Threads (no crossed or missing threads)	None Allowed	Not Repairable	Replace Shaft
28-13251	16	Retainer	O.D. 1.315 to 1.318	None Allowed	Not Repairable	Replace Retainer
			Shaft hole dia. .249 to .250	+ .0005	Not Repairable	Replace Retainer

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-11-83

Rev. 13
Jan 5/24

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.







Figure 11-20. Belt Tension Assembly Pylon Mount Inspection Areas

SECTION 12

FLIGHT CONTROLS

TABLE OF CONTENTS

Paragraph	Description	Page
12-1	Troubleshooting the Articulated Rotor System	MM-12-3
	A. General	MM-12-3
	B. Problems, Checks, Solutions	MM-12-3
12-2	Main Rotor Blade Tracking	MM-12-5
	A. Installation of Equipment	MM-12-7
	B. Tracking Procedure	MM-12-7
	C. Tabbing Out Feedback	MM-12-9
	D. Hover Tracking	MM-12-10
	E. Forward Flight Tracking	MM-12-10
	F. Lateral Balancing	MM-12-12
	G. Clock Angle Corrections	MM-12-14
12-3	Collective Pitch Control Stick	MM-12-19
	A. Description	MM-12-19
	B. Removal – Pilot Collective -	MM-12-19
	C. Installation – Pilot Collective	MM-12-19
	D. Removal – Copilot Collective	MM-12-20
	E. Installation – Copilot Collective	MM-12-20
12-4	Collective Trim System	MM-12-22
	A. Removal	MM-12-22
	B. Disassembly	MM-12-25
	C. Assembly	MM-12-25
	D. Installation	MM-12-26
	E. Rigging	MM-12-26
12-5	Cyclic Pitch Control Stick	MM-12-27
	A. Description	MM-12-27
	B. Cyclic Stick - Removal	MM-12-27
	C. Cyclic Stick - Installation	MM-12-27
12-6	Lateral and Longitudinal Trim Actuators	MM-12-28
	A. Troubleshooting	MM-12-28
	B. Removal – Lateral Trim Actuator	MM-12-28
	C. Removal – Longitudinal Trim Actuator	MM-12-30
	D. Disassembly – Trim Actuator	MM-12-30
	E. Trim Actuator Part Replacement	MM-12-30
	F. Assembly – Trim Actuator	MM-12-32
	G. Installation – Lateral Trim Actuator	MM-12-33
	H. Installation – Longitudinal Trim Actuator	MM-12-33
12-7	Flight Control Rigging	MM-12-34
	A. Preliminary Rigging	MM-12-34
	B. Cyclic Rigging – Seat Deck Area	MM-12-34
	C. Collective Rigging – Seat Deck Area	MM-12-36

SECTION 12

FLIGHT CONTROLS

TABLE OF CONTENTS

Paragraph	Description	Page
	D. Cyclic Rigging to Swashplate	MM-12-39
	E. Main Rotor Hub – Cyclic and Collective Rigging	MM-12-39
12-8	Cyclic Azimuth Check	MM-12-42
	A. Verification of Rigging.....	MM-12-42
	B. Autorotative RPM Adjustment	MM-12-43
12-9	Cyclic Trim Springs Rigging Procedure	MM-12-44
	A. Lateral Bias Spring Installation	MM-12-44
	B. Lateral Adjustment.....	MM-12-44
	C. Longitudinal Bias Spring Installation.....	MM-12-44
	D. Longitudinal Adjustment	MM-12-44
12-10	Lower Swashplate Assembly	MM-12-46
	A. Removal	MM-12-46
	B. Disassembly	MM-12-46
	C. Inspection	MM-12-47
	D. Assembly.....	MM-12-50
	E. Installation	MM-12-53
12-11	Upper Swashplate Assembly	MM-12-58
	A. Removal	MM-12-58
	B. Disassembly	MM-12-60
	C. Troubleshooting.....	MM-12-60
	D. Inspection	MM-12-62
	E. Assembly.....	MM-12-62
	F. Installation	MM-12-64
12-12	Main Rotor Push Pull Rods	MM-12-70
	A. Removal	MM-12-70
	B. Inspection	MM-12-70
	C. Installation	MM-12-70
12-13	Flight Test Procedure	MM-12-75
	A. Preliminary Checks.....	MM-12-75
	B. Flat Pitch Test.....	MM-12-75
	C. Hover Test	MM-12-76
	D. Cruise Flight Test	MM-12-77
	E. Autorotation Check	MM-12-78
	F. V _H and V _{NE} Checks	MM-12-78
	G. Flight Check – Lateral Trim	MM-12-79

12-1 TROUBLESHOOTING THE ARTICULATED ROTOR SYSTEM

A. General Information

Helicopter vibration and cyclic feedback are often attributed to an out-of-track main rotor system when the actual cause can be traced to components within the system that are worn, damaged or out of adjustment.

The following troubleshooting guide is provided to direct maintenance personnel to possible problem areas within the rotor system that can cause vibration or roughness.

This guide covers some of the problems and related causes that can be checked prior to attempting to track the blades. Performing the suggested checks and attention to routine maintenance schedules will help reduce time unnecessarily spent in attempting to track blades that may not be the cause of the problem.

B. Problems, Checks, and Solutions

NOTE: While this is not a complete listing of possible problems that could produce system vibration, it illustrates the fact that proper maintenance and inspection of system components can reduce maintenance time involved in trying to track blades that are reacting to problems elsewhere in the system.

1. Aircraft develops a sudden roughness or cyclic feedback during flight.

<u>Cause</u>	<u>Check</u>	<u>Solution</u>
(a) Lamiflex bearing failure.	Disconnect the rotor pitch links at the upper walking beams (See Figure 1, Item A) and flex the blade grip in no more than a 30° (i.e. ± 15°) arc. Failure of the blade grip to spring back indicates a failed lamiflex bearing.	Replace lamiflex bearing.
(b) Main rotor damper seized or relief valve stuck or open.	Cycle blades fore and aft to move damper piston in and out. Failure of damper to cycle indicates a restrictor is plugged.	Disassembly and clean damper and restrictor. Replace relief valves.
(c) Leading edge tape bubbling, loosening, or peeling (if blade tape is used).	Inspect tape for separation from blades.	Repair or replace leading edge tape (para. 9-10.S)
(d) Main rotor blade/ leading/trailing edge separation occurring.	Inspect blades for evidence of separation.	Replace or repair blade.
NOTE: Replacement blades must be matched by Enstrom Helicopter Service. Provide serial numbers of good blades and helicopter serial number. Blade repairs must be performed by an authorized blade repair facility.		
(e) Main rotor blade suffered strike.	Inspect blades for evidence of strike damage.	Extent of damage will determine if the blade requires replacement.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2. Aircraft's first flight is rough or has cyclic feedback; previous day's flight was smooth.

<u>Cause</u>	<u>Check</u>	<u>Solution</u>
(a) Trapped air in the dampers.	Check air in dampers.	Bleed damper.
(b) Lamiflex bearing failure	Disconnect the rotor pitch links at the upper walking beams and flex the blade grip in no more than a 30° (i.e. ± 15°) arc. Failure of the blade grip to spring back indicates a failed lamiflex bearing.	Replace lamiflex bearing.
(c) Leading edge tape bubbling, loosening, or peeling (if blade tape is used).	Inspect tape for separation from blades.	Repair or replace leading edge tape (para. 9-10.S)
(d) Grip seal pushed out during servicing	Check that the seals are installed in the grips.	Remove purge plug and push seal back in.
(e) Main rotor blade tab inadvertently bent.	Check tab angles. Inspect tabs for damage or deformation.	Reset tab angles as recorded on the "Blade Information Sheet", or replace tabs if damaged.
NOTE: If tab angles are not available, contact Enstrom Helicopter Service for original angles. Provide aircraft serial number.		
(f) Main rotor blades suffered "hangar rash" damage.	Inspect blades for evidence of damage.	Extent of damage will determine if blade replacement is required.
(g) Improper main rotor blade grip servicing	Check lubrication procedure in accordance with para. 4-28.	Relieve any internal pressure by removing purge screw feathering the blade grip. Then replace the purge screw.

3. Aircraft generally develops in increasing roughness or cyclic feedback over a period of days.

<u>Cause</u>	<u>Check</u>	<u>Solution</u>
(a) Trapped air in the dampers.	Check air in dampers.	Bleed damper.
(b) Lamiflex bearing failure.	Disconnect the rotor pitch links at the upper walking beams and flex the blade grip in no more than a 30° (i.e. ± 15°) arc. Failure of the blade grip to spring back indicates a failed lamiflex bearing.	Replace lamiflex bearing.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(c) Leading edge tape bubbling, loosening, or peeling (if blade tape is used).	Inspect tape for separation from blades.	Repair or replace leading edge tape (para. 9-10.S)
(d) Worn linkage. Dogleg uni-ball bearings worn excessively (Figure 12-22, Item 10). Overall control system rod end bearings or bellcrank spacers/bushings are worn.	Check the swashplate dog leg assemblies for excessive bearing play/wear (paragraph 12-11.D)	Reswage or replace bearings as required. Replace worn components as required.
(e) Blade paint, spar flaking, voids, skin, doublers, or retention plate damage.	Check the blade assembly condition (See paragraph 9-9 and limits in Figure 9-20).	Repair damage in accordance with paragraph 9-10, A , as applicable. If voids exceed limits, replace blade.
(f) If aircraft is new, touching up the blade track may be required due to wear in and seating of system components.	Check track. <u>NOTE:</u> Refer to the tracking procedures in Section 12-2.F	Track blades.

12-2 MAIN ROTOR BLADE TRACKING

NOTE: The Honeywell Chadwick 2000 system installation and operation are described in the following instructions. Follow the operating instructions for the equipment being used if different than the instructions for the Chadwick 2000.

NOTE: This procedure should be followed when using the MicroVib™II and ACES systems with modifications required by the individual system used.

NOTE: Previously published tracking instructions are not optimum for tracking helicopters using modern tracking equipment including Chadwick 177 and 8350 models and/or on helicopters that have blades with leading edge spars manufactured by Universal. Universal spar blades can be identified by the serial number that is stamped on the root of the blade. Main rotor blade serial numbers are identified one of two ways: a 16-digit series, XXXX-YZZ-ZZZZZ-Z, where XXXX is the blade S/N, and Y is the spar code, and ZZ-ZZZZZ-Z is the Enstrom part number; or a 5-digit series, XXXX-Y where XXXX is the blade S/N, and Y is the spar code.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Blades manufactured with Universal spars must be hover tracked to .2 IPS or less before any attempt is made to work out the cyclic feedback; otherwise, the cyclic feedback will return when the hover is tracked.

NOTE: Blades manufactured with Martin, Reynolds, or Alcoa spars, can be tracked with the following procedures, but the initial hover track segment can be eliminated before working out the cyclic feedback with the outboard tabs.

NOTE: Do not change the tip weights in the blades from original factory settings.

NOTE: If there is no cyclic feedback and the helicopter has been flying satisfactorily, it is recommended not to change outboard tab settings.

The purpose in tracking the main rotor blades is to obtain a smooth ride. This is accomplished by adjusting the blade track to reduce vibration. An out-of-track condition will produce a vibration, usually a one-per rev which is felt as a vertical vibration, however for the rotor system to be in track, it does not necessarily mean that the blades are flying in the same plane. With the advent of modern digital tracking equipment it has been found that the best ride is not necessarily the result of the blades flying in plane, but in a track that gives the least magnitude of vertical vibration. For this reason, Enstrom recommends that the strobe light only be used on the ground for initial ground track or for initial hover track if the initial ride is unacceptably rough.

The tracking procedure (vertical) follows this flow chart:




Figure 12-1. Tracking Procedure Flow Chart

A. Installation of Equipment

1. Install the optical sensor on the fuel tank (F-28F) or on the top air intake fairing (280FX) (Figure 12-2).
2. The number one blade (Target blade) must be at the 12 o'clock position relative to the front of the helicopter when the magnetic pick-up is opposite the interrupter on the swashplate, or when the optical sensor is opposite the reflective tape on the mast.
3. Install the vertical velocimeter on the right side of the instrument panel pedestal (Figure 12-3).

NOTE: Enstrom recommends not using a strobe light to track blades. Three-blade rotor systems do not necessarily fly in track and the strobe may produce misleading information and lengthen the tracking procedure.

4. Install the strobe light, if desired, or if there is reason to believe that the initial hover will be unacceptably rough.
5. Set up the analyzer using the manufacturer's instructions and the following parameters:
 - a. Three main rotor blades
 - b. Counterclockwise rotation when viewed from above
 - c. 350 RPM

B. Tracking Procedure

1. Grease the flapping bearings (para. 4-30).
2. Bleed the main rotor dampers (para. 4-18).

NOTE: If the helicopter is already flying reasonably well do not make any adjustments to the tabs at this time.

3. Set the tabs at recorded angles on the "Blade Information Sheet" or zero all the tabs.

WARNING: The following steps are to be performed by authorized personnel.

4. Ground run helicopter with rotor engaged at full "flat pitch" rpm.
5. If the strobe light is being used, observe the track of the blades and use pitch links to adjust the track into a reasonable flat track.
6. Hover the helicopter into the wind at 350 RPM.

NOTE: The best results are obtained if the helicopter is loaded so that the helicopter is relatively heavy. Normally, adding weight will make the blades fly at a higher angle of attack and will increase the roughness of the ride, while as the helicopter gets lighter from fuel burn, the ride will improve.




Figure 12-2. Optical Sensor Installation (280FX)



Figure 12-3. Velocimeter Installation (280FX)

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- Record the ips reading and the clock angle. Using the Vertical Velocimeter Channel B Polar Chart (Figure 12-4), adjust track for ips readings of less than .2 using pitch links.

NOTE: If the move line of the weight change does not coincide with the move lines on the chart, use the "Clock Angle Correction" procedure (para. 12-G).

NOTE: The rotor system must be hover tracked to .2 ips or less before performing the procedure to tab out cyclic feedback.

C. Tabbing Out Feedback

Cyclic feedback is a pulsing felt in the cyclic stick at main rotor 1/rev frequency. Tabbing out cyclic feedback is the most difficult and the most important procedure in achieving optimum ride in Enstrom helicopters with minimum cyclic vibration. Less than optimum outboard tabbing will result in excessive inboard tab to achieve a smooth ride and also excessive cyclic stick vibration. Unfortunately there is no reliable method of determining the correct outboard tab other than trial and error.

- Create a chart such as the one shown below to record the results of the tabbing runs.

Tab	Result
1 Up	
1 Down	
2 Up	
2 Down	
3 Up	
3 Down	

- Operate the helicopter on the ground at full flat pitch blade RPM (350 RPM).
- Move the cyclic six to eight inches in a forward and aft movement at approximately one cycle per second and feel for feedback in the cyclic motion.

NOTE: Feedback will not necessarily be indicated by cyclic stick shake, although stick shake will result from significant feedback.

- Stop the blades and add 2 degrees up to the #1 blade outboard tab.
- Run the helicopter again using the same procedures and check the cyclic for feedback again. The purpose of this procedure is to compare the feedback to the original tabbing and to the last tab attempt. The severity of the feedback will stay the same, get better or get worse. Record this result in the table above.
- If the feedback is eliminated, this procedure is finished. If the magnitude of the cyclic feedback either stays the same, or worsens, then change the setting on the same outboard tab to two degrees down. If the feedback gets better but is still present, add one more degree. Do not use more than 4° in any tab.

7. Run the helicopter again and using the same procedure, compare the magnitude of the cyclic feedback. Again, it should either be eliminated, stay the same or get worse. If it stays the same or gets worse, then set the #1 blade outboard tab back to zero, and add two degrees up to the #2 blade outboard tab.
8. Continue this procedure until each blade has been checked for both up and down tab, or until the feedback has been eliminated.
9. By following this procedure it should be possible to eliminate the cyclic feedback with one outboard tab adjustment on one blade.

D. Hover Tracking

1. Using pitch links, re-track the hover to less than .2 ips using Figure 12-4 (vertical polar chart). If the above procedure is followed, once the hover has been tracked smooth, the cyclic feedback should not reoccur.

E. Forward Flight Tracking

1. Forward flight is tracked using the inboard blade tabs.
 - a. Fly the helicopter at normal cruise settings (29 in MP) and record the ips reading and the clock angle.
 - b. Using the same polar chart (Figure 12-4) adjust the forward flight to less than .2 ips with the inboard tabs.

NOTE: If addition of inboard tab affects the hover, take that tab out again and try opposite tab on the other two blades.

NOTE: When making clock angle corrections, if a tab change does not improve the ips reading, it is advised to take the tab adjustment out again and try adjusting the inboard tab on another blade. Failure to follow this procedure will result in excessive tab amounts on all the blades.

2. Continue this procedure until the forward flight ips reading is .2 or less.




Figure 12-4. Vertical Accelerometer Channel "B" Polar Chart

F. Lateral Balancing

CAUTION: Balancing the main rotor blades should only be necessary if work has been done to the blades that may have created an out of balance condition. An out of balance exists **ONLY** if the Lateral IPS reading is higher than the Vertical IPS reading.

Reading the Lateral channel is recommended as a troubleshooting procedure to isolate a faulty component that is creating an out of balance condition.

If work has been done to the blades as per paragraph 12-1, follow the procedures listed below.

1. It is not recommended to change tip weights in the Enstrom rotor system because there is no centering mechanism in the hydraulic lead-lag dampers. Changing tip weights usually results in the blade flying in different lead-lag position but will not cure the underlying cause of a lateral imbalance.
2. If a set of blades is suspected to be out of balance, they can be statically balanced as a set. Contact Enstrom Product Support for information about static balancing blades or obtaining a static balance kit.
3. The Lateral Accelerometer Channel "A" Polar Chart (Figure 12-5) can be used to help determine which axis (lead-lag bearing, damper, or out-of-balance blade is causing the lateral vibration.
 - a. Install the optical sensor and a velocimeter on a top fuel tank screw, indexed 90° to the longitudinal axis of the helicopter.
 - b. Obtain a vertical and lateral ips and clock angle reading. The higher of the two readings is usually the axis that is causing the vibration.
 - 1) IPS readings around .2 or less are unreliable for determining if the vibration is vertical or lateral.
 - 2) A significant ips vibration in either axis will pull up the ips reading of the other axis also. (A high vertical will also cause a high lateral and vice-versa.)
 - 3) Plot the clock angle of the lateral reading. This should indicate the blade axis that is causing the lateral vibration.
 - 4) It may be necessary to make a temporary weight change in the indicated blade to establish if there is a clock angle correction required on the "A" chart.




Figure 12-5. Lateral Accelerometer Channel "A" Polar Chart

G. Clock Angle Corrections

NOTE: The clock angle correction is seldom the same in hover as it is in forward flight so when the tracking progresses to the forward flight phase, a new chart should be used, and the correction will have to be figured again.

NOTE: In some cases, particularly when the ips readings progress from a large number to a small number, the clock angle correction may change or go away entirely. The technician needs to plot all the moves and to be ready to recalculate or abandon the clock angle correction, if needed.

If a series of plotted blade track corrections move in a circular direction on the polar chart rather than moving toward the center of the chart, a clock angle correction is required. The following procedure was developed using the Chadwick Vibrex 2000 balance system. The procedure can be adapted for use with any of the digital balance boxes when the internal learning program is disabled.

1. A reading of .6 ips at a clock angle of 3:30 for the first hover run is plotted on the polar chart (Figure 12-6).
2. #2 blade is adjusted approximately 1/3 flat down. A reading of .5 ips at a clock angle of 1:30 for the second hover run is plotted (Figure 12-6.1). Clearly, the adjustment did not produce the expected move on the polar chart. This indicates that the polar chart is not correctly aligned to the helicopter.
3. Observation of run #1 and run #2 plots indicates that the tracking response is following the #3 blade axis line. Therefore, the blade correction move lines must be shifted clockwise one flat (60°) (Figure 12-6.2). This is the Clock Angle Correction.
4. According to the corrected chart, the #3 blade should be adjusted 1/3 flat down. A reading of .2 ips at a clock angle of 1:00 for the third hover run is plotted on the corrected chart (Figure 12-6.3). The move corresponds well with the corrected chart and the tracking procedure is complete.




Figure 12-6. Main Rotor Clock Angle Correction Example




Figure 12-6.1. Main Rotor Clock Angle Correction Example

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 12-6.2. Main Rotor Clock Angle Correction Example

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 12-6.3. Main Rotor Clock Angle Correction Example

12-3 COLLECTIVE PITCH CONTROL STICK

A. Description

The collective pitch control stick controls rate of climb when pulled upward by increasing the pitch of all three main rotor blades simultaneously and to the same degree. Downward movement of the collective stick decreases the pitch of the blades which decreases lift on the rotor and allows for a controlled descent. The collective pitch control stick is incorporated into the throttle correlator system. This mechanism combines the throttle motion with the collective stick movement such that the proper power inputs are automatically established as the collective stick is moved. The correlator is designed to keep the rotor/engine rpm within the desired green band for the majority of all flight regimes. Friction control is provided on the throttle grip of the collective stick. See Figure 12-7 for locations of the friction control points.

For F-28F S/N 809 through S/N 832 and 280FX S/N 2001 through S/N 2166, the engine starter button is located on the end of the pilot's and co-pilot's collective sticks (if equipped with dual start). Subsequent S/N are equipped with an illuminated control switch box mounted on the forward end of the collective stick. The control box includes the starter button, and forward and aft landing light switches.

B. Removal – Pilot Collective (Figure 12-7)

1. Remove the fiberglass cowl over the collective stick.
2. Disconnect the electrical wiring, as applicable.
 - a. Disconnect the starter button wires at the the quick disconnect terminals.
 - b. (Illuminated collective control only) Disconnect the electrical harness from the electrical connector on the forward side of the seat deck.
3. Remove bolt (1) connecting the throttle bellcrank to the collective stick

NOTE: Do not disconnect the co-pilot collective linkage or the correlator linkage attached to the throttle bellcrank.

4. Cut safety wire and remove bolt (2) from the top of the collective bellcrank.
5. Remove the collective stick from the collective and throttle bellcranks. Keep the DU washer (3) for reinstallation.

C. Installation – Pilot Collective

1. Install the collective stick into the collective bellcrank and align the holes.
2. Install washer and bolt (2). Torque bolt and safety wire with .032 wire.
3. Install DU washer (3) on stick with the DU side of the washer facing forward toward grip.
4. Install the throttle bellcrank and align holes.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

5. Install bolt (1), washers, nut and torque.
6. Connect the electrical wiring, as applicable.
 - a. Connect the wire terminals for the starter button.
 - b. (Illuminated collective control only) Connect the electrical harness to the connector on the forward side of the seat deck.
7. Cycle the collective stick up and down and rotate throttle to check freedom of movement.
8. Install the fiberglass cowl and screws.

NOTE: Grease or oil build-up on torque tube may cause collective friction to slip. To remedy this problem spray Loctite 7471 Primer T, or equivalent, into slotted area of collective clamp on torque tube until oil is removed.

D. Removal – Copilot Collective


1. (Illuminated collective control only) Disconnect the electrical harness from the electrical connector on the forward side of the seat deck.
2. Lift tab of the expando pin (4) to a vertical position and pull to remove.
3. Remove the co-pilot's stick from collective bellcrank.

E. Installation – Copilot Collective

1. Align the slot in the end of collective stick with the bolt in the collective bellcrank and slide into place.
2. Align the expando pin holes and install the pin.
3. Flip eccentric tab of the expando pin to secure.
4. (Illuminated collective control only) Connect the electrical harness to the connector on the forward side of the seat deck.

NOTE: To adjust tightness of the expando pin, loosen the set screw on side and rotate the pin to the required tension. Tighten the set screw. The expanding segments must be contained for tight fit.

NOTE: The expando pin can be folded down in one of two different positions but only one position locks it in place. The correct position is the when the cam causes the pin to expand and it is the position that requires the most force to push the lever down.



- | | | | |
|----|-------------|----|-------------------------|
| 1. | Bolt | 6. | Threaded Shaft |
| 2. | Bolt | 7. | Check nut |
| 3. | DU Washer | 8. | Spring Capsule Assembly |
| 4. | Expando Pin | 9. | Pivot Retainer Strap |
| 5. | Control Rod | | |

Figure 12-7. Collective Control System

12-4 COLLECTIVE TRIM SYSTEM

NOTE: Refer to Service Information Letter SIL 0184, latest revision, regarding a collective trim system update to simplify collective balance adjustment.

A. Collective Trim Capsule Removal (Figure 12-9)

1. Remove the fiberglass seat deck.
2. With the collective stick down and the spring capsule in compressed position, install special tool T-0022 between bottom of the hex nut and the top of the spring housing.
3. Secure tool T-0022 in position by wrapping upper end with .032 safety wire (Figure 12-8).
4. Release the collective friction and gently raise the collective so that the capsule is fully extended into tool T-0022.

WARNING: With the spring capsule in compressed position there is approximately 180 lbs of force exerted by the springs. Handle with extreme care.


5. Remove nuts (1) and washers (2) from the spring capsule pivot (3).
6. Remove bolts (5), washers (6), and nuts (7) from brackets (4). Remove brackets.
7. Remove bolt (9), washers (10) and nut (11) from the pivot retainer straps (8). Remove spacer (12).
8. Slide the pivot retainer straps (8) outboard on torque tube to detach from capsule pivot (3).

NOTE: The pivot retainer straps must rotate freely on the collective torque tube. The strap bearing over the torque tube should be lubricated with Tri-Flow brand lubricant (or equivalent).

9. Remove bolt (13), nut (15), and washers (14) from the upper end of spring capsule.
10. Carefully remove the spring capsule assembly.
11. To remove tie rod assembly from seat, remove bolt (19), washers (14) and (16), spacer (20) and nut (15).



Figure 12-8. Collective Spring Capsule in Holding Tool T-0022
(As removed from the collective trim system)



- | | | | |
|-----|----------------------|-----|-----------------|
| 1. | Nut | 15. | Nut |
| 2. | Washer | 16. | Washer |
| 3. | Capsule Pivot | 17. | Spacer |
| 4. | Bracket | 18. | Bellcrank |
| 5. | Bolt | 19. | Bolt |
| 6. | Washer | 20. | Spacer |
| 7. | Nut | 21. | Check Nut |
| 8. | Pivot Retainer Strap | 22. | Tie Rod |
| 9. | Bolt | 23. | Link |
| 10. | Washer | 24. | Spring Housing |
| 11. | Nut | 25. | Spring |
| 12. | Spacer | 26. | Washer |
| 13. | Bolt | 27. | Spring Retainer |
| 14. | Washer | 28. | Link Assembly |

Figure 12-9. Collective Trim, Spring Capsule Assembly

B. Collective Trim – Disassembly

1. Carefully place the spring capsule assembly horizontally between jaws of bench vise.
2. Cut safety wire from special tool T-0022.
3. Slowly rotate the vise handle to release spring pressure until all tension is relieved.
4. Remove spring housing (24), spring (25), washer (26), and spring retainer (27).
5. Remove the spring capsule pivot (3) from spring retainer (27).
6. Rod assembly - break torque on the check nuts (21) and turn the link (23) and link assembly (28) to remove from the tie rod (22).

C. Collective Trim – Assembly (Figure 12-9)

1. Apply grease (MIL-PRF-81322) to spring (25).
2. Install the spring capsule pivot (3) on spring retainer (27) with 3 to 4 threads extended above spring capsule pivot.
3. Install washer (26) in the spring retainer (27).
4. Install spring (25) into spring retainer (27).
5. Install spring housing (24).
6. Place tool T-0022 on the spring capsule and carefully compress the capsule in vise until lip of tool locks between the ears of spring housing (24) (Figure 12-8).

WARNING: With the spring capsule in compressed position, there is approximately 180 lb of force exerted by the springs. HANDLE WITH EXTREME CARE.

7. With the spring capsule still in the vise, wrap tool T-0022 with .032 safety wire to secure in position.
8. Install check nuts (21) on the tie rod (22).
9. Install link (23) and link assembly (28) on tie rod (22), leaving the check nuts loose for adjustment.

D. Collective Trim – Installation (Figure 12-9)

1. Install bushing (20) into link assembly (28).
2. Place washers (16) on each side of the link assembly (28) and install assembly into seat mount.
3. Install bolt (19), washers (14) and nut (15). Torque (30-40 in-lb/3.4-4.5 Nm). Ensure the link assembly (28) pivots in the seat mount.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4. Install spacer (17) into bellcrank (18).
5. Place washers (16) on each side of bellcrank (18) and carefully slide the spring capsule assembly into position.
6. Attach the spring capsule to bellcrank (18) with bolt (13), washers (14), and nut (15). Torque (30-40 in-lb/3.4-4.5 Nm). Ensure the spring capsule rotates in the bellcrank (18).
7. Slide pivot retainer straps (8) inboard and onto the spring capsule pivots (3).
8. Install straps (4) onto spring capsule pivots (3).
9. Place spacer (12) between upper end of the pivot retainer straps (8) and secure in place with bolt (9), washers (10), and nut (11). Torque 12-15 in-lb/1.4-1.7 Nm.

NOTE: Do not over torque bolt (9), as this will cause binding in the system. You must be able to rotate spacer (12) by hand after tightening.

10. Install washers (2) and nuts (1) and torque (12-15 in-lb/1.4-1.7 Nm). Ensure straps (4) rotate on the capsule pivot (3).
11. Install bolts (5) with washers (6) through brackets (4) and link (23). Adjustment of shaft (22) may be required to align bolt holes for the brackets. Install nuts (7) and torque (12-15 in-lb/1.4-1.7 Nm).
12. Cut safety wire and remove tool T-0022.

E. Collective Trim – Rigging (Figure 12-7)

NOTE: Rigging adjustments to be made with collective stick in down position

1. Adjust threaded shaft (6) so the upper end of the spring capsule assembly (8) is slightly aft of the forward edge of the pivot retainer straps (9).
2. Adjust the lower end of the spring capsule assembly (8) to balance out pilot's collective force load in flight.

NOTE: When correct adjustment is complete, the collective stick should stay in full down position with collective friction released. Collective should also have equal pressure in both directions of travel in flight.

CAUTION: For helicopters with T-T straps, the collective will normally stay down with the blades turning.

CAUTION: For Lamiflex bearing-equipped models only: When properly adjusted for collective trim in flight the collective may have a tendency to pop up during ground operation when blades are rotating at full flat pitch RPM. USE EXTREME CARE.

NOTE: If needed, contact Enstrom Product Support for additional assistance regarding collective trim adjustments.

- a. To correct for an out-of-balance condition, a light collective (easier up than down), release tension on the spring in the trim capsule.
 - b. For a heavy collective, increase spring tension.
3. Secure checknuts (7) against link (23) and link assembly (28).

12-5 CYCLIC PITCH CONTROL STICK

A. Description

The cyclic stick controls the movement of the helicopter forward, aft, left and right while in flight. Longitudinal control is obtained by the forward or aft motion of the cyclic stick, which causes the swashplate to tilt forward or aft at a 45° angle to the ship centerline, resulting in a variable pitch change of each rotor blade per revolution. With the swashplate in a forward angle, the rotor blades assume a higher pitch angle in the retreating sector of the plane of rotation, and a lower pitch angle to the advancing sector. This causes the blades to fly low in front and high in back, thus inducing a forward thrust component in the rotor system. This will cause forward flight at the desired speed when coordinated with the proper application of collective pitch and throttle. Rearward or lateral flight is similarly accomplished by moving the cyclic stick in the appropriate direction. The cyclic control stick has a grip that contains a cyclic trim switch, to reduce stick loads during flight

B. Cyclic Stick – Removal

1. Disconnect the snap fasteners and remove boots.
2. Disconnect the cannon plug from receptacle.
3. Remove the two bolts connecting cyclic stick to bellcrank.
4. Remove the stick assembly.

C. Cyclic Stick – Installation

1. Install the cyclic stick on bellcrank.
2. Install bolts, washers and nuts and torque.
3. Connect the cannon plug to seat receptacle.
4. Install the boot and snap fasteners.


12-6 LATERAL AND LONGITUDINAL TRIM ACTUATORS

A. Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Trim Actuator Inoperative	(1) Faulty motor (2) Faulty microswitch (3) Spring capsule binding on acme shaft (4) Binding of internal gears	Remove the actuator assembly. Troubleshoot in the following order to determine which area is causing problem. (1) Disconnect wires and remove the motor. Test motor with 12V or 24V battery for operation. (2) Remove microswitch assembly and inspect switches. (3) Rotate spring capsule on acme shaft and check for freedom of movement for full travel. (4) Remove rubber coupling and rotate internal gears with screwdriver to check for freedom of movement.

B. Removal – Lateral Trim Actuator (Figure 12-10)

1. Identify wires and their location before disconnecting from microswitches.
2. (12V) Disconnect wires from microswitches and from the quick disconnect attached to ground wire.
3. (24V) Disconnect trim actuator electrical connector from the trim switch unit (TSU).
4. Remove bolt (3), light washers (4), and nut (6) from the spring capsule (2).
5. Remove bolt (7), washers (4), and nut (6) from the housing (1).
6. Remove the lateral trim actuator from the seat structure.
7. Remove spacers (8) from housing (1).
8. Remove spacer (13) from the spring capsule (2).



- | | | | |
|----|----------------|-----|------------------------|
| 1. | Housing | 9. | Housing |
| 2. | Spring Capsule | 10. | Spring Capsule |
| 3. | Bolt | 11. | Bolt |
| 4. | Light Washer | 12. | Heavy Washer |
| 5. | Spacer | 13. | Spacer |
| 6. | Nut | 14. | Bolt |
| 7. | Bolt | 15. | Harper (ECD050) Washer |
| 8. | Spacer | | |

Figure 12-10. Trim Motor Installation

C. Removal – Longitudinal Trim Actuator (Figure 12-10)

1. Identify wires and their location before disconnecting from the microswitches.
2. (12V) Disconnect wires from the microswitches and from the quick disconnect attached to ground wire.
3. (24V) Disconnect the trim actuator electrical connector from TSU.
4. Remove bolt (11), light washers (4), heavy washers (12), and nut (6) from the spring capsule (10).
5. Remove bolt (14), harper washers (15), spacers (5), and nut (6) from the housing (9).
6. Remove the longitudinal trim actuator from the seat structure.
7. Remove spacer (8) from the housing (9).
8. Remove spacer (13) from the spring capsule (10).


D. Disassembly – Trim Actuators (Figure 12-11)

1. Separate the wire leads to the microswitch and disconnect.
2. Remove screws (1) and washers (2) attaching the switch assembly. Remove the switch assembly.
3. Rotate the spring capsule assembly (5) to remove from the acme shaft.
4. Remove nuts (13), lockwasher (12) and washer (11) from motor (7). Remove the motor.
5. Remove coupling (8) and snap ring (9).
6. Remove the remaining screws (1) and washers (2) from the shaft and cover assembly (6).
7. Gently tap the cover to one side and pull the acme shaft to remove the shaft and cover assembly (6) from the housing (4).
8. Tap face of housing (4) against work bench to remove the worm gear assembly (10).

E. Trim Actuator Part Replacement

NOTE: After determining which part of the trim actuator is causing a malfunction, replace the applicable item as follows:

1. Microswitch - remove the two screws and washers holding the switch in place and remove switch. Install new switch and replace the screws.



- | | |
|------------------------------------|------------------------|
| 1. Screw | 8. Coupling |
| 2. Washer | 9. Snap Ring |
| 3. Switch Assembly | 10. Worm Gear Assembly |
| 4. Housing | 11. Washer |
| 5. Spring Capsule Assembly | 12. Lock Washer |
| 6. (ACME) Shaft and Cover Assembly | 13. Nut |
| 7. Motor | |

Figure 12-11. Trim Motor Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

2. Spring capsule assembly – Acme nut replacement is accomplished by removing the three screws at base of capsule. Remove and replace nut. Reinstall the switch activator and screws to the base of the capsule.

The rubber bumper at base of capsule is attached by applying contact cement adhesive to both the bumper and acme nut. Press bumper firmly into place

3. Cover and acme shaft assembly, worm gear assembly, and motor assembly are replaced as assembly units.

F. Assembly – Trim Actuator (Figure 12-11)

1. Install the worm gear assembly (10) into the housing (4) until the aft bearing is aligned with the bearing seat in the housing. Do not install into the bearing seat at this time.
2. Apply grease (MIL-PRF-81322) in housing (4), packing the grease against the outer walls and the worm gear.
3. Install cover and shaft assembly (6) into housing (4) with the cover turned to side exposing worm gear (10).
4. With the cover seated in housing, push the worm gear assembly (10) into place, seating the bearings in place, and install the snap ring (9).
5. Rotate the cover into position and install two screws (1) and washers (2) in the cover holes located opposite the worm gear.
6. Rotate the worm gear with a screwdriver to check for binding in gears.
7. Install the coupling (8) onto slotted end of worm gear.
8. Align the slots in motor with the coupling and install the motor into position on the housing (4).
9. Install washer (11), lockwasher (12) and nut (13) on the motor studs and torque.
10. Apply grease (MIL-PRF-81322) to the threads of the acme shaft and turn the spring capsule (5) onto the acme shaft until the rubber bumper at the base of the spring capsule is approximately one inch from the cover.
11. Turn the switch activator of spring capsule to align with slot in the microswitch assembly (3) and attach to housing (4) using screws (1) and washers (2).
12. Torque the screws and lockwire (.032).
13. Connect wires to the switch.

G. Installation – Lateral Trim Actuator (Figure 12-10)

1. Install spacer (8) into housing (1).
2. Install spacer (5) into spring capsule (2).
3. Install the actuator assembly into the seat structure and align with mounts.
4. Install bolt (7) through light washer (4), seat structure mount and spacer (8).
5. Install light washer (4) and nut (6).
6. Install bolt (3) through washer (4), seat structure mount and spacer (5).
7. Install light washer (4) and nut (6). Torque nuts (6) in two places.
8. (12V) Connect wires at ground and microswitches.
9. (24V) Connect the electrical connector to the TSU.
10. Test the trim actuator for freedom of movement and full travel in both directions.

H. Installation – Longitudinal Trim Actuator (Figure 12-10)

1. Install spacer (17) into housing (9).
2. Install spacer (13) into spring capsule (10).
3. Install the actuator assembly into the seat structure and align with mounts.
4. Install spacers (16) on each side of housing (9) with the chamfered side of spacer facing outboard.
5. Install bolt (14) through harper washer (15), seat structure, and spacers (16) and (17).
6. Install harper washer (15) and nut (6).
7. Install a heavy washer (12) and light washer (4) on each side of the spring capsule (10).
8. Install bolt (11) through washers (4), seat structure, washers (12), and spacer (13).
9. Install washer (4) and nut (6). Torque nuts (6) in two places.
10. (12V) Connect wires at ground and microswitches.
11. (24V) Connect the electrical connector to the TSU.
12. Test the trim actuator for freedom of movement and full travel in both directions

12-7 FLIGHT CONTROL RIGGING

NOTE: Cyclic and collective rigging must be done in sequence starting with the cyclic pitch controls. A rigging check must be accomplished any time components of the control system have been removed and exact dimensions such as rod lengths or bellcrank angles are not available prior to re-installation of that component.

NOTE: Install the connecting rod ends during rigging as follows:

1. HMVV5M right hand rod end to the right, top, and aft.
2. HMLVV5M left hand rod end to the left, bottom, and forward.

A. Preliminary Rigging (Figure 12-12)

1. Level the helicopter with reference to the lower left hand and forward pylon bay tubes.
2. Remove the fiberglass seat deck and flooring panels.
3. Remove the side cowling panels above the engine compartment.
4. Disconnect control rods (13) and (14) from bellcranks (9) and (11).

B. Cyclic Rigging – Seat Deck Area (Figure 12-12)

1. Adjust rod (1) connecting the cyclic stick bellcranks until the bellcranks (17) and (18) are centered laterally in the stop ring hole. Secure the check nuts.

Adjustment check - move the cyclic stick full left and full right to assure both bellcranks (17) and (18) hit the stops

CAUTION: Check inspection holes in control rods for minimum thread engagement of rod ends. Rod end bearings must be centered between the bellcrank ears to allow full pivot after check nuts have been tightened.

2. Adjust rod (5) until the outboard edge of bellcrank (2) and the inboard edge of bellcrank (4) are parallel to each other and perpendicular to the firewall. Secure the jam nuts.

NOTE: When adjusting rod (5), the left hand rod end HMLVV5M must be adjusted one turn past witness hole and secured. All adjustments must be made by rotating the right hand rod end only.

3. Move the cyclic stick full forward and adjust rods (3) and (6) until both bellcranks (17) and (18) hit the stop ring.

Adjustment check - Pull the cyclic stick aft to assure the bellcranks are hitting the stops. Adjust if necessary.




Figure 12-12. Cyclic Rigging Chart

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

4. Secure jam nuts and move the cyclic stick laterally to assure the rod ends do not bind.

Adjustment check - Rotate the pilot's cyclic stick around the cyclic stop ring. Check that both left and right bellcranks maintain contact with the stop ring through 360 degrees of travel.

NOTE: If binding or interference exists, make slight adjustments to the rod lengths or reposition the rod end bearings to correct the condition.

5. Install cyclic centering tool T-1775 in the stop ring (Figure 12-13).
6. Position bellcrank (7) so the forward edge is in vertical position. Adjust length of rod (8) to hold this position. Secure check nuts.

Adjustment check - Remove centering tool T-1775 and move cyclic stick fore and aft to check rod end and check nut clearance to bellcrank.

7. Place the pilot's cyclic stick in the full forward position (bellcrank aft against stop) and centered laterally. Position bellcrank (9) so the lower edge is parallel to its cabin mount. Adjust length of rod (10) to maintain in this position (Figure 12-14). Secure check nuts.

Adjustment check - Cycle to check for interference.

8. Connect longitudinal trim actuator to bellcrank (7) if disconnected (para. 12-6, H).
9. Place the pilot's cyclic stick in the full left position and centered longitudinally. Position bellcrank (11) so the lower edge is parallel to its cabin mount. Adjust the length of rod (12) to maintain this position (Figure 12-14). Secure check.

Adjustment check - Cycle to check for interference.

NOTE: Recheck security of all check nuts and rod end clearances.

C. Collective Rigging – Seat Deck Area (Figure 12-7)

1. Place the collective control stick in full down position and tighten friction.
2. Adjust rod (5) to obtain 1/8" to 3/16" clearance between the collective bearing housing spacer and swashplate mount flange (Figure 12-15). Secure check nuts.




Figure 12-13. Cyclic Stick Rigging, Tool T-1775 Installed




Figure 12-14. Cyclic Bellcranks Parallel to Mount




Figure 12-15. Collective Housing to Seal Housing Clearance

D. Cyclic Rigging – To Swashplate

1. Install rigging tool T-1775 in the cyclic stop ring (Figure 12-13).

NOTE: Run the trim motors to slightly preload cyclic stick against tool.

2. Install swashplate centering tools T-1575 to hold the swashplate perpendicular to the main rotor shaft (Figure 12-16).
3. Connect rod (13) to the swashplate. Adjust the length of rod (13) until the attachment bolt slides freely into the bellcrank (11) (Figure 12-12). Install spacers and mount hardware. Secure the check nuts and hardware. See paragraph 12-10, E, for hardware attachment to the swashplate.
4. Connect rod (14) to the swashplate. Adjust the left hand rod end HMLVV5M at bellcrank (9) until the attachment bolt slides freely into the bellcrank (Figure 12-12). Install spacers and mount hardware. Secure the check nuts and hardware. See paragraph 12-10, E, for hardware attachment to the swashplate.

E. Main Rotor Hub – Cyclic and Collective Rigging

1. Level the aircraft along pylon bay tube inside the left engine door. Install the tripod stand under the tail rotor guard to hold ship level.

NOTE: Avoid standing on or sitting in the aircraft after leveling.

2. Phase main rotor blades 120° apart. This is accomplished by moving each blade grip until one inch of the damper piston shaft is exposed on each damper.
3. Rotate the main rotor hub until #1 grip is at the 97° azimuth position (Figure 12-17).

NOTE: The 90° position is to the right side of the helicopter. The 97° position may be checked by observing that the dog leg rod end bearing controlling the #1 blade is directly over and in line with rod (14) of Figure 12-12, Cyclic Rigging.

4. Place a bubble type protractor on the top flat area of the main rotor blade grip. Adjust the pitch change link to obtain 6.5 degrees ± .5 degree. Center the rod end bearings for full pivot and secure check nuts.

NOTE: Protractor will be positioned perpendicular to the leading edge of the blade.

5. Repeat the sequence for blades 2 and 3. Recheck #1 blade.




Figure 12-16. Installation of Swashplate Rigging Tool T-1575




Figure 12-17. Main Rotor Azimuth Positions

6. Remove tool T-1575.
7. Place the collective control stick in full up position.
8. Rotate #1 blade to the 97° azimuth position (Figure 12-17).
9. Set protractor at +19° and position it on top of the flat area of the blade grip. Adjust the collective up stop at the seat deck until the bubble is centered, giving +19 degrees ± .5 degree. Secure the collective up-stop check nut.
10. Remove tool T-1775.

12-8 CYCLIC AZIMUTH CHECK

A. Verification of Rigging

1. Rotate #1 blade to the 97° azimuth position (Figure 12-17).

NOTE: The 90° position is to the right side of the helicopter. The 97° position may be checked by observing that the dogleg rod end bearing controlling the #1 blade is directly over and in line with rod (14) of Figure 12-12.

2. Lower the collective stick to full down position and tighten friction. Recheck 6.5 degrees ± .5 degree measurement of the main rotor blade grip.
3. Move the cyclic stick to full aft position. Measure blade grip angle. Measurement to be 14.5 degrees ± .5 degree.

NOTE: If adjustments are required, adjust the left hand rod end HMLVV5M on rod (14) (Figure 12-12).

4. Move the cyclic stick to full forward position. Measure the blade grip angle. Measurement to be -2.5 degrees ± .5 degree.

NOTE: Total travel must be 17 degrees ± .5 degree.

NOTE: Because push-pull rod adjustments in the cyclic rigging affect all three main rotor blades equally, it is only necessary to do an azimuth angel check on one blade.

5. Rotate the main rotor hub until the dog leg rod end bearing controlling the #1 blade is directly over and in line with rod 13) of Figure 12-12, Cyclic Rigging.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

6. Move the cyclic stick to full right position. Measure the blade grip angle. Measurement to be 14.5 degrees \pm .5 degree.

NOTE: If adjustments are required, adjust rod (13) (Figure 12-12).

7. Move the cyclic stick to full left position. Measure blade grip angle. Measurement to be -2.5 degrees \pm .5 degree. Total travel must be 17 degrees \pm .5 degree.
8. Rotate the cyclic stick 360° around the stop ring to check for evidence of binding.

CAUTION: Upon completion of any adjustments to control system check to see if autorotative RPM is in a safe range during first ground run-up.

Range: 16 to 19 inches manifold pressure at 3050 RPM

NOTE: A high manifold pressure indicates a low autorotation RPM. A low manifold pressure indicates a high autorotation RPM. See Item B for autorotative RPM adjustment.

B. Autorotative RPM Adjustment

1. Determine the helicopter gross weight for adjusting autorotative RPM by consulting the Autorotational RPM Correction Chart (Figure 12-27).
2. Adjust rotor RPM.
 - a) Disconnect the pitch link rod ends at the walking beams on all three blades.
 - b) Rotate only the disconnected rod ends one full turn (360°).

NOTE: One 360° turn of the rod ends, shortening the pitch links, will decrease autorotative RPM by 10. One turn of the barrel = 20 RPM.

- c) Connect the pitch links to walking beams and safety.
 - d) Secure the jam nuts.
3. Flight check for performance.

12-9 CYCLIC TRIM SPRINGS RIGGING PROCEDURE

NOTE: The lateral bias spring installation is configured one of two ways. Helicopters certified to 2350 lb gross weight are configured as shown in Figure 12-18(a); Helicopters certified to 2600 lb gross weight (configured to Enstrom Specification Drawing 28-100015) are configured as shown in Figure 12-18(b).

A. Lateral Bias Spring Installation (Figure 12-18)

NOTE: The lateral bias spring is located on the left side of the seat structure.

1. Attach spring (1) to bracket (2) and to the third hole from forward end of bracket (3).
2. Flight check the helicopter to see if the desired lateral trim forces can be obtained.

B. Lateral Adjustment (Figure 12-18)

1. Maximum left lateral trim is obtained by moving the spring outboard on bracket (3).
2. Maximum right lateral trim is obtained by moving the spring inboard on bracket (3).

C. Longitudinal Bias Spring Installation (Figure 12-19)

NOTE: The longitudinal bias spring is located on the right side of the seat structure.

1. Attach spring (1) to bracket (2) and to the fourth hole from top of bracket (3).
2. Flight check the helicopter to see if the desired longitudinal trim forces can be obtained.

D. Longitudinal Adjustment (Figure 12-19)

1. Moving spring down on bracket (3) will provide maximum forward trim force.
2. Moving spring upward on bracket (3) will provide maximum aft trim force.

NOTE: Should locating the spring in the top hole of bracket (3) provide insufficient aft spring force, the bracket may be moved aft to the second notch and the choice of hole location repeated.




Figure 12-18. Lateral Bias Spring Installation

(a) Applicable to 2350 lb gross weight helicopters

(b) Applicable to 2600 lb gross weight helicopters configured to Enstrom Specification 28-100015




Figure 12-19. Longitudinal Bias Spring Installation

12-10 LOWER SWASHPLATE ASSEMBLY

A. Removal – Lower Swashplate Assembly (Figure 12-20)

1. Remove both side panel cowls.
2. Drain fuel tanks.
3. Disconnect fuel lines and remove the left side fuel tank (para. 13-10).
4. Disconnect the longitudinal cyclic rod (2) from lower bearing housing (1) by removing bolt (3), washers (4) and (5), spacer (6) and nut (7).
5. Disconnect the lateral cyclic rod (11) from bearing housing (1) by removing bolt (8), washers (9), and nut (10).
6. Disconnect rod ends (15) in three places from the lower swashplate housing (17) by removing bolts (16), spacers (14), washers (13) and nuts (12).
7. Cut safety wire and remove bolts (screws on older helicopters) (18) and washers (19) in six places.
8. Pull downward on lower bearing housing (1) to remove lower swashplate assembly.

B. Disassembly – Lower Swashplate Assembly (Figure 12-21)

1. Install tool T-0016 in the end of the tie rod (19). Place a wrench on the tool T-0016 to prevent the tie rod from rotating and remove the cotter pin (10), nut (11), light washer (21), washer (12), DU washer (13), and shims (14) from the tie rod.
2. Tap the tie rod out of the bushings (15) using an aluminum drift. Separate the lower universal housing (7) from the upper universal housing (18). Remove the spacers (20) from inside the bushings (15) in the housing.
3. Remove the shims (14) and the DU washer (13) from the tie rod (19).
4. Temporarily install the tie rod (19) in the universal shaft (17) to prevent it from rotating and remove the cotter pins (10), nuts (11), washers (12), DU washers (13), and shims (14) from both ends of the shaft (17).
5. Tap the end of the shaft with an aluminum drift to remove the shaft and sleeve (16) from the lower universal housing (7).
6. Tap the opposite sleeve to remove it from the lower universal housing.
7. Tap the sleeves from the upper universal housing (18) using an aluminum drift.
8. Hold the bolt (1) with a wrench and remove the cotter pin (10), nut (9), and washer (8).

CAUTION: A variation of the lower universal housing has a set screw plug that must be loosened to allow removal of the bolt (1).

9. If applicable, back out the set screw (22) in the lower universal housing (7).

10. Pull the bolt (1) and bearing assembly (3) and (4) from the lower universal housing (7).
11. Press the bolt (1) from the bearing (3) and remove slinger (6) and spacer (5).
12. Remove the retaining ring (2) and grease fitting from the housing (4).

WARNING: Use extreme caution when removing or installing heated parts and assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

13. Heat the housing (4) to approximately 250°F/121°C and remove the bearing (3) from the housing.
14. Press the DU bushings (15) from the sleeves (16).

C. Lower Swashplate Assembly – Inspection


1. Use the following procedure to inspect the lower swashplate assembly during periodic inspections (100 Hour/Annual):
 - a) Remove both side panel cowls, if not previously removed.
 - b) Disconnect the pitch change bellcranks located on the main rotor hub from the main rotor push-pull rods located in the mast and from the pivot brackets.
 - c) With the aid of an assistant, remove the collective friction and move the collective up and down throughout the range and wiggle the cyclic stick (movement of the collective and cyclic stick does not have to occur simultaneously). Observe and **carefully** feel the lower swashplate assembly for any looseness (e.g. vertical play at the universal joint or end play along the universal shaft and tie rod axes). Any looseness is most noticeable with a collective control reversal and/or reversal of the cyclic controls.

NOTE: Vertical looseness may also be evident at the collective stick as a sudden change in stick force or may exhibit itself as a clinking sound. Using a 9/16 inch crows foot and torque wrench set to 60 in-lb/6.8 Nm, check that the torque required to rotate the tie rod assembly at the nut on the end of the tie rod assembly is more than 60 in-lb/6.8 Nm. Do not remove the cotter pin from the nut during the check and stop the torque check if 60 in-lb/6.8 Nm is reached without the tie rod assembly rotating. Any rotation of the tie rod with less than 60 in-lb/6.8 Nm of torque is unacceptable.

NOTE: Refer also to paragraph 12-1, Troubleshooting.


- d) If neither looseness nor loss of torque is evident, reconnect the pitch change bellcranks and return the aircraft to service.
- e) If any looseness or loss of torque is found, remove the lower swashplate assembly from the aircraft and perform the following additional inspections:

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL



- | | | | |
|-----|----------------------------|-----|--------------------------|
| 1. | Lower Bearing Housing | 11. | Lateral Push-Pull Rod |
| 2. | Longitudinal Push-Pull Rod | 12. | Nut (P/N AN320-4) |
| 3. | Bolt | 13. | Washer |
| 4. | Washer | 14. | Spacer |
| 5. | 1/4 Harper Washer | 15. | Rod End (Dog Leg) |
| 6. | Spacer | 16. | Bolt |
| 7. | Nut | 17. | Lower Swashplate Housing |
| 8. | Bolt | 18. | Bolt |
| 9. | Washer | 19. | Washer |
| 10. | Nut | 20. | Cotter Pin |

Figure 12-20. Lower Swashplate Installation



- | | | | |
|-----|---------------------------|-----|-------------------------|
| 1. | Bolt (Shaft) | 12. | Washer |
| 2. | Retaining Ring | 13. | DU Washer |
| 3. | Bearing | 14. | Shim |
| 4. | Bearing Housing | 15. | DU Bearing |
| 5. | Spacer | 16. | Sleeve |
| 6. | Slinger | 17. | Universal Shaft |
| 7. | Lower (Universal) Housing | 18. | Upper Housing |
| 8. | Washer | 19. | Tie Rod Assembly |
| 9. | Nut | 20. | Spacer |
| 10. | Cotter Pin | 21. | Light Washer |
| 11. | Nut | 22. | Set Screw (if equipped) |

Figure 12-21. Lower Swashplate Assembly

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- 1) Inspect the universal joint for looseness/play by twisting and pushing and pulling the upper and lower housings of the lower swashplate against each other.
 - 2) Inspect the tie rod and universal shaft axis for end play by attempting to move the upper and lower housings against each other along the tie rod and universal shaft axes.
 - 3) Check the pre-load of the tie rod and universal shaft axis. The pre-load should be between 0.5 and 2.0 pounds (.23 and .91 kg) using a spring scale, with no noticeable end play.
 - f) Disassemble the lower swashplate assembly and inspect the detail parts in accordance with Table 12-1.
 - g) Replace unserviceable parts as required and reassemble the lower swashplate in accordance with paragraph 12-10, D.
 - h) Reinstall the lower swashplate assembly and reconnect the pitch change bellcranks.
2. See Table 12-1 for the detailed inspection requirements for the lower swashplate assembly.

D. Lower Swashplate – Assembly (Figure 12-21)

1. Remove the seal from one side of the bearing (3).

WARNING: Use extreme caution when removing or installing heated parts and assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

2. Heat the bearing housing (4) to approximately 250°F/121°C.
3. Apply a small amount of Loctite 277 to the O.D. of the bearing (3) and install the bearing (3) with the open side toward the “closed end” of the bearing housing (4). Allow the housing assembly to cool.

NOTE: Install the housing assembly onto the lower swashplate assembly with the retaining ring away from the swashplate.

4. Install the retaining ring (2) and grease fitting in the housing (4).

NOTE: Install the bolt with the head on the same side as the retaining ring.

5. Support the inner race of the bearing (3) and press the bolt (1) into the bearing.
6. Install the spacer (5) with the narrow side of the spacer against the inner race of the bearing.
7. Install the slinger (6) on the bolt (1).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- Lubricate (MIL-PRF-81322) the bolt (1) and install into the lower universal housing (7). Install the washer (8) and nut (9). Torque the nut and install a cotter pin. Apply VC3 Vibra-Tite over the end of the bolt, nut, and cotter pin.

NOTE: A variation of the lower universal housing (7) has a set screw plug (22) that must be installed upon reassembly.

- If applicable, apply a small amount of Loctite 277 to set screw (22) and install set screw into the lower universal housing (7).
- Install the DU bushings (15) into the sleeves (16) (4 places).
- Check the fit of the universal shaft (17) and the tie rod (19) in the bushings. The universal shaft and tie rod should move freely in the bushings. If required, use an expandable reamer and lightly ream the bushings so that the shaft and tie rod move freely in the bushings. Do not ream the bushings so they have free play (loose fit).

NOTE: The lower universal housing may be heated with a heat gun to allow easier installation of the sleeves. Do not exceed 250°F/121°C. Allow the parts to cool before shimming.

WARNING: Use extreme caution when removing or installing heated parts and assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

- Lubricate (MIL-PRF-81322) the O.D. of two of the sleeves (16) and the bores of the ears on the lower universal housing (7).
- Install one of the sleeves (16) into the lower universal housing using tool T-0100-1.

CAUTION: Ensure that the correct universal shaft, P/N 28-16223-19, is used when assembling the lower swashplate assembly. (The length of the bushing surface is 1.289 in ± .001 in/32.74 mm ± .03 mm). Failure to install the correct universal shaft can result in premature wear of the tie rod and universal shaft.

- Install the universal shaft (17) into the lower universal housing (7) through the ear without the sleeve and then install a sleeve (16) into the lower universal housing using T-0100-1. The shaft should rotate freely in the bushings.
- Shim the universal shaft using the following procedure:
 - Using a felt tip marker, place a mark on one of the ears on the lower universal housing and install a .020 in/.5 mm shim (14) on the end of the universal shaft (17). The mark indicates a .020 in/.5 mm shim is installed.
 - Install a DU washer (13) on the shaft (17) with the Teflon (grey) side of the washer against the sleeve (16).
 - Install a washer (12) on the shaft (17) with the pin towards the DU washer (13).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- d) Install the tie rod (19) into the universal shaft (17) to prevent the shaft from rotating and install a nut (11). Ensure the DU washer is properly seated on the retention pin on the washer (12). Torque the nut to 110-150 in-lb/12.5-17.0 Nm and check that the cotter pin hole is aligned. This may require installing different nuts until the proper torque and cotter pin hole alignment is achieved. Do not back the nut off for cotter pin alignment.
- e) Install a .020 in/.5 mm shim (14), DU washer (13), washer (12), and nut (11) on the opposite end of the universal shaft. Ensure the DU washer (13) is properly seated on the retention pin on the washer (12). Torque the nut to 110-150 in-lb/12.5-17.0 Nm and check that the cotter pin hole is aligned. This may require installing different nuts until the proper torque and cotter pin hole alignment is achieved.
- f) Tap each end of the universal shaft (17) with an aluminum drift and hammer to seat the stack up.
- g) Insert the tie rod or an appropriate size bolt in the tie rod bore of the universal shaft and check the preload with a spring scale at a 3 in/7.5 cm arm. The preload should be 1.5-2.0 lb/.68-.91kg. If too loose, fewer shims are required. If too tight, more shims are required. Ideal shimming of the assembly is to have equal amounts of shims on each end of the universal shaft; however, a .005 in/.13 mm maximum difference in shims is allowed from end to end to obtain proper preload.

NOTE: The upper universal housing may be heated with a heat gun to allow easier installation of the sleeves. Do not exceed 250°F/121°C. Allow the parts to cool before shimming.

WARNING: Use extreme caution when removing or installing heated parts and assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

15. Lubricate (MIL-PRF-81322) the O.D. of the two remaining sleeves (16) and the bores of the ears on the upper universal housing (18). Using tool T-0100-1, install the sleeves into the upper universal housing.

CAUTION: Ensure that the spacers used on the tie rod are the correct length (Refer to Table 12-1). Failure to install the correct length spacers can result in premature wear of the tie rod and universal shaft.

16. Install a DU washer (13) onto the tie rod (19). Ensure the Teflon (grey) surface is facing inboard and the DU washer is properly seated on the retention pin. Install a spacer (20) and then a .020"/.5 mm shim (14) onto the tie rod (19).
17. Place the upper universal housing over the lower universal housing and align the proper openings.
18. Insert the tie rod (19) through the sleeve in the upper housing that is in line with the dog leg ears of the lower housing, the universal shaft, and the opposite sleeve in the upper housing.

CAUTION: Ensure that the spacers (20) used on the tie rod are the correct length (Refer to Table 12-1). Failure to install the correct length spacers can result in premature wear of the tie rod and universal shaft.

19. Install the remaining spacer (20) onto the tie rod.
20. Install a .020 in/.5 mm shim, DU washer (13), washer (12), light washer (21), and nut (11) on the tie rod (19). Ensure the DU washer is properly seated on the retention pin on the washer. Using tool T-0016 to secure the tie rod, torque the nut to 110-150 in-lb/12.5-17.0 Nm and check that the cotter pin hole is aligned. This may require installing different nuts until the proper torque and cotter pin hole alignment is achieved.
21. Tap each end of the tie rod (19) with an aluminum drift and hammer to seat the stack up.
22. Install the lower swashplate assembly on tool, T-0134 (Plate Assembly), a spare bell housing, P/N 28-16112-1, clamped in a vise, or on the upper swashplate assembly.
23. Insert a bolt through one of the ears on the cyclic bearing housing and check the preload of the tie rod axis. The preload on the tie rod axis should be the same as the universal shaft preload \pm .25 lb/.11 kg. If too loose, fewer shims are required. If too tight, more shims are required. Ideal shimming of the assembly is to have equal amounts of shims on each end of the tie rod; however, a .005 in/.13 mm maximum difference in shims is allowed from end to end to obtain proper preload.
24. Install the cotter pins when the preload is set.

E. Lower Swashplate – Installation (Figure 12-20)

1. Install the lower swashplate with the attachment ears aligned to the doglegs (15).
2. Secure in place with washers (19) and bolts (18). Torque (30-35 in-lb/3.4-4.0 Nm) and lockwire (.025) the bolts in pairs.
3. Secure the doglegs (15) to the lower swashplate housing using bolts (16) and spacers (14).
 - a) Clean/Degrease the threads on the three bolts (16) using a suitable cleaner (contact cleaner, brake cleaner, etc. procured from local source).

NOTE: Spacers (14) are installed with chamfer inboard toward bearing in dogleg.

4. Install washers (13) and nuts (12) on bolts (16). Torque the nuts to 40-60 in-lbs/4.5-6.8 Nm and install the cotter pins (20) (3 places). Liberally apply a coating of Vibra-Tite VC-3 onto the nut and cotter pin installations.

NOTE: When torquing the nut to align the cotter pin hole, the nut must be turned in the direction of tightening; the nut may not be loosened to line up the cotter pin hole. Replace the nut, washer, spacer, and/or bolt as required if the cotter pin hole will not line up at the 40-60 in-lbs/4.5-6.8 Nm torque application.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

5. Install spacer (6) in the longitudinal push-pull rod (2).
6. With washers (5) on each side of spacer (6), insert push-pull rod (2) into the lower bearing housing (1).
7. Install bolt (3), washers (4) and nut (7) to secure the rod in place. Torque (30-40 in-lb/3.4-4.5 Nm) the nut and install the cotter pin (20).
8. Connect the lateral push-pull rod (11) to the housing (1) using bolt (8), washers (9) and nut (10). Torque (60-85 in-lb/6.8-9.6 Nm) the nut and install the cotter pin (20).
9. Rotate the cyclic stick to check for binding in the system. Check all connections for security.
10. Install the fuel tank and connect fuel lines. Install fuel and check for leaks.
11. Replace side panel cowls.
12. Perform a maintenance test flight (para. 12-13).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-1. Inspection Requirements – Lower Swashplate Assembly

P/N	Fig. 12-21 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16123-1	1	Bolt	Bearing surface Dia. .4723 to .4726	-.0002	Not Repairable	Replace Bolt
			Threads (crossed or missing)	None allowed	Not repairable	Replace Bolt
ECD009-11	3	Bearing	O.D. 1.2595 to 1.2598	No Tolerance Allowed	Not Repairable	Replace Bearing
			I.D. .4722 to .4724	No Tolerance Allowed	Not Repairable	Replace Bearing
			Ratcheting or roughness	None allowed	Not Repairable	Replace Bearing
28-16361-1	4	Bearing Assembly	Bolt holes in pivot ears for elongation	None Allowed	Not Repairable	Replace Housing
			Surface nicks or scratches	None Allowed	≤ .010 deep	Blend and polish out smooth
			Security of the uni-ball race in the housing	None Allowed	Not Repairable	Replace Housing
			Cracks	None Allowed	Not Repairable	Replace Housing

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-55

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-1. Inspection Requirements – Lower Swashplate Assembly

P/N	Fig. 12-21 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16228-1	5	Spacer	Nicks and gouges	None Allowed	≤ .003 deep	Polish out smooth
28-16387-1	6	Slinger	Check for bends in outer edges	.005	Not Repairable	Replace Slinger
28-16119-3, -5	7	Housing	Bushing bores Dia. .7500 to .7505 (-3) .7495 to .7500 (-5)	+ .0005	Not Repairable	Replace Housing
			Center bolt bore Dia. .4370 to .4380 (no galling allowed in this bore)	+ .0005	Not Repairable	Replace Housing
			Large bolt bore Dia. in the pivot ears .375 to .376	+ .0005	Not Repairable	Replace Housing
			Small bolt bore Dia. in the pivot ears .250 to .251	+ .0005	Not Repairable	Replace Housing
			Cracks	None Allowed	Not Repairable	Replace Housing
28-16227-3	12	Washer	Nicks and gouges	None Allowed	Not Repairable	Replace Washer
28-16263-5	13	DU Washer	Thickness .0585 to .0605	-.008	Not Repairable	Replace DU Washer
08DU08	15	DU Bearing	**I.D. .4992 to .5019	+ .0025	Not Repairable	Replace DU Bearing
28-16226-5	16	Sleeve	O.D. .7503 to .7508	-.0003	Not Repairable	Replace Sleeve
			I.D. .5937 to .5941	+ .0002	Not Repairable	Replace Sleeve

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-56

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-1. Inspection Requirements – Lower Swashplate Assembly

P/N	Fig. 12-21 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16223-19	17	Universal Shaft	O.D. .4991 to .4995	-.0003	Not Repairable	Replace Shaft
			Tie Rod Bore .3750 to .3752	+.0005	Not Repairable	Replace Shaft
			Concentricity	.0015 FIM	Not Repairable	Replace Shaft
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Shaft
28-16116-1, -11	18	Housing	Bushing bores Dia. .7500 to .7505	+.0005	Not Repairable	Replace Housing
			Cracks	None Allowed	Not Repairable	Replace Housing
28-16224-5	19	Tie Rod	O.D. .3748-.3750	-.0005	Not Repairable	Replace Tie Rod
			Concentricity	.002 FIM	Not Repairable	Replace Tie Rod
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Tie Rod
28-16225-19	20	Spacer	O.D. .4991 to .4995	-.0003	Not Repairable	Replace Spacer
			†Length 1.037 to 1.036	-.001	Not Repairable	Replace Spacer

* All dimensions are in inches.

** Inspect DU Bearing I.D. with the bearing installed in the sleeve, P/N 28-16226-5.

† Measure length at several locations to check for uneven wear.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-57

Rev. 11
Oct 25/19

12-11 UPPER SWASHPLATE ASSEMBLY

A. Removal – Upper Swashplate Assembly (Figure 12-22)

1. Remove the screws and fiberglass cover over the collective push-pull rod located above the seat deck in the cabin.
2. If required, remove screws (19) and washers (18) to remove the magnetic pickup bracket (17) (Figure 12-23).
3. Remove the lower swashplate assembly (para. 12-10, A).
4. Remove bolt (1) connecting the push-pull rod (2) and the walking beam (6).
5. Remove bolts (5), washers, and nuts from pivot straps (3). Pull the pivot straps (3) off of the studs.
 - a) If the pivot strap bushings (4) are worn, press to remove from the pivot strap.
 - b) If the pivot strap bushings are replaced, they will require reaming before reassembly.
6. Cut the safety wire and remove bolts (7) and bushings (8) (if equipped) from the upper bearing housing. Pull the walking beam (6) outward to remove from the bearing housing.
7. Remove the cotter pins from the castle nuts (9) of the lower end of the push-pull rods (11).

NOTE: Index mark each dogleg (10) to its respective push-pull rod (11) before disassembly. Doglegs have tapered bores which are matched to push-pull rods.


8. Remove the castle nuts (9) from push-pull rods (11).
9. Install puller tool T-0045 over dogleg (10) with center pivot of tool aligned with push-pull rod (11), and remove doglegs (10).
10. Disconnect the upper end of push-pull rods (11) at the main rotor hub (Figure 9-1):

NOTE: Index mark the pitch change bellcranks to their respective push-pull rod.

- a) Remove bolt (3), washers, and nut from the pitch change bellcrank (5).
- b) Remove bolt (4), washers, and nut from walking beam bracket (3) (Figure 9-2). Lift walking beam out of bracket and separate from the push-pull rod.

NOTE: Secure spacers (7) and (8) in push-pull rod and pitch change bellcrank with a piece of safety wire on disassembly and removal (Figure 9-1).

11. Remove the push-pull rods (11) through upper end of mast.
12. Remove bolts (12) and washers (13) connecting the swashplate to the gearbox (3 places).



- | | | | |
|----|---------------------|-----|-------------------------|
| 1. | Bolt | 8. | Bushing (ref. SIL 0178) |
| 2. | Push-Pull Rod | 9. | Nut |
| 3. | Pivot Strap | 10. | Dogleg |
| 4. | Pivot Strap Bushing | 11. | Push-Pull Rod |
| 5. | Bolt | 12. | Bolt |
| 6. | Walking Beam | 13. | Washer |
| 7. | Bolt | | |

NOTE: See Figure 12-23 if equipped with optional magnetic pickup bracket.

Figure 12-22. Upper Swashplate Installation

13. Slide bell of the upper swashplate up and down to tap the swashplate assembly from the lower end of the mast.

B. Disassembly – Upper Swashplate Assembly (Figure 12-23)

1. Install blocks (T-1758) on each side of the control housing (14) and clamp blocks in a vise with the nuts (1) facing up for removal.
2. Bend the locking tab (2) back to a flat position and remove nuts (1) with special socket tool T-0086. Remove the locking tab.
3. Place the swashplate assembly in an arbor press using blocks T-1758 for support and positioned with bell housing (3) up.
4. Position plug tools T-0102-1 three places in the threaded end of guide tube assembly (16) and press the swashplate assembly apart.
5. If DU bearings (13) are worn, press to remove from the control housing (14).
6. Press spacer (12) from the bearing housing assembly and remove the rain slinger (11).
7. Cut the safety wire and remove screws (4), washers (5), bearing retainer (6), and shims (7).
8. Heat the bearing housing (9) to approximately 250°F/121°C and press bearing (8) from housing.

C. Troubleshooting – Upper Swashplate Assembly

NOTE: If a lower swashplate has been operating in a worn condition, it may have caused the upper swashplate to wear also.


1. Upon removal of the lower swashplate, check the upper swashplate as follows:
 - a) Check the uni-ball in the doglegs for looseness or binding.

NOTE: The uni-ball preload should be equal in all three doglegs.

- b) Check the security of the doglegs to the push-pull rods.
- c) Exert fore and aft force on the lower bell housing of the upper swashplate to check for DU bushing wear.

NOTE: The upper swashplate should be removed and rebuilt if the DU bushings have excess of .010 play.

- d) Check the upper collective bearing by disconnecting the yoke and rotating the bearing to check for roughness.
- e) Exert up and down force on the attachment of the walking beam to the transmission mount to check for pivot strap bushing wear.



- | | | | |
|-----|------------------|-----|--|
| 1. | Nut | 12. | Spacer |
| 2. | Lock Plate | 13. | Bushing |
| 3. | Bell Housing | 14. | Control Housing |
| 4. | Bolt | 15. | Bushing |
| 5. | Washer | 16. | Retainer and Guide Shaft Assembly
(Guide Tube Assembly) |
| 6. | Bearing Retainer | 17. | Magnetic Pickup Bracket |
| 7. | Shims | 18. | Washer |
| 8. | Bearing | 19. | Screw |
| 9. | Bearing Housing | 20. | Nut |
| 10. | Lube Fitting | 21. | Interrupter |
| 11. | Slinger | | |

Figure 12-23. Upper Swashplate Assembly

D. Inspection – Upper Swashplate Assembly

1. Inspect the swashplate rod end (dog leg) (10, Figure 12-22) assemblies for excessive bearing play/wear.
 - a) Using a suitable light source and inspection mirror, as required, visually inspect each of the dog leg assemblies for condition and/or excessive radial play/wear between the bearing uni-ball and the uni-ball bearing race (Figure 12-22). To accomplish this inspection, a second person should slightly rotate, in the pitch axis, the main rotor blade corresponding to the dog leg assembly being inspected.
 - b) If the visual inspection of the dog leg assemblies indicates obvious uni-ball play exceeding approximately .025 in/.635 mm, remove the lower swashplate assembly from the aircraft and remove the dog leg assemblies from the aircraft. Inspect and replace the dog leg assemblies with airworthy components as required.
 - c) If the lower swashplate assembly has been removed, inspect the corresponding mounting lugs of the lower swashplate assembly for excessive wear/damage (Refer to Figure 12-20). Repair or replace the lower swashplate as applicable.
 - d) If the lower swashplate assembly has been removed, inspect bolts (16) and spacers (14) for excessive wear/damage (Figure 12-20). Replace the bolts and/or spacers as required.
2. See Table 12-2 for detailed inspection requirements of the upper swashplate assembly.

E. Assembly – Upper Swashplate Assembly (Figure 12-23)

1. If installing a new bearing, remove the seal from one side of the bearing (8).

WARNING: Use extreme caution when removing or installing heated parts and assemblies to prevent from injuring personnel.

WARNING: Use protective gloves when handling heated parts.

2. Heat bearing housing (9) to approximately 250°F/121°C.
3. Apply a lubricant (MIL-PRF-81322) to O.D. of bearing (8) and I.D. of housing (9). Install the bearing in housing with the open side of the bearing facing up against the closed side of the housing. Allow the assembly to cool.
4. Calculate the thickness of shims (7) required to preload the bearing in the housing using the following procedures:
 - a) Use a depth micrometer to measure distance from face of bearing to face of housing.
 - b) Subtract .003 in/.08 mm from measurement in step (a) to equal the shims required.

NOTE: Shims are available in thicknesses of .002, .003 and .005 inch.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

5. Place the shims (7) on the face of housing (9).
6. Install the bearing retainer (6) in place and secure with washers (5) and screws (4). Torque (12-15 in-lb/1.4-1.7 Nm) the screws in an alternating sequence and lockwire in pairs with .025 safety wire.
7. Install tool T-1709 on the inner race on the sealed side of the bearing (8). Place the slinger (11) on the open face of bearing and press the spacer (12) into the inner race of the bearing.
8. Clean the guide tube bores of the control housing (14) and O.D. of DU bushings (13) with Loctite Primer.
9. Apply adhesive (Loctite 277) to the O.D. of DU bushings and press the bushings (13) into the control housing (16) until they are flush with the face of the control housing. Rotate the assembly and repeat the installation on the opposite end.
10. Install the control housing (14) on the guide tube assembly (16) with the large flange of the housing facing toward threaded end of the guide tubes.
11. Place the guide tube assembly in an arbor press with the threaded end of the guide tubes up.
12. Lubricate (MIL-PRF-81322) the guide tubes (16) and the I.D. of the holes in spacer (12) installed in the bearing housing assembly. Press the bearing housing assembly onto the guide tubes with the slinger (11) facing the control housing (14) on the guide tube assembly (16).
13. Lubricate (MIL-PRF-81322) holes in bell housing (3) and press the housing onto the guide tubes. Ensure the bell housing is seated into bearing (8).
14. Slide the control housing (14) up and down on the guide tubes. If the housing is excessively tight or binding, mark the positions of the bell housing (3), spacer (12), and the bearing housing (9) on the guide tubes (16). Press the assembly apart, rotate the above items 120° on the guide tubes and re-assemble the components. Re-check to ensure the control housing (14) slides with no interference.
15. Clean the threads of guide tubes and the nuts (1) with Loctite Primer.
16. Install the aluminum blocks (T-1758) on the control housing (14) and clamp in a vise with the bell housing (3) up.
17. Install the lock plate (2) on guide tubes.
18. Apply Loctite 277 to the threads of the nuts (1) and install the nuts onto the guide tubes. Torque the nuts to 240 in-lb/27.1 Nm (3 places) using special socket T-0086.
19. Secure the lock tab (2) by bending up on two flats for each nut.

F. Installation – Upper Swashplate Assembly and Guidetubes (Figure 12-22)

1. Lubricate (MIL-PRF-81322) the bore of main rotor mast at the lower end.
2. Align the slot in the control housing (14) with the locking pin in lower end of the mast and install the upper swashplate assembly into the mast. Gently tap the swashplate into position by sliding the swashplate assembly up and down on the guide tubes.
3. Install washers (13) and bolts (12) in three places. Torque (30-40 in-lb/3.4-4.5 Nm) the bolts and lockwire (.025).

NOTE: Rotate the upper swashplate bearing housing with the swashplate in the full up position and ensure the lockwire does not interfere with the collective bearing housing.

4. Install the walking beam (6) into the ears of the bearing housing (9, Figure 12-23).
5. Install bolts (7) and bushings (8), if required, through the walking beam into the bearing housing. Torque (25-30 in-lb/2.8-3.4 Nm) and lockwire (.032).
6. If the pivot strap bushings (4) were replaced, apply a small amount of Loctite 277 on the O.D. of the bushings and press the pivot strap bushings (4) into the pivot straps (3). Ream with a 3/8" reamer.
7. Install the pivot straps (3) on the gearbox and walking beam studs.
 - a) Install the gearbox attachment bolt (5) and hardware. Torque (30-40 in-lb/3.4-4.5 Nm).
 - b) Check the pivot strap for binding or freedom of movement. If the binding is detected, remove hardware. File the hat-end of the bushing (4) to reduce the thickness or protrusion. Deburr and remove any debris from the assembly.
 - c) Repeat step b) and check for binding.
 - d) If there is no binding, then install the walking beam attachment bolt (5). Torque (30-40 in-lb/3.4-4.5 Nm).
 - e) Perform step b) and repeat as necessary until there is no binding of the pivot strap.
 - f) Install cotter pins.
8. Install the push-pull rod (2) into the walking beam (6) and connect with hardware (1). Torque (60-85 in-lb/6.8-9.6 Nm) and install cotter pin.
9. Connect the push-pull rods to the pitch change bellcrank (Figure 9-1):

NOTE: Stuff a shop cloth into the upper end of the mast to prevent anything from being dropped into the mast when connecting the push-pull rods to the pitch change bellcranks. Remember to remove the shop cloth when installation is complete.

WARNING: If anything is dropped into the mast it must be removed prior to moving the flight controls.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- a) Insert stainless steel spacer (7) into the end of the push-pull rods (6) and spacer (8) into the center pivot of the pitch change bellcrank (5).
- b) Install push-pull rods (6) into mast and connect to the pitch change bellcrank (5) with bolts (3), washers, and nuts. Torque (30-40 in-lb/3.4-4.5 Nm) nuts and install cotter pins.
- c) Connect the pitch change bellcrank (5) to the mount brackets (3, Figure 9-2) with bolts (4), washers, and nuts. Torque (60-85 in-lb/6.8-9.6 Nm) nuts and install cotter pins.

10. Install the doglegs (10) as follows: (Figures 12-22)

- a. Position dogleg (10) on the push-pull rod (11) and install nut (9) finger-tight.

NOTE: Doglegs must be re-installed to the respective push-pull rods they were removed from.

- b. Position special tool T-0054 on bell housing of upper swashplate assembly while aligning the dogleg parallel to its respective walking beam on the main rotor hub. Install the screws to hold the tool in place. Place the spacer on each side of the swivel ball in the dogleg and install the bolt to position the dogleg on the tool (Figure 12-24).
- c. Torque the nut (9) to 130-140 in-lb/14.7-15.9 Nm and install cotter pin.

NOTE: When torqueing the nut to align the cotter pin hole, the nut must be turned in the direction of tightening; the nut may not be loosened to line up the cotter pin hole. Replace the nut, washer, spacer, and/or bolt as required if the cotter pin hole will not line up at the 130-140 in-lb/14.7-15.9 Nm torque application.

- d. Repeat steps (1) through (c) on each dogleg.

11. Install the lower swashplate (para. 12-10, E).

12. If required, install the magnetic pickup bracket (17) with screws (19) and washers (18).

13. Install the fuel tank and connect fuel lines. Install fuel and check for leaks.

14. Replace side panel cowls.

15. Perform a maintenance test flight (para. 12-13).




Figure 12-24. Alignment Tool T-0054 for Dog Leg Installation

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-2. Inspection Requirements – Upper Swashplate Assembly

P/N	Fig. 12-22 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16132-4	4	Pivot Strap Bushing	I.D. .3750 to .3755	+0.0005	Not Repairable	Replace Bushing
P/N	Fig. 12-23 Item #	Part Name	Inspection	Serviceable Limits*	Repair Limits*	Repair or Action
28-16113-1	1	Nut	Threads (crossed or missing)	None Allowed	Not Repairable	Replace Nut
			Hex corners for rounding or deformation	None Allowed	Not Repairable	Replace Nut
28-16126-1	2	Locking plate				Replace on re-assembly
28-16112-15, -17	3	Bell Housing	Guide tube bore Dia. .9062 to .9069	+0.0003	Not Repairable	Replace Housing
			Nicks and gouges	.005 deep	.025 deep	Blend and polish out smooth. Apply Iridite finish.
			Threads (crossed or missing)	None Allowed	Not repairable	Replace Housing
28-16043-19	6	Bearing Retainer	Nicks and scratches	.005 deep	≤.010 deep	Blend and polish out smooth
ECD013-11	8	Bearing	O.D. 3.9370	-0.0004	Not Repairable	Replace Bearing
			I.D. 2.5591	+0.0000 -0.0004	Not Repairable	Replace Bearing
			Condition of balls and cage after cleaning	No pits or flat spots allowed	Not Repairable	Replace Bearing

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-67

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-2. Inspection Requirements – Upper Swashplate Assembly

P/N	Fig. 12-23 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16108-2, -11	9	Bearing Housing	Bearing bore Dia. 3.9365 to 3.9371	No Tolerance Allowed	Not Repairable	Replace Housing
			Pivot holes for galling or wear	None Allowed	Not Repairable	Replace Housing
			Threads	None Allowed	Not Repairable	Replace Housing
28-16386-1	11	Rain Slinger	Check for deformation	None Allowed	Not Repairable	Replace Slinger
28-16106-2	12	Spacer	Guide tube holes for galling	None Allowed	Not Repairable	Replace Spacer
16-DU-12	13	Bushing	O.D. 1.125	+0.000 -0.005	Not Repairable	Replace Bushing
			I.D. 1.000	+0.005 -0.000	Not Repairable	Replace Bushing
28-16103-1	14	Control Housing	Bushing bore Dia. 1.1250 to 1.1256	+0.004	Not Repairable	Replace Housing
			O.D. 2.6465 to 2.6470	-0.003	Not Repairable	Replace Housing
			O.D. for galling	.001 deep	.005 deep	Polish to Remove
			Cracks	None Allowed	Not repairable	Replace Housing

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-68

Rev. 11
Oct 25/19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-2. Inspection Requirements – Upper Swashplate Assembly

P/N	Fig. 12-23 Item #	Part Name	Inspection*	Serviceable Limits*	Repair Limits*	Repair or Action
28-16260-1	16	Retainer and Guide Shaft Assembly	Sheared or worn rivets	None Allowed	If rivet is sheared with no other damage to assembly	Replace Rivet
			Threads (crossed or missing)	None Allowed	Not Repairable	Replace Guide Shaft in the retainer
			Looseness of guide shaft in the retainer	No movement allowed	Not Repairable	Replace Assembly
			Galling of guide shafts	.001 deep	≤.005 deep and ≤ 1.0" long	Blend and polish out smooth
			Cracks	None Allowed	Not Repairable	Replace Assembly

* All dimensions are in inches.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-69

Rev. 11
Oct 25/19

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

12-12 MAIN ROTOR PUSH PULL RODS

NOTE: The following was formerly contained in Section 23 and includes data incorporated from SIL 0156. See also SDB 0096.

A. Removal – Main Rotor Push-Pull Rods


1. Remove the push-pull rod in accordance with para. 12-11, A, steps 7 through 11.

B. Inspection – Main Rotor Push-Pull Rods (Figure 12-25, Figure 12-26, Figure 12-27)

1. Inspect the main rotor push-pull rods for corrosion pitting.
2. Inspect for excessive looseness between steel journal bushing (3) and Teflon bearing insert (2).
3. Remove and inspect steel journal bushing (3) for galling or roughness.
4. Inspect Teflon bearing insert (2) for linear damage or wear.
5. If necessary, remove and replace the Teflon insert.
6. Reinstall the steel journal bushing.
7. Inspect bolt (5) for wear or damage and replace as necessary.
8. Insert bolt (5) into the inboard end of bellcrank (8) and check for looseness.
9. Inspect steel bushings (9) and (10) for roughness, galling, and wear.
10. If necessary, press flanged bushings (9) and (10) out the bellcrank (8) and replace.
11. Repeat for the other two bellcrank/push-pull rod assemblies.
12. See Table 12-3 for additional detailed inspection requirements for the main rotor push-pull rods.


C. Installation – Main Rotor Push-Pull Rods

1. Install the push-pull rods into the mast from the upper end and through the guide tubes in the upper swashplate.
2. Complete the main rotor push-pull rod installation in accordance with para. 12-11, F, steps 9 and 10.




- | | | | |
|----|------------------------|-----|------------------------|
| 1. | Push-Pull Rod Assembly | 6. | Washer |
| 2. | Teflon Bearing Insert | 7. | Nut |
| 3. | Bushing | 8. | Pitch Change Bellcrank |
| 4. | Washer | 9. | Bushing |
| 5. | Bolt | 10. | Bushing |


Figure 12-25. Main Rotor Push-Pull Rod Installation



a) Inspection Area Identification



b) Push-Pull Rod Runout Inspection



c) Lower Fitting Contact Wear Limits

Figure 12-26. Main Rotor Push-Pull Rod Inspections



Figure 12-27. Main Rotor Push-Pull Rod Corrosion Pitting

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Table 12-3. Inspection Requirements – Main Rotor Push-Pull Rod

Part Name	Inspection	Serviceable Limits	Repair Limits	Repair or Action
Push-Pull Rod Assembly	Cracks or Dents	No Tolerance Allowed	Not Repairable	Replace Push-Pull Rod Assembly
	Nicks, scratches, or corrosion in Area A (See Figure 12-26,a)	.007 in / .18mm (See Repair or Action)	.007 in / .18 mm	Blend and polish out smooth
	Nicks, scratches, or corrosion in Area B (See Figure 12-26,a; Figure 27)	.015 in / .38mm (See Repair or Action)	.015 in / .38mm	Blend and polish out smooth
	Bent push-pull rod assembly (See Figure 12-26,b)	.030 in / .76 mm	.030 in / .76 mm	Replace Push-Pull Rod Assembly
Lower Fitting	Cracks	None Allowed	Not Repairable	Replace Push-Pull Rod Assembly
	Contact wear from guide tube assembly (See Figure 12-26,c)	.030 in / .76 mm (See Repair or Action)	.030 in / .76 mm	Blend and polish out smooth
	Threads (rolled or missing)	None Allowed	Not Repairable	Replace Push-Pull Rod Assembly
Upper Fitting	Cracks	None Allowed	Not Repairable	Replace Upper Fitting or Replace Push-Pull Rod Assembly
	Nicks, scratches, or corrosion	.010 in / .25 mm (See Repair or Action)	.010 in / .25 mm	Blend and polish out smooth
	Bore wear on Bearing, P/N MS21240-08-C-12	.505 in/12.83 mm	Not Repairable	Replace Bearing
Vinyl Sleeve	Wear	Worn Through	Not Repairable	Replace Vinyl Sleeve

* Contact wear can be repaired on two sides of the lower fitting. The rod assembly may be rotated 180° and reused when the contact wear reaches the repair limit on one side. Refer to Figure 12-26.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-12-74

Rev. 11
Oct 25/19

12-13 FLIGHT TEST PROCEDURE

A. Preliminary Checks

NOTE: Whenever a helicopter has had work accomplished to the flight controls, it is recommended that a flight test be conducted before returning the helicopter to service.

1. Perform a preflight inspection. See Rotorcraft Flight Manual, Section 4.
2. Perform a Verification of Rigging (para. 12-7).
3. Perform normal start and run-up checks to 2300 RPM.

B. Flat Pitch Test (low RPM checks)

NOTE: The following test is used to check rigging of the flight controls.

1. Adjust engine RPM to 2300 with rotor engaged.

WARNING: Clear all persons from tip path plane area as blades may dip as low as 5 feet during this test.

2. Displace cyclic fore, aft, and laterally while visually inspecting for proper tip path plane reactions. Center cyclic stick after test.
3. Displace cyclic laterally to the left until a slight mast bumping is felt through the airframe. Measure the gap between the cyclic stick and the stop ring in the floor. Repeat this procedure for right lateral, fore, and aft. All four positions should have approximately the same distance from stop ring, indicating proper rigging of push-pull tubes. Center cyclic after this procedure.
4. Trim cyclic stick to neutral position and release cyclic grip. Visually watch cyclic stick for motion. Cyclic should remain centered and still. Move cyclic fore and aft without trimming and check smoothness. No hard vibrations should be present.

NOTE: If hard vibrations are present or the cyclic wanders, either the aircraft will have to be tracked or a problem exists in the main rotor control system.

5. Displace the left tail rotor pedal approximately 2 inches. Observe engine tach for a drop in RPM indicating proper rigging. Return pedals to neutral position after performing this procedure.

CAUTION: If aircraft is on a slippery surface it may turn during this test.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

6. Retard throttle to idle position and check for disengagement of sprag clutch by observing tachometer needle split.
7. Smoothly rejoin tach needles and set engine RPM at 3050. Perform normal run-up procedures.
8. Check throttle for false limit at 3050 RPM. No stop should be contacted prior to 3050 RPM.
9. Check that engine has 16-19 inches of manifold pressure at 3050 RPM.

NOTE: 19 inches of manifold pressure indicates that adequate autorotational RPM will be available in later tests.

C. Hover Test

1. With rotor engaged and engine at 3050 RPM, release the collective friction and slowly increase collective pitch. While making minor adjustments to controls, watch for proper response as aircraft becomes light on the skids.

NOTE: If rocking or bouncing occurs at this point the aircraft may need tracking, oleo, or damper work performed.

2. Bring aircraft to a hover with cyclic stick centered laterally and slightly forward of center in static stop ring.

NOTE: This test should be performed in low wind conditions. If winds are in excess of 10 MPH the cyclic will be displaced in that direction. If aircraft has rough ride, see troubleshooting and tracking procedures for hover track (para. 12-1 and 12-2).

3. Pedal position in a hover should be 1/2" to 1" right pedal.

NOTE: Improper pedal position requires tail rotor rigging check at this point. Collective should be in normal position and throttle must not be against false stop or into override.

4. Stabilize aircraft at a hover and check the following:

- a) Change collective setting up and down approximately one inch and note collective spring loadings. If collective has equal forces in both directions, release throttle to check for override contact.

NOTE: Throttle and collective should remain in position without friction.

- b) Adjust cyclic trim to full left and full aft. The cyclic should have slight right force (approximately 2 lb) with pilot and passenger and "0" forces fore and aft. Record discrepancies in control forces and make adjustments for throttle, cyclic position, and collective position.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Do not adjust for minor trim conditions until necessary adjustments for autorotation, V_{NE} , and cruise procedures have been completed which are discussed later in this test procedure.

5. For left pedal and collective rigging low rpm check, proceed as follows:
 - a) Stabilize aircraft at 1 foot hover and normal operating range with heading into the wind.
 - b) Slowly reduce engine RPM while maintaining one foot hover. As aircraft reaches 220 rotor RPM, sufficient left pedal should be available to maintain heading into the wind.
 - c) Continue to decrease engine RPM until aircraft contacts the ground. The collective up stop should not be contacted until touchdown. This indicates proper collective rigging to upper control arms.
6. For right pedal rigging check, proceed as follows:
 - a) Hover aircraft at one foot heading into wind.
 - b) Perform hovering autorotation while maintaining one foot altitude.
 - c) As the rotor passes through 220 RPM, the aircraft will settle to the ground.

NOTE: Collective should not contact the up stop prior to ground contact.

- d) Sufficient right pedal should be available until firmly on the ground.

NOTE: If above conditions cannot be met, check rigging of appropriate items.

7. For 20 MPH hover checks - proceed as follows:
 - a) Position aircraft over a flat smooth area.
 - b) Hover aircraft at 20 MPH airspeed and normal operating RPM (3050 RPM). Check in both directions laterally, forward and rearward. No stops should be contacted during this phase.
 - c) If no stops are contacted, repeat procedure at minimum RPM (2900 RPM).

D. Cruise Flight Test - 75% Power

1. Perform normal takeoff and level off at 1000' AGL and set altimeter to 29.92. Record pressure altitude, temperature and gross weight information.
2. Set engine RPM at 3050 and 29" manifold pressure with steady heading approximately 90-95 MPH.

NOTE: Allow two minutes for aircraft to stabilize.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

3. Visually check static ring for cyclic position on pilot's side. Cyclic stick should be centered and slightly aft in the ring.
4. Trim aircraft to neutral forces. Release cyclic to ensure adequate trim is available.
5. Change collective setting to check spring forces of collective bungee. Record if other than "0" forces.
6. Release collective to check that throttle holds position.

E. Autorotation Checks at 58 MPH

NOTE: Pilot must calculate gross weight and predicted density altitude in accordance with the RPM correction chart, Figure 12-28, to avoid overspeeding the rotor while performing the autorotation check.

1. Climb to 1500 ft AGL. Set up autorotational landing to suitable area.

CAUTION: Enter autorotation by lowering collective while maintaining engine RPM. **DO NOT** exceed maximum rotor RPM. Split tach needles to ensure adequate rotor RPM for autorotation.

2. Enter straight into autorotation and adjust airspeed to 58 MPH.
3. At 58 mph in stabilized autorotation, depress right pedal smoothly to pedal stop. Sufficient pedal should be available to yaw the aircraft to a minimum of 25° to the right of course.
4. Re-establish autorotational glide at 58 MPH and full down collective.

CAUTION: **DO NOT** exceed maximum rotor RPM.

5. Record temperature, pressure altitude, gross weight information, and autorotation RPM.
6. As aircraft approaches 100 ft AGL, power recover by bringing engine rpm to low green. Rejoin tach needles by pulling collective pitch and adjust throttle as necessary while establishing climb.

CAUTION: Land aircraft and make adjustments to unsafe conditions before continuing tests.

7. Compare the autorotation RPM to the Autorotational RPM Correction Chart (Figure 12-28). The autorotational RPM should be within \pm RPM as indicated on the chart.

F. V_H and V_{NE} Checks

1. Fly aircraft to 1000 feet AGL. Record pressure altitude, temperature, and gross weight information.
2. Adjust engine RPM to 3050 with 39" manifold pressure in level flight.
3. Allow two minutes for aircraft to stabilize. Record airspeed.

CAUTION: Do not exceed V_{NE} speed envelope or maximum manifold pressure during this test.

4. Visually inspect cyclic position in static stop ring. Cyclic should be centered laterally with a minimum of 1/2" clearance to aft portion of static stop ring.
5. Trim aircraft and check for zero forces fore and aft. Check for zero lateral forces at 110 mph by momentarily releasing grip after trimming. Aircraft should maintain level flight.
6. Adjust engine RPM and repeat step (4) above.
7. Record discrepancies, land and make corrections.

G. Flight Check – Lateral Trim

NOTE: Flight check with a pilot and passenger, approximately 360 lb.


1. Hover - Cyclic should have approximately 2 lb left force (pressure to the right) with full lateral trim.

NOTE: If aircraft is adjusted to obtain full lateral trim in a hover, it will not be able to obtain full lateral trim in forward flight.

2. Forward Flight - Flying to 110 mph and trimmed laterally, the aircraft should fly straight and level with full trim (no yaw to left or right).

Lateral Cyclic Positions:

3. Hover (no wind) - Cyclic stick bellcrank should be centered in cyclic stop ring in floor.
4. Forward flight at 75% power (28" MP) - Cyclic stick should be centered (same as hover) but bellcrank should be slightly aft in stop ring.
5. Forward Flight at V_{NE} – Sea level conditions (112 mph), low rotor rpm – 332. Cyclic stick bellcrank should be centered laterally and have approximately clearance from aft portion of stop ring.



EXAMPLE:

RPM CHECKED PASSING THROUGH 2000 FEET PRESSURE ALTITUDE
 OAT AT THIS ALTITUDE: 45°F (7°C)
 DENSITY ALTITUDE IS 1500 FEET
 AIRCRAFT WEIGHT WHEN RPM WAS CHECKED: 2110 POUNDS
 AUTOROTATION RPM SHOULD BE 367 WITH COLLECTIVE FULL DOWN

CHECK RPM IN STEADY 60 MPH AUTOROTATION WITH THE COLLECTIVE FULL DOWN. RECORD PRESSURE ALTITUDE (ALTIMETER SET TO 29.92), OAT, ROTOR RPM, AND AIRCRAFT WEIGHT. DO NOT EXCEED 385 RPM OR DROP BELOW 332 RPM.

Figure 12-28. Autorotational RPM Correction Chart – Sea Level Base Altitude

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

SECTION 13

POWERPLANT AND ASSOCIATED SYSTEMS

TABLE OF CONTENTS

Paragraph	Description	Page
13-1	Powerplant.....	MM-13-1
	A. General Description.....	MM-13-1
	B. Operating Specifications.....	MM-13-1
13-2	Engine	MM-13-3
	A. Engine and Turbocharger Troubleshooting	MM-13-3
	B. Preparation for Engine Removal for Replacement or Overhaul	MM-13-9
	C. Removal	MM-13-12
	D. Inspection Prior to Engine Reinstallation	MM-13-12
	E. Installation	MM-13-16
	F. Cylinder Removal in Helicopter	MM-13-18
	G. Cylinder Installation	MM-13-18
13-3	Engine Exhaust System	MM-13-19
	A. General Information	MM-13-19
	B. Exhaust Manifold Removal.....	MM-13-19
	C. Exhaust Manifold Inspection.....	MM-13-20
	D. Exhaust Manifold Installation.....	MM-13-20
	E. Wastegate Operational Check.....	MM-13-21
	F. Wastegate Rigging	MM-13-21
	G. Wastegate Removal	MM-13-21
	H. Wastegate Inspection	MM-13-21
	I. Wastegate Installation	MM-13-23
13-4	Fuel Injection System	MM-13-23
	A. General Information	MM-13-23
	B. Fuel Injection System Troubleshooting	MM-13-23
	C. General Operating Information	MM-13-27
	D. Injector.....	MM-13-28
	E. Mixture Control	MM-13-37
	F. Automatic Mixture Control (AMC).....	MM-13-40
	G. Fuel Servo Screen.....	MM-13-41
	H. Fuel Flow Divider.....	MM-13-42
	I. Air Bleed Nozzles	MM-13-43
13-5	Turbocharger.....	MM-13-47
	A. General Information.....	MM-13-47
	B. Turbocharger Removal.....	MM-13-47
	C. Turbocharger Inspection.....	MM-13-48
	D. Turbocharger Installation.....	MM-13-48
	E. Turbocharger Repair	MM-13-49
13-6	Turbocharger Static Air Fuel Nozzle Pressure System.....	MM-13-49
	A. General Information.....	MM-13-49
	B. Turbocharger Static Air Fuel Nozzle Pressure System Troubleshooting.....	MM-13-51
	C. Ambient Air Check Valve.....	MM-13-52

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

Paragraph	Description	Page
13-7	Primary Airflow System	MM-13-52
	A. General Information	MM-13-52
	B. Air Filter and Housing	MM-13-55
13-8	Cooling System	MM-13-57
	A. General Information	MM-13-57
	B. Fan Assembly	MM-13-57
	C. Fan Shroud	MM-13-60
	D. Firewall Repairs	MM-13-62
13-9	Ignition System	MM-13-64
	A. General Information	MM-13-64
	B. Ignition System Troubleshooting	MM-13-64
	C. Vibrator-Magneto Check.....	MM-13-66
	D. Magneto Operation Check.....	MM-13-67
	E. Magneto.....	MM-13-68
	F. Harness Assembly.....	MM-13-70
13-10	Fuel System	MM-13-72
	A. General Information	MM-13-72
	B. Fuel Tanks	MM-13-72
	C. Fuel Boost Pump	MM-13-80
	D. Engine-Driven Fuel Pump	MM-13-81
	E. Fuel Filter.....	MM-13-84
	F. Fuel Pressure Switch.....	MM-13-86
	G. Fuel Shutoff Valve	MM-13-87
13-11	Lubrication System	MM-13-88
	A. Description.....	MM-13-88
	B. Oil Coolers.....	MM-13-90
	C. Scavenge Pump	MM-13-93
13-12	Correlator	MM-13-94
	A. Operating Principles	MM-13-94
	B. Verifying Proper Correlator Operation	MM-13-94
	C. Troubleshooting the Correlator.....	MM-13-94.1
	D. Correlator Pre-Flight Rigging.....	MM-13-95
	E. Injector Rigging.....	MM-13-96
	F. Correlator Post-Flight Rigging	MM-13-98
	G. Adjusting the Correlator After Maintenance.....	MM-13-99

MAINTENANCE MANUAL

SECTION 13

POWERPLANT AND ASSOCIATED SYSTEMS

13-1 POWERPLANT

A. General Description

The "F" model Enstrom helicopter utilizes a Lycoming air-cooled horizontally opposed four-cylinder direct drive engine, model H10-360-F1AD. The engine is turbocharged by Enstrom giving it the power capability of maintaining 225 HP up to a 12,000 foot density altitude.

The engine is mounted in the center airframe pylon by a dynafocal mount system attached to the rear engine case facing forward in the helicopter. The turbocharger is mounted to a tubular frame that is attached to the rear engine crankcase and accessory housing and is easily removable. Easy access to the engine is provided by two large hinged panels, one on either side of the helicopter and another removable panel, located in the cabin firewall, for access to the rear engine accessory section.

B. Operating Specifications

Powerplant Limitations

Engine Lycoming model H10-360-F1AD
with Rajay model #BT5EE10J2
turbocharger

Fuel 100/130 minimum grade

Oil viscosity 50 hour break-in period
MIL-L-6082B

<u>Average ambient temperature</u>	<u>SAE Grade</u>
Above 80°F	60
Above 60°F	50
30°F to 90°F	40
0° to 70°F	30
Below 10°F	20

After break-in period
MIL-L-22851 Ashless Dispersant

<u>Average ambient temperature</u>	<u>SAE Grade</u>
All temperatures	15W50 or 20W50
Above 80°	60
Above 60°F	40 or 50
30°F to 90°F	40
0°F to 70°F	40, 30 or 20W40
Below 10°F	30 or 20W30

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

Horsepower	225 HP at 3050 rpm, 39.0 in. Hg manifold pressure
Operating rpm	3050 maximum 2900 minimum
Idle rpm	1500 minimum (clutch disengaged)
Manifold pressure	39.0 in. Hg, sea level to 12,000 ft density altitude
EGT	1650°F maximum
Oil temperature	245°F maximum
Oil pressure	Normal - 50 to 95 psi Idling - 25 psi minimum Starting & warmup - 115 psi
Main rotor gearbox	225°F maximum
Cylinder head temp.	500°F maximum
Fuel mixture	Engine may be leaned at 75% power or below to 1600°F on rich side of peak. NEVER exceed 1650°F EGT. Mixture must be full rich for landing and takeoff regardless of power for proper engine cooling

Rotor - Flight Limitations (Power Off)

Maximum	385 rpm
Minimum	332 rpm

Instrument Markings

Rotor tachometer	red line	385 rpm
	red line	332 rpm
	green arc	332-385 rpm
Engine tachometer	red line	3050 rpm
	red line	2900 rpm
	green arc	2900-3050 rpm
Airspeed indicator	red line	112 mph (F-28F)
		117 mph (280F)
		117 mph (280FX)
Manifold pressure	red line	39.0 in. Hg
Engine oil temp.	red line	245°F
	green arc	120-245°F
	yellow arc	60-120°F

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

Oil pressure	red line	100 psi
	red line	25 psi
	green arc	60-100 psi
	yellow arc	25-60 psi
EGT	red line	1650°F
Cylinder head temp.	red line	500°F
	green arc	200-500°F
Transmission oil temp.	red line	225°F
	green arc	0-225°F

13-2 ENGINE

A. Engine & Turbocharger Troubleshooting

Experience has proven that the best method of troubleshooting is to analyze all symptoms of the problem and carefully eliminate any systems that are not contributing to it. The following troubleshooting chart has been prepared to help the maintenance personnel pinpoint the problem areas by focusing on specific engine operating symptoms. In the following charts these are depicted by the major headings followed by the most probable cause and remedy.

NOTE: The remedies and/or actions in the following charts are in an abbreviated form. For full description of any of the problems turn to the specific paragraph in the following sections of the Powerplant Section.

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Failure of engine to crank over.	Dead battery, starter relay defective, defective starter or corroded terminals on ground or battery leads.	Self explanatory.
Failure of engine to start.	Lack of fuel to engine.	Check main fuel valve "ON", fuel level, boost pump pressure, filters and mixture setting.
	Static air nozzle vent valve stuck closed. May be accompanied by induction tube sump valve fuel leakage or backfire.	Clean valve or replace.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Failure of engine to start. (CONTINUED)	Shower of sparks inoperative, no buzz from vibrator.	Check for low voltage to ignition circuit during cranking (9.5V min), defective vibrator relay, or corroded connections.
	Sump valves stuck open accompanied by backfire or popping.	Clean all three sump valves.
	Magneto inoperative or "P" lead grounded.	Check ignition lead for spark, or breakage. Check retard action, and "P" lead connections.
	Engine kicks back.	Check shower of sparks vibrator relay operation, check retard timing and breaker action, magneto timing, damaged distributor cap or shorting internally.
Failure of engine to start, accompanied by puffing black smoke from exhaust stack, fuel dripping from sump valves.	Severe flooding.	Review starting procedure.
	Excessive priming.	Review starting procedure.
	Servo center body seal leak.	Replace servo.
	Servo mixture valve plates leaking.	Remove and repair mixture valve plates.
	Excessive fuel boost pressure.	Reduce duration of priming - check fuel boost pressure.
Failure of engine to idle properly.	Incorrect idle mixture setting.	Correct idle mixture setting.
	Leak in induction system, sump drain valves stuck open.	Check induction system for leaks, check operation of sump drain valves.
	Incorrect idle air adjustment.	Adjust throttle stop to obtain correct idle speed.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-4

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Failure of engine to idle properly. (CONTINUED)	Dirt in air side of fuel nozzle.	Carefully clean nozzles.
	Bad or fouled spark plugs.	Replace or clean as required.
	Shorting of ignition lead.	Check ignition leads.
Unable to pull full rated power, missing, or engine twitching in mounts.	Mixture too rich, indicated by sluggish operation, red exhaust flame, black soot residue in exhaust stack and smoky black exhaust.	Check fuel servo for proper fuel output metering.
	Partially clogged or clogged fuel injection nozzle or nozzles on either fuel or air side.	Clean as required.
	Air leaks in the air induction system, sump drain valves stuck open.	Check induction system for leaks, clean sump drain valves.
	Inadequate fuel supply, servo mis-rigged, restricted static air nozzle in fuel system, usually accompanied by high temperatures, vent valve stuck open.	Check fuel flow, filters and rigging of controls.
	Restriction in air intake.	Check ducting, condition of filter and intake scoop.
	Turbocharger wastegate and throttle override not functioning properly.	Check wastegate for proper operation, rigging and override actuator ride, internal heat erosion.
	Leak in engine exhaust system, reducing exhaust pressure to turbo system.	Check exhaust flange gaskets, turbo gaskets and couplings or system tube failures.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-5

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Unable to pull full rate power, missing, or engine twitching in mounts. (CONTINUED)	Turbo rotating assembly rubbing on housing, distorted housing, dirt accumulation on impeller, carbon build-up, or foreign object damage, bearing seizure.	Check freedom of assembly. Allowable shaft radial play is .017 to .028 inch on bearings, allowable shaft axial play is .004 to .009 inch.
	Engine timing is slightly off.	Check timing to required specifications.
	NOTE: During magneto check if EGT has a variance of more than 100° from R to L magneto check timing.	
	High speed ignition, high tension leak or faulty spark plugs.	Check wiring harness and plugs.
Engine will not accelerate from idle.	Idle mixture set too lean, fuel pressure too low, fuel supply restricted, or air supply restricted.	Check idle mixture, fuel pressure, supply and air intake obstruction.
Engine accelerates from idle but is rough and erratic.	Idle mixture on lean side, servo too rich or center body pin hang-up caused by internal misalignment.	Check mixture or replace servo.
Rough engine operation at high power settings.	Engine mounts deteriorated, or improper torque.	Check mounts, belts and torque.
	Plugged or partially plugged fuel nozzle (air or fuel side). This is indicated by higher than normal fuel flow and slight increase in MAP.	Clean fuel nozzles thoroughly.
	Misfiring of ignition system, high tension leak, fouling spark plug.	Check ignition high tension system and plugs.
	Misfiring due to detonation, due to excessive cylinder head temperatures.	Check fuel octane rating, reduce power, and increase mixture setting.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Low oil pressure at operating rpm.	Insufficient oil supply, improper grade of oil, excessive operating temperatures.	Check oil level, grade of oil, increase mixture setting for high ambient temperatures.
	Oil pressure relief valve hung up, defective or loose.	Check oil pressure relief valve setting and operation.
	Oil leakage from lines or fittings.	Check all lines and fittings.
	Oil pump failing or sump suction screen partially blocked.	Check oil pump output and suction screen.
High oil and cylinder head temperatures.	Insufficient cooling air to engine and oil coolers.	Check cooling air inlet for obstruction, check cylinder fins for excessive dirt accumulation, check oil cooler inlets for dirt and debris.
	Insufficient quantity of oil or improper grade.	Check oil level and grade.
	Operating at excessively high power settings exceeding EGT limitations.	Reduce power, increase mixture settings.
Excessive oil consumption.	Improper grade of oil, turbo seals failed, engine ring and/or valve clearance out of limits.	Check grade of oil. If turbo seals are bad, oil seepage from induction sump valves may occur after parking, and this oil may be found in turbo assembly. This condition is usually indicated by excessive exhaust smoke on start-up and at idle.
	<u>NOTE:</u> Oil input line check valve hang to the turbo housing will indicate the same problem.	

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Excessive oil consumption. (CONTINUED)	On new engines or rebuilt engines ring may not be properly seated.	Continue to break in engine with recommended oil until oil consumption stabilizes.
	<u>NOTE:</u> Avoid continuous operation at maximum power settings and EGT's during this break-in period.	
	Glazed cylinder walls, caused by improper engine operation during break-in period.	Cylinders must be removed and reworked by honing.
Loss of, reduction of, or fluctuation of manifold pressure when turbocharging.	Clogged engine crank-case breather vent line. In cold weather frost can restrict this vent and cause nose seal to fail or pump oil.	Clean vent of sludge, be sure small side vent in tube inside of cowl line is clear and open. This will allow engine to breathe properly if the exposed portion below frosts closed.
	Malfunction of MAP indicator may be the result of debris in the MAP reference line to engine.	Clear line and recheck.
	Air intake restriction, duct collapsing or air filter blocked or icing.	Check condition of ducting.
	Turbo output leakage through induction system, loose duct, adapter or collar, failure of intake pipe.	Check complete induction system for leaks or failures.
	Partial fuel vapor locking due to hot fuel, altitude, or combination of both with high power settings, may be accompanied by detonation.	Reduce power
	Malfunctioning fuel pump or pressure regulator, blown seal or leaking pump deck pressure line.	Reduce power. If engine begins to detonate, terminate operation.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Engine runs hot during turbocharging.	Ambient temperatures too hot.	Reduce power to safe EGT levels.
	Over-boosting or mixture too lean.	Reduce power to proper MAP and EGT limitations. Increase mixture setting.
	Ignition timing off.	Check timing to required specification.

B. Preparation for Engine Removal for Replacement or Overhaul (See Figure 13-1)

The engine is removed as a unit with components of engine associated systems and engine accessory items (alternator, starter, magnetos, wiring harness, etc.) attached to the engine.

- (1) Disconnect battery.
- (2) Remove segmented cowl, baggage box, side panels, lower cowl and engine compartment doors.
- (3) Remove fuel tanks and drain fuel lines.

NOTE: Upon removal all line, fittings and/or openings to engine, tanks or coolers should be plugged with dust caps or covers to protect from contamination.

- (4) Drain oil from engine, oil coolers and oil lines.
- (5) Remove jack strut and fan assembly.
- (6) Remove main rotor transmission.

NOTE: Utilizing some type of overhead lifting device is recommended as the easiest and safest method of engine removal. If overhead lifting capability is not available, it will not be necessary to remove the transmission (step 6) or install lifting ring (step 10).

- (7) Disconnect fuel line from the fuel shutoff valve and detach the doubler encircling the fuel line at the fire curtain.
- (8) Remove upper engine baffling.
- (9) Remove or detach fire curtain as required.
- (10) Remove primary oil cooler (right side).
- (11) Remove induction air box and ducting.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (12) Disconnect exhaust gas temperature probe and remove exhaust system and associated flexible ducting.
- (13) Detach fan shroud from engine and remove mount brackets from top and bottom of engine.
- (14) Pull fan shroud and secondary oil cooler away from engine.
- (15) Detach clutch cable clamps from bay tube.
- (16) Disconnect fuel lines from main fuel strainer.
- (17) Remove bay tubes.
- (18) Remove sump drain lines and valves.
- (19) Disconnect fuel inlet line to fuel pump, scavenge pump inlet line and remove fuel pump drain line.
- (20) Disconnect engine ground strap starter and alternator lines.
- (21) Remove turbocharger, wastegate and injector adapter.
- (22) Remove injector, inlet air adapter and flexible duct.
- (23) Disconnect static pressure lines from induction tube and remove induction tube.
- (24) Disconnect static pressure line from fuel pump.
- (25) Disconnect tach drive, oil cooler oil lines and crankcase breather tube from engine.
- (26) Disconnect oil temperature, pressure, and cylinder head temperature probes.
- (27) Remove fuel pressure lines from flow divider.
- (28) Disconnect magneto primary leads.
- (29) Remove static pressure manifolds from engine baffling.
- (30) Remove top ignition wires from engine baffling.
- (31) Remove remaining engine baffling.
- (32) Remove oil filler tube.
- (33) Remove turbocharger and injector mount brackets.
- (34) Install caps or plugs on all disconnected lines, fittings and engine openings to prevent contamination.
- (35) Position all lines, wires, etc. to prevent interference with engine removal.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED


ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

1. Engine oil pressure fitting; restricted fitting required. (Refer to Para. 13-2, D., (3), (b) and SDB 0123)

2. Restricted turbo oil outlet fitting

3. Engine oil temperature probe fitting location


4. Chamfered case plug location



5. Check blank stud holes for break-through of case, to prevent oil leakage

6. Oil outlet
CAUTION: Do not overtorque fitting (140-160 in-lb max., 20% less if engine is hot). Case may crack.

7. Turbo mount hole – must be threaded to receive mount bolt



8. Scavenge pump and piggy-back fuel pump installation

9. Check engine sump for a machined flat and tapped hole to receive turbo mount




Figure 13-1. Engine Accessory Section

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-11

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

C. Engine – Removal

- (1) Install lifting ring; attach at third case half the bolt from the accessory case.
- (2) Support the weight of the engine with the lifting device.
- (3) Remove the four mount bolts and mount assemblies.
- (4) Lower engine to a suitable support on the floor, tilting it as necessary to allow accessories to clear pylon.
- (5) Remove any remaining lines, fittings, brackets, probes and accessories as required, preparing the engine for overhaul and replacement.

D. Inspection Prior to Engine Reinstallation

(1) Engine Compartment

- (a) Check engine mount rings and tubes for cracks or distortion.
- (b) Check pylon for worn spots, distorted tubes, cracks at welded joints and corrosion.
- (c) Check firewall for loose fittings, cracks and holes.
- (d) Inspect fire curtain for general condition. Repair or replace as necessary (see page MM-13-62, paragraph D).
- (e) Inspect mounts for checks, cracks, deformity and age hardening. Replace as required.
- (f) Check electrical panel for security and condition of wiring, and clean ground connections.
- (g) Clean main fuel sump screen and replace filter as required.
- (h) Check oil cooler for cracks, damaged fins, seal deterioration, and restrictions to airflow.

CAUTION: If engine removal was necessary due to internal engine failure, it will be necessary to flush oil lines and coolers with mineral spirits, kerosene, etc. to ensure removal of all possible contaminants. Inspect turbocharger and oil lines for damage or contamination.

NOTE: Oil coolers must be sent out for overhaul if oil exhibits metal contamination.

MAINTENANCE MANUAL

(2) Associated Engine Components

- (a) Check all lines, hoses, fittings and seals for evidence of deterioration, damage or contamination.
- (b) Check exhaust system for cracks and distortion of mounting flanges.
- (c) Check wastegate for evidence of internal heat erosion, freedom of movement, cracks and distortion.
- (d) Check exhaust tube matting flanges and V clamps for distortion and cracks.
- (e) Check heater muff and heat exchanger for evidence of cracks or deterioration.
- (f) Check turbocharger for freedom of rotation, cracks, indications of leakage, condition of heat shroud and security of fittings.
- (g) Check turbo mount tubing and fittings for cracks, distortion and excessive corrosion.
- (h) Check intake induction tube for cracks or distortion of mounting flange, and matting duct adaptor for deterioration.
- (i) Check static air fuel nozzle vent check valve for dirt contamination and freedom of movement at low pressures.
- (j) Check three sump drain valves, two in bottom engine sump and one low point in intake induction tube, for sticking or clogging.

NOTE: These valves are open in a neutral pressure position; a slight positive or negative pressure will close them.

- (k) Check engine baffling, fan shroud and fan for cracks, galling or other damage.

NOTE: For full inspection requirements see specific section identified.

(3) Engine Preparation Prior to Installation

- (a) Check mounting points on rear and case of new or rebuilt engine; hole on right upper rear case flange must be drilled and tapped for turbo mount bolt (Ref. 7, Fig. 13-1). Check bottom aft lower right sump for flatness and turbo mount clearance to drain boss radius.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Transfer restricted oil pressure fitting (P/N ECD110-11) (Fig 13-1, Ref. 1) (see also SDB 0123).
- (c) Transfer restricted oil feed fitting to turbo (Ref. 2, Fig 13-1).
- (d) Transfer oil return line fitting from scavenge pump (Ref. 8, Fig. 13-1).
- (e) Transfer oil inlet and outlet fittings (Ref. 6, Fig 13-1).
- (f) Check four cast holes (Ref. 5, Fig. 13-1) in accessory housing for break-through. If they show evidence of breaking through the case, the holes will have to be drilled and tapped to seal them or the accessory housing will have to be replaced.
- (g) Transfer case plug (Ref. 4, Fig. 13-1) to upper port and install oil temperature pick-up in lower port.


NOTE: If a new plug is being used, machine the edge of the nut so that it will not contact the engine mount lug on the pylon. If a used plug is installed, the previously machined section of the nut may not align in the correct position; it will also need to be machined.

NOTE: Items (1), (3), (5), (6), and (7) must be accomplished prior to engine installation. If not, engine may have to be removed to perform.


- (h) Remove fuel pump, transfer scavenge pump and bolts, and install fuel and scavenge pump.
- (i) Check security of oil filter.
- (j) Check condition and security of magneto. Be sure fuel pressure line clamp support is attached under upper bolt. Verify timing per Page 13-68.
- (k) Check security of alternator if new and remove fan to install spacer. If transferring alternator, inspect for cracks, check brushes and bearings, and reinstall.
- (l) Check starter for security, condition of electrical connections and brushes, and lubricate Bendix assembly. Check for proper ring gear clearance to Bendix.
- (m) Install lifting ring, attach at third top engine case bolt from the accessory end.

MAINTENANCE MANUAL

LEFT
SIDE



RIGHT
SIDE



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FIGURE 13-2. ENGINE COMPARTMENT VIEWS

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

E. Engine – Installation

- (1) Place engine in position under the pylon and attach lifting device.
- (2) Raise engine into pylon, tilting as necessary to insure accessories are not damaged.
- (3) Install serviceable mounts and bolts with one to three AN 960-716 washers under the nuts.

CAUTION: Check number of washers required on each installation so nut will not bottom out at torqueing.

- (4) Torque upper engine mount bolts to 460-500 in-lbs. before releasing the weight of the engine.
- (5) Install cotter pins on top bolts.
- (6) Disconnect and remove lifting device.
- (7) Torque lower engine mount bolts to 460-500 in-lbs. and install cotter pins.
- (8) Remove lifting ring.
- (9) Install baffling around sides of engine.
- (10) Install ignition wires to engine through baffling.
- (11) Install static air manifolds on baffling and safety wire screws in pairs.
- (12) Connect static air lines to nozzles.
- (13) Install oil filler tube.
- (14) Loosely install fan shroud and mount brackets.
- (15) Replace fan shroud foam rubber air seal if required.
- (16) Temporarily install fan to align shroud. Use small wood wedges, or similar shims around the fan to maintain equal clearance between the edges of the fan blades and the inside of the shroud.
- (17) Secure fan shroud, baffling and brackets, ensuring the shroud stays centered during the process.
- (18) Remove the fan.
- (19) Install fuel lines to engine driven fuel pump, oil lines to engine crankcase breather tube and fuel pump drain.
- (20) Install induction tube to engine sump.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (21) Install sump drain valves, three places.
- (22) Install bay tubes and fuel filter.
- (23) Connect fuel lines to filter.
- (24) Install induction tube to engine.
- (25) Install induction air line from fuel pump to induction tube.
- (26) Install primary oil cooler and ducting.
- (27) Install oil lines to both oil coolers.
- (28) Install induction air box, hoses, and fuel nozzle static air check valve.
- (29) Install engine ground strap, starter wire and alternator leads.
- (30) Install injector and turbocharger mount brackets.
- (31) Install injector, inlet adapter and AMC assembly.

NOTE: Ensure that the cooling shroud of the automatic mixture control is not contacting the forward pylon tubes or the horizontal upper deck static line. If the cover contacts the pylon, it will cause a vibration that will be felt by the pilot. If the shroud is touching the airframe, insert a flat blade screwdriver between the shroud and the pylon to move the shroud. If the shroud contacts the static line or the clamp that secures the line to the pylon, the clamp on the pylon should be relocated so there is no interference

- (32) Connect fuel and air lines to injector.
- (33) Install inlet adapter to injector and safety wire.
- (34) Install turbocharger and connect induction tube, oil lines and controls.
- (35) Connect manifold pressure line.
- (36) Install cylinder head, oil temperature, and oil pressure probes and connections.
- (37) Install exhaust system and exhaust gas temperature probe.
- (38) Connect flexible duct to heater muff, heater control and fan shroud.
- (39) Connect fuel and pressure lines to the fuel flow divider.
- (40) Install fire curtain and seal with fire barrier sealant CP 25WB+ (3M) or equivalent.
- (41) Install fuel line to fuel shutoff valve and seal doubler around line to the fire curtain with fire barrier sealant CP 25WB+ (3M) or equivalent.
- (42) Install top engine baffling.

MAINTENANCE MANUAL

- (44) Install fan and jack strut assembly.
- (45) Install baggage box.
- (46) Install fuel tanks.
- (47) Connect battery.
- (48) Service engine according to H10-360- Operators Manual.
- (49) Run engine to check control operation, fuel pressure and for evidence of system leaks.
- (50) Install all cowling.

F. Cylinder Removal in Helicopter

- (1) Remove upper side cowling to gain access to cylinder.
- (2) Remove engine baffling above affected cylinder.
- (3) Disconnect fuel and airlines from nozzle.
- (4) Remove any clamps attached to cylinder tubes.
- (5) Remove static air manifold.
- (6) Remove ignition wires as necessary and remove side baffling.
- (7) Disconnect exhaust system.
- (8) Remove induction tube to cylinder.
- (9) Disconnect oil return line from cylinder.
- (10) Remove probes if there are any in the affected cylinder.
- (11) Remove or relocate any other hoses or lines obstructing cylinder removal.
- (12) Refer to Avco Lycoming H10-360 Operators Manual for detailed procedure on cylinder removal, inspection and assembly.

G. Cylinder - Installation

- (1) Install cylinder per instructions in Avco Lycoming H10-360 Operators Manual.
- (2) Install any probes removed for disassembly.
- (3) Connect oil return lines to the cylinder.
- (4) Check condition of induction tube.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-18

- (5) Check exhaust system flanges and gaskets and install exhaust system.
- (6) Install engine side baffling.
- (7) Install ignition wires.
- (8) Install static air manifold, safety wire screws in pairs.
- (9) Install flow divider fuel line clamp.
- (10) Install nozzle and connect fuel and static air lines.
- (11) Service engine oil and fuel systems.
- (12) Run engine to check for system leaks.
- (13) Install remaining baffling and cowling.

13-3 ENGINE EXHAUST SYSTEM

A. General Information

The exhaust system on the engine consists of two manifolds which route exhaust gases through the heater-muffler and out through the wastegate and/or turbocharger, depending on engine power requirements.

B. Exhaust Manifold – Removal (See Figure 13-3)

- (1) Disconnect exhaust gas temperature (EGT) probe (1) from exhaust manifold.
- (2) Remove ducting from the heater muff (2).
- (3) Loosen turbocharger exhaust inlet clamp (3) and slide it down on the exhaust tube.
- (4) Remove exhaust inlet gasket.
- (5) Disconnect linkage (4) at the wastegate.
- (6) Remove clamp from turbocharger outlet (5).
- (7) Remove exhaust outlet and gasket.
- (8) Remove safety wire and retention pin (8) then remove wastegate (6).
- (9) Remove two nuts (7) on exhaust flange on each cylinder.
- (10) Break loose the sleeve joint at the heater muff. This will allow the exhaust system to be removed in two pieces.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

C. Exhaust Manifold – Inspection

Upon removal of the complete exhaust system, check the flange mounting of each exhaust stack for cracks, distortion of the flange and proper gaskets.

WARNING: At the 100-hour inspection it will be necessary to remove the cabin heat exchanger cover to inspect for any cracks internally which could allow carbon monoxide to enter the cabin through the heating system.

D. Exhaust Manifold – Installation (See Fig. 13-3)

- (1) Assemble the muffler cuff.
- (2) Install the right side manifold section with new gaskets and hardware. DO NOT TORQUE.
- (3) Insert heater muff sleeve on left half of manifold, over right side manifold.
- (4) Install left side manifold section to engine with new gaskets and hardware. DO NOT TORQUE.
- (5) Connect exhaust manifold to turbocharger inlet (3).
 - (a) Install new gasket.
 - (b) Slide collar up and rotate for proper alignment.
 - (c) Install turbocharger inlet clamp.
- (6) Install wastegate assembly (6).
- (7) Install exhaust outlet, shims, and clamp (5).
- (8) Check all attachment points for alignment.
- (9) Torque turbocharger clamps and manifold nuts to 80-90 in-lbs.
- (10) Safety wire turbocharger clamps.
- (11) Install EGT probe (1).
- (12) Install heater muff ducting (2).
- (13) Connect wastegate linkage (4).
- (14) Run engine and check for possible exhaust leaks.

MAINTENANCE MANUAL

E. Wastegate - Operational Check

NOTE: This check is done with the engine shut down.

- (1) Check freedom of operation of injector to wastegate rod "breakaway" function by holding the wastegate arm stationary, partially opened, and rotating the throttle in both directions causing rod to break away and move approximately two inches in each direction.
- (2) Insure breakaway mechanism is engaged after completion of operational check.

F. Wastegate - Rigging (See Fig. 13-3)

NOTE: Insure throttle arm is properly rigged to the injector.

- (1) Set injector to full throttle position.
- (2) Check wastegate butterfly to insure it is fully closed.
- (3) Adjust butterfly position by adjusting the inboard rod end.
- (4) Adjust wastegate closed stop to provide a .015-.020 gap between stop and arm.
- (5) Lock closed stop with jam nut.
- (6) Set injector to position throttle arm on the idle stop.
- (7) Check wastegate butterfly to insure it is open past center.
- (8) Adjust wastegate open stop to provide a .015-.020 gap between stop and arm.
- (9) Lock stop with jam nut.

G. Wastegate - Removal (See Fig. 13-3)

- (1) Disconnect wastegate linkage.
- (2) Disconnect clamp from turbocharger outlet.
- (3) Remove exhaust outlet and gasket.
- (4) Remove wastegate assembly.

H. Wastegate - Inspection

Check wastegate for internal heat erosion, freedom of movement, excessive clearance, cracks and distortion.




Figure 13-3. Engine Exhaust System and Wastegate

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

I. Wastegate – Installation (See Fig. 13-3)

- (1) Place wastegate in position on exhaust manifold.
- (2) Install exhaust outlet, gasket and clamp on turbocharger and wastegate.
- (3) Torque clamp to 20 in-lbs and safety wire.

NOTE: Later versions of wastegate installations no longer use the stainless band clamp. In its place is a stainless retention pin that is safetied with .032 ss ms wire.

- (4) Connect wastegate actuating rod.
- (5) Check assembly for security of attachment and freedom of movement.

13-4 **FUEL INJECTION SYSTEM**

A. General Information

All RSA type fuel injection systems are based on the principle of measuring engine air consumption by use of a Venturi tube and using the airflow forces to control fuel flow to the engine. Fuel distribution to the individual cylinders is obtained by the use of a fuel flow divider and fuel injection nozzles.

It is suggested that all adjustments to the RSA-5 fuel injection system be performed with the use of the Operation and Service Manual, Form 15-338C, published by the Bendix Corporation (Precision Airmotive).

B. Fuel Injector System - Troubleshooting

- NOTE:**
- a. Internal field maintenance of RSA type injector is limited to lapping the main metering jet and rotating plates, and replacing the "O" ring.
 - b. Repairs to and calibration of the regulator section must be done by an authorized Bendix Service Center or Overhaul Facility, for the specific parts list number indicated on the servo data plate.

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
<u>Hard starting</u> accompanied by the discharge of black puffs of smoke and popping from exhaust stack while cranking and possible fuel leakage from the engine sump drains.	Flooding because of excessive prime with boost pressure or improper mixture setting.	Clear engine by cranking with throttle in the wide open position, boost pump off and mixture in idle cut-off position.
	Flooding because of fuel servo leaky mixture control plate, usually indicated previously by failure to have a crisp shut-off when mixture control was placed at idle cut-off position.	See paragraph (C), page MM-13-29
	Flooding because of center body seal leak in servo.	See paragraph (B), page MM-13-29
<u>Hard starting</u> accompanied by possible backfiring and fuel leakage from induction tube sump drain.	Insufficient fuel prime, improper mixture control setting, no boost pressure or obstructed fuel flow.	Reference normal engine starting procedures page MM-13-37
	Insufficient fuel to fuel nozzles because fuel static air vent valve on air filter box stuck, resulting in fuel being drawn into induction sump tube and seeping from drain.	Clean fuel static air vent valve. Ref. paragraph (2)(i) page MM-13-13
<u>Rough idle.</u>	Mixture too rich or too lean.	Confirm with mixture control. A too rich mixture will be corrected and roughness decreased during lean-out, while a too lean mixture will be aggravated and roughness increased. Adjust idle to give a 25-50 rpm rise at 1400-1500 rpm.

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Rough idle. (CONTINUED)	Plugged nozzle(s), usually accompanied by high takeoff fuel flow readings and slightly higher MAP's.	Clean nozzles.
	Slight air leak into induction system through manifold drain check valve. Usually able to adjust initial idle, but rough in 1000-1500 rpm range, and will have a slightly higher MAP.	Confirm by temporarily plugging sump drain lines. Replace or clean check valves as necessary.
	Internal leak in injector (usually unable to lean out idle range).	Replace injector.
	<u>NOTE:</u> If engine does not stop crisply at mixture idle cut-off position, check paragraphs (b) and (c), page MM-13-29 and paragraph (9), page MM-13-35.	
Low takeoff fuel flow.	Fuel vaporizing in fuel line or distributor. Encountered only under high ambient temperature conditions or following prolonged operation at low idle rpm's.)	Increase engine rpm, turn into the wind or terminate ground operation. See paragraph C, page MM-13-27.
	Fuel filter or finger screen partially plugged.	Remove and clean in a suitable solvent.
	Injector out of adjustment.	Replace injector with properly calibrated unit.
	Faulty gauge.	Replace as necessary.
	Low fuel pressure.	Readjust to correct setting.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Poor cut-off.	Improper rigging of mixture control.	Adjust.
	Mixture control valve scored or not seating properly.	Eliminate cause of scoring (usually a burr or dirt) and lap mixture control valve and plug on surface plate.
	Boost on.	Turn off.
Rough engine and poor cut-off.	Fuel injection nozzle air bleed hole(s) clogged.	Clean or replace nozzles.
Erroneous fuel flow.	Faulty gauge.	Replace as necessary.
	AMC blast tube disconnected.	Repair as necessary.

TYPICAL FUEL FLOW PERFORMANCE FOR "F" MODELS

3050 RPM
SEA LEVEL DENSITY ALTITUDE

<u>MANIFOLD PRESSURE INCHES</u>	<u>HORSE POWER</u>	<u>PERCENT OF HORSE POWER</u>	<u>FUEL FLOW (PPH)</u>		<u>ENDURANCE (HOURS)</u>	
			<u>LEAN</u>	<u>- RICH</u>	<u>LEAN</u>	<u>- RICH</u>
20"	120	53%	62	76	3.8	3.1
22"	130	58%	68	82	3.4	2.8
24"	142	63%	74	89	3.2	2.6
26"	153	68%	80	97	2.9	2.4
28"	165	73%	87	107	2.7	2.2
30"	176	78%	NA	119	NA	2.0
32"	186	83%	NA	131	NA	1.8
34"	198	88%	NA	142	NA	1.6
36"	208	92%	NA	153	NA	1.5
38"	220	98%	NA	163	NA	1.4
39"	225	100%	NA	168	NA	1.4

NOTE: This performance is typical for Enstrom "F" models. There will be some variation between individual helicopters.

NOTE: "LEAN" limits denote EGT at 1650 degrees.

NOTE: "NA" denotes not approved mixture setting.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-26

MAINTENANCE MANUAL

C. General Operating Information

Several phases of ground operation are adversely affected by fuel vaporization in the lines. Fuel vaporization is experienced under extreme conditions of ambient and/or nacelle temperatures. Starting idle operating and engine shutdown procedures must all be modified to obtain optimum results under these conditions.

(1) Starting

In cold weather the engine compartment (nacelle) temperature drops off rapidly following engine shutdown and the nozzle lines remain nearly full of fuel. Cold weather starting procedures are therefore simple with highly predictable results. However, in extremely hot weather, nacelle temperatures increase rapidly following engine shutdown and fuel in the lines vaporizes and escapes out into the manifold. Hot weather starting procedures therefore depend on how soon the next start is attempted. Within the first 20-30 minutes wait; the vaporized fuel in the manifold will have nearly disappeared and some slight "priming" could be required to refill the nozzle lines and keep the engine running after first firing.

(2) Idling

During ground operation every precaution should be taken to keep nacelle temperatures from increasing to the extent that fuel will vaporize in the fuel lines. The following suggestions are aimed at minimizing this problem.

(a) Keep nacelle temperatures as low as possible by:

- 1 Avoiding excessive ground operation.
- 2 Keeping cooling airflow up by keeping engine RPM's as high as possible.
- 3 Upon restarting of a hot engine, operate engine at 1200-1500 rpm for several minutes to reduce the residual heat in the engine compartment.

(b) Keep fuel temperatures as low as possible. Higher RPM's with the accompanying higher line pressure and flow will help to dissipate some of the heat within the lines.

(c) Make an idle speed and mixture adjustment that is a compromise between the engine's requirement during the cool of the morning and the heat of the day. The higher than normal temperature encountered during the heat of the day results in the engine requiring a considerably leaner idle mixture. However, with fuel injection, this richer setting at the heat of the day will help dissipate more engine heat.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

(3) Shutdown (Cut-Off)

The idling procedure practiced just prior to engine shutdown has considerable bearing on the "cleanliness" or smoothness with which the engine stops. If the idling procedures suggested above are not followed and fuel is vaporizing in the lines, the engine will continue to idle very rough for several seconds. This, despite a 100% cut-off of fuel supply by the mixture control.

D. Injector

(1) General

Since the air differential pressure is a function of the airflow, and the fuel differential pressure is a function of the fuel flow, the correct fuel-to-air ratio is always maintained with this system regardless of the quantity of air being consumed by the engine.

Provisions have been made to compensate for the low air forces experienced in the idle range by the incorporation of the constant head idle spring. This spring provides a constant fuel differential pressure that will allow adequate fuel supply for the idle range. As the air forces increase, the spring compresses until the spring retainer touches the air diaphragm and acts as a solid member.

NOTE: The Bendix Model RSA5AB1 fuel injector which is supplied with the H10-360-F1AD Lycoming engine is internally adjusted specifically for the Enstrom turbocharged installation. ALL replacement injectors must be acquired from your nearest Lycoming or Bendix distributor by parts list number.

(2) Operational Checks

(a) Idle Mixture and rpm Check

- 1 Engine - Normal operating temperature.
- 2 Check magneto.
- 3 rpm - 1450 to 1500
- 4 Rotor - Disengaged
- 5 Boost pump - On

MAINTENANCE MANUAL

6 Slowly lean the engine, observing rpm change.

NOTE: Mixture to full rich before engine cuts out.

rpm rise during leaning--idle mixture is rich.

Immediate rpm drop--idle mixture is lean.

7 Perform idle mixture and rpm adjustment if necessary.

(b) Center Body Seal Leakage Check

1 Remove intake flex hose from injector inlet.

2 Disconnect injector fuel outlet line.

3 Cap injector fuel outlet fitting.

4 Magneto Switch - Off

5 Throttle - Full On

6 Mixture - Full Rich

7 Master Switch - On

8 Boost Pump - On

9 Observe injector impact tubes for fuel leakage.

NOTE: Leakage indicates a damaged center body seal. This repair is done ONLY by an authorized Bendix Service Center or Overhaul Facility.

10 Replace injector if necessary.

(c) Mixture Control Plates Leakage Check

1 Magneto Switch - Off

2 Disconnect injector fuel outlet line from injector.

3 Mixture Control - Full Lean

4 Throttle - All the way out (off).




FIGURE 13-4 FUEL SERVO

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- 5 Master Switch – On
- 6 Boost Pump – On
- 7 Observe open fitting for evidence of fuel leakage.

NOTE: Fuel leakage indicates scored (a) mixture control jet, (b) rotating plates or a damaged "O" ring on the jet.

- 8 Lap plates as necessary. See paragraph (9), page MM-13-35.

(3) Normal Operating Characteristics

- (a) Mixture full rich, engine at 3050 rpm.

- 1 29" MAP fuel flow - 110/120 lbs/hr.

- 2 39" MAP fuel flow - 150/155 lbs/hr.

- (b) Cold or hot engine may not idle with boost pump off.
- (c) At normal operating temperature engine should idle with boost pump on or off.
- (d) Engine idle rpm will not decrease, boost off to boost on.
- (e) When throttle is rapidly reduced to idle (chopped) from 3050 rpm, engine idle will not drop below normal idle setting.

(4) Rigging Throttle and Wastegate Actuating Arm to Injector

- (a) Position centerline of throttle arm two serrations (approximately 30°) counterclockwise from an imaginary line drawn between the throttle shaft end and the center of the idle valve arm pivot point.

(5) Injector - Removal (See Fig. 13-5)

NOTE: Injector removal, through the firewall access, can be accomplished without removing the turbocharger or the turbocharger can be removed to improve accessibility.

- (a) Disconnect hose from blast tube assembly (1).
- (b) Disconnect mixture control cable (2).
- (c) Disconnect and plug fuel inlet (3) and outlet lines (4).

MAINTENANCE MANUAL

- (d) Disconnect throttle (5) and wastegate (6) controls.
 - (e) Remove four attachment bolts (7).
 - (f) Disconnect air inlet hose (8) from injector adapter.
 - (g) Disconnect injector and air inlet adapter (9) by removing the four connecting bolts, two of which attach these components to the mounting bracket.
 - (h) Remove the injector, inlet adapter and outlet gasket.
- (6) Injector - Inspection
- (a) Check air inlet hose and blast tube hose for evidence of wear that could cause leakage.
 - (b) Check condition of gasket between injector and turbocharger.
- (7) Injector - Installation (See Fig. 13-5)

NOTE: On new injectors and those that have had throttle arm removed, it will be necessary to check rigging of throttle arm to injector and adjust idle stop screw prior to installation. (See Fig. 13-5)

- (a) Place injector and air inlet adapter (9) in position in the engine compartment.
- (b) Attach air inlet adapter to injector with the two forward bolts.
- (c) Assemble shock mounts on mounting bracket.
 - 1 Place one large diameter shock mount on each side of bracket, aligned with the hole.
 - 2 Insert small diameter shock mount into two large diameter shock mounts and mounting bracket.
 - 3 Insert metal spacer into small diameter shock mount.
- (d) Install injector and air inlet adapter on mounting bracket with one washer on each side of the shock mounts.
- (e) Connect air inlet hose (8) to adapter (9).
- (f) Insert gasket (10) between injector and turbocharger adapter and secure the components with the four bolts (7).




Figure 13-5. Fuel Servo Installation

MAINTENANCE MANUAL

- (g) Safety wire injector inlet adapter bolts (7).
- (h) Connect throttle cable (5) and wastegate actuating rod (6).
- (i) Connect fuel line (3) and outlet (4) lines.
- (j) Connect mixture control (2).
- (k) Connect hose to blast tube (1).

CAUTION: On new servos, when transferring blast tube assembly by removing AMC screws and replacing them, be sure the gasket is not rotated to block vent hole.

- (l) Check security of all connections.
- (m) Install turbocharger if it has been removed.
- (n) Test run engine to insure freedom of control movement and proper function.
- (o) Shut engine down and inspect for leaks.

(8) Injector - Adjustments (See Fig. 13-4)

(a) Idle Mixture and rpm

- 1 Engine - At normal operating temperature.
- 2 Check magneto.
- 3 Rotor - Disengaged
- 4 Boost Pump - On
- 5 Mixture - Full Rich
- 6 Adjust idle stop to provide 1450-1500 rpm idle.
- 7 Loosen jam nut on throttle lever to idle valve lever linkage.

NOTE: Rotation to shorten the linkage leans the mixture (turning the coarse thread into the throttle lever block).

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

8 Lean engine until the RPM rise just before shut down is 0 to 25 RPM.

NOTE: If the linkage rod bottoms out or disengages at either end during adjustments, it will be necessary to remove, adjust and reassemble linkage rod, threaded pin and block as follows:

Remove cotter pins and washers holding throttle lever block and idle valve lever pin to their respective levers.

Remove and measure the overall length of the block, linkage rod and pin assembly.

Disassemble block, rod and pin.

Reassemble to the same length as measured previously allowing enough thread at each end for further adjustment.

Reassemble linkage to the injector levers.

9 Increase the idle mixture until the engine will accelerate through the 1800 to 2200 RPM range without stuttering.

NOTE: After each adjustment clear engine (2000 rpm).

10 Perform injector operational check.

11 Lock linkage jam nut.

12 Engine – Normal cooling and shutdown procedure.

NOTE: Optional idle mixture adjustments: Required equipment: 100 cc flask and spare 28-12463-1 fuel outlet line.

Method: Engine off, mixture full rich, main fuel valve on, throttle at idle, attach spare fuel line to servo outlet, turn boost pump on and measure flow in cc. For one minute - flow should be 90-100 cc. If not, readjust idle mixture to required flow.

MAINTENANCE MANUAL

(9) Injector Repairs

(a) Lapping idle valve and mixture control valve.

1 Disconnect mixture control cable from the injector mixture control lever.

2 Remove the following:

Two screws holding the mixture control lever assembly in injector body.

Mixture control lever assembly.

Packing.

Idle valve.

NOTE: A hook fabricated from 1/8" brass rod can be used to hook the orifice of the idle valve and gently work it out.

3 Visually inspect non-tapered end of valves and control plates for scoring.

4 Remove scores by lapping components in a figure 8 pattern with crocus cloth and clean oil on a surface plate.

5 Wash components with clean gasoline or solvent.

6 Reinspect components to insure they are free of scores.

7 Reinstall the components as follows:

Idle valve, flat side first.

NOTE: Idle valve has a full length keyed slot.

New packing and "O" ring on mixture control valve.

Mixture control valve, flat side out.

Mixture control lever assembly.

8 Connect mixture control cable.

9 Perform leakage check.

E. Mixture Control

(1) General Information

The mixture control cable is manually operated by depressing the knob in end of control handle and pushing inward to richen mixture and pulling out to lean mixture. The mixture control handle also has a vernier adjustment to complete fine mixture adjustments. Vernier adjustments are made by turning the large diameter portion of the control handle.

CAUTION: It is important to keep friction on the mixture control shaft to prevent vibration from turning the vernier control during flight. If unobserved, cylinder head temperatures and exhaust gas temperature could exceed limits, causing engine and/or turbocharger damage.

Mixture control friction should be adjusted to provide sufficient "drag" to prevent rotation due to vibration, yet allow normal mixture adjustment without binding. Friction adjustments can be made by varying the torque on the large hex nut (11) by finger pressure without disturbing the mounting position of the control. See Fig. 13-6.

(2) Mixture Cable – Removal (See Figure 13-6)

- (a) Remove fiberglass seat deck and firewall inspection panels.
- (b) Remove covers from instrument console.
- (c) Disconnect mixture cable rod end (5) from mixture control lever (3) on injector.
- (d) Break check nut (6) loose from rod end (5) and remove both items from cable (9).
- (e) Remove check nuts (7) securing mixture cable to pylon mount which is aft of firewall. Remove nuts from cable.
- (f) Cut tie wraps securing cable in seat structure.
- (g) Remove check nut (10) from mixture cable inside instrument console.
- (h) Carefully pull mixture cable (9) through seat structure and out through instrument console.




Figure 13-6. Mixture Control Rigging

MAINTENANCE MANUAL

(3) Mixture Cable - Installation (See Fig. 13-6)

- (a) Install mixture cable (9) through instrument panel and route it through seat structure and firewall.

NOTE: Install check nut (10) on cable before routing through seat structure.

- (b) Secure mixture control to instrument console with check nuts (10).

NOTE: Mixture control is to be located in panel with a .120" gap between friction nut (11) and check nut (10). See Fig. 13-6.

- (c) Route mixture cable through pylon mount (8) on aft side of firewall and temporarily secure with check nuts (7).

NOTE: The final steps of cable installation are completed in the following Rigging Procedure.

(4) Mixture Control Rigging (See Fig. 13-6)

- (a) Locate mixture control lever (3) on injector as follows:

1 Rotate the mixture control arm (2) until it hits stop (1) in the full rich position. See Fig. 13-5.

2 Locate mixture control lever (3) in a down position, leaving a slight gap between lever and blast tube cover (5) while aligning notches to mesh with mixture control arm (2).

3 Install nut to secure mixture control lever (3) in this position.

NOTE: Recheck arm and lever positions after tightening nut. Control arm will sometimes rotate with nut during torque procedure.

- (b) Install check nut (6) and rod end (5) on mixture cable. Rotate rod end until it bottoms out on cable.

- (c) Attach mixture cable rod end to mixture control lever (3) and secure with hardware. Torque nut and install cotter pin.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (d) Tighten check nut (6) against rod end (5).
- (e) Position mixture control knob allowing 1/16 in. gap between check nut (12) and friction nut (11).
- (f) With mixture control in this position, loosen check nuts (7) at pylon mount and adjust cable sheath at mount bracket (8) until mixture control arm (2) hits the stop (1). Secure check nuts (7).

NOTE: Mixture control arm (2) must be in full rich position as shown in Fig. 13-6.

- (g) Pull mixture control knob out to full lean position and check that control arm (2) hits the stop (1).
- (h) Inspect all hardware for security.
- (i) Install covers on instrument console.
- (j) Install firewall inspection panels and fiberglass seat deck.

F. Automatic Mixture Control (AMC)

(1) General Information

This unit provides a variable orifice between impact pressure. It is responsive to both changes in air temperature and pressure (density) and will keep the differential air pressure between the two air chambers constant for any airflow, regardless of changes in the air inlet density.

The automatic mixture control incorporates a contoured needle that is moved in or out of an orifice by a bellows assembly. The sealed bellows, which reacts to changes in air density, is filled with helium gas and a small quantity of inert oil to help damp vibration. Under high density conditions, the bellows is contracted and positions the needle in the orifice so that the effect of impact pressure on venturi throat pressure in the airflow section is at a minimum. As density decreases, due to either a decrease in pressure or an increase in temperature, the bellows elongates and repositions the needle in the orifice to increase the effect of impact pressure on venturi pressure which decreases the air metering forces to maintain a constant fuel-air ratio.

Attached to the aluminum housing, enclosing the temperature sensitive AMC unit, is a blast tube assembly which provides the necessary cooling airflow.

NOTE: To facilitate removal and cleaning of the fuel injection servo finger screen, Enstrom recommends upgrading the AMC shroud to the latest configuration (P/N 28-181007-5), if not previously installed.

MAINTENANCE MANUAL

- (2) AMC - Removal (See Fig. 13-4)
 - (a) Disconnect blast tube hose.
 - (b) Remove safety wire and two screws attaching blast tube assembly and AMC unit.

NOTE: Observe position of gaskets and spacer to insure correct reassembly and operation.
- (3) AMC - Cleaning
 - (a) Remove the 9/16-24 plug and immerse unit in clean naphtha.
 - (b) Invert the unit to fill with fluid.
 - (c) Exercise the AMC needle with a hardwood or plastic rod to facilitate cleaning.
 - (d) Shake the unit vigorously while allowing fluid to drain.
 - (e) Repeat steps 2 through 4 several times.
 - (f) Allow naphtha to evaporate thoroughly. DO NOT dry with pressurized air.
 - (g) Install 9/16-24 plug and gasket.
 - (h) Torque plug to 55-60 in. lbs. and install safety wire.
- (4) AMC - Installation (See Fig. 13-4)
 - (a) Install screws with washers through blast tube assembly and AMC.
 - (b) Position gaskets and spacer on the screws and install assembly on injector.
 - (c) Safety wire.
 - (d) Connect air hose to blast tube.

G. Fuel Servo Screen

- (1) Servo Screen - Removal (See Fig. 13-4)
 - (a) Remove automatic mixture control and blast tube assembly.
 - (b) Disconnect and cap fuel inlet line.

MAINTENANCE MANUAL

- (c) Remove fuel inlet elbow.
- (d) Remove fuel screen carefully to avoid depositing residue from screen in the injector.

(2) Servo Screen - Cleaning

Refer to Bendix Overhaul Manual for RSA-AB1 Fuel Injectors, Form 15-419.

(3) Servo Screen - Installation (See Fig. 13-4)

- (a) Insert screen into injector body.
- (b) Install new "O" ring and fuel inlet elbow.
- (c) Connect fuel inlet line.
- (d) Run engine and check for fuel leakage around the inlet elbow.

H. Fuel Flow Divider

(1) Flow Divider - Removal (See Fig. 13-7)

- (a) Remove top right and left engine baffles.
- (b) Disconnect fuel lines (1) and (2) from flow divider.
- (c) Disconnect fuel nozzle lines (5).
- (d) Remove bolt (3) attaching center of flow divider mount bracket.
- (e) Remove two bolts (4) attaching inboard side of mount bracket to engine case.
- (f) Remove flow divider and mount bracket from engine compartment.

(2) Flow Divider - Disassembly

Refer to Bendix Form 15-540A Flow Divider Overhaul Manual.

(3) Flow Divider - Installation (See Fig. 13-7)

- (a) Place flow divider and mount bracket in position on the top right side of the engine.
- (b) Install bolt (3) attaching center of mount bracket to engine case.
- (c) Install two bolts (4), washers and nuts attaching top side of mount bracket to engine case.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-42

MAINTENANCE MANUAL

- (d) Connect fuel lines (1) and (2).
- (e) Connect fuel nozzle lines (5).
- (f) Briefly run engine and check connections for fuel leaks.
- (g) Install baffling.

I. Air Bleed Nozzles

(1) Nozzles - Troubleshooting

Engines operating with a plugged nozzle may exhibit some of the following characteristics:

- (a) Rough idle (with severe obstruction, a popping exhaust noise).
- (b) Roughness during high power settings.
- (c) Engine may quit with power reduction with severe obstruction.
- (d) Fuel nozzle pressure will indicate slightly higher fuel flows than normal.
- (e) Slightly higher MAP setting than normal for conditions.

(2) Nozzles - Operational Check (See Fig. 13-7, View A)

- (a) Disconnect the fuel and air lines at the nozzles. See Removal Procedure.
- (b) Remove nozzles.
- (c) Reattach nozzles to fuel lines.
- (d) Direct nozzles into bottles of equal size.
- (e) Move throttle and mixture controls full forward.
- (f) Turn on boost pump.
- (g) Fill bottles about half full of fuel.

NOTE: Observe fuel flow from the nozzles. Fuel should flow in a stream, approximately the size of the lead in a mechanical pencil, from the discharge end of the nozzle. Leakage from the air bleed hole indicates an obstructed nozzle.

MAINTENANCE MANUAL

- (h) Remove the bottles and place them on a table or some other flat, level surface.
 - (i) Compare fluid levels in the bottles to identify which nozzles, if any, are obstructed.
- (3) Nozzles - Removal (See Fig. 13-7, View A)
- (a) Remove right and left panels from top of engine.
 - (b) Disconnect air line hoses (2) from nozzles.
 - (c) Disconnect fuel line fittings (1) from nozzles.
 - (d) Remove air line fitting (3) and spring to provide access for socket installation on nozzle, and remove nozzles.

NOTE: Use care in retaining the two "O" rings located inside airline fitting for reinstallation.



- (4) Nozzles - Cleaning (See Fig. 13-7, View A and Fig. 13-8)
- (a) Remove fuel restrictor from nozzle body and clean in MEK or acetone. Fuel restrictors should be cleaned annually. More frequent cleaning may be required, not to exceed 100 hours operational time.
 - (b) Use air pressure to clean the nozzle body. The nozzle body should be removed annually to reduce possibility of seizure in the cylinder. Do not clean any internal passages with sharp instruments such as drills, pins, needles, etc.

NOTE: Keep each restrictor with its respective body.


- (5) Nozzles - Installation (See Fig. 13-7, View A)
- (a) Install nozzles in cylinders. Torque to 60 in. lbs.
 - (b) Install air line fitting (3) and nozzle springs.
- NOTE: Be sure to install both "O" rings under air line fitting.
- (c) Connect fuel line fittings (1) to nozzles. Torque 25-50 in-lbs maximum.
 - (d) Connect air line hoses (2) to nozzle fittings (3) and secure with clamp.
 - (e) Install right and left top engine panels.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL



FLOW DIVIDER INSTALLATION



TYPICAL AIR BLEED NOZZLE INSTALLATION
LOOKING AFT

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED


MAINTENANCE MANUAL

LA-8249A AIRBLEED NOZZLE ASSEMBLY SAME AS LW-18267 EXCEPT DEVIATIONS AS NOTED FOR ITEM NUMBER 3 AND NOTCHED RESTRICTOR.



NOTE: ONE NOTCH ON RESTRICTOR

AIRBLEED NOZZLE ASSEMBLY LA-8249A



- 1. SPRING HOLDER
- 2. SPRING
- 3. SPRING HOLDER
- 4. PREFORMED PACKING
- 5. TUBE ASSEMBLY
- 6. PREFORMED PACKING
- 7. BODY ASSEMBLY

AIRBLEED NOZZLE ASSEMBLY LW18267

FIGURE 13-8

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

13-5 TURBOCHARGER

A. General Information

The turbo units primary moving parts are a rotating shaft with a turbine wheel on one end and a compressor impeller on the other, all precision balanced and each impeller contained in its own housing. The turbine wheel, driven by exhaust gas energy, drives the impeller which compresses intake air to a density equivalent of near sea level and delivers it to the engine intake. This increased volume of air allows the engine to "breathe" with the same volumetric efficiency, and produce equivalent power, at all altitudes up to 12,000 feet density altitude.

When turbocharged, the engine's entire intake system is pressurized. The fuel/air mixture is literally forced into the cylinder the instant the intake valve starts to open; completely filling the entire chamber prior to the start of the compression stroke. This assures a full charge of the fuel/air mixture, resulting in more power during each combustion stroke. It also assures a more evenly balanced air/fuel/power ratio between cylinders.

B. Turbocharger - Removal (See Fig. 13-9)

- (1) Remove seat cushions and back access panel in fiberglass seat deck.
- (2) Remove firewall access panels from cabin firewall.
- (3) Open left side engine panel.
- (4) Remove clamp from exhaust outlet and gasket.
- (5) Disconnect and remove turbo heat shield.
- (6) Remove exhaust inlet clamp and slide adapter collar down on the exhaust tube. Remove gasket.
- (7) Loosen induction tube clamps and slide adapter collar down on the induction inlet tube.
- (8) Disconnect inlet and outlet lines.

NOTE: Leave the lower elbow and flexible line attached to the turbocharger.

- (9) Remove the four bolts from the turbo inlet adapter at the injector. Leave inlet adapter mounted on the turbocharger.
- (10) Detach turbocharger from the turbo mount brackets.

NOTE: Identify washers (shims) for proper reassembly.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-47

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (11) Slide turbocharger up and off the mount brackets to remove turbo and adapter gasket from the aircraft.
- (12) Cover openings at injector, induction tube and exhaust system to prevent contamination.
- (13) Remove injector inlet adapter and gasket from turbocharger.

NOTE: Identify orientation of adapter to turbocharger for reassembly.

C. Turbocharger – Inspection

Check turbocharger unit for the following:

- (1) Rotating unit rubbing housing.
- (2) Cracked or distorted housing.
- (3) Dirt accumulation on impeller.
- (4) Carbon buildup on turbine wheel.
- (5) Foreign object damage.
- (6) Evidence of looseness between compressor and turbine sections.

D. Turbocharger – Installation (See Fig. 13-9)

- (1) Install a new gasket between the turbo inlet adapter and the turbocharger and secure adapter, properly oriented, to the turbocharger. Torque the screws to 35 in-lbs/4.0 Nm. Safety wire screws.

NOTE: Replace slotted head screws with cap screws (P/N NAS1352-3H8P).

- (2) Install the lower outlet oil elbow and flexible outlet line to the turbocharger on the bench. Torque and safety wire.
- (3) Install inlet oil elbow, if removed.
- (4) Install turbocharger on mount brackets with washers (shims) located properly. DO NOT torque bolts.
- (5) Install turbocharger heat shield. Safety wire from a cap on one side of each mount bracket, behind the bracket, to the next cap.
- (6) Install a new gasket and the bolts connecting the injector to turbo inlet adapter. DO NOT torque bolts.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (7) Connect exhaust collar and steel gasket to the turbocharger exhaust inlet. Rotate the collar for correct alignment. Install exhaust inlet clamp, torque to 70-80 in-lb/7.9-9.0 Nm and safety.

NOTE: Slip clamp over end of tube to assemble. Do not spread.

NOTE: If required, loosen turbo mount brackets on the engine to achieve proper turbo alignment.

- (8) Install the flexible sleeve and clamps between the induction inlet tube and the turbocharger compressor. Torque 40-45 in-lb/4.5-5.1 Nm and safety (MS20995C32).

NOTE: The turbocharger center divider clamp may be released to rotate the compressor section for adjustment. DO NOT break the seal.

- (9) Install gasket, exhaust outlet and clamp. Torque clamp to 70-80 in-lb/7.9-9.0 Nm.

- (10) Torque the two turbocharger mount bolts.

NOTE: If required, torque and resafety the lower engine turbocharger mount bracket bolts.

- (11) Torque injector outlet attaching bolts. If required, torque turbo center divider clamps and safety.

- (12) Connect oil inlet and outlet lines.

NOTE: Be sure that check valve located in the oil inlet line has arrow pointing toward turbocharger.

- (13) Inspect all areas prior to closure of the engine compartment and flight check.

E. Turbocharger – Repair

Consult Hartzell Engine Technologies, or an authorized Hartzell/Rotomaster/Rajay turbocharger repair facility for information on turbocharger repair or overhaul.

13-6 Turbocharger Static Air Fuel Nozzle Pressure System

A. General Information

In order to attain positive pressure at the air bleed nozzles for starting, idle, and all other operating environments, a static air system is required.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL




Figure 13-9. Turbocharger Installation

MAINTENANCE MANUAL

Installed in the static air system is a single, swing type, check valve which is vented to ambient air pressure on the filtered side of the inlet container. During starting, idling and manifold pressure up to ambient, this valve is open. The valve closes automatically when turbocharger compressor inlet pressure exceeds the existing ambient pressure. Pressurized air is now being furnished to the air bleed nozzle from a line connected to the induction inlet tube. Static pressure lines run to manifold pipes located above the rocker covers on each side of the engine. Flexible lines run from these manifolds to each cylinder nozzle to provide positive system pressure in all operating environments.

B. Turbocharger Static Air Pressure System - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Hard starting or will not start.	Ambient air check valve stuck closed or sticky.	Clean or replace valve.
	Dirt in nozzle.	Clean lines and nozzles.
	Dirt in air manifolds.	Disconnect lines and blow out static air manifolds.
Engine rough at idle and low power.	Ambient air check valve partially closed or sticky.	Clean or replace valve.
Excessive smoking at idle.	Ambient air check valve stuck closed or sticky.	Clean or replace valve.
Excessive EGT at high power.	Ambient air check valve stuck open.	Clean or replace valve.
Engine quits with power reductions at high density altitude.	Ambient air check valve stuck closed or sticky.	Clean or replace valve.

MAINTENANCE MANUAL

C. Ambient Air Check Valve

(1) Ambient Air Check Valve - Removal (See Fig. 13-10)

Disconnect inlet and outlet lines at the ends of the valve. Observe airflow marking on valve case for correct installation.

(2) Ambient Air Check Valve - Disassembly

Remove "hinge" end of valve (marked on hex flat) by locking opposite end in vise and loosening hinge end with a wrench.

(3) Ambient Air Check Valve - Cleaning

Carefully clean inside surfaces and components with a clean, lint-free cloth and air.

(4) Ambient Air Check Valve - Installation (See Fig. 13-10)

Connect to inlet and outlet lines to allow "free flow" from the air inlet container to the static pressure lines.

13-7 PRIMARY AIRFLOW SYSTEM

A. General Information (See Fig. 13-11)

Intake air is drawn in through the non-ram air scoop mounted on the right side of the aircraft. The intake air then passes through the air filter on its way to the injector. At the injector the air volume is metered in proper proportion to the fuel mixture that the engine requires. The metered air is drawn into the compressor impeller section of the turbocharger where it is compressed. This compressed air is forced into the intake manifolds where it is delivered to the various cylinders. After combustion, the exhaust gases are expelled out the exhaust ports and through the exhaust manifolds back to the turbocharger. The engine exhaust gases drive the turbocharger exhaust turbine wheel which drives the compressor impeller through a common rotating shaft. Exhaust gases are then dumped overboard through the exhaust outlet. A bypass, just before the turbocharger exhaust inlet, incorporates a wastegate which is mechanically linked to the throttle lever to regulate exhaust flow through the turbocharger for varying engine power requirements.

TURBOCHARGER STATIC PRESSURE SYSTEM




FIGURE 13-10

PRIMARY AIR FLOW SCHEMATIC




FIGURE 13-11

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

B. Air Filter and Housing

(1) General Information

A polyurethane filter is utilized to remove all foreign material from the air before it enters the induction system. The filter is installed in a housing which also incorporates an alternate air door and auxiliary bypass door. In the event of a filter blockage, due to ingested dirt or ice buildup, the spring loaded alternate air door will open, allowing engine compartment air to be drawn into the injector. The auxiliary bypass door prevents damage to the filter assembly and flexible intake hose by allowing back pressure, due to engine backfire, to escape with minimal restriction.

(2) Filter Removal (See Fig. 13-12)

Filter change is recommended every 100 hours. More frequent changes will be necessary for aircraft used for agricultural spraying, dusting or operation in dusty areas.

- (a) Remove air box cover (1).
- (b) Remove filter retainer (2).
- (c) Remove and discard filter (3).

(3) Filter Installation (See Fig. 13-12)


NOTE: Clean air box and check for freedom of operation of the alternate air door (4) and auxiliary bypass door (5) before installing filter.

- (a) Install filter in air box (6).
- (b) Install filter retainer with auxiliary bypass door (5) oriented to align with aft side of inlet hole in air box cover(1).
- (c) Install air box cover.

(4) Housing Removal (See Fig. 13-12)

- (a) Disconnect flexible intake hose (7) from air box.
- (b) Disconnect static air line (8) above hose.
- (c) Disconnect unit from pylon mount bracket (9).
- (d) Support air box and disconnect it from the firewall mount bracket (10).
- (e) Lift unit from aircraft, allowing drain line (11) to pull through cowlings.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED



FILTER - PRIMARY AIRFLOW SYSTEM

FIGURE 13-12

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-56

MAINTENANCE MANUAL

- (5) Housing Installation (See Fig. 13-12)
 - (a) Position unit in aircraft with drain line (11) going out through the lower side cowl.
 - (b) Secure unit to firewall mount bracket (10).
 - (c) Secure to pylon mount bracket (9).
 - (d) Connect static air line (8).
 - (e) Connect flexible intake hose (7).

13-8 COOLING SYSTEM

A. General Information

The cooling system consists of the fan assembly, shroud assembly, oil coolers and ducting. Outside air is drawn in by the fan and forced through the shroud assembly to provide cooling air flow to the engine and other components.

B. Fan Assembly

- (1) Fan - Removal
 - (a) Remove aft cowl and baggage box.
 - (b) Remove idler pulley assembly.
 - (c) Remove jack strut and drive pulley.
 - (d) Remove fan.

NOTE: The fan, like the starter ring gear support, is designed to fit on the output flange of the engine in only one position. Marking a fan mount hole and its associated stud is suggested to ease installation.

(2) Fan - Disassembly

NOTE: Disassembly of the fan to replace blades requires that the fan be statically rebalanced prior to installation. Repair and balancing can be accomplished by Enstrom Helicopter Corporation or a maintenance facility equipped with tools specified in the Balancing Procedure.

- (a) Mark blade ring and fan disc to show proper relationship for reassembly.

MAINTENANCE MANUAL

- (b) Remove all nuts, bolts and washers attaching blade ring to fan disc.

NOTE: Check for elongation of bolt holes. Fan should be replaced if evidence of hole elongation exists.

- (c) Discard used locknuts.
- (d) Drill out rivets securing damaged blade(s).

(3) Fan - Reassembly

- (a) Attach new fan blade(s) to blade ring with AN427M4-7 rivets.

- (b) Align and attach blade ring to fan disc.

NOTE: Attach with AN3-6A bolts, one AN960-10L washer under each nut, and new AN364-1032 nuts.

- (c) Balance fan.

(4) Fan - Balancing (See Fig. 13-13)

- (a) Install balancing arbor (T-1900) to fan assembly.

- (b) Place assembly on balancing stand and allow heavy side to settle to the bottom. Identify blade that is closest to the bottom.

- (c) Remove bolts, nuts and washers from heavy side and replace with AN3-5A bolt, (2) AN960-10L washers, and a AN364-1032 nut and/or remove AN960-10L washers from light side and replace with AN960-10 washers as required for balancing.

NOTE: Not more than (3) AN960-10 washers may be used per bolt for balancing.

Fan blade should balance in any position with blade drift not exceeding one inch in five seconds from any check position.

- (d) Torque all nuts.

(5) Fan - Installation


- (a) Align and install fan on engine output flange.

NOTE: Insure shim is installed on output flange before installing fan.

- (b) Install jack strut and lower drive pulley.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL



NOTE:

NOT MORE THAN (3) AN960-10 WASHERS
MAY BE USED PER BOLT FOR BALANCING.

FAN BLADE SHOULD BALANCE IN ANY
POSITION WITH BLADE DRIFT NOT
EXCEEDING ONE INCH IN FIVE SECONDS
FROM ANY CHECK POSITION.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

FIGURE 13-13 FAN BALANCING

MAINTENANCE MANUAL

- (c) Install idler pulley assembly.
- (d) Slowly rotate fan to check for proper fan to shroud clearance. Adjust shroud as necessary.
- (e) Run engine to check belt tracking and fan operation.
- (f) Install baggage box and cowling.

C. Fan Shroud

(1) Fan Shroud - Removal

- (a) Remove aft cowling and cowling from both sides.
- (b) Remove baggage compartment.
- (c) Remove idler pulley assembly.
- (d) Remove jack strut and drive pulley.
- (e) Remove fan assembly.
- (f) Remove shim, starter ring gear and alternator drive belt.
- (g) Disconnect lines and drain oil from auxiliary oil cooler.

NOTE: Raise lines as they are disconnected to prevent drainage of oil from lines and primary oil cooler.

- (h) Remove auxiliary oil cooler.
- (i) Disconnect shroud from bracket attaching it to the bottom of the engine.
- (j) Disconnect flexible duct to heater muff.
- (k) Remove two lower panels from the front of the shroud assembly.
- (l) Disconnect alternator from belt tension adjustment bracket and remove bracket.
- (m) Remove fasteners attaching fan shroud to fire curtain and top and side engine baffling.
- (n) Disconnect air deflection vanes.
- (o) Remove air deflection vanes.
- (p) Remove fan shroud assembly by pulling it aft and tipping it as necessary to clear pylon.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(2) Fan Shroud – Installation

- (a) Position fan shroud in engine compartment and loosely attach it to the top engine bracket and side baffling.
- (b) Temporarily install the fan to align shroud and tighten fasteners.
- (c) Install air deflection vanes.
- (d) Install two lower panels on front of shroud assembly and attach lower engine shroud bracket.
- (e) Attach fire curtain.
- (f) Install belt tensioning bracket.
- (g) Install auxiliary oil cooler.
- (h) Seal holes where leakage may occur with fire barrier sealant CP 25WB+ (3M) or equivalent.
- (i) Connect flexible duct to heater muff.
- (j) Connect lines to primary oil cooler.
- (k) Install alternator drive belt and starter ring gear.
- (l) Check shroud foam tape and replace if necessary.
- (m) Install shim and fan assembly.
- (n) Install drive pulley and jack strut.
- (o) Install idler pulley assembly.
- (p) Check engine oil level and replace oil removed with oil cooler.
- (q) Run engine to check fan clearance and belt tracking.

(3) Foam Tape – Installation

- (a) Remove all tape from the fan shroud and check fan blade to shroud clearance. Adjust if necessary.

NOTE: If significant amounts of tape were missing, check oil coolers for partial obstruction by tape fragments.

- (b) Remove all grease, oil and contaminants from area to be taped by cleaning with solvent. Avoid finger prints on cleaned area.
- (c) Cut end of foam tape at approximately 45° angle.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(d) Install tape and cut finishing end to match.

CAUTION: Upon initial running of the engine, it is necessary to clean oil cooler air passages of foam tape particles sheared off by the fan.

D. Firewall Repairs (See Fig. 13-14)

NOTE: All openings in the firewall in excess of 1/32 inch are to be repaired. Small openings, such as around pylon tubes, may be caulked with CP 25WB+ (3M) or equivalent sealant. Fire curtains requiring extensive repairs should be replaced.

- (1) Clean area of repair with acetone.
- (2) Holes up to 1/4 inch in stainless steel cabin firewall:
 - (a) Caulk with fire barrier sealant CP 25WB+ (3M) or equivalent.
- (3) Holes up to 1 inch in fabric (see Fig. 13-14 A):
 - (a) Form (2) round patches of 0.015 thick stainless steel, allowing 1/2 inch overlap on all sides of existing hole.
 - (b) Drill 0.015 inch diameter hole in center of both patches.
 - (c) Coat one side of each patch with fire barrier sealant CP 25WB+ (3M) or equivalent.
 - (d) Place one patch of each side of fabric hole with fire barrier sealant CP 25WB+ (3M) or equivalent against the fabric.
 - (e) Fasten patches over the hole with (1) AN525-6R6 screw, (1) AN960-6L washer, and (1) AN364-632 nut.
- (4) Areas of worn fabric around pylon tubes or cables (see Fig. 13-14 B):
 - (a) Cut a patch of firewall curtain (or equivalent) to cover 1/2 inch to 3/4 inch beyond the damaged area.
 - (b) Coat one side of patch with fire barrier sealant CP 25WB+ (3M) or equivalent.
 - (c) Apply patch, sealant side against fabric.
 - (d) Attach patch with AN525-6R6 screws, AN960-6L washers, and AN364-632 nuts at 3/4 inch to 1 inch spacing.
 - (e) Seal nonessential gaps (around pylon tubes, etc.) with fire barrier sealant CP 25WB+ (3M) or equivalent.

MAINTENANCE MANUAL




FIGURE 13-14

STANDARD FIRE CURTAIN REPAIR PROCEDURE

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (5) Tears in fabric material which are less than 3" in length (Fig. 13-14 C):
 - (a) Lace damaged area together with .020 inch stainless steel safety wire.
 - (b) Apply sealant to repaired area on the side away from the engine compartment.
- (6) Tears in fabric material in excess of 3 inches in length:
 - (a) Cut two 1-inch wide strips of .015 inch stainless steel to a length allowing for 1/2 inch overlap at each end of the repair (Fig. 13-14 D).
 - (b) Drill .150 inch (approximate) diameter holes, space 1 inch apart diagonally.
 - (c) Apply patch, sealant side against fabric.
 - (d) Attach patch, sealant sides against fabric, with AN525-6R6 screws, AN960-6L washers, and AN364-632 nuts.

13-9 IGNITION SYSTEM

A. General Information

The D-3200 ignition system consists of a dual magneto which features two electrically independent ignition circuits in one housing, a harness assembly, starting vibrator (for shower of sparks starting system), and the magneto switch.

At low cranking speed of the engine the vibrator provides the high voltage spark necessary to fire the plug. The vibrator provides interrupted battery current to the primary coil of the magneto where it is stepped up by transformer action, producing a shower of sparks which is directed to the spark plugs through the retard points located in the left magneto. Detailed operation, installation and service instruction may be found in Bendix Operational Manual No. L-928 and Overhaul Manual No. L-945.

B. Ignition System - Troubleshooting

NOTE: Reference information found in Bendix Installation, Operating and Maintenance Instructions Manual L-928.

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Hard starting.	Low voltage at vibrator input (9.5 volts minimum on 12 volt systems, measured between vibrator "IN" and ground terminal with starter engaged).	Check and change or replace battery as required. Use of an auxiliary power unit is recommended for cold weather starts. Check all electrical grounds and connections for corrosion or looseness.
	Inoperative vibrator (no buzzing audible when starter is engaged).	Check - ground and power in. Replace vibrator.
	Incorrect vibrator point gap.	.025" ± .005" gap.
	Retard points opening too late.	Check timing of retard points according to paragraph E (2), page MM-13-68.
Engine kicks back during starting.	Open retard circuit. Engine fires only in its normal advance position.	Check continuity (10 ohms or less) between LR terminal of the vibrator to nearest paint-free ground. If circuit is open, retard contact spring in magneto may not be making contact.
	Retard points not closing due to incorrect adjustment.	Check and adjust retard points as necessary.
	Poor electrical connection.	Check connections at vibrator and magneto.
	Internal relay in vibrator unit not functioning.	Replace vibrator assembly.
	Magneto incorrectly timed to the engine.	Check magneto to engine timing (see Magneto Installation and Timing to Engine).
	Magneto internal timing incorrect.	Check magneto timing per paragraph E (2), page MM-13-68.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

<u>Problem</u>	<u>Cause</u>	<u>Action</u>
Engine roughness.	Fouled or defective spark plugs.	Clean or replace spark plugs.
	Defective spark plug leads.	Check plug leads for continuity and breakdown.
	Arcing in distributor.	Check distributor block for moisture and carbon tracking.
	Eroded or compressed distributor block contact spring(s).	Check contact springs in distributor block.
	Burned magneto contacts.	Check magneto contact assemblies for burring or dirt.
Excessive magneto drop on rpm check.	Magneto to engine timing incorrect.	Adjust timing.
	Incorrect contact adjustment.	Inspect contact assemblies for proper opening.
	One or more cylinders misfiring.	Check plugs and leads.

C. Vibrator-Magneto Check

- (1) Disconnect starter input wire to prevent engine from turning during this check.
- (2) Turn engine in direction of normal rotation to bring number one cylinder to top dead center on its compression stroke.
- (3) Check to insure retard points have opened.
- (4) Hold No. 1 cylinder top plug wire 3/16 inch from ground.
- (5) Turn magneto switch to BOTH.
- (6) Depress starter button.

NOTE: A steady spark should be visible between the plug wire and ground. A weak or missing spark indicates possible faulty vibrator, electrical connection or magneto internal timing.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (7) Release the starter button.
- (8) Turn the magneto switch to OFF.
- (9) Check the system, replace or adjust components as necessary.
- (10) Repeat checking procedure before reconnecting the starter.

D. Magneto Operation Check

- (1) Start the engine and engage the rotor.

NOTE: Maintain rotor in flat pitch during the following procedure.

- (2) Advance the throttle to 1800 rpm and allow cylinder head temperature to reach 200°F.
- (3) Slowly advance the throttle to 2300 rpm and allow oil temperatures to reach 80°F.
- (4) Advance the throttle to 3050 rpm.
- (5) Check manifold pressure; 17-19 inches.
- (6) Check fuel flow; 60-80 lb/hr.
- (7) Turn the magneto switch from BOTH to L (left magneto) position. Note rpm drop (125 rpm max.) and EGT rise (100°F max.) in 5 seconds.
- (8) Return the switch to BOTH position and allow rpm to stabilize.
- (9) Turn the magneto switch from BOTH to R (right magneto) position. Note rpm drop (125 rpm max.) and EGT rise (100° F max.) in 5 seconds.

NOTE: Maximum permissible rpm differential between left and right magnetos is 50 rpm without engine roughness. A differential of greater than 50 rpm or a drop in rpm greater than 125 rpm may indicate spark plug, spark plug lead wire, or magneto problems.

An EGT rise in excess of 100°F, while operating either in L or R position of the magneto switch indicates a magneto timing problem.

- (10) Return the switch to BOTH position and allow rpm and EGT to stabilize prior to engine shutdown.

E. Magneto

- (1) Magneto – Removal
 - (a) Remove the magneto cover.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (b) Remove nuts and washers from the magneto mounting clamp studs.
- (c) Pull the flow divider fuel line bracket forward to clear the stud and rotate the bracket and clamp upwards to allow clearance for magneto clamp removal.
- (d) Remove the magneto and clamps.

(2) Magneto Installation and Timing to the Engine

NOTE: Refer to Enstrom Tech Tip, Magneto Maintenance, for additional information regarding magneto installation before proceeding.

NOTE: Remove bottom spark plugs for ease of turning over engine.

- (a) Remove the bottom spark plugs.
- (b) Remove the plastic viewing plug from the left side of the magneto. Ensure that the other three plugs are installed and that the vented plug(s) is not in the top.
- (c) Turn the magneto drive shaft in the direction of normal rotation until the chamfered tooth on the distributor gear is visible in the timing hole and the "C" printed on the rotating magnet is aligned with the cast marker on the inside of the magneto housing.

NOTE: Observe at this time that the pointer in the rotor viewing window aligns with the "L" marked on the rotor. If internal timing of the magneto is required, refer to the Enstrom Tech Tip or Bendix Operation and Maintenance Manual No. L-928.

- (d) Set engine No. 1 cylinder at $21.5^{\circ} +0.05/-0$ BTDC (align mark on the starter ring gear with the mark on the starter housing) on its compression stroke (see Figure 13-15).
- (e) Maintain magneto No. 1 firing position (chamfered tooth visible in the hole and pointer aligned with "C" on the rotor).

NOTE: Ensure the flow divider fuel line support bracket is placed on the magneto mount stud before the nut and washer are installed.

- (f) Install the magneto to the engine. Install the clamps, new lock washers, nuts, and the flow divider fuel line bracket. Tighten the nuts finger tight so that the magneto can be moved for final timing to the engine.
- (g) Attach the "P" lead wires from the magneto timing light to each "P" lead, black lead to ground.
- (h) Turn the entire magneto in the direction of rotor rotation until the timing light indicates the contacts (points) have closed.

TIMING MARKS

NOTES: TIMING MARKS ARE VISIBLE THROUGH HOLES IN THE FAN ASSEMBLY

NEWER FLYWHEEL SUPPORTS INCLUDE A 23° INDEX MARK

LOCATION OF INDEX MARKS RELATIVE TO GEAR TOOTH WILL VARY DEPENDING HOW GEAR WAS INITIALLY MARKED




Figure 13-15

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (i) Rotate the magneto in the opposite direction until the first set of contacts opens.
- (j) Tighten the magneto clamps and install the plug in the viewing hole.
- (k) Back the engine up approximately 20° to 30° and then carefully bump the engine forward while observing the timing light.
- (l) At the No. 1 firing position (21.5° BTDC), the first contact should open. The second contact should open within +0.5 / -1.5° of the first contact.

NOTE: Each tooth of the starter ring gear is approximately 2°.

- (m) Torque the magneto hold-down nuts to 17 ft-lb (23 Nm)
- (n) Disconnect the timing light leads from the "P" leads and reconnect one to the retard breaker terminal.
- (o) Rotate the crankshaft to bring No. 1 cylinder to half tooth (1°) on the ring gear after TDC.

NOTE: The timing light should go out at a half tooth after TDC indicating the retard points have opened.

- (p) Loosen the retard cam securing screw and adjust the cam, as necessary, to achieve correct timing.
- (q) Retorque the cam securing screw to 16-20 in-lb/1.8-2.3 Nm.
- (r) Back the engine off 20° to 30° and bump it forward again until the timing light goes out. Check the timing mark on the starter ring gear to ensure the crankshaft is at half tooth in the ring gear after TDC (1° crankshaft rotation after TDC). Adjust the retard cam as necessary.
- (s) Remove the timing light leads.
- (t) Install the magneto cover. Torque the screws to 30-35 in-lb (3.4-4.0 Nm).
- (u) Install the "P" leads.

NOTE: It is important that the retard P lead slides freely within the magneto cover to ensure that the P lead makes an electrical connection with the retard points (contactor) inside the magneto.

NOTE: Is it possible to distort the retard points (copper contactor tang) when installing the cover; thus, it is important to check that the retard P lead is actually contacting the retard points during installation of the P lead. When installing the retard P lead, and before the coupling nut is installed, push the P lead insulator into the magneto cover and ensure that the contactor inside the magneto is touching and pushes the insulator back out a small amount.

- (v) Install the bottom spark plugs and torque in accordance with Lycoming specifications (30-35 ft-lb/40.7-47.5 Nm).

F. Harness Assembly (See Figure 13-16)

Ignition wires are routed from the left magneto to all the cylinder top spark plugs and those from the right magneto to all the cylinder bottom spark plugs.




Figure 13-16. Ignition Wire Installation

MAINTENANCE MANUAL

13-10 FUEL SYSTEM

A. General Information

The fuel system consists of the fuel tanks, fuel boost pump, valve, filter, fuel lines, engine driven fuel pump and fuel pressure switch. Fuel is gravity fed from the tanks through the shut-off valve, boost pump, filter and fuel lines to the inlet side of the engine driven fuel pump. This fuel pump functions whenever the engine is operating and delivers a constant flow of fuel under a regulated pressure to the fuel metering section of the injector. The fuel metering section operates by measuring the airflow through the throttle body of the injector and uses this measurement to operate a servo valve within the section. The accurately regulated fuel pressure established by the servo valve is used to control the flow divider, which then schedules fuel flow to the cylinders in proportion to airflow.

B. Fuel Tanks

(1) Tank - Removal (See Fig. 13-17)


- (a) Drain fuel into suitable containers, siphon fuel from tanks, then drain remaining fuel by opening the tank drain valves (1) at the bottom of each tank.
- (b) Disconnect vent lines (2) at top of tanks.
- (c) Disconnect fuel level sending unit wires at the "wristlock" connections located between the tops of the tanks.
- (d) Disconnect fuel outlet lines (3), tank drain lines (1), and scupper drain lines (4) at bottom of tank.
- (e) Remove screws (5) attaching tanks to bulkhead and cabin.
- (f) Remove fuel tanks.

NOTE: Shims dislodged during tank removal should be resecured in position with 3M brand Trim Adhesive, P/N 08021, or equivalent.

(2) Tank - Installation (See Fig. 13-17)

- (a) Position tanks on bulkheads and install attachment screws (5), at cabin and bulkhead.
- (b) Connect vent lines (2) at top of tanks.
- (c) Connect fuel level sending unit wires at the "wristlock" connections.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED



FUEL TANK INSTALLATION

FIGURE 13-17

MAINTENANCE MANUAL

- (d) Secure plastic covers over "wristlock" connections with tie-wrap.
 - (e) Secure wires to main rotor transmission vent pipe with tie-wrap.
 - (f) Connect fuel outlet lines (3), tank drain lines (1), and scupper drain lines (4) at bottom of tank.
 - (g) Fill fuel tanks to check gauge calibration. (See Markings and Gauge Calibration.)
- (3) Markings and Gauge Calibration (See Fig. 13-18)

NOTE: Fuel quantity markers on fuel tank sight windows are installed with aircraft in ground attitude, ground handling wheels up, aircraft setting on landing gear. Cabin fuel gauge calibration is done with aircraft in flight attitude, ground handling wheels down.

- (a) Position aircraft in flight attitude, ground handling wheels down.
- (b) Add one gallon of fuel to each tank.

NOTE: Allow fuel level to stabilize between tanks after each addition of fuel.

- (c) Adjust float arm (1) to get cabin fuel gauge reading of "zero" at this level to include unusable fuel. (See Fig. 13-19)

NOTE: Cabin fuel gauge adjustments are made by bending float arm on fuel quantity sending unit.

- (d) Position aircraft with ground handling wheels retracted.
- (e) Add five gallons of fuel to each tank.
- (f) Install 60 lb. markers (1) adjacent to this fuel level on the fuel tank sight window.

NOTE: Some F-models will not be equipped with the fuel tank sight window.

- (g) Place aircraft in flight attitude, ground handling wheels down.

MAINTENANCE MANUAL





FIGURE 13-18

FUEL TANK SIGHT GAUGE USED ON SOME
EARLY F MODEL FUEL TANKS

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-75

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.



FUEL LEVEL
SENDING UNIT

FIGURE 13-19

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(h) Connect vent lines (2) at top of tanks.

NOTE: Excessive deviation between fluid level and gauge reading is cause for replacement of the sending unit.

(i) Place aircraft in ground attitude, ground handling wheel retracted.

(j) Add five gallons of fuel to each tank.

(k) Install 20 lb. markers (2) adjacent to this fuel level on the fuel tank sight window.

(l) Measure up approximately 10-7/8 inches from bottom edge of tank along forward side of sight window and install 180 lb. markers (3) at this point.

(m) Install 240 lb. decal (4) at top forward corner of sight window decal.

Usable Fuel Quantity

1/4 = 60 lbs or 10 gallons

1/2 = 120 lbs or 20 gallons

3/4 = 180 lbs or 30 gallons

Full = 240 lbs or 40 gallons

NOTE: Each tank contains one gallon of unusable fuel.

(4) Fuel Level Sending Unit

(a) Sending Unit – Removal (See Fig. 13-19)

1 Remove three screws (2) attaching sending unit cover to top of right fuel tank.

2 Remove cover (3) and spacers (4).

3 Clean sealant from cover and its mounting location.

4 Inspect the fuel transmitter for condition and corrosion. Inspect the wiring for condition and security.

5 Disconnect ground wire (5) and transmitter output wire (6).

6 Remove remaining screw attaching unit to fuel tank, note location for reassembly.

7 Lift sending unit assembly out of fuel tank.

NOTE: Due to the shape of the float, it is necessary to tilt the unit to get float out of fuel tank opening.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

(b) Sending Unit – Installation (See Fig. 13-19)

- 1 Replace seal (7) around fuel tank opening, if damaged.

NOTE: Seal is secured in place with 3M brand Trim Adhesive, P/N 08021, or equivalent.

- 2 Install sending unit (1) into fuel tank.

- 3 For a new replacement unit, apply CP8-TB (Kopr-Shield) to the ground wire contact (5) and the transmitter output wire contact (6).

- 4 Install screws, attaching ground wire (5) to sending unit and sending unit directly to the tank.

- 5 Connect transmitter output wire (6).

- 6 Apply a light coat of ACF-50 corrosion inhibitor to the ground wire and transmitter wire connections and remaining exposed sending unit surface within the cavity.

- 7 Place a bead of Dow Corning Silicone Rubber Sealant (or equivalent) around recess to act as a seal when cover is installed.

- 8 Install cover (3), spacers (4), and screws (2). Secure screws.

(5) Fuel Tank – Repairs

- (a) Drain fuel from tanks.

- (b) Remove leaking tank(s) from aircraft.

- (c) Repair seepage of fuel through fiberglass tank.

- 1 Remove fuel level sending unit (right tank) and all fittings.

CAUTION: Carefully remove fittings that are bonded in to prevent damage to scupper bag.

- 2 Plug all openings except the fuel cap opening.

- 3 Pour one quart of sloshing compound into the tank.

NOTE: Sloshing compound used in 3M Scotch-Clad brand Fuel Resistant Coating 776.

- 4 Plug fuel cap opening.

- 5 Slowly roll tank to ensure that all surfaces have been completely covered with compound.

- 6 Place tank with bottom parallel to floor and drain excess compound through the main fuel outlet.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

7 Open all openings and force ventilate tank to cure slushing compound.

NOTE: Allow a minimum of eight hours cure time. (Slushing compound is tack-free when cured.)

8 Install main fuel outlet and strainer, adding a new bond of PR1440 B-2 fuel tank sealant (PPG PRC DeSoto).

NOTE: Allow PR1440 B-2 to cure tack-free before fueling tank.

9 Install remaining hardware.

10 Check sump drain to assure it is not blocked.

11 Cap all fuel outlets.

12 Place approximately five gallons of fuel in the tank to check for leaks before installation on the aircraft.

13 Drain fuel and reinstall tank on aircraft.

(d) Repair leak(s) around tank cover seam.

1 Drill out rivets in area of leak.

2 Remove old fuel tank sealant from between tank and cover by scraping.

3 Install a new coating of PR1440 B-2 fuel tank sealant.

4 Drill out rivet holes and install next size larger diameter rivets.

5 Allow PR1440 B-2 to cure tack-free.

6 Coat interior of tank in area of repair with slushing compound.

CAUTION: Care must be taken to prevent slushing compound from coating fuel fittings. Remove fittings and plug holes if necessary

7 Drain excess slushing compound.

8 Allow compound to cure tack-free.

9 Place approximately five gallons of fuel in tank to check for leaks.

10 Drain tank and reinstall on aircraft.

MAINTENANCE MANUAL

C. Fuel Boost Pump

(1) General Information

The fuel system boost pump is factory set at a pressure of 27 psi. A pressure switch monitors the fuel system pressure and activates the indicator panel lights. The green light will come on when the fuel system pressure increases to 20 psi and above. The red warning light will come on when the fuel system pressure falls to 15 psi or below.

NOTE: Newer F-models will not have the green normal fuel pressure indicator.

(2) Boost Pump - Adjustment

NOTE: Adjustments are to be made with a fully charged battery.

- (a) Master switch - OFF
- (b) Boost pump switch - OFF
- (c) Fuel shutoff valve - CLOSED
- (d) Remove 7/16 inch plug from RSA fuel injector.
- (e) Install 0-50 psi pressure gauge.
- (f) Fuel shutoff valve - OPEN
- (g) Mixture control to idle cutoff.
- (h) Master switch - ON
- (i) Magneto switch - OFF
- (j) Boost pump switch - ON

NOTE: Fuel pressure should read 27 psi.

- (k) Loosen jam nut on boost pump relief valve adjustment screw.
- (l) Adjust boost pump pressure.

NOTE: Clockwise rotation of the adjustment screw decreases pressure.

- (m) Lock adjustment screw with jam nut.
- (n) Recheck pressure.
- (o) Boost pump switch - OFF

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-80

MAINTENANCE MANUAL

- (p) Master switch - OFF
- (q) Fuel shutoff valve - CLOSED
- (r) Adjust engine-driven fuel pump.

D. Engine-Driven Fuel Pump

(1) Engine-Driven Fuel Pump - Removal (See Fig. 13-21)

WARNING: Insure fuel shutoff valve is closed.

- (a) Remove firewall access panels.
- (b) Disconnect fuel inlet line (1) and outlet line (2).
- (c) Disconnect static pressure line (3) and drain line (4).
- (d) Cut safety wire and remove bolts (5) which secure fuel pump to scavenge pump and engine accessory case mounting pad.
- (e) Remove fuel pump and fiber spacer (7).

CAUTION: Withdraw fuel pump straight away from engine. Scavenge pump will remain in position with oil lines intact.

(2) Engine-Drive Fuel Pump - Inspection

Perform an inspection and operational check on the engine-driven fuel pump in accordance with manufacturer's overhaul instructions.

(3) Engine-Driven Fuel Pump - Installation (See Fig. 13-21)

NOTE: On new fuel pumps, install elbows in correct locations prior to installation on engine.


- (a) Install bolts (5) with washers through the fuel pump.
- (b) Install fiber spacer (7) on bolts.
- (c) Align splined shaft and bolts to scavenge pump and slide fuel pump into position, lubricate spline.

NOTE: Be sure gasket between scavenge pump and engine is properly aligned before securing bolts.

- (d) Secure scavenge pump and fuel pump to engine accessory case. Torque bolts and safety wire in pairs with .032 wire.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED


MM-13-81



FUEL FLOW SCHEMATIC

FIGURE 13-20

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED



ENGINE DRIVEN FUEL PUMP
AND SCAVENGE PUMP

FIGURE 13-21

MAINTENANCE MANUAL

- (e) Connect drain line (4) and static line (3).
- (f) Connect fuel inlet line (1) and outlet line (2).

NOTE: Following the removal and overhaul of any fuel system-related engine components, turn fuel on and check operation of fuel system. Every 25 hours a visual check of the pump drain should be made with the engine running. If the engine-driven pump fails there is a possibility that it will pump fuel overboard through the drain line.

(4) Engine-Driven Fuel Pump - Adjustment

NOTE: Fuel boost pump pressure should be adjusted prior to adjustment of engine-driven fuel pump.

- (a) Remove safety wire from engine-driven fuel pump adjustment screw (6).
- (b) Follow normal engine starting and rotor engagement procedures.
- (c) Engine rpm - 3050
- (d) Boost pump - OFF
- (e) Adjust engine driven fuel pump to 24 ± 1 psi.

NOTE: Clockwise rotation of the adjustment screw increases pressure.

- (f) Follow normal engine cooling and shutdown procedure.
- (g) Safety wire adjustment screw (6).
- (h) Remove 0-50 psi pressure gauge.
- (i) Reinstall and safety wire 7/16 inch plug.
- (j) Run engine and check for fuel system leaks.
- (k) Perform idle mixture and rpm check.

E. Fuel Filter

(1) Fuel Filter - Removal

- (a) Shut off fuel with fuel shutoff valve.
- (b) Drain fuel from filter by opening sump drain.
- (c) Disconnect sump drain valve extension shaft from assembly.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (d) Disconnect fuel inlet and outlet line.
- (e) Cap lines and fittings.
- (f) Remove safety wire from pipe plug at top of assembly.
- (g) Remove bolts securing strainer assembly to pylon mount bracket.

(2) Fuel Filter - Disassembly

NOTE: The assembly does not have to be removed from aircraft for filter inspection.

- (a) Remove safety wire from bolt at bottom of filter retaining bracket.
- (b) Loosen filter retaining bracket bolt.
- (c) Swing retaining bracket forward to release bottom cover, outer body and gaskets.
- (d) Remove retaining pin at bottom of filter to release end cap.

(3) Fuel Filter - Inspection

- (a) Check fuel filter assembly for:
 - 1 Cracks and evidence of corrosion.
 - 2 Loose or damaged fittings.
 - 3 Worn or damaged gaskets.
 - 4 Security of filter retaining pin.
- (b) Check filter for:
 - 1 Rips, dents or deformation.
 - 2 Contamination.

(4) Fuel Filter Assembly - Cleaning

- (a) Clean all housing parts with a suitable solvent.

NOTE: Pay particular attention to fittings and passageways within housing body.

- (b) Clean interior and exterior surfaces of housing with solvent and fine bristle brush.

CAUTION: Damage to filter can occur if excessive force is used during cleaning.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

(5) Fuel Filter Housing - Assembly

- (a) Install upper gasket, filter top ring, filter and end cap.
- (b) Secure filter with pin.
- (c) Install gasket in bottom cover.
- (d) Install outer body and end cap on assembly.

NOTE: Align drain port on end cap with fuel outlet port on top of assembly.

- (e) Swing retaining bracket under assembly and align bolt with recess in end cap.
- (f) Secure assembly by tightening retaining bracket bolt and safety wiring bolt to bracket.
- (g) Install drain valve and tube in bottom of assembly.

(6) Fuel Filter Assembly - Installation

- (a) Attach filter assembly to pylon with drain valve positioned aft.
- (b) Safety wire plug on top of assembly.
- (c) Attach fuel inlet line to the forward top port.
- (d) Attach fuel outlet line to the aft top port.
- (e) Attach drain valve extension.
- (f) Close drain valve.
- (g) Open fuel shutoff valve.
- (h) Turn boost pump ON.
- (i) Mixture control to idle cutoff.
- (j) Check for fuel leakage.
- (k) Turn off boost pump and close fuel shutoff valve.

F. Fuel Pressure Switch

(1) Fuel Pressure Switch - Removal

- (a) Close fuel shutoff valve.
- (b) Drain fuel sump.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (c) Remove safety wire from electrical connection.
 - (d) Disconnect electrical connection.
 - (e) Disconnect switch assembly from pylon attachment.
 - (f) Loosen jam nut on fuel line attachment fitting.
 - (g) Remove switch assembly from fuel line fitting.
- (2) Fuel Pressure Switch - Installation
- (a) Install switch assembly on fuel line fitting.
 - (b) Secure with jam nut.
 - (c) Attach switch assembly to pylon clamp.
 - (d) Install electrical connector.
 - (e) Safety wire connector to switch assembly.
 - (f) Open fuel shutoff valve.
 - (g) Turn boost pump on.
 - (h) Mixture control to idle cutoff.
 - (i) Check for fuel leakage.
 - (j) Turn off boost pump and close fuel shutoff valve.

G. Fuel Shutoff Valve

- (1) Fuel Shutoff Valve - Removal
- (a) Remove left fuel tank to gain access to shutoff valve.
 - (b) Disconnect fuel line from aft side of valve.
 - (c) Disconnect fuel lines from left and right sides of valve.
 - (d) Disconnect cable from valve actuating arm; loosen jam nut, loosen screw, and unhook wire.
 - (e) Remove bolts securing valve to pylon.
- (2) Fuel Shutoff Valve - Installation
- (a) Secure valve to pylon mount with two nuts and bolts.
 - (b) Install and check rigging of control cable.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (c) Connect fuel inlet and outlet lines.
 - (d) Install fuel tank.
 - (e) Place fuel in tanks and check for leaks prior to flight.
- (3) Fuel Shutoff Valve - Rigging
- (a) Position top of shutoff valve actuating arm full forward to insure valve is open.
 - (b) Position cockpit shutoff valve control knob pushed in to within $\frac{1}{4}$ inch of nut securing it to firewall.
- NOTE: This $\frac{1}{4}$ inch "cushion" is used to insure the valve is completely open when the control knob is pushed in.
- (c) Insert wire from control cable through hole in valve actuating arm attachment swivel.
 - (d) Secure cable sheath to pylon.
 - (e) Secure wire in swivel by tightening the screw on the swivel end and locking it with the jam nut.
 - (f) Form a hook in the wire end by bending it upward and aft.
 - (g) Check control operation by pulling the knob out, to close valve, and push it back in to open the valve. With valve fully open the knob should not bottom out at the firewall.

13-11 LUBRICATION SYSTEM


A. Description (See Fig. 13-22)

Engine oil flows to the turbocharger from the engine through a restricted elbow fitting. On this same line, a valve is located just before the oil inlet to the turbocharger. This check valve prevents an oil buildup in the turbocharger after the engine is shut down. An engine-driven scavenge pump is utilized to return the turbocharger oil back to the engine sump. The scavenge pump parts are stamped "in" or "out" and the correct rotation is marked.

Two reverse flow oil coolers are used to cool the oil for the entire system. Cooling air from the fan is directed through the cores of the coolers and exhausted into the atmosphere. Regulation of oil flow through the cooler is accomplished by a temperature and pressure sensitive valve located in the engine accessory case.

The cockpit oil pressure gauge line runs from under the instrument console back to the engine accessory case.

MAINTENANCE MANUAL



OIL SYSTEM DIAGRAM

FIGURE 13-22

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-89

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

MAINTENANCE MANUAL

B. Oil Coolers

(1) Oil Cooler - Removal

The primary oil cooler is mounted on the right-hand side of the engine compartment. The auxiliary oil cooler is mounted to a duct located on the lower left side of the cooling fan shroud.

(a) Primary Oil Cooler

1 Open right side cowl.

NOTE: Place magneto switch in OFF position.

2 Drain oil out of the lower inlet oil line fitting.

NOTE: Place container beneath the radiator when disconnecting lines to collect any drain oil from the cooler and lines.

3 Disconnect and cap the inlet lines.

4 Remove four bolts holding the oil cooler boot to the inboard side of the oil cooler.

5 Remove four bolts holding the oil cooler air exit duct to the outboard side of the oil cooler.

NOTE: Upon removal of cooler, visually inspect rubber flex boot for rips. Replace the boot assembly if necessary.

(b) Auxiliary Oil Cooler

1 All switches - OFF

2 Drain oil from engine sump.

3 Open left cowl.

4 Place oil catch pan beneath oil cooler.

5 Disconnect and plug inlet and outlet lines.

6 Remove two screws and washers from bottom of oil cooler heat shield.

7 Remove two screws and washers from top of oil cooler heat shield.

8 Remove heat shield.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-90

MAINTENANCE MANUAL

9 Remove two screws and washers attaching aft side of oil cooler to oil cooler duct.

10 Remove oil cooler.

(2) Oil Cooler - Inspection

(a) Inspect oil coolers for:

1 Bent, broken or dirty core fins.

2 Nicked, burred, or deformed plumbing fittings.

3 Deformed screw holes.

4 Loose boot attachment to radiator inlet.

(b) Inspect oil cooler air ducts for:

1 Cleanliness.

2 Cracks, checking, tears or dents.

3 Integrity of mounting flanges.

(c) Inspect oil inlet and return lines for:

1 Cleanliness and freedom from obstructions.

2 Cracks, checking, swelling, and kinks.

3 Integrity of wire shields.

4 Plumbing fittings for nicks, burrs, and deformity.

(3) Oil Cooler - Leakage Check

(a) Perform a hydrostatic test on the radiator. Operate test set in accordance with manufacturer's instructions, or take radiator to certified radiator shop and have it pressure tested for leakage.

(b) Install pressure cap on one oil cooler fitting.

(c) Connect test set to remaining oil cooler fitting.

(d) Regulate test set pressure to 150 psi.

(e) Check for leakage.

NOTE: Leakage is indicated by escaping fluid and a drop in regulator pressure.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-91

MAINTENANCE MANUAL

(f) Locate and mark source of leak, if any.

NOTE: Use standard procedure to repair leaks. If required repairs are inaccessible or extensive, replace oil cooler with a new unit. After repairs are completed, repeat steps (a) through (e).

(g) Remove oil cooler from test set.

(4) Oil Cooler - Installation

(a) Primary oil cooler.

1 Secure radiator to the oil cooler boot and lower mount with four bolts.

2 Secure oil cooler inlet and return lines.

3 Secure air inlet duct to oil cooler and lower mount with four bolts.

4 Thoroughly inspect the oil cooler assembly installation, torque on fittings, routing of lines, and ducting.

5 Perform preflight inspections; service engine as required.

6 Perform operational check of engine prior to flight.

7 After the engine has been run up to operating temperature, inspect assembly for oil leaks.

NOTE: Oil circulates through the entire system only when engine is at operating temperature.

8 Secure right side cowl.

(b) Auxiliary Oil Cooler

1 Position oil cooler in place on the duct from the cooling fan shroud with inlet and outlet fittings aft.

2 Install two screws and washers in aft side of oil cooler mount.

3 Place heat shield in position.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-92

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- 4 Install two screws and washers in top of heat shield.

NOTE: It may be necessary to bend the heat shield slightly to facilitate installation of the top two screws.

- 5 Install two screws and washers in the bottom of the heat shield.
- 6 Remove inlet and outlet line plugs and connect lines to oil cooler.
- 7 Check routing of lines.
- 8 Check fittings and attachment hardware for security.
- 9 Service oil system to proper level.
- 10 Run engine to bring oil to normal operating temperature.
- 11 Shut down engine and inspect for leaks.

C. Scavenge Pump

(1) Scavenge Pump – Removal (See Fig. 13-21)

The scavenge pump is removed with the same procedure listed under Engine-Driven Fuel Pump Removal – Section 13-10, with the following additions:

- (a) Disconnect oil inlet line (8).
- (b) Disconnect oil outlet line (9).
- (c) Pull engine-driven fuel pump and scavenge pump out as a unit.
- (d) Remove gasket (10).

(2) Scavenge Pump – Installation (See Fig. 13-21)

Complete Engine-Driven Fuel Pump Installation Procedure, Section 13-10, with the following additions:

- (a) Install scavenge pump and gasket (10) on bolts (5) with spacer (7) and engine-driven fuel pump.
- (b) Install both pumps as a unit into engine case.
- (c) Connect oil inlet line (8) and outlet line (9).
- (d) Check for both oil and fuel leaks.

13-12 Correlator

This specification presents the method to most accurately and safely rig the throttle correlator system used on the F-28F and 280F aircraft. The correlator rigging is a repetitive process and, by necessity, some of the steps are repeated. Although this procedure is written to incorporate the minimum number of steps, the more repetitions used to rig the correlator, the better the correlator will perform.

A. Operating Principles

The mechanical correlator installed on the Enstrom Piston Engine helicopters automatically operates the throttle when the pilot moves the collective relieving the pilot of having to manipulate the throttle to maintain blade RPM in the green arc.

The correlator is unlike an electronic governor in that the throttle twist grip must not move during collective operation. This forces the correlator to change the position of the throttle arm on the servo. If the throttle twist grip is allowed to rotate during collective operation, the correlator will not cause the throttle arm on the servo to move in the correct relationship to the collective, and the correlator will not work correctly.

With the helicopter sitting on the ground, the pilot begins the take-off process by opening the throttle to bring the engine and rotor RPM into the green arc, and then raises the collective while rolling OFF the throttle to maintain the RPM in the green arc. As the collective is raised, the correlator will automatically increase the throttle so to maintain the RPM in the green, the pilot must roll off throttle as the collective is raised.

As the helicopter lifts into a hover with the RPM in the green, the throttle is then CORRELATED to the collective and the engine for the helicopter gross weight, density altitude, wind, etc., for that particular flight. As the pilot moves the collective up and down, the correlator automatically adjusts the throttle to maintain engine RPM.

The throttle friction must be set firmly enough so that when the collective is moved up and down, the throttle twist grip on the collective does not move.

B. Verifying Proper Correlator Operation

- (1) Remove the collective cover and the firewall access cover in the seat back to gain access to the correlator and to the fuel injector servo and waste gate linkage.
- (2) Place the collective down and the throttle so the rivet is in the 12 o'clock position.
- (3) Check that the idle speed adjustment screw is against the stop on the servo.
- (4) Check that the clearance between the waste gate arm and the open stop is 0.06 to 0.09 inch (Figure 13-22.1a). (The waste gate should be in the open position, Figure 13-22.1b.)
- (5) Completely close the throttle; there should be no change in the position of the throttle-arm position on the servo. The throttle position between the point where the rivet is at 12 o'clock and fully closed is the override position and should have no effect on the position of the throttle arm on the servo. It is there only to make the correlator function properly.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (6) Open the throttle to the full throttle position.
- (7) The throttle arm on the servo should be at least 90% open.
- (8) Open and close the throttle several times.
- (9) The operation of the output lever (Figure 13-22.2, Item 210) should be smooth and the output lever should rotate freely (perpendicular to the mounting plate (10) on its shaft (270) without causing the shaft to move laterally. If moving the throttle causes the pivot shaft to lean over (move laterally forward) this is an indication that there is friction in the system, throttle cable, servo, or wastegate.
- (10) Raise the collective about 2 inches. Rotate the throttle from the idle position (closed) to the wide-open position. As before, the actuator arm must rotate freely on the pivot shaft parallel to the seat frame and the pivot shaft should not lean over laterally (forward). There will be no override position at the closed throttle position with the collective up two inches.
- (11) Open and hold the throttle at 100%, slowly raise the collective. As the collective is raised the shaft supporting the output lever should lean over sideways (forward) and allow the collective to be raised about 2 inches without the throttle turning. At about 2 inches, the throttle will begin to close as the pivot shaft deflection reaches its limit.
- (12) If the output lever shaft leans over at any time other than when the throttle arm on the servo is at the full open position, it is an indication that there is binding (friction) in the system.

C. Troubleshooting the Correlator

NOTE: If the throttle cable actuator arm moves laterally (forward) when the throttle is rotated, there is an issue with the system binding that must be corrected for the correlator to operate correctly.

- (1) Throttle Cable:
 - (a) Disconnect the throttle cable from the servo and operate the throttle. If the throttle output lever rotates on the pivot shaft and the pivot shaft does not move out of plane, (laterally forward), the correlator and throttle cable are working correctly and the servo or the waste gate are causing the problems.
 - (b) If the throttle actuator arm (Fig 13-22.2, Item 210) continues to pivot sideways (forward) on its shaft when the throttle is twisted, disconnect the throttle cable from the throttle actuator arm and test the correlator operation again.
 - (c) If the correlator now works correctly, the throttle cable has internal friction and should be replaced.
- (2) Correlator:
 - (a) If the actuator arm pivot shaft is still moving laterally (forward) after the throttle cable has been disconnected, there is a problem with the correlator. Contact Enstrom product support if the cause cannot be determined.




Figure 13-22.1. (a) Clearance between the arm and the stop; (b) Open position




Figure 13-22.2. Correlator Assembly

- (3) Wastegate:
 - (a) Disconnect the wastegate actuating arm from the throttle arm on the servo and operate the wastegate by hand.
 - (b) Operate the throttle and observe the throttle actuating arm for lateral movement on the pivot shaft, if the correlator now works correctly the issue is in the servo.
- (4) Servo:
 - (a) If the correlator, throttle cable, and wastegate have been eliminated as causes, the servo is the issue.
 - (b) Operate the throttle arm on the servo by hand. If the throttle arm is stiff, disconnect the mixture arm control rod and operate the mixture arm and the throttle arms independently to determine if the issue is in the throttle shaft or the mixture side of the servo.

D. Correlator Preflight Rigging

NOTE: The rigging procedure is written for three considerations:

- (1) When installing a new throttle cable or replacing any part of the correlator or throttle system start with Item B - Correlator Preflight Rigging.
- (2) For service adjustments to cover idle adjustment, injector servicing or replacement, start with Item C - Correlator Post-Flight Rigging.
- (3) When installing a replacement throttle cable, fuel servo, waste gate or engine the throttle arm to waste gate rigging should be performed first to insure that the throttle arm is installed in the correct position on the servo.

NOTE: When installing a replacement throttle cable, wastegate, or engine the wastegate to servo adjustment should be performed first to insure that the throttle arm is installed in the correct position on the servo.)

Wastegate Link Rod Adjustment:

- (1) Disconnect throttle cable from servo throttle arm.
- (2) Set throttle arm against the full throttle stop (Figure 13-30).
- (3) Adjust wastegate link length for 0.015 inch gap at wastegate closed stop. (**DO NOT** adjust stop. Stop was previously set for a 0.015 inch gap with the butterfly in the fully closed position.)
- (4) Set throttle arm against the idle stop (Figure 13-26).
- (5) Check that the gap at the waste gate open stop is .09 / .06 in clearance.

E. Injector Rigging

- (1) The injector shall be rigged as shown in Figure 13-26. The injector is at idle position. The lever may be repositioned in 15° increments by loosening the butterfly shaft nut.
- (2) The injector used for the "F" model shall be one of two types:
 - (a) Part No. 2524858-A. This injector has been modified to obtain 85E butterfly travel with the idle screw fully backed out. Preflight idle is to be set such that the butterfly is closed to .020 inch gap in the sidewall.
 - (b) Part No. 2524858-1 and higher has the idle position preset at 97° and no further check is required.
- (3) Connect the throttle cable:
 - (a) Set aft cable attach position at 6.88 plus .13/-.25 inch (Figure 13-24).
 - (b) Set the forward cable attach position at 1.13 ± .13 inches (Figure 13-23).
 - (c) Pre-adjust point "B" override stop to 0.60 ± .02 inches (Figure 13-25).
 - (d) Set collective stick on down stop and lock.
 - (e) Set injector at idle stop (Figure 13-26).
 - (f) Set summing lever (1) on idle stop, point "A." (Figure 13-25).
 - (g) Adjust throttle cable rod ends to fit. Attach at injector.
- (4) Adjust override stop, point "B" (Figure 13-27):
 - (a) Position collective stick on down stop.
 - (b) Rotate throttle twist grip open enough to insert a 0.14 ± .01 inch thick shim or tool No. T-0113 between idle stop screw and stop pin on injector (Figure 13-28). Rotate twist grip against shim and maintain pressure during step 3-c.
 - (c) Check for 5.0 ± .06 inches dimension between offset shaft and summing lever output arm (points "D" and "E" respectively, Figure 13-27) by:
 - 1 Use tool gauge T-0111 or similar device and slip over offset shaft (point "D") adjacent to offset fitting (1).
 - 2 Attempt to slip other end of tool over cone washer on summing lever, point "E."
 - 3 Adjust override stop, point "B", until gauge tool slips over cone washer on summing lever.
 - (d) Lock jam nut on stop bolt, point "B."
 - (e) Remove 0.14-inch shim from injector stop.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

- (f) Set injector idle stop arm against stop pin (Figure 13-26).
- (g) Set correlator summing lever at idle stop, point "A" (Figure 13-25).
- (h) Remove bolt connecting throttle cable to throttle arm on servo and check that bolt is a slip fit and that the throttle stop is against the stop (Figure 13-26).

NOTE: If there is insufficient thread engagement in rod end, then aft cable housing attachment on pylon (Figure 13-24) can be moved 6.88 +13/-.25 inches.

(5) Check wide open rigging:

- (a) Raise collective stick 2 inches at handle or .25 inch at stop (Figure 13-29) from down stop position and lock.
- (b) Rotate twist grip to wide open position.
- (c) Check if injector wide open stop arm is against stop pin for (A) only (Figure 13-30). On -1 or -2 servos, stop arm may not contact stop pin; adjust to within .125 inch of stop pin.

NOTE: If adjustment is required, make adjustments at cable rod ends and aft cable attach point dimension 6.88 +.13/-.25 inches (Figure 13-24).

- (d) Check if output lever (1) is within 0.06 inch of stop point "C" (Figure 13-29). If out of tolerance, adjust aft cable attach point dimension 6.88 +.13/-.25 inches (Figure 13-24) and repeat steps 4-c and 4-d.

NOTE: Primary open stop should be at the injector and the stop at point "C" is secondary.

- (e) Secure all hardware on cable rod ends.

(6) Recheck idle adjustments by:

- (a) Set collective stick on down stop and lock.
- (b) Rotate throttle twist grip to idle stop.
- (c) Check at the injector that the idle adjustment screw is against the stop pin (Figure 13-26).

NOTE: The throttle twist grip must have enough authority to force all backlash out of the system and cable. A piece of paper placed between the idle adjustment screw and the stop pin should be clamped. However, only 10° rotation (20° maximum) of the twist grip should release the paper enough to be able to pull it free. Any more rotation than this causes a large dead band which uses up too much correlator motion, thus causing improper collective/throttle correlation. To adjust, move the aft cable attach point (Figure 13-24). Usually no more than one rotation of the jam nuts is required. For insufficient clamping of the paper, move the cable down. For excessive clamping move the cable up.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL

NOTE: Preflight rigging is now completed. Correlator will perform satisfactory until idle screw/mixture linkage adjustment has been made. Readjustment of correlator is then required for satisfactory and safe correlator function.

F. Correlator Post-Flight Rigging

(1) Readjust override stop, point "B" (Figure 13-27).

- (a) Position collective stick on down stop.
- (b) Rotate throttle twist grip open enough to insert a 0.14 ±.01 inch thick shim or tool No. T-0113 between idle stop screw and stop pin on injector (Figure 13-28). Rotate twist grip against shim.
- (c) Check for 5.0" ± 0.06 dimension between offset shaft and summing lever output arm (points "D" and "E" respectively, Figure 13-27) by:
 - 1 Use tool gauge T-0111 or similar device and slip over offset shaft (point "D") adjacent to offset fitting (1).
 - 2 Attempt to slip other end of tool over cone washer on summing lever, point "E."
 - 3 Adjust override stop, point "B", until gauge tool slips over cone washer on summing lever.
- (d) Lock jam nut on stop bolt, point "B."
- (e) Remove 0.14 inch shim from injector stop.

(2) Check idle stop position.

- (a) Set collective stick on down stop and lock.
- (b) Rotate throttle twist grip to idle stop.
- (c) Check at the injector that the idle adjustment screw is against the stop pin (Figure 13-26).

NOTE: The throttle twist grip must have enough authority to force all backlash out of the system and cable. A piece of paper placed between the idle adjustment screw and the stop pin should be clamped. However, only 10° rotation (20° maximum) of the twist grip should release the paper enough to be able to pull it free. Any more rotation than this causes a large dead band which uses up too much correlator motion, thus causing improper collective/throttle correlation. To adjust, move the aft cable attach point (Figure 13-24). Usually no more than one rotation of the jam nut is required. For insufficient clamping of the paper, move the cable down. For excessive clamping move the cable up.

- (d) Readjust stop on wastegate, if necessary, to provide .06/.09 inch clearance.

- (3) Check wide open injector position:
 - (a) Raise collective stick 2" from down stop position and lock or .25 inch from stop (see Figure 13-29).
 - (b) Rotate twist grip to wide open position.
 - (c) Check if injector wide open stop arm is against stop pin.
 - (d) Readjust wastegate link length, if necessary, for 0.015 inch gap at wastegate stop. (DO NOT adjust stop. This stop was previously set for a 0.015 inch gap with the butterfly in fully closed position.)

G. Adjusting the Correlator After Maintenance

- (1) Adjustments to the engine such as magneto timing and fuel injection mixture adjustments may affect the correlator operation requiring fine tune adjustments after a test flight.
- (2) Throttle friction must be set high enough to prevent the throttle from moving when the collective is raised and lowered.
- (3) Fly the helicopter with the RPM set at 2900, 25 in MAP, and 55 MPH.
- (4) While holding airspeed at 55 MPH, increase collective to 39 in MAP.
- (5) Note the RPM change.
- (6) Hold airspeed and reduce collective to 25 in MAP.
- (7) Note RPM change.
- (8) The desired operation of the correlator will not allow the RPM to exceed the maximum RPM while increasing collective or the minimum RPM while lowering the collective.
- (9) Make a small adjustment to the summing lever bolt (Figure 13-22.2, Item 180) (No more than 1/8 to 1/4 turn of the summing lever bolt each adjustment.)
- (10) Fly the operational test again and continue to make adjustments until the best operation of the correlator is obtained.




Figure 13-23. Forward Cable Attach Point




Figure 13-24. Aft Cable Attach Point




Figure 13-25. Correlator Idle Stop Position

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-13-102




Figure 13-26. Fuel Servo Throttle Bellcrank




Figure 13-27. Override Stop Adjustment




Figure 13-28. Fuel Servo with Tool No. T-0113 Installed




Figure 13-29. Correlator Full Throttle Stop Position




Figure 13-30. Fuel Servo Full Throttle Position

I

INTENTIONALLY LEFT BLANK

MAINTENANCE MANUAL

SECTION 14

UTILITY SYSTEMS

14-1 CABIN HEAT

A. Description

Warm air used for heating the cabin is derived from a heat exchanger mounted on the exhaust muffler. The air enters this system from the engine cooling shroud and is ducted by a flexible hose to the heat exchanger. Air flows to the heater control valve which is mounted on the aft side of the firewall and regulates the air flow into the cabin area. The control is located on the left hand side of the pilot's seat for easy access to vary the temperature by pushing in to the OFF position or out to the ON position. There are three heat delivery ducts inside the cabin. The main duct is located in the center of the seat structure, with two smaller ducts located just forward of the tail rotor control pedals on either side of the cabin floor.

B. Cabin Heating System - Troubleshooting

<u>Problem</u>	<u>Cause</u>	<u>Required Action</u>
Exhaust fumes enter cabin when cabin heat is applied.	Crack in exhaust stack or heat exchanger.	Replace stack, heat exchanger, or repair by welding.
Insufficient heat.	Flexible hoses forward of firewall off or loose.	Connect hoses and secure with clamps.
	Control linkage disconnected or loose.	Connect linkage properly.
	Defective heater shroud.	Replace or repair heater shroud.
	Defective valve assembly.	Replace or repair valve assembly.

C. Heater Valve Assembly

(1) Heater Valve - Removal (See Figure 14-1, View A)

(a) Remove fiberglass seat deck from cabin.

(b) Disconnect the heater control cable (1) from heater valve (2).

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (c) Disconnect and remove hose (3) from aft side heater valve.
 - (d) Remove the attachment screws securing heater valve to hose divider (4) and firewall. Remove valve.
- (2) Heater Valve - Installation (See Figure 14-1, View A)
- (a) Install heater valve (2) with valve control lever on top and align to hose divider (4) on firewall.
 - (b) Install attachment screws to secure valve to firewall, and torque screws.
 - (c) Connect heater control cable (1) to heater valve and adjust. See heater control cable installation.
 - (d) Connect hose (3) to aft side of heater valve and secure.
 - (e) Install fiberglass seat deck.

D. Heater Control Cable

- (1) Heater Control Cable - Removal (See Figure 14-1, View A)
- (a) Remove fiberglass seat deck.
 - (b) Disconnect control cable (1) at the heater valve (2).
 - (c) Disconnect cable clamp (6) from forward landing gear cross tube.
 - (d) Remove cable nut securing control knob to seat structure and pull cable out through front of seat structure.
- (2) Heater Control Cable - Installation (See Figure 14-1, View A)
- (a) Slide cable (1) through seat structure and install nut and lock washer on inboard side. Secure nut to mount cable control knob in place.
 - (b) Connect cable (1) to heater valve (2) and secure with clamp (5).

NOTE: Remove hose from aft end of heater valve (2) so valve damper is visible for cable adjustment.

- (c) Adjust cable until valve is in closed position with 1/4" to 3/8" gap between seat structure and cable control knob with control knob pushed in.

NOTE: Adjustment is made by sliding cable sheath in or out at the cable clamp (5) on top side of heater control valve. Check that valve fully opens and closes after adjustment.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL

- (d) Install hose and secure to aft side of control valve.
- (e) Connect cable clamp (6) at landing gear cross tube.
- (f) Install fiberglass seat deck and cushions.

E. Heater Shroud

- (1) Heater Shroud - Removal (See Figure 14-1, View B)
 - (a) Remove hoses (7) and (9) from heater shroud (8).
 - (b) Remove screws along top of heater shroud.
 - (c) Separate shroud and remove from heat exchanger.
- (2) Heater Shroud - Installation (See Figure 14-1, View B)
 - (a) Install heater shroud (8) around heat exchanger with shroud seam on top.
 - (b) Install screws to secure shroud to heat exchanger.
 - (c) Connect hoses (7) and (9) to heater shroud and secure with hose clamps.

MAINTENANCE MANUAL




FIGURE 14-1
CABIN HEATING SYSTEM

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED
MM-14-4

ENSTROM MAINTENANCE MANUAL SUPPLEMENT

SECTION 15

SUPPLEMENTAL PROCEDURES

NOTE: This Maintenance Manual Supplement provides information defining the differences between the 280FX and the 1986 F-28F models from the standard F-28F and 280F helicopters. This supplement is specifically written to be used in conjunction with the basic Model F-28F and 280F Series Maintenance Manual. Should any questions arise from its use, please contact Enstrom Product Support for clarification.

NOTE: Content in this supplement may have been incorporated into the basic Model F-28F and 280F Series Maintenance Manual.

15-1 INTRODUCTION

This maintenance manual supplement sets forth the recommendations and procedures for maintaining and servicing the Model 280FX and 1986 F-28F helicopter, manufactured by the Enstrom Helicopter Corporation. This Supplement must be used in conjunction with the Model F-28F and 280F Series Maintenance Manual. The procedures in this manual supersede any conflicting procedures listed in the earlier manuals and/or supplements.

15-2 TABLE OF CONTENTS

See Table of Contents at the beginning of the revised model F-28F and 280FX Maintenance Manual.

15-3 MANUAL CHANGES AND REVISIONS

Reference Section 1, Paragraphs 1-3, 1-4, and 1-5.

I

INTENTIONALLY LEFT BLANK

SECTION 16

[RESERVED]

I

INTENTIONALLY LEFT BLANK

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

SECTION 17

[RESERVED]

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-17-1

Rev. 4
Jun 21/12

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

INTENTIONALLY LEFT BLANK

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-17-2

Rev. 4
Jun 21/12

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

MAINTENANCE MANUAL SUPPLEMENT

SECTION 18

POWERPLANT AND ASSOCIATED SYSTEMS

18-1 POWERPLANT - REFERENCE SECTION 13

For all power plant requirements see Section 13 of F-28F and 280F Maintenance Manual. The only exception is a new door seal on the air induction intake scoop. This seal consists of a tubular rubber extrusion attached to the cover of the air filter box. This forms a seal with the engine door, preventing hot engine compartment air from entering the induction system. This seal should be inspected and kept in good repair, as leaks in this seal will reduce engine performance.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

MAINTENANCE MANUAL SUPPLEMENT

SECTION 19

MAIN ROTOR TRANSMISSION

19-1 GENERAL - REFERENCE SECTION 11-6

Except for the location of the oil temperature probe, the low rotor rpm sensor, and the magnetic chip detector, the main rotor transmission is essentially identical to the transmission on the F-28F & 280F. The oil temperature probe has been moved from the bottom of the pinion case to the bottom cover at approximately 30° left of front center. This does not affect the operation of the helicopter. The low rotor rpm sensor is installed in the forward side of the top cover. This unit is described in Section 33 under "Low Rotor Warning." NOTE: The chip detector is not standard in F-28F models.

19-2 MAIN ROTOR GEARBOX CHIP DETECTOR

The 280FX is equipped with a main rotor transmission chip detection system. This chip detection system consists of a magnetic chip detector in the transmission which is wired to a caution light in the annunciator panel on the instrument console (ref. Section 21). The magnetic chip detector is located on the transmission bottom cover approximately 30° left of rear center. This unit comprises a magnetic plug which locks into a self-sealing base. If the main rotor gearbox chip light illuminates, inspect the chip detector as described below:

- A. Remove access panel below left fuel tank.
- B. Remove magnetic plug as follows:
 - (1) Do not disconnect wire.
 - (2) Grasp plug and push upward.
 - (3) While holding upward pressure, begin turning plug counter-clockwise.
 - (4) Turn plug counter-clockwise one-quarter turn.
 - (5) Pull plug out of socket in base fitting. See Figure 19-1.
- C. Inspect plug.

NOTE: New or recently overhauled gearboxes will often make a magnetic "fuzz" which will collect on the magnetic plug as a gray sludge. This is normal and may be cleaned off the plug. The plug may then be reinstalled and the helicopter returned to service. If any chips are found which are larger than 1/16 inch in cross-section, contact the nearest Enstrom Service Center or the Enstrom factory.

MAINTENANCE MANUAL SUPPLEMENT

- D. After determining that the transmission is airworthy, clean the magnetic plug. This may be accomplished with a soft cloth or with a strong magnet attached to a pointed object such as a knife or a small screwdriver. Use caution to avoid scratching the magnetic plug.
- E. Reinstall magnetic plug as follows:
 - (1) Insert plug into socket in base fitting.
 - (2) Align lugs in plug with slots in base fitting.
 - (3) Push plug upward while turning plug clockwise (approximately one-quarter turn).
 - (4) When plug stops turning, pull downward.
 - (5) Check plug to insure that it is locked in base.
- F. Reinstall access panel.

19-3 LUBRICANT CHANGE

The main rotor transmission lubricant should be changed Per Section 4 and proceed as described below.


- (1) Remove and inspect magnetic chip detector plug as described above.
- (2) Remove safety wire from chip detector base fitting.
- (3) Place a trough under the base fitting to carry the oil out the left side of the helicopter, and place a container under the trough.
- (4) Remove base fitting.
- (5) Allow all oil to drain from transmission.
- (6) Replace crush washer on base fitting.
- (7) Replace base fitting.
- (8) Safety base fitting with .032 lock wire.

NOTE: The base fitting may be safetied to the pylon tube after wrapping the tube with suitable tape to provide protection.

- (9) Reinstall magnetic plug as described above.
- (10) Service transmission with 5½ pints of Enstrom approved lubricant.
- (11) Inspect transmission for leaks.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MAINTENANCE MANUAL SUPPLEMENT



NOTE: To remove press inward and rotate outer hex assembly counter clockwise. To reinstall push inward and rotate clockwise until detent engages and locks over center, check for leakage and security.

WARNING: Do not operate helicopter with chip detector probes removed as severe lubrication loss may occur.

TYPICAL CHIP DETECTOR INSTALLATION
FOR MAIN ROTOR AND TAIL ROTOR TRANSMISSIONS

FIGURE 19-1

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

SECTION 20

[RESERVED]

NOTE: Content previously contained in this section has been incorporated into Section 11.

INTENTIONALLY LEFT BLANK

SECTION 21

ELECTRICAL SYSTEMS AND COMPONENTS

21-1. General – Reference Section 6 for Other Information

Updates to the electrical systems of the 280FX and F-28F include changes listed below:

- Combined anticollision and navigation lights and LED landing lights (para. 21-2)
- Annunciator Panel 280FX and F-28F S/N 746 and subsequent (para. 21-3)
- Hi/Lo rotor RPM warning system (para. 21-7)
- Engine monitor 280FX and F-28F (refer to Section 24)
- Illuminated switch panel, radio panel, and collective control panel (para. 21-9)

NOTE: Early F-28F aircraft do not have the annunciator panel but do have press-to-test lights for required items in para. 21-3.

Refer to paragraph 21-8 for the F-28F and 280FX electrical schematics.

21-2. Exterior Lighting

Refer to paragraph 21-4 for troubleshooting an inoperative LED landing light and refer to paragraph 21-5 for replacement part numbers.

A. LED Forward and Aft Landing Lights

F-28F S/N 833 and subsequent and 280FX S/N 2167 and subsequent helicopters are equipped with LED landing lights (forward landing light standard for both models; aft landing light standard for 280FX, optional for F-28F). The installations are shown in Figure 21-1. Controls for landing light operation are provided by a forward landing light switch and an aft landing light switch on the pilot collective and co-pilot collective (if installed). The switches and location are shown in Figure 21-3.

Annunciation for the two modes of operation (“On” and “Pulse”) of the forward landing light is provided by an annunciator light installed in the upper left portion of the instrument console (Figure 21-4). The annunciator illuminates a green FWD LDG LT ON or FWD LDG LT PLS depending on the mode of operation. “On” annunciation of the aft landing light is also provided by an annunciator light installed next to the forward landing light annunciator. The annunciator illuminates a green AFT LDG LT ON when the light is in operation.

Both annunciators are readable in sunlight and include a discrete dimming feature that dims the annunciator when the PANEL LTS toggle switch located on the switch/circuit breaker panel is toggled ON.

B. Combined Anticollision and Navigation Lights

The 280FX and F-28F S/N 744 and subsequent are equipped with combined anticollision-navigation lights. These light assemblies are mounted on the outside of each vertical stabilizer, and the anti-collision light power supplies are located under the floor on either side of the cabin, as shown in Figure 21-1.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Figure 21-1. Forward and Aft Landing Light (280FX shown) and Anti-Collision and Navigation Light Systems

21-3. Annunciator Panel

All of the warning and caution lights for 280FX helicopters are contained in an annunciator panel, which is located at the top of the instrument panel. On early production helicopters, the warning lights include LOW ROTOR RPM, CLUTCH ENGAGE, and LOW FUEL PRESS; the caution lights include OVERBOOST, MRGB CHIP, and TRGB CHIP. On later production helicopters, STARTER RELAY is added to the warning lights and LOW VOLTAGE is added to the caution lights.

The annunciator panel for F-28F helicopters was optional equipment starting with S/N 746. Later F-28F production helicopters incorporated the annunciator panel with all eight segments as standard equipment.

For aircraft equipped with the Hi/Low Rotor RPM Warning System, ROTOR RPM replaces LOW ROTOR RPM in the annunciator panel.

Pressing the “press-to-test” switch at the extreme left of the panel will illuminate all of the indicator lights.

A. Lamp Replacement – Annunciator Panel

Each indicator light contains two lamps. These lamps can be replaced as follows:

- (1) Press inward on the right edge of the indicator until indicator opens.
- (2) Swing indicator fully open.
- (3) Grasp base of lamp firmly and pull lamp out of socket.
- (4) Insert replacement lamp and push into place.
- (5) Swing indicator closed.
- (6) Push on left side of indicator to close.

B. Clutch Disengagement Warning Circuit

The clutch disengagement warning circuit consists of a microswitch on the clutch plate which operates a red warning light in the annunciator panel. This switch is normally closed and completes a circuit to ground when the clutch is disengaged. When the clutch snaps overcenter into the engaged position, an arm on the actuating mechanism opens the switch, which turns out the light. The “normally open” side of this switch arms the rotor rpm circuit.

If the clutch disengagement light does not go out when the clutch is engaged, or if the light comes on in flight, this indicates that the clutch is misrigged or the clutch actuator cable needs servicing. The problem must be found and corrected before the aircraft is returned to service. Press to test warning indicator on F-28F.

C. Low Fuel Pressure Warning Circuit

The low fuel pressure warning circuit comprises a pressure switch in the fuel line between the electric boost pump and the engine-driven fuel pump which activates a red light in the annunciator panel. If the pressure in this fuel line drops below 15 psi, the switch will turn on the red light. This circuit provides the pilot with a warning if the electric boost pump should

fail. This light does not indicate the condition of the engine-driven fuel pump. Press to test warning indicator on F-28F.

D. Low Rotor RPM Circuit

The low rotor rpm circuit comprises a magnetic sensor in the main rotor transmission, a signal conditioning unit behind the passenger's seat, an amber light in the annunciator panel, and a warning horn. The magnetic sensor is located in the forward portion of the main rotor transmission housing. It is positioned to sense the passage of the ring gear teeth. The signal is sent to a small unit located in the backrest of the passenger's seat. The unit reads the signal from the magnetic sensor and activates the light and the warning horn.

The system is armed by the same switch which activates the clutch disengagement light. Thus, the low rotor rpm light will be on only when the clutch disengaged light is out, and the main rotor rpm is below 334. In addition, the warning horn is wired through a position switch on the collective torque tube such that the horn will not operate with the collective fully down. The horn has a pulsing tone of 2900 Hz at 80-95 decibels.

After the engine is started, the following sequence should occur in the annunciator panel. The red clutch disengagement light will be on until the clutch is engaged. When the clutch snaps into the engaged position, the red clutch disengagement light will go out and the amber low rotor rpm light will turn on. The low rotor rpm light will remain on until the rotor rpm exceeds 334. The horn will sound if the rotor rpm is below 334 and collective is raised off the lower stop.

This system is set to trigger the light and horn at 334 rpm \pm 1 rpm. The system can be adjusted with a potentiometer on the top of the signal conditioning unit. The position of the magnetic sensor was set at the factory and will need no readjustment. Contact Enstrom Product Support for service on the magnetic sensor. For electrical schematic see Diagram 21-4, for RPM adjustment on low rotor indicator see Figure 21-2.

E. Hi/Lo Rotor RPM Circuit

F-28F S/N 831 and subsequent and 280FX S/N 2136 and subsequent are equipped with a Hi/Lo Rotor RPM Circuit. Refer to paragraph 21-7 for maintenance procedures.


F. Overboost Circuit

The overboost circuit consists of a pressure switch behind the instrument panel and connected to the manifold pressure line which activates an amber warning light in the annunciator panel. The light will illuminate between 37.0 and 40.5 in-Hg manifold pressure. The light may be triggered by short pressure pulses which will not appear on the manifold pressure gauge. The manifold pressure gauge is the primary manifold pressure indicator, while the annunciator panel is a secondary indicator. The manifold pressure gauge should be used to determine severity of any overboost.



G. Main and Tail Rotor Gearbox Chip Detectors

The main and tail rotor gearboxes are equipped with magnetic chip detectors which operate amber lights in the annunciator panel. There is a separate circuit and light for each gearbox. When a chip attaches to the chip detector, it completes a circuit to ground, turning on the light. Further information on the chip detectors is included in Sections 19 and 25, which describe the main and tail rotor transmissions, respectively.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT



Set rotor RPM needle at 334 - warning light should come on at a decreasing RPM at 334 and lower and off at an increasing RPM above 334 RPM



TO ADJUST LO ROTOR RPM WARNING LIGHT:

Turn clockwise to increase trip point or RPM

Turn counter clockwise to reduce trip point or RPM

Lo rotor RPM control unit

Low Rotor RPM Indicator Adjustment
(F-28F S/N 830 and prior; 280FX S/N 2136 and prior)

Figure 21-2

21-4. Anticollision and Navigation Lights, Annunciator Panel, and Landing Lights Troubleshooting

PROBABLE CAUSE	REQUIRED ACTION
Anti-collision lights both out with master on and anti-collision light switch on:	
Circuit breaker tripped	Reset circuit breaker. Check for wire shorted to ground.
Open circuit	Check all connections and continuity of wiring harness.
One anti-collision light out:	
Open circuit	Check all connections and continuity of wiring harness.
Failed power supply	Check for audible tone from power supply. If no tone, replace power supply.
Lamp burned out	Replace lamp.
Navigation lights all out with master on and navigation light switch on:	
Circuit breaker tripped	Reset circuit breaker, check for wire shorted to ground.
Open circuit	Check all connections and continuity of wiring harness.
One navigation light out:	
NOTE: F-28F S/N 833 and subsequent and 280FX S/N 2148 and subsequent are equipped with LED position lights.	
Lamp burned out	Replace lamp or assembly, as applicable.
Open circuit	Check all connections and continuity of wiring harness.
Annunciator panel does not illuminate when “press-to-test” is pressed and “panel light” switch is off:	
Master off	Turn master on
Circuit breaker tripped	Reset “Inst.” circuit breaker
Open circuit	Check wiring harness connector inside console. Also check wiring harness connections.
NOTE: For F-28F models, test each press to test indicator individually and take indicated required action.	
Annunciator panel will not illuminate when “press-to-test” is pressed and panel light switch is on:	
Master off	Turn master on.
Dimmer switch fully dimmed	Brighten lights.
Circuit breaker tripped	Reset panel lights circuit breaker.
One indicator will not illuminate when “press-to-test” is pressed:	
Both lamps burned out	Replace both lamps.
Open circuit in warning circuit	Check connections and wiring in circuit

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

PROBABLE CAUSE	REQUIRED ACTION
One indicator is dim when "press-to-test" is pressed:	
One lamp burned out	Replace lamp. If no change, reinstall first lamp and replace second lamp.
Low rotor rpm circuit, including horn, doesn't work:	
Blown fuse	Replace 1 amp fuse, in line between low rotor signal conditioning unit and 12-volt bus.
Open circuit	Check all connections and continuity of wiring harness
NOTE: The troubleshooting steps listed below apply to F-28F S/N 831 and subsequent and 280FX S/N 2136 and subsequent.	
Annunciator panel rotor RPM circuit, including horn and tone, doesn't work:	
Blown fuse	Replace 1 amp fuse, in line between signal conditioning unit and bus.
Open circuit	Check all connections and continuity of wiring harness.
ROTOR RPM light does not extinguish:	
Open circuit	Check connections and continuity of wiring between the signal conditioner and the magnetic sensor.
Magnetic sensor improperly positioned	Remove the magnetic sensor inspection plug located on the front of the main rotor transmission. Ensure the gap between the ring gear and the magnetic sensor is between 0.030-0.045"/0.76-1.14 mm. Adjust the amount of shims under the head of the magnetic sensor as required. Replace the inspection plug.
Defective magnetic sensor	Using a multi-meter, check for 270-330 ohms across the leads. Replace the magnetic sensor if the ohm check is outside the 270-330 ohm range or if inspection of the system components and wiring isolates the problem to the magnetic sensor.
NOTE: F-28F S/N 833 and subsequent and 280FX S/N 2167 and subsequent are equipped with LED landing light assemblies.	
LED Landing Lights, Forward and Aft (for F-28F, if equipped)	
LED burned out (D52, forward; D53, aft)	Replace LED, as applicable
Landing light breaker open or failed (CB45, forward; CB46, aft)	Reset or replace breaker
Collective control switch failed Forward: (SW121, pilot; SW120, co-pilot) Aft: (SW 133, pilot; SW 132, co-pilot)	Replace landing light switch

21-5. Lamp/Assembly Replacement Guide Chart

Lamp Location	Quantity	Manufacturer	Number	
			12 volt	28 volt
NOTE: F-28F S/N 832 and prior; 280FX S/N 2147 and prior are equipped with incandescent position light/strobe assemblies at the time of manufacture.				
Anti-collision strobe	2	Whelen	02-0250276-00	02-0250276-00
Left and right position	2	Whelen	34-0414020-65	34-0428020-65
NOTE: F-28F S/N 833 and subsequent; 280FX S/N 2148 and subsequent are equipped with LED position light/strobe assemblies at the time of manufacture.				
Anti-collision strobe	2	Whelen	N/A	36-0050626-01
LED Left and right position (LED assembly only)	1	Whelen	N/A	01-0271789-03 (green)
	1		N/A	01-0271789-04 (red)
Anti-collision strobe/LED Left and right position (Complete assembly)	1	Whelen	N/A	01-0790340-03 (green)
	1		N/A	01-0790340-04 (red)
Tail navigation	2	Whelen	34-0412070-63	34-0428070-64
Annunciator Panel	12*	G.E.	330 (MS25237-330)	327 (MS25237-327)
* 2 lamps per indicator				
NOTE: F-28F S/N 833 and subsequent; 280FX S/N 2167 and subsequent are equipped with LED landing light assemblies at the time of manufacture.				
Landing Light (forward)	1	AeroLEDs	N/A	28-19132-1
Landing Light (aft; F-28F, if equipped)	1	Whelen	N/A	28-19132-3

21-6. Ampere Load Conditions

NOTE

Table 21-1 and Table 21-2 provide the ampere load conditions for earlier F-28F and 280FX production and are not to be referenced for current production. Due to the variations in avionics installations, current production F-28F (S/N 830 and subsequent) and 280FX (S/N 2135 and subsequent) electrical load analysis tables are omitted from this manual but are documented and maintained with the build records for each aircraft manufactured. Contact Enstrom Product Support to inquire about the ampere load conditions for your aircraft.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

Table 21-1. 280FX Flight Ampere Load Conditions

NOTE: The information in this table applies to early production (see paragraph 21-6 NOTE).

ELECTRICAL DEVICE	DAY					NIGHT						
	A ¹	B	C	D	E	F ²	G	H	I	J	K	L
Boost Pump	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5
Longitudinal Trim ³	-	6.0	-	6.0	-	-	6.0	-	6.0	-	6.0	-
Lateral Trim ³	-	-	6.0	-	6.0	-	-	6.0	-	6.0	-	-
Radio, Transmit ³	-	6.0	6.0	-	-							
Radio, Receive	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8	0.8
Transponder	1.8	1.8	1.8	1.8	1.8	1.8	1.8	1.8	1.8	1.8	1.8	1.8
Loran-C	2.3	2.3	2.3	2.3	2.3	2.3	2.3	2.3	2.3	2.3	2.3	2.3
Instrument Cluster ⁴	0.64	0.64	0.64	0.64	0.64	0.64	0.64	0.64	0.64	0.64	0.64	0.64
Master Relay	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Anticollision Lights	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
Navigation Lights	-	-	-	-	-	8.2	8.2	8.2	8.2	8.2	8.2	8.2
Panel Lights	-	-	-	-	-	2.0	2.0	2.0	2.0	2.0	2.0	2.0
Forward Landing Light ⁵	-	-	-	-	-	-	-	-	-	-	20.8	20.8
Aft Landing Light ⁵	-	-	-	-	-	-	-	-	-	-	3.14	3.14
TOTAL	15.44	27.44		21.44		25.64	37.64		31.64		61.58	49.53

- NOTES:
- 1 Flight condition 'A' is normal day cruise
 - 2 Flight condition 'B' is normal night cruise
 - 3 Device subject to intermittent use
 - 4 Including graphic engine monitor and low rotor rpm circuit
 - 5 Device subject to short duration (5 minutes)

The above load conditions include all standard electrical equipment for the 280FX helicopter. If other equipment is added, the load conditions above must be modified. F-28F loads same as indicated in Section 6-15, page MM-6-27.

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-21-9

Rev. 8
Sep 20/17

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

Table 21-2. F-28F/280FX Flight Ampere Load Conditions – 28 Volt System

NOTE: The information in this table applies to early production (see paragraph 21-6 NOTE).

ELECTRICAL DEVICE	DAY					NIGHT						
	A	B	C	D	E	F	G	H	I	J	K	L
Nav Lights @ 0.805 amps ea	-	-	-	-	-	3.22	3.22	3.22	3.22	3.22	3.22	3.22
Boost Pump	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75
Long. Trim *	-	2.0	-	2.0	-	-	2.0	-	2.0	-	2.0	-
Lat. Trim *	-	-	2.0	-	2.0	-	-	2.	-	2.0	-	2.0
Radio – Transmit *	-	1.75	1.75	-	-	-	1.75	1.75	-	-	1.75	-
Radio – Receive	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3
Instrument Cluster	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07
Master Relay	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
Anti-Collision	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5
Panel Lights	-	-	-	-	-	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Forward Landing Light	-	-	-	-	-	-	-	-	-	-	8.93	8.93
Aft Landing Light	-	-	-	-	-	-	-	-	-	-	8.93	8.93
Landing Light Relay	-	-	-	-	-	-	-	-	-	-	0.11	0.11
TOTAL	7.12	11.87		9.12		11.34	15.09		13.34		33.06	29.31

NOTES: Flight condition 'A' is normal day cruise
 Flight condition 'B' is normal night cruise
 * Denotes intermittent use
 Denotes short duration use (5 min.)

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Rev. 8
 Sep 20/17

21-7. Hi/Lo Rotor RPM Warning System

The Hi/Lo Rotor RPM Warning System consists of the P/N ECD4079-1 Hi/Lo Rotor RPM switch (signal conditioning unit), a ROTOR RPM warning light, a magnetic sensor, microswitches (S19 and S24), a lamp test switch (S25), warning horn, and a warning tone generator interfaced with the audio panel. The magnetic sensor, located in the forward portion of the main rotor transmission housing, is positioned to sense the passage of the ring gear teeth. A signal is sent to the signal conditioning unit, which activates the ROTOR RPM warning light on the annunciator panel, an audible warning horn, and a tone in the audio system headsets when the main rotor rpm is below 332 RPM or above 385 RPM. The signal conditioning unit is also activated by switch (S24) on the clutch actuator mechanism. The ROTOR RPM warning light, horn, and tone will be on when the CLUTCH ENGAGE light is out, and the main rotor rpm is below 332 RPM or above 385 RPM. A microswitch (S19), located on the collective torque tube behind the pilot's seat, deactivates the warning horn and tone when the collective controls are on the down stop. The annunciator panel press-to-test switch (S25) will illuminate the ROTOR RPM warning light for test purposes when the switch (S25) is pressed.

A. Signal Conditioning Unit

The signal conditioning unit, located behind the passenger's back cushion, reads the signal from the magnetic pickup and activates the ROTOR RPM warning light, and audio horn and tone. The wiring schematic diagram of the Hi/Lo Rotor RPM Warning System is detailed in Diagram 21-5 Sheet 3.

B. Removal – Signal Conditioning Unit

- (1) Ensure all electrical power is off.
- (2) Remove the back cushions and seatback access panel.
- (3) Unplug the electrical connector from the signal conditioning unit.
- (4) Remove the four screws mounting the signal conditioning unit to the bulkhead.
- (5) Remove the signal conditioning unit.

C. Inspection – Signal Conditioning Unit

- (1) Inspect the signal conditioning unit for damage, security of installation, and proper operation.

D. Repair – Signal Conditioning Unit

- (1) Replace the signal conditioning unit if damaged or the unit fails to activate the light and horn or the unit cannot be set to activate at rotor speeds below 332 RPM and above 385 RPM.

- (2) The signal conditioning unit has been adjusted at the factory to activate at rotor speeds below 332 RPM or above 385 RPM. The unit should not need readjustment, but if it does, the operator may adjust the LO or HI potentiometers located on the top of the unit.
 - a. Turn the LO adjustment counter clockwise to reduce the low-end (i.e. 332 RPM) activating rpm and clockwise to increase the low-end (i.e. 332 RPM) activating rpm.
 - b. Turn the HI adjustment counter clockwise to reduce the high-end (i.e. 385 RPM) activating rpm and clockwise to increase the high-end (i.e. 385 RPM) activating rpm.

E. Installation – Signal Conditioning Unit

- (1) Install the signal conditioning unit by securing the unit onto the bulkhead with four screws, washers, and nuts.
- (2) Plug the electrical connector into the signal conditioning unit.
- (3) Replace the seatback access panel and back cushions.

F. Functional Test – Hi/Lo Rotor Rpm Warning System

- (1) Apply electrical power to the aircraft. Check the CLUTCH ENGAGE light is illuminated and the ROTOR RPM light is not illuminated.
- (2) Engage the belt clutch. Check the ROTOR RPM light is illuminated and the CLUTCH ENGAGE light is not illuminated.
- (3) Push the TEST button adjacent to the annunciator panel. Check that the ROTOR RPM and CLUTCH ENGAGE lights are illuminated. Release the button. (The ROTOR RPM light will remain illuminated with the clutch engaged.)
- (4) Raise the collective controls off of the down stop. Check the ROTOR RPM horn and tone activate.
- (5) Place the collective controls against the down stop. Check the ROTOR RPM horn and tone deactivate.
- (6) Carefully disengage the belt clutch.

WARNING

The following checks are to be performed by authorized personnel.

- (7) Run up the aircraft in accordance with the operator's manual. Check the CLUTCH ENGAGE warning light extinguishes and the ROTOR RPM light illuminates when the clutch is engaged.
- (8) Increase the power to bring rotor up to 334 rpm and check the ROTOR RPM warning light extinguishes at 333 ± 1 rpm. If the light does not illuminate or extinguish at 333 ± 1 rpm, refer to paragraph D, step (2)a for adjustment.

WARNING

The following test procedure requires flying the aircraft in an autorotation. The test should be conducted by an appropriately rated pilot using appropriate safety precautions.

- (9) Fly the aircraft to an altitude and location where an autorotation can be safely performed and recovered.
- (10) Enter a stabilized autorotation and allow the rotor RPM to build to the upper red line, 385 RPM

CAUTION

Rotor RPM can build very quickly in autorotation. Use care when approaching the upper red line.

NOTE

The aircraft will have to be moderately heavy to achieve a high enough autorotation RPM. An accelerated maneuver, such as a turn or flare, may also be required to increase the RPM.

- (11) Check that the ROTOR RPM warning light illuminates above 385 ± 2 RPM. Do not allow the rotor RPM to exceed 390.

NOTE

If the collective is fully down, the horn and tone will not activate.


- (12) Bring RPM down. Check that the ROTOR RPM warning light extinguishes below 385 ± 2 RPM.
- (13) If the warning light does not illuminate or extinguish at 385 ± 2 RPM, refer to paragraph D, step (2)b for adjustment.
- (14) Check the operation of the ROTOR RPM and CLUTCH ENGAGE warning lights during the shutdown procedure

21-8. Schematic Diagrams

Table 21-3. List of Diagrams


- Diagram 21-1. 12 Volt Power Distribution – 280FX
- Diagram 21-2. 12 Volt Power Distribution – F-28F
- Diagram 21-3. 24 Volt Power Distribution – F-28F and 280FX
- Diagram 21-4. Annunciator Panel Schematic – F-28F S/N 830 and prior and
280FX S/N 2135 and prior
- Diagram 21-5. 24 Volt Power Distribution – F-28F S/N 831-832
280FX S/N 2136-2166
- Note: Sheet 6 (EDM-700) applicable to:
F-28F S/N 831-832
280FX S/N 2140-2166
- Note: Sheet 7 (LED Position Lights)
applicable to:
280FX S/N 2148-2166
- Diagram 21-6. 24 Volt Power Distribution – F-28F S/N 833 and subsequent
(begin page MM-21-37) 280FX S/N 2167 and subsequent
- Diagram 21-7. 28 to 14 Volt Converter and Dual 14 Volt Power Sockets (Option)

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Diagram 21-1
Rev. 11, Oct 25/19
MM-21-15



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT



Annunciator Panel Schematic
(F-28F, S/N 830 and prior; 280FX, S/N 2135)

Diagram 21-4

INTENTIONALLY LEFT BLANK




DIAGRAM 21-5 SHEET 1
DIAGRAM 21-5 SHEET 2

Diagram 21-5. 24 Volt Electrical System Schematic (F-28F, S/N 831 and subsequent; 280FX, S/N 2136 and subsequent) Sheet 1
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED Rev. 8, Sep 20/17
 MM-21-21/MM-21-22 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.




Diagram 21-5. 24 Volt Electrical System Schematic (F-28F, S/N 831 and subsequent; 280FX, S/N 2136 and subsequent) Sheet 2
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED Rev. 8, Sep 20/17
 MM-21-23/MM-21-24 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-5. 24 Volt Electrical System Schematic (F-28F, S/N 831 and subsequent; 280FX, S/N 2136 and subsequent) Sheet 3
UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED Rev. 8, Sep 20/17
 MM-21-25/MM-21-26 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-5. 24 Volt Electrical System Schematic – Cyclic Grip
 (F-28F, S/N 831 and subsequent; 280FX, S/N 2136 and subsequent) Sheet 4

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT





Diagram 21-5. 24 Volt Electrical System Schematic – Trim Switch Modules (F-28F, S/N 831 and subsequent; 280FX, S/N 2136 and subsequent) Sheet 5

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Diagram 21-5, 24-Volt Electrical System Schematic – EDM-700 (F-28F, S/N 851 and subsequent; 280FX, S/N 2140 and subsequent) Sheet 6

Rev. 8, Sep 20/17

MM-21-29/MM-21-30 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-5. LED Position Light Schematic (F-28F, S/N 833 and subsequent; 280FX, S/N 2148 and subsequent) Sheet 7

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

INTENTIONALLY LEFT BLANK

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

MM-21-32

Rev. 8
Sep 20/17

21-9. Illuminated Panels

NOTE

F-28F S/N 833 and subsequent and 280FX S/N 2167 helicopters are equipped with illuminated collective switch panel, illuminated circuit breaker/switch panel, and illuminated radio panel.

A. Illuminated Collective Switch Panel


The illuminated collective panel provides illumination for the switches contained in the control box mounted on the forward end of both the pilot collective and co-pilot collective sticks. A depiction of the illuminated collective panel and assembly is shown in Figure 21-3.

Removal

- (1) Remove the two screws (1) and two washers (2) from the front of the illuminated panel.
- (2) Lift the illuminated panel (3) to the side remove two screws (4) from the switch plate (5).
- (3) Remove the two screws (6) from the handle assembly (7) and remove the switch plate cover (8).
- (4) Cut the red and black wires 1.5 in/3.8 cm from the back of the switch plate (5) and remove the illuminated panel (3).

Installation

- (1) Connect the red and black wires to the replacement illuminated panel (3).
 - (a) Strip 0.25 in/6.4 mm of the insulation from the cut ends of the two red wires.
 - (b) Slide 1.25 in/ 32 mm of shrink tube (P/N FIT-221V-1/8 or equivalent) over a red wire.
 - (c) Tin and solder both ends of the red wires together.
 - (d) Slide the shrink tube over the solder and shrink it with a heat gun.
 - (e) Repeat this operation with the black wires.
- (2) Install the switch plate cover (8) under the handle assembly (7) and with two screws (6). Torque the screws 10.8 in-lb/1.22 Nm.
- (3) Install the switch plate (5) onto the housing (9) and secure with two screws (4). Torque the screws 10.8 in-lb/1.22 Nm.
- (4) Install the illuminated panel (3) onto the switch plate (5) and secure it with two screws (1) and washers (2). Torque the screws to 2 in-lb/0.23 Nm.
- (5) Verify that the illuminated switch panel operates correctly.



- | | | | |
|----|-------------------|----|--------------------|
| 1. | Screw | 6. | Screw |
| 2. | Washer | 7. | Handle Assembly |
| 3. | Illuminated Panel | 8. | Switch Plate Cover |
| 4. | Screw | 9. | Housing |
| 5. | Switch Plate | | |

Figure 21-3. Illuminated Collective Panel Assembly and Installation

B. Illuminated Switch and Circuit Breaker Panel and Radio Panel

An illuminated panel located between the upper instrument console and lower radio stack provides illumination for installed circuit breakers, switches, and dimmer control.

A separate illuminated radio stack panel also provides illumination for additional avionic system switches, such as transponder and remote ELT switches, for example.

A depiction of the illuminated panels is shown in Figure 21-4.




Figure 21-4. Illuminated Switch/Circuit Breaker and Radio Panels

Removal – Switch and circuit breaker panel:


- (1) Remove power from the aircraft.
- (2) Center all toggle switches and remove the PNL LTS DIMMER knob.
- (3) Remove the screws (4X) (Figure 21-4).
- (4) Lift the panel away from the console to access the electrical connector.
- (5) Disconnect the electrical connector and remove the panel.

Removal – Radio panel:

- (1) Remove power from the aircraft.
- (2) Center all toggle switches.
- (3) Remove the screws (6X) (Figure 21-4).
- (4) Lift the panel away from the console to access the electrical connector.
- (5) Disconnect the electrical connector and remove the panel.

Installation – Switch and circuit breaker panel and radio panel:

- (1) Connect the electrical connector.
- (2) Install the panel in position.
- (3) Install the screws, as required (Figure 21-4).
- (4) Install the dimmer knob, if required, and toggle all switches to OFF or as required, as applicable.
- (5) Apply aircraft power and check the illuminated panel operation.



Notes

For clarity, Sheets 1 through 9 on subsequent pages may be altered from the diagram shown above.

- 2 See 28-22140 for optional alternator RFI filter interface.
- 3 Aft landing light is optional for F-28F. When not configured, wire #35-24A will be disconnected and tied back near the cutouts for SW132 and SW133 in the collective stick assemblies. Connector J98 and J339 will be tied back to the harness.
- 4 CB/Switches location and quantity may vary depending on customer preferences.
- 5 Typical
- 6 Typical


UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Diagram 21-6 (Sheet 0). 24 Volt Electrical System Schematic
 (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 Rev. 10, Feb 7/19
 MM-21-37/MM-21-38 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT



SEE SHEET 2

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Diagram 21-6 (Sheet 1). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent) Rev. 10, Feb 7/19 MM-21-39/MM-21-40 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT





Diagram 21-6 (Sheet 2). Power Distribution
 (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 Rev. 10, Feb 7/19
 MM-21-41/MM-21-42 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT



UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Diagram 21-6 (Sheet 3). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent) Rev. 10, Feb 7/19 MM-21-43/MM-21-44 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-6 (Sheet 4). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 Rev. 10, Feb 7/19
 MM-21-45/MM-21-46 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-6 (Sheet 5). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 Rev. 10, Feb 7/19
 MM-21-47/MM-21-48 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.




Diagram 21-6 (Sheet 6). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 Rev. 10, Feb 7/19
 MM-21-49/MM-21-50 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-6 (Sheet 7). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED
 Rev. 10, Feb 7/19
 MM-21-51/MM-21-52 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-6 (Sheet 8). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
 UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED
 Rev. 10, Feb 7/19
 MM-21-53/MM-21-54 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT




Diagram 21-6 (Sheet 9). Power Distribution (F-28F S/N 833 and Subsequent; 280FX S/N 2167 and Subsequent)
Rev. 10, Feb 7/19
MM-21-55/MM-21-56 Blank

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

UNCONTROLLED COPY WHEN DOWNLOADED OR PRINTED

Visit www.enstromhelicopter.com for instructions to order an original manual and to register for email notification of updates.





Diagram 21-7. 28 to 14 Volt Converter and Dual 14 Volt Power Sockets (Option)

I

INTENTIONALLY LEFT BLANK

SECTION 22

[RESERVED]

I

INTENTIONALLY LEFT BLANK

SECTION 23

[RESERVED]

NOTE: Content previously contained in this section has been incorporated into Section 12.

INTENTIONALLY LEFT BLANK

SECTION 24
INSTRUMENTS
TABLE OF CONTENTS

Paragraph	Description	Page
24-1	Engine Monitor	MM-24-1
24-2	Description	MM-24-1
24-3	Maintenance	MM-24-2
24-4	Programming Alarm Limits.....	MM-24-2
24-5	Troubleshooting	MM-24-2
24-6	Clock	MM-24-7
24-7	Outside Air Temperature Indicator (OAT)	MM-24-7
24-8	Magnetic Compass	MM-24-7
24-9	Rotor RPM Magnetic Pickup	MM-24-8
	Removal.....	MM-24-9
	Inspection.....	MM-24-9
	Repair	MM-24-9
	Installation.....	MM-24-9

INTENTIONALLY LEFT BLANK

SECTION 24

INSTRUMENTS

24-1. Engine Monitor

24-2. Description – Engine Monitor

Later F-28F and all 280FX production aircraft are equipped with an engine monitor as an aid for fuel mixture leaning in cruising flight. The engine monitor replaces the turbocharger inlet temperature gauge (analog indicator) used in 280F and early F-28F production aircraft.

NOTE

For F-28F aircraft equipped with the analog indicator, the term defining the temperature of the exhaust gases delivered into the turbocharger unit is designated as exhaust gas temperature (EGT).

For F-28F and 280FX aircraft equipped with an engine monitor, the EGT term is replaced by the designation turbine inlet temperature (TIT). The term EGT is retained but is designated as the temperature of exhaust gas of the individual cylinders.

Therefore, in portions of paragraph 7-11 and applicable text stated elsewhere in this manual, note that the term EGT is synonymous with the term TIT if the aircraft is equipped with the analog indicator.

Later production F-28F (S/N 830 and prior) and 280FX (S/N 2139 and prior) are equipped with the Graphic Engine Monitor (GEM) Model 603 or Model 610. Current production F-28F (S/N 831 and subsequent) and 280FX (S/N 2140 and subsequent) are equipped with the Engine Data Management (EDM) Model EDM-700.

The GEM and EDM models display EGT and cylinder head temperature (CHT) in bar graphs, one for each cylinder. TIT is displayed digitally for both models and is also displayed in bar graph on the EDM model. The GEM 610 and EDM-700 also display EGT, CHT, and outside air temperature (OAT) digitally. The EDM-700 also monitors and displays rate of change of CHT (CLD), maximum EGT differential (DIF), and voltage (BAT).

NOTE

For Model 603, the TIT is displayed as a three-digit number (equal to the actual TIT in °F divided by 10); for Model 610, TIT is displayed as a four-digit number.

Figure 24-1 depicts the location of the engine monitoring instrument.

24-3. Maintenance – Engine Monitor

The engine monitor instrument requires no scheduled maintenance checks, calibration, field adjustments or field-serviceable components. Built-in self-tests start automatically on power-up to detect instrument malfunctions. Common start-up malfunctions are caused by a wiring anomaly. Refer to Diagram 21-5 Sheet 3 or 6, as applicable, to diagnose an open wire or probe with a poor connection.

Refer to Section 7 for instrument replacement (para. 7-18) and inspection (para. 7-19) procedures. In addition, inspect the instrument for proper operation. The inspection for proper engine monitor operation should consist of either a maintenance ground run or a maintenance test flight to compare the instrument indications to the indications observed during normal operation. The troubleshooting and diagnosis chart, Table 24-2, will help diagnose engine problems.

24-4. Programming Alarm Limits – Engine Monitor

The EDM-700 has programmable alarms. The alarm limits are based on factory default settings but may be modified. Recommended alarm limit values are defined in Table 24-1. The operator may choose to reduce these to provide additional margins or increase engine life. Lycoming and various industry groups have additional guidance.

NOTE

Limits will reset to factory defaults when the display is switched between Fahrenheit and Celsius.

Table 24-1. EDM-700 Recommended Alarm Limit Values

Parameter	Description	Recommended Limit
CHT	Cylinder head temperature	500°F (260°C)
TIT	Turbine inlet temperature	1650°F (900°C)
CLD	Cylinder head cooling rate	-100°F/min (-55°C/min)
DIF	Difference between highest and lowest EGT values	500°F (280°C)
H BAT	Battery high voltage limit	30.0V
L BAT	Battery low voltage limit	24.5V





24-5. Troubleshooting – Engine Monitor

Refer to Table 24-2 to help diagnose engine problems when using the engine monitor. Not all possible engine monitor displays are presented. Refer to the applicable engine monitor installation and/or operation manual for a complete troubleshooting and diagnosis listing.

WARNING

Magneto checks should be conducted on the ground. They may be conducted hovering IGE with a pilot and a mechanic to manipulate the magneto switch, but the pilot must be prepared for sudden, complete engine stoppage.

Table 24-2. Graphic Engine Monitor Troubleshooting


Problem	Cause	Required Action
<p>Gradual or sudden increase in EGT of one cylinder.</p> <p style="text-align: center;"><u>EDM-700</u></p>  <p style="text-align: center;"><u>GEM 603/610</u></p>  <p style="text-align: center;">NOTE GEM 603/610 display will blink when this occurs.</p>	<p>Partially plugged fuel nozzle, indicated by no variation in EGT during magneto check for that cylinder.</p> <p>Fouled or defective spark plug or ignition lead.</p>	<p>Remove and clean indicated cylinder nozzle.</p> <p>Perform a magneto check on the ground. Cylinder that has a faulty spark plug or ignition lead will drop on the bar graph and other cylinders will rise, indicating the top, bottom plug or lead, with the problem.</p> <p>Replace spark plug or lead as required on indicated cylinder.</p>
<p>Rising EGT readings on all cylinders.</p> <p style="text-align: center;"><u>EDM-700</u></p>  <p style="text-align: center;"><u>GEM 603/610</u></p>  <p style="text-align: center;">NOTE GEM 603/610 display will blink when this occurs.</p>	<p style="text-align: center;">WARNING This is a serious indication and can cause abrupt engine failure, if proper steps are not taken.</p> <p>Magneto out of time, or faulty.</p> <p>Restriction in fuel system or servo not flowing correctly.</p>	<p>Perform a magneto check on the ground. RPM drop on both magnetos should be excessive.</p> <p>Check timing. If correct, overhaul or replace magnetos.</p> <p>Check fuel filters and clean.</p> <p>Perform fuel flow check at nozzles.</p> <p>Check lines for damage or flex lines for twist.</p> <p>Return servo to authorized Bendix overhaul center.</p>

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

Problem	Cause	Required Action																																																															
<p>Above normal temperatures in one or more cylinders (CHT).</p> <p align="center"><u>EDM-700</u></p> <table border="0"> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> <td align="center">T</td> <td></td> </tr> <tr> <td>CHT</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td rowspan="4">%</td> </tr> <tr> <td>450</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>350</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>250</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> </table> <p align="center"><u>GEM 603/610</u></p> <table border="0"> <tr> <td></td> <td align="center">EGT</td> <td></td> <td align="center">CHT</td> <td></td> </tr> <tr> <td>*</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> <td align="center">5 4 3</td> </tr> </table>		1	2	3	4	T		CHT	████	████	████	████	████	%	450	████	████	████	████	████	350	████	████	████	████	████	250	████	████	████	████	████		EGT		CHT		*	████	████	████	████	o	████	████	████	████	o	████	████	████	████	o	████	████	████	████		1	2	3	4	5 4 3	<p>Cracked, missing or open baffles or doors. Obstruction or debris in cylinder fins. Cowl panel doors not secure.</p>	<p>Repair or replace baffles, remove obstructions, and close panel doors.</p>
	1	2	3	4	T																																																												
CHT	████	████	████	████	████	%																																																											
450	████	████	████	████	████																																																												
350	████	████	████	████	████																																																												
250	████	████	████	████	████																																																												
	EGT		CHT																																																														
*	████	████	████	████																																																													
o	████	████	████	████																																																													
o	████	████	████	████																																																													
o	████	████	████	████																																																													
	1	2	3	4	5 4 3																																																												
<p>Low EGT reading in one cylinder, continually.</p> <p align="center"><u>EDM-700</u></p> <table border="0"> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> <td align="center">T</td> <td></td> </tr> <tr> <td>CHT</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td rowspan="4">%</td> </tr> <tr> <td>450</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>350</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>250</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> </table> <p align="center"><u>GEM 603/610</u></p> <table border="0"> <tr> <td></td> <td align="center">EGT</td> <td></td> <td align="center">CHT</td> <td></td> </tr> <tr> <td>*</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td>o</td> <td>████</td> <td>████</td> <td>████</td> <td>████</td> </tr> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> <td align="center">5 4 3</td> </tr> </table>		1	2	3	4	T		CHT	████	████	████	████	████	%	450	████	████	████	████	████	350	████	████	████	████	████	250	████	████	████	████	████		EGT		CHT		*	████	████	████	████	o	████	████	████	████	o	████	████	████	████	o	████	████	████	████		1	2	3	4	5 4 3	<p>Defective or blown exhaust gasket. Cracked or loose exhaust system.</p>	<p>Inspect exhaust system and correct as required.</p>
	1	2	3	4	T																																																												
CHT	████	████	████	████	████	%																																																											
450	████	████	████	████	████																																																												
350	████	████	████	████	████																																																												
250	████	████	████	████	████																																																												
	EGT		CHT																																																														
*	████	████	████	████																																																													
o	████	████	████	████																																																													
o	████	████	████	████																																																													
o	████	████	████	████																																																													
	1	2	3	4	5 4 3																																																												
	<p>Intake valve not opening completely causing low compression.</p>	<p>Perform a compression check.</p>																																																															
	<p>Plugged fuel nozzle.</p>	<p>Clean nozzle.</p>																																																															

ENSTROM F-28F/280F SERIES MAINTENANCE MANUAL SUPPLEMENT

Problem	Cause	Required Action																																																																						
<p>Decline in EGT uniformity, most visible at cruise power settings.</p> <p align="center"><u>EDM-700</u></p> <table border="0"> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> <td align="center">T</td> <td></td> </tr> <tr> <td>CHT</td> <td align="center">████</td> <td align="center">██████</td> <td align="center">████</td> <td align="center">████</td> <td align="center">██████</td> <td></td> </tr> <tr> <td>450</td> <td align="center">████</td> <td align="center">██████</td> <td align="center">████</td> <td align="center">████</td> <td align="center">██████</td> <td align="center">%</td> </tr> <tr> <td>350</td> <td align="center">████</td> <td align="center">██████</td> <td align="center">████</td> <td align="center">████</td> <td align="center">██████</td> <td></td> </tr> <tr> <td>250</td> <td align="center">████</td> <td align="center">██████</td> <td align="center">████</td> <td align="center">████</td> <td align="center">██████</td> <td></td> </tr> </table> <p align="center"><u>GEM 603/610</u></p> <table border="0"> <tr> <td></td> <td align="center">EGT</td> <td></td> <td align="center">CHT</td> <td></td> </tr> <tr> <td></td> <td align="center">████</td> <td></td> <td align="center">████</td> <td></td> </tr> <tr> <td>*</td> <td align="center">████</td> <td></td> <td align="center">████</td> <td></td> </tr> <tr> <td>o</td> <td align="center">████</td> <td></td> <td align="center">████</td> <td align="center">5</td> </tr> <tr> <td>o</td> <td align="center">████</td> <td></td> <td align="center">████</td> <td align="center">4</td> </tr> <tr> <td>o</td> <td align="center">████</td> <td></td> <td align="center">████</td> <td align="center">3</td> </tr> <tr> <td></td> <td align="center">1</td> <td align="center">2</td> <td align="center">3</td> <td align="center">4</td> </tr> </table>		1	2	3	4	T		CHT	████	██████	████	████	██████		450	████	██████	████	████	██████	%	350	████	██████	████	████	██████		250	████	██████	████	████	██████			EGT		CHT			████		████		*	████		████		o	████		████	5	o	████		████	4	o	████		████	3		1	2	3	4	<p>Fuel system restriction or dirty injection nozzles.</p>	<p>Clean fuel nozzles. Do flow check for uniformity, and if problem persists check fuel system for proper pressure and flow.</p>
	1	2	3	4	T																																																																			
CHT	████	██████	████	████	██████																																																																			
450	████	██████	████	████	██████	%																																																																		
350	████	██████	████	████	██████																																																																			
250	████	██████	████	████	██████																																																																			
	EGT		CHT																																																																					
	████		████																																																																					
*	████		████																																																																					
o	████		████	5																																																																				
o	████		████	4																																																																				
o	████		████	3																																																																				
	1	2	3	4																																																																				
<p>Magneto Check:</p> <p>EGT is often a better indicator of ignition problems that have been traditionally diagnosed by observing rpm drop during run-up. If one spark plug or ignition wire on each mag is defective the single mag check would indicate an equal rpm drop on each. Such a double failure would go undetected. The engine monitor will not only identify the problem but pinpoint the affected cylinder.</p>																																																																								
<p>Mixture check:</p> <p>The engine monitor displays a uniform EGT rise of all cylinders during mixture control check. An abnormally large exhaust gas temperature differential in one or more cylinders in fuel injected engines may warn of a fuel injector constriction.</p>																																																																								



NOTE: Instrument panel layouts may vary depending on customer preferences.

- | | |
|---|--|
| 1. Airspeed Indicator | 6. Ammeter |
| 2. Rotor and Engine Tachometer (Dual Tach) | 7. Engine Oil Pressure Indicator |
| 3. Manifold/Fuel Pressure Indicator | 8. Engine Oil Temperature Indicator |
| 4. Fuel Quantity Indicator | 9. Cylinder Head Temperature Indicator |
| 5. Main Rotor Gearbox Temperature Indicator | 10. Inclinometer |
| | 11. Altimeter |
| | 12. Engine Monitor |
| | 13. Annunciator Panel |

Figure 24-1. Instrument Panel Layout

24-6. Clock

A digital clock, if equipped, may be installed in the switch and circuit breaker panel or the instrument panel (F-28F S/N 833 and subsequent; 280FX S/N 2167 and subsequent). The clock is powered by an internal alkaline battery which should be replaced every 12 months. Vendor information is provided in Table 24-3.

Refer to paragraph 7-18 for removal and installation instructions.

Refer to the vendor's published literature for clock specifications and operation (see Table 24-3).

24-7. Outside Air Temperature Indicator (OAT)

OAT indication is shown by the numeric display on the engine monitoring system (GEM or EDM). The interior, top cabin mounted outside air temperature indicator was discontinued for F-28F S/N 832 and subsequent and 280FX S/N 2147 and subsequent.

Refer to the vendor's published manuals for OAT display (see Table 24-3).

24-8. Magnetic Compass

NOTE

Due to improved performance, F-28F S/N 833 and subsequent and 280FX S/N 2167 and subsequent helicopters are equipped from the factory with a SIRS Navigation Aircraft Compass.

The compass installation is mounted to the center windshield post and includes the correction card adjacent the compass. The compass may feature a fluorescent card legend, LED illumination, and silicone card damping.


Power for illumination is provided by the PNL LT switch and brightness may be controlled with the DIMMER PANEL LT knob.

Refer to paragraph 7-18 for removal and installation instructions.

Refer to paragraph 7-19 for inspection requirements.

In the event the compass must be replaced, refer to the manufacturer's installation instructions. Vendor information is provided in Table 24-3.

Table 24-3. Vendor Contact Information

Component	Vendor
GEM 603 or 610	Insight Instrument Corporation Tel: 905-871-0733; Fax: 905-871-5460 www.insightavionics.com
EDM 700	J.P. Instruments Tel: 1-800-345-4574 or 714-557-3805; Fax: 714-557-9840 sales@jpinstruments.com www.jpinstruments.com
Clock - M800	Davtron Tel: 1-866-369-5588; Fax: 650-369-9988 www.davtron.com
Magnetic Compass – NV2C-28V() 	SIRS Navigation Ltd. Compass House – Bowes Estate Wrotham Road, Meopham Kent DA13 OQB England Tel: +44 (0) 1474-816320 Fax: +44 (0) 1474-816321 sales@sirs.co.uk https://www.sirs.co.uk/contact


24-9. Rotor RPM Magnetic Pick-up

NOTE

This procedure for installing the magnetic pick-up must be followed to avoid serious damage to the main rotor transmission gears.

- A. Removal – Rotor RPM Magnetic Pick-up (Figure 24-2)
- (1) Remove the left side fuel tank (para. 13-10).
 - (2) Place ground handling wheels in the down position.
 - (3) Place 2 blocks (approximately 1.5 inches/3.8 mm) under the forward strut attachment points under the skid tube.
 - (4) Place the wheels in the up position. This will allow the oil in the gearbox to run aft and not leak out when the access plug is removed.
 - (5) Disconnect the magnetic pick-up electrical connector.
 - (6) Remove the magnetic pick-up from the main rotor transmission. If replacing the magnetic pick-up, remove any shims installed on the pick-up.

- B. Inspection – Rotor RPM Magnetic Pick-up
- (1) Inspect the magnetic pick-up for security of installation and condition and security the electrical wires and connectors.
 - (2) Using a multi-meter, check for 270-330 ohms across the leads.
- C. Repair – Rotor RPM Magnetic Pick-up
- (1) Repair damaged wiring or electrical connectors.
 - (2) Replace the magnetic pick-up if the ohm check is outside the 270-330 ohm range or if inspection of the system components and wiring isolates the problem to the magnetic pick-up.
- D. Installation – Rotor RPM Magnetic Pick-up (Figure 24-2)
- (1) Remove the magnetic pick-up inspection plug on the forward, lower section of the main rotor gearbox.
 - (2) Turn the gearbox until a gear tooth is directly under the center of the magnetic pick-up installation hole.
 - (3) Install the magnetic pick-up into the main rotor transmission.
 - a. Insert a 0.030 feeler gauge through the access plug hole.
 - b. Install any shims, P/N 28-16524-(), from the old pick-up onto the replacement magnetic pick-up between the check nut and the top base of the magnetic pick-up.
 - c. Replace the O-ring on the magnetic pick-up.
 - d. Screw the magnetic pick-up in until it touches the feeler gauge.
 - e. Adjust the amount of shims as required to set the final clearance between the magnetic tip of the pick-up and the gear tooth to .030-.045 inch/.76-1.14 mm.
 - f. Torque the magnetic pick-up to 60-65 in-lb/6.8-7.3 Nm.
 - (4) Install the inspection plug.
 - a. Replace the O-ring on the plug and reinstall the plug in the front of the transmission.
 - b. Torque the plug and lockwire (.032) the magnetic pick-up to the plug.
 - (5) Reconnect the electrical connector.
 - (6) If required, service the main rotor transmission (para. 4-12).
 - (7) Install the left side fuel tank (para. 13-10).



Left: Inspection Plug; Right: Magnetic Pick-up




Figure 24-2. Magnetic Pick-up Installation

SECTION 25

[RESERVED]

NOTE: Content previously contained in this section has been incorporated into Section 4 and Section 10.

INTENTIONALLY LEFT BLANK