



Adjusting Door Latches on Late Model F28-F Doors

It is quite common for the door cables to loosen up on new F28-F doors as the components will initially 'wear in' as they are used.

1. To adjust the cables tighter or to adjust the position of the latches, first remove the covers from the top and bottom latches and off of the inside of the door at the handle.
2. Position the handle in the **unlatched** position and release the clamping on the cables at the top and bottom latch.



Upper door latch

Release the clamping on the cable by loosening this set screw.

3. Position the latch in the position shown in the photo above as that will allow slack in the cable.

4. At the handle loosen one of the set screws clamping the cable into the cable drum.

Set screw clamping cable



5. Pick the cable end out of the groove of the drum and pull a little of it through the clamping bushing and then re-tighten the set screw.
6. Push the tail end of the cable back into the groove.
7. Adjust the top and bottom latches so that they lay flat when in the **unlatched position**, engage the striker plate when in the **latched** position.
8. Install the cover plates.

