



ENSTROM HELICOPTER CORPORATION

CASE NUMBER (SN/ Hours) _____

Trouble Shooting Information Form (Piston Helicopters)

Please fill out all relevant fields provided in this document. This will help our product support staff trouble shoot your aircrafts problems more effectively. These records will kept on file at Enstrom Helicopter Corp. ***Please note that a helicopter should NEVER be operated under unsafe conditions!***

CUSTOMER INFORMATION:

1. Point of Contact _____ Date _____
2. Company _____
3. Email _____
4. Phone _____

Address

AIRCRAFT HISTORY:

Aircraft Serial Number _____ Registration _____ Helicopter Total Time _____

Time since Overhaul _____ Engine Time _____ Engine Serial number _____

OPERATIONAL INFORMATION:

1. Full Rich Idle (Ground Idle): ENG RPM SET AT: **1500** ENG RPM RISE **b.** _____

TIT **a.** _____ FUEL FLOW **a.** _____ CHT: EGT:

MANIFOLD PRESSURE **a.** _____ OIL TEMP **a.** _____ OIL PRES **a.** _____ #1 _____ #1 _____

OBSERVATION NOTES:

#2 _____ #2 _____

#3 _____ #3 _____

#4 _____ #4 _____

a.

Step a. At normal operating temps, Record TIT, Fuel Flow, MP, CHT, EGT, and Oil P & T.

Step b. Lean Mixture to idle cutoff and record engine RPM rise.

NOTE: Leaning Mixture to idle cutoff is done by; slowly pulling the mixture knob out until a slight rise in engine RPM's is noticed. The rise should happen just before the engine begins to shut off.



ENSTROM HELICOPTER CORPORATION

CASE NUMBER (SN/ Hours) _____

2. Flight idle:

1. Blades engaged.
2. Mixture full rich.
3. Advance engine RPM to **3050**

CHT:	EGT:
#1 _____	#1 _____
#2 _____	#2 _____
#3 _____	#3 _____
#4 _____	#4 _____

ENG RPM SET AT: **3050** TIT a. _____ b. _____ FUEL FLOW a. _____ b. _____

MANIFOLD PRESSURE a. _____ b. _____ OIL TEMP a. _____ b. _____

OIL PRES a. _____ b. _____

MAGNETO CHECK AT 3050 ENGINE RPM, in accordance with the RFM:

LEFT MAG RPM DROP a. _____ b. _____ TIT RISE a. _____ b. _____

RIGHT MAG RPM DROP a. _____ b. _____ TIT RISE a. _____ b. _____

OBSERVATION NOTES:

CHT:	EGT:
#1 _____	#1 _____
#2 _____	#2 _____
#3 _____	#3 _____
#4 _____	#4 _____

a.

b.

Step a. stabilized at flight idle, record all parameters.

Step b. Lean Fuel flow to 65 pounds per hour, and record all parameters again.



ENSTROM HELICOPTER CORPORATION

CASE NUMBER (SN/ Hours) _____

3. Light on the Skids:

Leaned in accordance with previous procedure step b.

NOTE: TIT should be between 1450 and 1500

ENG RPM SET AT: **3050** TIT _____ FUEL FLOW _____

MANIFOLD PRESSURE _____ OIL TEMP _____ OIL PRES _____

CHT:	EGT:
#1 _____	#1 _____
#2 _____	#2 _____
#3 _____	#3 _____
#4 _____	#4 _____

OBSERVATION NOTES:

CAUTION

DO NOT FLY THE HELICOPTER IF CONSIDERED TO BE IN A UN AIRWORTHY CONDITION!



ENSTROM

HELICOPTER CORPORATION

CASE NUMBER (SN/ Hours) _____

4. Hover:

NOTE: TIT should be between 1450 and 1500

Field elevation _____

Pressure Altitude _____

OAT _____

ENG RPM _____ TIT _____ FUEL FLOW _____

MANIFOLD PRESSURE _____ OIL TEMP _____ OIL PRES _____

CHT:	EGT:
#1 _____	#1 _____
#2 _____	#2 _____
#3 _____	#3 _____
#4 _____	#4 _____

OBSERVATION NOTES:



ENSTROM HELICOPTER CORPORATION

CASE NUMBER (SN/ Hours) _____

5. Forward Flight:

NOTE: TIT should be between 1450 and 1500

Field elevation _____

Density Altitude _____

OAT _____

Air speed _____

ENG RPM _____ TIT _____ FUEL FLOW _____

MANIFOLD PRESSURE _____ OIL TEMP _____ OIL PRES _____

CHT:	EGT:
#1 _____	#1 _____
#2 _____	#2 _____
#3 _____	#3 _____
#4 _____	#4 _____

OBSERVATION NOTES: